

The South African National Roads Agency SOC Limited

DRAINAGE MANUAL

6th Edition



Creating wealth through infrastructure

Published by The South African National Roads Agency SOC Ltd, © 2013

48 Tambotie Avenue, Val de Grace, Pretoria, 0184, South Africa
P.O. Box 415, Pretoria, 0001, South Africa
www.sanral.co.za

First edition in Afrikaans called “Handleiding vir Paddreinerings”	Pretoria, 1981
Second edition translated into English called “Manual on Road Drainage”	Pretoria, 1983
Third partly revised edition	Pretoria, 1986
Fourth partly revised edition	Pretoria, 1993
Fifth Edition – Fully revised and called the “Drainage Manual”	Pretoria, 2006
2 nd print (including corrections up to 15 October 2007)	Pretoria, 2007
Sixth Edition – Fully revised and extended	Pretoria, 2013

ISBN 978-0-620-55428-2 (Drainage Manual)

ISBN 978-0-620-55429-9 (Drainage Manual Application Guide – only available electronically)

Copyright:

Apart from any fair dealing for the purpose of research or private study, or criticism or review, as permitted under the Copyright Act, this publication may not be reproduced in whole, or in part, for commercial purposes. Additional copies for private use may, however, be printed off the PDF version, obtained from the website, www.sanral.co.za

The copyright does not extend to the methods or intellectual property rights of any of the authors.

In addition, photocopies of the whole, or parts of the publication may be made by academic institutions for students.

Editor	Edwin Kruger
Sub-editors	Nuno Gomes, Fanie van Vuuren and Marco van Dijk
Cover design	Nitrogen Advertising & Design, Johannesburg

Disclaimer:

Although every effort has been made as to the accuracy and applicability of the information contained in this publication (including supporting flash drive/DVD and software), the publisher, The South African National Roads Agency SOC Ltd (SANRAL), and the authors, cannot accept any legal responsibility or liability for any errors, omissions or for any other reason whatsoever.

FOREWORD


Water is often thought of as the source of civilization; hence the hypothesis that the development of hydraulics is related to the evolution of ancient societies such as those of Mesopotamia and Egypt. Owing to the structure of the early states, which entailed a closed system of absolute monarchy and monopoly with only a small number of literate scholars, the pace of technological advancement was cumbersome. The basket remained the only water-lifting device in Egypt until the sheduf was introduced during the time of the New Kingdom – almost 3 500 years after the commencement of agriculture in Egypt and 1 500 years after the rise of the nation-state. The development of the waterwheel and the Archimedes clean water screw followed 1 000 years later in Alexandria.

Founded by the Egyptian ruler, during the Ptolemies dynasty (323 BC to AD 30), the Mouseion in Alexandria hosted scholars such as Euclid and Archimedes (287 to 212 BC) who made significant advances in mathematics of cones and cylinders as well as differential equations leading to major advances in hydraulic engineering. These Alexandrian scholars laid the foundations of theoretical hydrology in connection with practical applications. Around the same time the Persians too had already made an ingenious contribution to hydraulic engineering by developing a water delivery system known as qanats – a subterranean system of tunnels connecting wells. However, it is the Romans who were instrumental in expanding the science of hydraulic engineering to various parts of their empire.

Through the ages, civil engineers have always had to cope with unforeseen natural forces. The external forces created by climatic change, and further exacerbated by human induced variables, can unexpectedly and significantly influence the hydrological cycle with serious socio-economic effects. Although mathematical analysis and modelling cannot cater for every eventuality, we can certainly attempt to scientifically predict the behaviour of these natural forces and minimise their impacts on our environment.

South Africa, for instance, is known for its low average annual rainfalls and large seasonal variations. Despite the latter, abnormal rainfalls have historically had disastrous consequences. Although our problems are not without precedent, societies are always inter-linked and local catastrophes could have serious regional and national repercussions.

The channelling of water by societies for usage and development has remained an on-going challenge since the days of the early mathematicians through to modern-day engineers. We trust that this manual, published as a guide to both students and practitioners will assist in meeting these challenges. It must, however, be emphasised that it is merely an aid and should ultimately not replace sound engineering analysis and judgement.



Nazir Alli

Chief Executive Officer

The South African National Roads Agency SOC Limited


ACKNOWLEDGEMENTS AND STRUCTURE OF THE DRAINAGE MANUAL

The South African National Roads Agency SOC Ltd (SANRAL) wishes to thank all parties involved in extensively revising and updating the *Road Drainage Manual* (first published in 1981) and now known as the *Drainage Manual*. The previous editors and authors of the original manual, J Bosman, A Rooseboom, MS Basson, CH Loots, JH Wiggett, assisted by ZP Kovács and AM van Vuuren (neè Mouton), is hereby also acknowledged.

In realising the goals of producing a manual of high standard the co-operation between authors and reviewers to this and previous editions of the manual has been critical. All contributions, too numerous to mention individually, both big and small is gratefully acknowledged. We have in the manual endeavoured to take differing views into account which at times has proven to be a challenge. The manual, we believe, is a summary of both historical and modern thought pertaining to drainage.

Feedback, comments and suggestions from users of the previous editions of the manual have been incorporated where possible. This edition of the manual still covers all the previous background theory but has been extended to include additional flood calculation methods, the analyses and design of stormwater systems, the hydraulic assessment of existing culverts and the modelling of free surface flows and flood line calculations. With the further expansion of the manual it was deemed necessary to separate the manual into two distinct documents; the first being the **Drainage Manual** and the second being the **Drainage Manual Application Guide**.

The front covers of the two documents are as shown below.



Thank you to my fellow editors, Professor Fanie van Vuuren, Marco van Dijk and Nuno Gomes for their commitment and enthusiasm in updating the manual. The compilation and editing was not an easy task but has been completed with passion and dedication.


Edwin Kruger

Editor
The South African National Roads Agency SOC Limited

Feedback:

Any positive feedback for possible incorporation into future editions will be appreciated. Please email such comments/feedback to the Editor at bridges@nra.co.za

ABOUT THE AUTHORS (Listed in chapter order)

SJ van Vuuren (Chapters 2, 3, 4, 5, 7, 9, 10, 11 and 13)

Prof Fanie van Vuuren obtained the MBA and PhD Engineering degrees from the University of Pretoria. His professional experience included working for the Government and Municipal Sectors, Contractors and serving as a director of consulting engineering firms before he opted for an academic career. Fanie has lectured locally and abroad, published several papers and research reports and has presented numerous courses on pipelines, pump stations and drainage systems. He currently heads the Water Division of the Department of Civil Engineering, University of Pretoria.

WJ Pienaar (Chapter 2)

Prof Wessel Pienaar is Professor of Logistics at the University of Stellenbosch. He has obtained the following advanced qualifications: MEcon in Transport Economics (University of Stellenbosch); MS in Civil Engineering at the University of California, Berkeley; DCom in Transport Economics at the University of South Africa; and PhD(Eng) in Civil Engineering at the University of Stellenbosch. In 2000 and 2011 he received the Rector's Award for Outstanding Research at the University of Stellenbosch. He is rated as an established researcher by the National Research Foundation.

M van Dijk (Chapters 3, 9, 11 and 13)

Marco van Dijk graduated from the University of Pretoria with a degree in Civil Engineering in 1996 and worked for a consulting engineering firm during which time he also completed his BEng (Hons) degree. He then joined the Department of Civil Engineering of the University of Pretoria and obtained a MEng degree in Water Resource Engineering in 2003. He is presently enrolled for a PhD (Civil Engineering). He lectures in hydrology and hydraulics and has 16 years of experience in this field. He has presented numerous courses on flood determination, flood lines, drainage structures and stormwater modelling.

JC Smithers (Chapter 3)

Prof Jeff Smithers obtained his BSc Eng (Agric) and MSc Eng degrees from the University of Natal. After working for the Department of Agriculture he joined the University of Natal and was awarded his PhD by the University of KwaZulu-Natal (UKZN). He has extensive research and consulting experience in design and engineering hydrology and also has research interests in hydrological modelling and in efficient and sustainable water and energy utilization in agricultural production systems. He is currently Professor of Agricultural Engineering at UKZN and is also an Adjunct Professor in the Faculty of Engineering and Surveying at the University of Southern Queensland in Australia.

A Rooseboom (Chapters 4, 5, 7, 8 and 12)

Professor Albert Rooseboom is Professor Emeritus from the University of Stellenbosch where he has served as head of the Department of Civil Engineering. He taught hydraulics to many practitioners since he lectured in this field from 1970, starting at the University of Pretoria where he obtained DSc in 1976. He has pioneered the development of methods for the prediction of sedimentation yield and reservoir sedimentation in South Africa. He was co-recipient of the 2nd International Qian Ning Prize for Erosion and Sedimentation Technology in 2010. Albert was instrumental in the compilation of the first drainage manual, then known as the Road Drainage Manual, dealing with drainage pertaining to roads. He has published widely and has been internationally recognized for his expertise in free surface flow.

EJ Kruger (Chapters 6 and 8)

Edwin Kruger, the Editor of the Drainage Manual, is both a Professional Engineer and a Chartered Engineer. He obtained his BSc in Civil Engineering (Cum Laude) at the University of Natal in 1977 and has over 35 years of experience. His speciality is all aspects relating to bridge design including the hydrological and hydraulic aspects. In 2000 he left the consulting engineering firm where he was a director and joined the South African National Roads Agency SOC Ltd (SANRAL) as Bridge Network Manager. He is in charge all structural matters relating to national roads and formulates and sets applicable policy pertaining to design and construction of bridges and other road structures. Presently he is also Chairman of the COTO Road Structures Committee of the South African Committee of Transport Officials (COTO). He has authored or co-authored several publications and presented several papers at both international and local conferences and seminars.

PA Pienaar (Chapter 6)

Dr Pine Pienaar obtained the PhD degree with the title “The management of tertiary road networks in rural areas” (University of Pretoria, 1993) after a period of involvement with transport infrastructure design, construction and maintenance in rural areas. He has a specific interest in low cost draining infrastructure, especially low-level river crossings. He is presently the CEO of a consulting engineering firm which has designed and implemented numerous low-level river crossings.

AM Jansen van Vuuren (Chapter 8)

Anna van Vuuren obtained BSc (Eng) and MEng degrees from the University of Pretoria and has lectured hydrology and hydraulics for eight years. She was one of the original contributing authors of the first drainage manual, then known as the Road Drainage Manual, dealing with drainage pertaining to roads. Since 1983 she worked in the consulting engineering field and has been mostly involved in hydraulic designs and flood estimations.

N Gomes (Chapters 10 and 12)

Nuno A. De N. C. Gomes obtained his BSc from UNISA and his MSc (Eng) (Civil) in water engineering from the University of the Witwatersrand. His career of more than 22 years of professional experience started in the design office of the Department of Transport (Roads), followed by being a project engineer with the South African National Roads Agency SOC Ltd. Currently he is divisional head for Routine Road Maintenance section at the Northern Regional office of SANRAL. He is registered as Incorporated Engineer with the Institution of Civil Engineers.

GM James (Chapter 12)

Garth James is registered as a Professional Natural Scientist who has a geology degree from the University of Natal (1975). He has 10 years experience with geotechnical engineers followed by 28 years with a company specialising in geotextiles and geosynthetic solutions that addresses problems in erosion control, sub-soil drainage and filtration, road maintenance and rehabilitation and reinforcement solutions. He has authored and co-authored numerous papers in these areas of application.

J Maastrecht (Chapter 12)

Julian Maastrecht has a BTech degree from the Peninsula University of Technology. He has worked for consulting engineers and since 1998 works for a company specialising in geotextiles and geosynthetic solutions that addresses problems in erosion control, drainage and filtration, road maintenance and rehabilitation and horticulture solutions. He is a regional manager of the company.

DW Stipp (Chapter 12)

Deon Stipp has a NHDip in civil engineering. His experience includes work for a provincial road department and presently is a regional manager of a firm specialising in geotextiles and geosynthetic solutions that addresses problems in erosion control, drainage and filtration, road maintenance and rehabilitation and horticulture solutions.

GL Coetzee (Chapter 13)

Louis Coetzee joined the academic environment of the University of Pretoria directly after completing his undergraduate Civil Engineering studies. He has since obtained his BEng (Hons) (Cum Laude) and has been involved in consulting work as well as presenting courses on flood determination, flood lines, drainage structures, stormwater modelling and drainage systems.

DRAINAGE MANUAL TABLE OF CONTENTS

Foreword	i
Acknowledgements	ii
Table of Contents	v
List of symbols	xiii
 CHAPTER 1 – INTRODUCTION	 1-1
1.1 HISTORICAL OVERVIEW	1-1
1.2 CURRENT POSITION OF SANRAL	1-1
1.3 LAYOUT OF THE DRAINAGE MANUAL	1-3
1.4 REFERENCES	1-7
 CHAPTER 2 - ECONOMIC EVALUATION OF DRAINAGE SYSTEMS AND LEGAL ASPECTS PERTAINING TO DRAINAGE SYSTEMS	 2-1
2.1 INTRODUCTION	2-1
2.2 BASIC PRINCIPLES OF ECONOMIC EVALUATION	2-2
2.2.1 Economic value of resources	2-2
2.2.2 Future inflation	2-4
2.2.3 The evaluation base date	2-4
2.2.4 The time value of money	2-4
2.2.5 The discounting procedure	2-6
2.3 ECONOMIC EVALUATION TECHNIQUES	2-6
2.2.6 Introduction	2-6
2.2.7 Present Worth of Cost (PWOC) technique	2-6
2.2.8 Net Present Value (NPV) technique	2-7
2.2.9 Benefit/Cost Ratio (B/C) technique	2-7
2.2.10 Internal Rate of Return (IRR) technique	2-8
2.3 DESCRIPTION OF THE EVALUATION PROCESS	2-8
2.3.1 Overview of the evaluation process	2-8
2.3.2 Establish the purpose of the economic evaluation	2-9
2.3.3 Selection of appropriate economic evaluation technique(s)	2-9
2.3.4 Definition of project alternatives	2-10
2.3.5 Calculate recurring user costs / project benefits	2-10
2.3.6 Determination of project investment costs	2-16
2.4 INCORPORATING THE RISK OF FLOOD DAMAGE	2-19
2.4.1 Overview of the flood damage evaluation procedure	2-19
2.4.2 The minimum design standard	2-20
2.4.3 Construction cost estimates	2-21
2.4.4 Maintenance and operation cost	2-21
2.4.5 Additional costs associated with abnormal floods	2-22
2.4.6 Economic evaluation	2-23
2.5 RISK AND UNCERTAINTY OF INPUT DATA	2-24
2.6 ECONOMIC SELECTION OF PROJECTS OR ALTERNATIVES	2-24
2.6.1 Selection criteria	2-24
2.6.2 Mutually exclusive projects	2-26
2.6.3 Independent projects	2-27
2.6.4 Mutually exclusive and independent projects	2-27

2.6.5	Timing of project implementation	2-30
2.7	LEGAL ASPECTS RELATED TO WATER INFRASTRUCTURE	2-30
2.7.1	Introduction	2-30
2.7.2	The National Water Act (Act No 36 of 1998)	2-31
2.7.3	The Environmental Conservation Act (Act No 73 of 1989)	2-31
2.7.4	Geoscience Amendment Act	2-31
2.7.5	Documents included in an electronic format	2-31
2.8	REFERENCES	2-31
CHAPTER 3 - FLOOD CALCULATIONS		3-1
3.1	OVERVIEW OF THIS CHAPTER	3-1
3.2	INTRODUCTION	3-1
3.2.1	Terminology	3-1
3.2.2	Different methods in use for the calculation of flood peaks	3-3
3.3	FACTORS AFFECTING RUN-OFF	3-6
3.3.1	Topographical factors	3-6
3.3.2	Antecedent soil moisture conditions	3-9
3.3.3	Developmental influences	3-9
3.3.4	Climatological variables	3-10
3.4	STATISTICAL METHODS	3-12
3.4.1	Applicability of statistical methods	3-12
3.4.2	Annual and partial series	3-13
3.4.3	Overview of probabilities	3-13
3.4.4	Methods of calculation used in statistical analysis	3-14
3.4.5	Use of short records in statistical analysis	3-16
3.5	DETERMINISTIC METHODS	3-17
3.5.1	Rational methods	3-17
3.5.2	Unit Hydrograph method	3-30
3.5.3	Standard Design Flood Method	3-42
3.5.4	SCS-SA method	3-47
3.6	EMPIRICAL METHODS	3-60
3.6.1	General	3-60
3.6.2	Empirical peak flow calculations for rural areas	3-60
3.6.3	Empirical deterministic peak discharge formula for return periods of up to 100 years	3-61
3.6.4	Experience curves of maximum flood peaks for the calculation of flood peaks for return periods of more than 100 years	3-65
3.7	METHODS THAT ARE NOT INCLUDED IN THIS MANUAL	3-68
3.7.1	Run Hydrograph method	3-68
3.7.2	REFSSA method	3-68
3.7.3	The Joint Peak-Volume Hydrograph Procedure (JPV)	3-69
3.8	REFERENCES	3-69
CHAPTER 4 - HYDRAULIC CALCULATIONS		4-1
4.1	INTRODUCTION	4-1
4.2	OPEN CHANNEL FLOW	4-2
4.2.1	General design problems in open channel flow	4-2
4.2.2	General definitions associated with open channel flow	4-4
4.2.3	Principle of continuity of mass (Conservation of mass)	4-5

4.2.4	Principle of conservation of energy (Energy principle)	4-6
4.2.5	Defining controls in open channel flow	4-9
4.2.6	Friction losses	4-12
4.2.7	Transition losses	4-21
4.2.8	Rules for the application of the energy equation	4-22
4.2.9	Conservation of momentum (Momentum principle)	4-26
4.2.10	Steps to be followed when applying the momentum equation	4-27
4.2.11	Analysis of transition conditions	4-28
4.3	PIPE FLOW	4-31
4.3.1	Introduction	4-31
4.3.2	Principle of continuity	4-32
4.3.3	Energy principle	4-32
4.3.4	Application of the energy equation	4-33
4.3.5	Principle of momentum conservation	4-34
4.4	REFERENCES	4-35
CHAPTER 5 - SURFACE DRAINAGE		5-1
5.1	INTRODUCTION	5-1
5.2	RUN-OFF ON ROADWAYS AND SHOULDERS	5-1
5.2.1	General	5-1
5.2.2	Vehicle speed	5-2
5.2.3	Depth of flow	5-2
5.2.4	Road surface	5-3
5.2.5	Wheel load, tyre type and tyre pressure	5-4
5.2.6	Further requirements regarding surface drainage	5-4
5.3	KERBS, BERMS AND OUTLETS	5-4
5.3.1	General	5-4
5.3.2	Use of kerbs, berms and outlets	5-4
5.3.3	Hydraulics of kerb and berm flows	5-6
5.3.4	Kerb and berm outlets	5-7
5.3.5	Hydraulic design of drop outlets (grid outlets)	5-9
5.3.6	Hydraulic design of side outlets	5-12
5.3.7	Kerb inlets with transitions	5-13
5.4	DISCHARGE CHANNELS	5-22
5.4.1	Introduction	5-22
5.4.2	Freeboard and provision for wave action	5-22
5.4.3	Permissible slopes of drains	5-23
5.4.4	Calculation of hydraulic capacity of channels	5-23
5.4.5	Permissible velocities: soils and grass covers	5-24
5.4.6	Channel linings: Solid materials	5-24
5.4.7	Indirect protection and stepped energy dissipation	5-31
5.5	DISCHARGE CHUTES	5-36
5.5.1	Introduction	5-36
5.5.2	Stepped energy dissipation in very steep channels of chutes	5-39
5.6	DISCHARGE PIPES	5-45
5.6.1	Introduction	5-45
5.6.2	Underground connector pipes	5-45
5.6.3	Discharge pipes down side slopes	5-45
5.7	COMBATING EROSION ON STEEP SLOPES	5-45

5.7.1	Introduction	5-45
5.7.2	Stepped energy dissipation on steep slopes	5-46
5.7.3	Direct protection	5-47
5.8	REFERENCES	5-48

CHAPTER 6 - LOW-LEVEL RIVER CROSSINGS 6-1

6.1	INTRODUCTION	6-1
6.1.1	Intended use of these guidelines	6-1
6.1.2	Definition of low-level river crossings	6-1
6.1.3	Terminology	6-1
6.1.4	Classification of LLRCs	6-2
6.1.5	The application of LLRCs	6-5
6.1.6	Key focus areas of the design of LLRCs	6-6
6.2	SITE SELECTION	6-6
6.2.1	Straight river section	6-6
6.2.2	River channel cross-section	6-6
6.2.3	The angle at which a road crosses a river	6-8
6.3	HYDROLOGY	6-9
6.3.1	Methods to calculate run-off	6-9
6.3.2	The appropriate design return period for LLRCs	6-9
6.3.3	Determination of design flow rate	6-9
6.4	HYDRAULIC CONSIDERATIONS	6-11
6.4.1	Introduction	6-11
6.4.2	Calculation of the discharge over the structure	6-11
6.4.3	Flow passing through the structure	6-12
6.4.4	Total flow	6-14
6.5	SELECTION OF STRUCTURE TYPE	6-15
6.5.1	Introduction	6-15
6.5.2	Comparing LLRCs and culverts	6-15
6.5.3	Comparing LLRCs and high-level bridges	6-15
6.5.4	Application of LLRCs for different road types	6-16
6.6	STRUCTURAL DESIGN CONSIDERATIONS	6-16
6.6.1	Structural dimensions	6-16
6.6.2	Road geometry	6-21
6.6.3	Foundations	6-21
6.6.4	Structural design	6-22
6.6.5	Approach fills	6-24
6.6.6	Erosion protection	6-24
6.6.7	Safety	6-25
6.7	OTHER CONSIDERATIONS	6-25
6.7.1	Community considerations	6-25
6.7.2	Labour-intensive construction	6-25
6.7.3	Environmental considerations	6-26
6.7.4	Legal aspects	6-26
6.7.5	Economic justification	6-26
6.8	REFERENCES	6-27

7 CHAPTER 7 - LESSER CULVERTS (AND STORMWATER CONDUITS)..... 7-1

7.1	INTRODUCTION	7-1
-----	--------------------	-----

7.2	PRACTICAL CONSIDERATIONS TO BE CONSIDERED FOR LESSER CULVERTS	7-2
7.2.1	Typical problems experienced at lesser culverts	7-2
7.2.2	Practical measures to be considered for lesser culverts	7-3
7.3	CULVERT HYDRAULICS	7-5
7.3.1	Hydraulic controls experienced in culverts	7-5
7.3.2	Basic hydraulic theory applicable to lesser culvert design	7-6
7.4	DETERMINATION OF CULVERT SIZE	7-10
7.4.1	Distinction between inlet and outlet control	7-10
7.4.2	Improving the inlet capacity and determining the discharge velocities of lesser culverts	7-10
7.5	FLOOD ATTENUATION AT CULVERTS	7-12
7.6	EROSION PREVENTION UPSTREAM OF CULVERTS	7-13
7.7	EROSION PREVENTION DOWNSTREAM OF CULVERTS	7-13
7.7.1	Determination of the outlet velocity	7-13
7.7.2	Protective downstream measures	7-14
7.8	REFERENCES	7-17
8	CHAPTER 8 - BRIDGES AND MAJOR CULVERTS	8-1
8.1	INTRODUCTION	8-1
8.2	ROAD CLASSIFICATION	8-3
8.3	DESIGN FLOOD FREQUENCY AND FREEBOARD REQUIREMENTS	8-6
8.3.1	The Design Flood	8-6
8.3.2	Freeboard	8-7
8.4	OTHER DESIGN CONSIDERATIONS	8-9
8.4.1	Debris build-up	8-9
8.4.2	Wave action	8-9
8.4.3	Super elevation of flow	8-9
8.4.4	Overtopping of the structure	8-9
8.5	BACKWATER DETERMINATION	8-10
8.5.1	Introduction	8-10
8.5.2	Backwater height, h_1^* for Type I flow through bridge	8-11
8.5.3	Backwater height, h_1^* for Type II bridge flow	8-14
8.5.4	Additional considerations	8-16
8.6	SCOUR AT BRIDGES AND CULVERTS	8-17
8.6.1	General Remarks	8-17
8.6.2	Concepts and definitions	8-18
8.8	SCOUR ESTIMATION	8-23
8.8.1	General remarks	8-23
8.8.2	Long-term general scour	8-23
8.8.3	Short-term general scour	8-23
8.8.4	Contraction Scour	8-25
8.8.5	Local Scour	8-27
8.9	TOTAL ESTIMATION USING APPLIED STREAM POWER PRINCIPLES	8-31
8.10	SPECIAL CASES OF SCOUR	8-32
8.10.1	Scour at bridges in tidal areas	8-32
8.10.2	Pressure scour	8-32
8.10.3	Lateral movement of rivers	8-32
8.11	PROCEDURES FOR INITIAL ESTIMATION OF SCOUR AT BRIDGES	8-34

8.12	SCOUR COUNTERMEASURES AT BRIDGES	8-36
8.12.1	Introduction	8-36
8.12.2	General considerations in respect of scour countermeasures	8-37
8.12.3	Spurs, Berms and Dykes	8-41
8.12.4	Revetments: Riprap protection	8-43
8.12.5	Revetments: Gabions and stone mattresses	8-46
8.12.6	Local scour armouring	8-46
8.12.7	Structural countermeasures	8-48
8.12.8	Maintenance measures	8-49
8.13	OTHER DESIGN ASPECTS	8-49
8.13.1	Piers and pier spacing	8-49
8.13.2	Provision of additional capacity	8-49
8.13.3	Monitoring	8-49
8.13.4	Scour at multiple bridges	8-49
8.13.5	Drainage of bridge decks	8-50
8.13.6	Forces acting on bridge structures	8-50
8.14	REFERENCES	8-50

CHAPTER 9 - STORMWATER SYSTEM ANALYSIS AND DESIGN.....9-1

9.1	OVERVIEW OF THIS CHAPTER.....	9-1
9.2	HYDRAULICS OF STORM DRAINAGE SYSTEMS	9-2
9.2.1	Flow types	9-2
9.2.2	Open channel or pressurised flow	9-3
9.2.3	Hydraulic capacity	9-4
9.2.4	Energy and Hydraulic Grade Lines	9-5
9.2.5	Storm drain outfalls	9-5
9.2.6	Energy losses	9-7
9.2.7	Pipe friction losses	9-14
9.2.8	Properties of circular sections	9-15
9.3	DESIGN GUIDELINES AND CONSIDERATIONS	9-17
9.3.1	Time of concentration and discharge	9-17
9.3.2	Maximum high water	9-18
9.3.3	Minimum velocity and grades	9-18
9.3.4	Cover depth.....	9-18
9.3.5	Access holes / Manholes	9-19
9.3.6	Junction chambers	9-21
9.3.8	Alignment of the storm water drains.....	9-21
9.4	MAINTENANCE CONSIDERATIONS	9-22
9.5	DETENTION AND RETENSION FACILITIES.....	9-22
9.5.1	Introduction.....	9-22
9.5.2	Detention facilities.....	9-23
9.5.3	Retention facilities.....	9-23
9.6	STORMWATER MODELLING	9-24
9.7	REFERENCES	9-26

CHAPTER 10 - ASSESSMENT OF THE HYDRAULIC CAPACITY OF EXISTING DRAINAGE STRUCTURES, APPLICATION OF FLOOD ROUTING AND THE VALUE OF MAINTENANCE		10-1
10.1	INTRODUCTION.....	10-1

10.2	DESIGN RETURN PERIOD REVIEW FOR EXISTING HYDRAULIC STRUCTURES	10-1
10.3	HYDRAULIC REVIEW OF EXISTING ROAD-DRAINAGE STRUCTURES	10-2
10.3.1	Introduction	10-2
10.3.2	Procedure for the hydraulic assessment of existing culverts operating under inlet control	10-2
10.3.3	Procedure for the hydraulic assessment of existing bridges	10-9
10.4	FLOOD ROUTING	10-10
10.4.1	Basic theory of flood routing	10-10
10.4.2	Level-pool routing	10-12
10.4.3	River routing	10-15
10.5	DIFFERENT FORMS OF INFLOW HYDROGRAPHS	10-19
10.6	UTILITY PROGRAM FOR LEVEL-POOL ROUTING	10-19
10.7	REMEDIAL ACTIONS TO BE CONSIDERED TO INCREASE THE HYDRAULIC CAPACITY OF EXISTING HYDRAULIC STRUCTURES	10-20
10.8	ROUTINE MAINTENANCE	10-22
10.8.1	Introduction	10-22
10.8.2	Aspects to consider during routine inspections	10-22
10.8.3	Influence of development close to road infrastructure	10-23
10.8.4	Alternative materials to reduce theft and damage to hydraulic structures	10-23
10.8.5	General problems	10-25
10.9	REFERENCES	10-29

CHAPTER 11 – MODELLING OF FREE SURFACE FLOW AND FLOOD LINE

	CALCULATIONS	11-1
11.1	INTRODUCTION	11-1
11.2	UNCERTAINTY IN CONVEYANCE CALCULATION	11-1
11.3	STATUTORY REQUIREMENTS	11-3
11.3.1	EIA Regulations (2007)	11-4
11.3.2	National Water Act (Act No 36 of 1998)	11-4
11.4	GUIDELINES FOR DEVELOPMENT WITHIN THE FLOOD LINE	11-5
11.4.1	Information requirements	11-5
11.4.2	Development guidelines	11-7
11.5	FLOOD PEAK AND FLOOD HYDROGRAPH DETERMINATION	11-7
11.6	RISK OF INUNDATION	11-7
11.7	CONSEQUENCES OF FLOODING	11-7
11.7.1	Loss of life	11-8
11.7.2	Structural damage	11-8
11.7.3	Damage to the contents of buildings	11-8
11.7.4	Damage due to the deposition of sediment	11-9
11.7.5	Insurance	11-9
11.8	OPEN CHANNEL FLOW	11-9
11.8.1	Gradually varied flow	11-9
11.8.2	Flow transitions	11-9
11.8.3	The general equation of gradually varied flow	11-10
11.8.4	Classification of flow profiles	11-11
11.8.5	Determining of surface profiles	11-13
11.8.6	Direct step method	11-14
11.8.7	Standard step method for regular channels	11-15

11.8.8	Standard step method for natural channels	11-15
11.9	DETERMINING FLOODLINES	11-16
11.10	REFERENCES	11-18
CHAPTER 12 – SUB-SURFACE DRAINAGE		12-1
12.1	INTRODUCTION	12-1
12.1.1	General	12-1
12.1.2	Sub-surface interception drainage (Trench drains)	12-3
12.1.3	Herringbone sub-surface drainage	12-3
12.1.4	Layer sub-surface drainage	12-3
12.1.5	Structural sub-surface drainage	12-3
12.2	PLANNING OF SUB-SURFACE DRAINAGE	12-4
12.3	DESIGN OF AN INTERCEPT DRAIN	12-5
12.3.1	General	12-5
12.3.2	Introduction to sub-surface intercept drains	12-5
12.3.3	Design capacity of intercept drains	12-5
12.4	DESIGNING A GRANULAR FILTER LAYER	12-7
12.5	DESIGNING A GEOTEXTILE FILTER	12-7
12.5.1	Introduction	12-7
12.5.2	Retention criteria	12-9
12.5.3	Permeability/permittivity criteria and requirements	12-10
12.5.4	Clogging resistance	12-11
12.5.5	Survivability criteria	12-12
12.5.6	Durability criteria	12-13
12.6	DESIGN OF UNDERGROUND PIPES	12-13
12.6.1	Slope of pipes	12-13
12.6.2	Pipe diameter and outlet spacing	12-14
12.6.3	Pipe perforations	12-14
12.6.4	Pipe material	12-14
12.6.5	Pipe bedding	12-16
12.6.6	Selection of geotextiles	12-18
12.7	DESIGN OF A HERRINGBONE SYSTEM	12-19
12.7.1	Spacing of laterals	12-19
12.7.2	Design of laterals	12-19
12.7.3	Main drainage pipes	12-19
12.8	DESIGN OF LAYER DRAINAGE	12-20
12.8.1	General	12-20
12.8.2	Open-graded base and subbase	12-21
12.8.3	Filter layer and collector drain	12-21
12.8.4	Design formulae	12-21
12.9	OUTLETS, MARKERS AND INSPECTION REQUIREMENTS	12-22
12.9.1	Outlets	12-22
12.9.2	Markers	12-23
12.9.3	Inspection requirements	12-23
12.9.4	Manholes	12-23
12.10	REFERENCES	12-23
CHAPTER 13 – WEB-BASED LINKS AND SUPPORTING SOFTWARE		13-1
13.1	INTRODUCTION	13-1

13.2	WEB-BASED LINKS	13-1
13.3	SUPPORTING FLASH DRIVE/DVD	13-1
13.3.1	Utility programs for Drainage (UPD)	13-3
13.3.2	Visual SCS-SA	13-4
13.3.3	Design rainfall estimation in South Africa	13-5
13.3.4	HEC-RAS	13-6
13.3.5	HY-8	13-6
13.3.6	EPA Storm Water Management Model (SWMM)	13-7
13.3.7	Routing Utility for the Investigation of Existing Hydraulic Structures	13-8
13.3.8	BridgeLCC	13-9
13.4	FEEDBACK	13-10
13.5	REFERENCES	13-10

APPENDICES

Appendix 3A	-	STATISTICAL ANALYSIS
Appendix 3B	-	STANDARD DESIGN FLOOD METHOD
Appendix 3C	-	STANDARD FLOOD CALCULATION FORMS
Appendix 3D	-	Q_T/Q_{RMF} RATIOS FOR DIFFERENT CATCHMENT AREAS
Appendix 3E	-	SCS-SA ADDITIONAL INFORMATION

LIST OF SYMBOLS

Chapter 2

AF	=	the damage cost of abnormal floods
AF_n^x	=	damage cost of an abnormal flood to design alternative X in year n
AFQ_D	=	damage cost of a design flood, Q_D
AF_{RMF}	=	damage cost of an RMF
B/C	=	benefit/cost ratio
C_A	=	all costs incurred in establishing a facility
C_A	=	investment (capital) cost that is required to implement the alternative A
C_A	=	the construction cost of alternative x
F	=	future value
FA	=	future amount at the end of year n
i	=	annual discount rate as a decimal fraction
IRR	=	internal rate of return technique
M	=	the normal annual cost of maintenance and operation of alternative x
n	=	discount period in years
NPV	=	net present value
PQ_D	=	probability of an SDF in year n, i.e. $(1/T_{SDF})$, where T_{SDF} is the return period of the SDF
P_{RMF}	=	probability of an RMF in year n, i.e. $(1/T_{RMF})$, where T_{RMF} is the return period of the RMF
PW	=	present worth (value in year zero)
PWOC	=	present worth of cost
$PWOC^x$	=	present Worth of Cost of alternative x
$PW(M_0+U_0)$	=	the present worth of facility maintenance costs and user costs of the null alternative
$PW(M_A+U_A)$	=	the present worth of facility maintenance costs and user costs of a proposed alternative
$PW(CS_A)$	=	consumer surplus gained through additional usage induced by the proposed alternative
r	=	rate at which the left-hand and right-hand sides of the equation are equal, resulting in a NPV of zero

Chapter 3

a	=	constant
A	=	area of catchment (km ²)
ARF	=	area reduction factor (%)
ARF _{IT}	=	area reduction factor (%)
b	=	constant
C	=	run-off coefficient (dimensionless)
C	=	catchment parameter with regard to reaction time
C ₁	=	run-off coefficient for rural area with a value between zero and one
C _{1D}	=	rural run-off coefficient incorporating the effect of dolomites
C _{1T}	=	rural run-off coefficient incorporating the effect of dolomites and initial saturation factor
C ₁₀₀	=	calibration coefficient (SDF method)
C ₂	=	calibration coefficient (SDF method)
C ₂	=	run-off coefficient for urban area with a value between zero and one
C ₃	=	run-off coefficient for lakes with a value between zero and one
CN	=	Curve Number
CN _f	=	Final Curve Number
CN _w	=	Curve Number for wet conditions
CN-II	=	retardance factor approximated by the initial Curve Number unadjusted for antecedent soil moisture
C _p	=	run-off coefficient according to average soil permeability
C _s	=	run-off coefficient according to average catchment slope
C _T	=	combined run-off coefficient for T-year return period (dimensionless)
C _v	=	run-off coefficient according to average vegetal growth
D	=	storm duration (hours)
F	=	lag coefficient
F _T	=	adjustment factor for initial saturation for return period T
f _{IT}	=	flood run-off factor (%)
H	=	height (m)
H	=	height of most remote point above outlet of catchment (m)
H _{0.10L}	=	elevation height at 10% of the length of the watercourse (m)
H _{0.85L}	=	elevation height at 85% of the length of the watercourse (m)
he _{IT}	=	effective rainfall (mm)
I	=	rainfall intensity (mm/hour)
I _a	=	initial losses (abstractions) prior to the commencement of stormflow, comprising of depression storage, interception and initial infiltration (mm)
I _T	=	average rainfall intensity for return period T (mm/h)
K	=	regional constant
K _{RP}	=	constant for T-year return period
K _T	=	constant for T-year return period
K _u	=	dimensionless factor
l	=	hydraulic length of catchment along the main channel (m)
L	=	hydraulic length of catchment (watercourse length) (km)
L	=	catchment lag time (h)
L _C	=	distance from outlet to centroid of catchment area (km)
m	=	order number
m	=	number, in descending order, of the ranked annual peak floods
M	=	2-year return period daily rainfall from TR102 ^(3.16)
M	=	mean of the annual daily maxima
M	=	total length of all contour lines (m)
MAP	=	mean annual precipitation (mm/a)
n	=	design life (years)
n	=	length of record (years)
N	=	contour interval (m)
P	=	mean annual rainfall (mm/annum)

P	=	probability (%)
P	=	daily rainfall depth (mm), usually input as a one-day design rainfall for a given return period
P_1	=	probability of at least one exceedence during the design life
P_{AvgT}	=	average rainfall over the catchment for the T-year return period (mm)
P_{AvgiT}	=	average rainfall for T-year storm duration (mm)
P_{iT}	=	point intensity for the return period T (mm/h)
P_T	=	point rainfall for the return period T (mm)
P_x	=	probability of x exceedances over the design life (n)
$P_{t,T}$	=	the precipitation depth for a duration of t minutes and a return period of T years
q_p	=	peak discharge (m^3/s)
Q	=	peak discharge (m^3/s)
Q	=	stormflow depth (mm)
Q_e	=	peak discharge of unit hydrograph (m^3/s)
Q_{iT}	=	peak discharge for T-year return period (m^3/s)
Q_p	=	unit hydrograph peak discharge (m^3/s)
Q_{RMF}	=	regional maximum flood peak flow rate (m^3/s)
Q_T	=	peak discharge for T-year return period (m^3/s)
r	=	roughness coefficient
R	=	average number of days per year on which thunder was heard (days/year)
S	=	potential maximum soil water retention (mm),
S_{av}	=	average slope (m/m)
T	=	time (hours)
T	=	return period (years)
T_C	=	time of concentration (hours)
T_L	=	lag time L (hours)
T_p	=	time to peak (hours)
T_{SD}	=	storm duration (hours)
t	=	duration (minutes)
x	=	number of exceedences
y	=	average catchment slope (%)
α	=	area distribution factor
β	=	area distribution factor
γ	=	area distribution factor
Δq_p	=	peak discharge of incremental unit hydrograph (m^3/s)
ΔQ	=	incremental stormflow depth (mm)
ΔD	=	unit duration of time, used with the distribution of daily rainfall to account for rainfall intensity variations (hours)
f_{30}	=	30-minute rainfall intensity for the 2-year return period (mm/h)

Chapter 4

A	=	sectional area (m^2)
A_1	=	upstream sectional area (m^2)
A_2	=	downstream sectional area (m^2)
B	=	channel width (m)
C_c	=	contraction coefficient ($\approx 0,6$)
C_L	=	loss coefficient for sudden transitions
E	=	specific energy (m)
f	=	roughness coefficient
F_x and F_y	=	force components exerted by the solid boundary on the water
g	=	gravitational acceleration (m/s^2)
h_f	=	energy loss over distance L (m)
k_s	=	roughness coefficient, representing the size of irregularities on bed and sides (m)
h_l	=	transition loss (m)
h_f	=	friction losses (m)

h_l	=	transition losses occurring where the flow velocity changes in magnitude or direction (m)
k_s	=	measure of absolute roughness (m)
L	=	distance (m)
L	=	pipe length (m)
Mg	=	weight of the enclosed fluid mass (N)
p	=	intensity of pressure at centre-line (Pa)
p_1 and p_2	=	intensities of pressure on either side of the bend (N/m^2)
q	=	discharge per unit width ($m^3/s/m$)
Q	=	discharge (m^3/s)
r_c	=	centre line radius (m)
R	=	hydraulic radius i.e. area divided by wetted perimeter (m)
S	=	energy slope, which is equal to bed slope only when flow is uniform (m/m)
v	=	uniform channel velocity (m/s)
V	=	volume stored (m^3)
\bar{v}	=	average velocity (m/s)
\bar{v}_1 and \bar{v}_2	=	upstream and downstream average velocities (m/s)
\bar{v}_x	=	average velocity component in x direction (m/s)
w	=	vertical sluice opening (m)
y	=	depth of flow measured perpendicular to the streambed (m)
\bar{y}	=	distance between water surface and centre of gravity of section (m)
z	=	bed level at point where depth of flow = y (m)
z	=	centre line elevation (m)
α	=	coefficient compensating for variations in velocity across a section
β_1 and β_2	=	angles of direction ($^\circ$)
$(\gamma \bar{y} A)_x$	=	force component in x direction
γ	=	specific weight (value for water $9,8 \times 10^3 \text{ N/m}^3$)
θ	=	longitudinal bed slope angle, ($^\circ$)
ρ	=	mass density = $1\,000 \text{ kg/m}^3$ for water
ν	=	kinematic viscosity ($\approx 1,14 \times 10^{-6} \text{ m}^2/\text{s}$ for water)

Chapter 5

A	=	effective cross-sectional plan area of the opening (m^2)
B	=	total flow width (m)
C	=	inlet coefficient (0,6 for sharp edges or 0,8 for rounded edges)
C_D	=	discharge coefficient
D	=	depth of flow (m)
E	=	specific energy (m)
F	=	blockage factor (say, 0,5)
Fr	=	Froude number
H	=	total energy head above grid (m)
H	=	energy head \approx flow depth for upstream conditions (m)
H	=	head (m)
K_L	=	discharge coefficient
s	=	energy gradient (m/m)
\bar{v}	=	average velocity (m/s)
V_s	=	settling velocity (m/s)
x	=	distance between obstructions (m)
y	=	depth of flow at deepest point (m)
y_2	=	equivalent sequent jump depth with a horizontal bed (m)
z	=	height of obstructions (m)

Chapter 6

A_{over}	=	area of flow over structure at the flow depth selected (m^2)
A_{eff}	=	the effective inlet area through the structure (m^2)

B	=	the width of the channel (or the length of the structure) (m)
d	=	depth of flow over the structure (m)
D	=	the height of the soffit of the deck above the river invert level (m)
f_i	=	a dimensionless factor related to the design level
Fr	=	Froude number
g	=	gravitational acceleration (9,81 m/s ²)
L_B	=	the total width of the deck of the structure (m)
n	=	Manning n-value (s/m ^{1/3})
n_{concrete}	=	Manning roughness coefficient of concrete (s/m ^{1/3})
n_{river}	=	Manning roughness coefficient of the river bed (s/m ^{1/3})
P_{cell}	=	the total wetted perimeter of each cell (m)
P_{concrete}	=	the part of the wetted perimeter that has a concrete surface per cell (m)
P_{eff}	=	ΣP_{cell} (effective wetted perimeter for the flow passing through the structure) (m)
P_{over}	=	wetted perimeter at the flow depth selected (m)
P_{river}	=	the part of the wetted perimeter that is made up by the riverbed per cell (m)
Q_2	=	discharge with a 1:2 year return period (m ³ /s)
Q_{design}	=	design discharge (m ³ /s)
Q_{over}	=	discharge over the structure within the selected flow depth (m ³ /s)
Q_{under}	=	discharge capacity of the openings through the structure (m ³ /s)
R	=	hydraulic radius (m)
S_0	=	slope in direction of flow (m/m)
\bar{v}_{under}	=	average velocity of flow through the structure (m/s)
x	=	thickness of the deck (depending on the structural design outcome) (m)

Chapter 7

B	=	width (inside of culvert) (m)
C_B	=	inlet coefficient for culverts
C_h	=	inlet coefficient for culverts
D	=	inside diameter (m)
D	=	height (inside of culvert) (m)
h_{f1-2}	=	friction losses between cross-section 1 and 2 (m)
Σh_{11-2}	=	transition losses between cross-section 1 and 2 (m)
H_1	=	upstream energy level, relative to the invert level (m)
H_2	=	downstream energy level, relative to the invert level (m)
\bar{I}	=	average inflow (m ³ /s)
K_{in}	=	inlet secondary loss coefficients
K_{out}	=	outlet secondary loss coefficients
S_0	=	natural slope (m/m)
S_c	=	critical slope (m/m), where Fr = 1
\bar{v}	=	average velocity (m/s)
y_n	=	normal flow depth (m)
y_c	=	critical flow depth (m)

Chapter 8

A_1	=	flow area at section 1 (m ²)
A_4	=	flow area at section 4 (m ²)
A_n	=	flow area at for normal flow conditions (m ²)
A_{n2}	=	projected flow area at constricted section 2 below normal water level (m ²)
B	=	mean channel width (m)
B_n	=	mean channel width for normal flow conditions (m)
B_n	=	total flow width for the normal stage (m)
b	=	pier width (m)
C	=	Chézy coefficient
C	=	a constant
C	=	coefficient for specific gravity and stability factors

C_b	=	backwater coefficient
D	=	flow depth (m)
d_{50}	=	average particle diameter (m)
D_{50}	=	median size of bed material (m)
D_{50}	=	riprap size (m)
D_{50}	=	median riprap size (m)
d_{avg}	=	average depth in the main channel
D_c	=	critical particle size for the critical velocity V_c (m)
D_m	=	effective mean bed material size ($1,25D_{50}$) (m)
d_s	=	local scour depth at pier (m)
e	=	voids ratio of soil mass
E_s	=	specific energy (m)
F	=	constant obtained from measured data
F_D	=	distance of the design flood, Q_T , below a deck soffit (underside of deck) (m)
Fr	=	Froude number
Fr_1	=	Froude number directly upstream of the pier
F_s	=	side factor to describe bank resistance to scour
F_{SBP}	=	freeboard to shoulder breakpoint (m)
g	=	gravitational acceleration ($9,81 \text{ m/s}^2$)
h^*	=	backwater damming height, afflux (m)
h^*_{1A}	=	backwater damming height abnormal stage conditions (m)
k_s	=	absolute roughness of river bed (m)
K^*	=	secondary energy loss coefficient
K	=	pier shape coefficient (1,5 for round-nosed and 1,7 for rectangular piers)
K	=	factor applied for abutments
K_1	=	a factor defined
K_1	=	correction for pier nose shape
K_2	=	correction factor for angle of attack of flow
K_3	=	correction factor for bed condition
K_4	=	correction factor for armouring due to bed material size
K_u	=	0,0059 (SI units)
L	=	pier length (m)
L_s	=	spacing between spurs (m)
n	=	Manning's coefficient of roughness ($\text{s/m}^{1/3}$)
Q	=	total discharge (m^3/s)
Q	=	equivalent steady discharge which would generate the channel geometry (m^3/s)
Q_T	=	design flood (m^3/s)
Q_{2T}	=	twice the recurrence interval design flood (m^3/s)
S	=	energy slope (m/m)
s	=	specific gravity of soil particles
S_s	=	specific gravity of riprap
SF	=	required stability factor to be applied
q	=	discharge per unit width ($\text{m}^3/\text{s.m}$)
q	=	discharge through the sub-channel ($\text{m}^3/\text{s.m}$)
V	=	velocity on pier (m/s)
\bar{V}_i	=	average velocity through sub-channel (a, b or c)
\bar{V}_1	=	average velocity through Section 1 (m/s)
\bar{V}_1	=	mean velocity upstream of the pier (m/s)
\bar{V}_1	=	average approach velocity (m/s)
\bar{V}_{2A}	=	average velocity in constriction during abnormal stage conditions (m/s)
\bar{V}_{2c}	=	average critical velocity in constriction (m/s)
\bar{V}_{n2}	=	average flow velocity at section 2 based on A_{n2}
\bar{V}_a	=	average velocity in the main channel

V_*	=	shear velocity (m/s)
V_{*c}	=	critical shear velocity (m/s)
V_i	=	approach velocity when particles at pier begin to move (m/s)
V	=	characteristic average velocity in the contracted section (m/s)
V_{ss}	=	particle settling velocity (m/s)
V_R	=	velocity ratio
V_{c50}	=	critical velocity for D_{50} bed material size (m/s)
V_{c90}	=	critical velocity for D_{90} bed material size (m/s)
y	=	mean depth of flow (m)
\bar{y}	=	depth of flow in the contracted bridge opening (m)
\bar{y}	=	projected normal flow depth in the constriction (m)
y_0	=	depth upstream of pier (m)
y_1	=	flow depth directly upstream of pier (m)
y_2	=	flow depth under bridge (m)
y_{2c}	=	critical depth in constriction (m)
y_s	=	scour depth (m)
Y_t	=	total maximum scour depth (m)
Y_0	=	maximum general scour depth (m)
Y_s	=	local scour depth (m)
α_1	=	velocity coefficient
α_2	=	velocity head coefficient for the constriction
θ	=	bank angle with the horizontal ($^\circ$)
ρ	=	density of water (kg/m^3)
ρ_d	=	dry bulk density (kg/m^3)
ρ_s	=	saturated bulk density (kg/m^3)
ϕ	=	riprap angle of repose ($^\circ$)
τ_c	=	critical tractive stress for scour to occur (N/m^2)
ν	=	kinematic fluid viscosity (m^2/s)

Chapter 9

a	=	area of partially full flowing pipe (m^2)
A	=	full-flow area (m^2)
A	=	area of the larger primary area (km^2)
A_C	=	most downstream part of the larger primary area that will contribute to the discharge during the time of concentration associated with the smaller, less pervious area (km^2)
A_i, A_o	=	cross-sectional areas of the inlet and outflow pipes (m^2)
B	=	structure diameter (m)
C_B	=	correction factor for benching
C_{D1}	=	correction factor for pipe diameter
C_{D2}	=	correction factor for flow depth
C_P	=	correction factor for plunging flow
C_Q	=	correction factor for relative flow
C_1	=	coefficient for the relative access-hole diameter
C_2	=	coefficient for the water depth in the access hole
C_3	=	coefficient for lateral flow, the lateral angle, and plunging flow
C_4	=	coefficient for the relative pipe diameters
d	=	water depth in the structure computed as the difference in HGL and invert at the upstream end of the outlet pipe (m)
d	=	depth of flow (m)
D_o	=	outlet pipe diameter (m)
D_i	=	inlet pipe diameter (m)
D	=	pipe inner diameter (m)
g	=	gravitational acceleration ($9.81 \text{ m}^2/\text{s}$)
h	=	difference in elevation between the highest incoming pipe invert and the centreline of the outlet pipe (m)
HGL_o	=	hydraulic grade elevation at the upstream end of the outlet pipe (m)

HGL _o	=	hydraulic grade line at the upstream end of the inlet pipe (m)
HMC _i	=	horizontal momentum check for pipe <i>i</i>
h_L	=	minor loss (m)
K	=	adjusted minor loss coefficient
K _O	=	initial head loss coefficient based on relative size of structure
k_s	=	absolute roughness of conduit (m)
n	=	coefficient of roughness ($s/m^{1/3}$)
p	=	wetted perimeter of partially full flowing pipe (m)
P	=	wetted perimeter (m)
Q	=	flow rate (m^3/s)
Q _A , Q _B	=	discharges for the pair of inflow pipes producing the largest value of C _{3D} (m^3/s)
Q _i	=	discharge in the incoming pipe of interest (m^3/s)
Q _o	=	discharge in the outflow pipe (m^3/s)
Q ₁ , Q ₂	=	discharge from inflow pipes 1 and 2 (m^3/s)
Q ₄	=	discharge into the access hole from the inlet (m^3/s)
r	=	hydraulic radius of partially full flowing pipe (m)
R	=	hydraulic radius (m) – A/P
S	=	slope of the energy grade line (m/m)
T _{C1}	=	time of concentration of the smaller, less pervious, tributary area (h),
T _{C2}	=	time of concentration associated with the larger primary area as is used in the first calculation (h)
V _o	=	velocity in the outlet pipe (m/s)
V _c	=	critical velocity (m/s)
V _i , V _o	=	velocity of flow in the inlet pipe and outflow pipes (m/s)
y_c	=	critical depth (m)
Z _o	=	elevation of the outlet pipe invert (m)
Z _o	=	invert elevation of the outlet pipe at the upstream end (m)
Z ₁ , Z ₂	=	invert elevations of the inflow pipes relative to the outlet pipe invert (m)
Z _A , Z _B	=	angle between the outlet main and inflow pipes 1, 2, and 3, degrees
Z _A , Z _B	=	invert elevation, relative to the outlet pipe invert, for the inflow pipes that produce the largest value of C _{3D}
θ	=	angle between inlet and outlet pipes
θ_A , θ_B	=	angle between the outlet main and inflow pipes for the pair of inflow pipes producing the largest value of C _{3D}
θ_c	=	angle at critical depth (radians)
θ_i	=	angle between the outlet pipe and inflow pipe <i>i</i>
\emptyset	=	angle of flow (radians)
ν	=	kinematic viscosity (m^2/s)

Chapter 10

c_1 , c_2 and c_3	=	dimensionless coefficients used in river routing
D	=	vertical dimension of the existing culvert.
$\frac{dS}{dt}$	=	the change in storage over the time step of dt (m^3)
\bar{I}	=	average inflow (m^3/s)
K	=	constant obtained when using Muskingum river routing (h)
N	=	auxiliary function (m^3/s)
O	=	outflow through culvert (m^3/s)
\bar{O}	=	average outflow (m^3/s)
Q _{T0}	=	design flood for the design return period which was obtained from the review of the road classification, R _{C0} and the index flood, Q ₂₀ (m^3/s)
Q _{C1}	=	maximum calculated existing inlet capacity of the culvert by limiting the total energy head to 1,2D (m^3/s)
Q _{C2}	=	maximum calculated current existing hydraulic capacity of the culvert by limiting the total energy head to be equal to the shoulder brake point level (SBP) (m^3/s)

Q_{T1}	=	design flood for the design return period which was obtained from the review of the road classification, R_{C-1} and the index flood, Q_{20} (m^3/s)
Q_{20}	=	index flood for the contributing catchment with a return period of 20 years (m^3/s)
Q_{2T0}	=	flow rate related to a return period twice that which was obtained for the design flood, Q_{T0} (m^3/s)
Q_{2T1}	=	flood rate related to a return period twice that which was obtained for the design flood, Q_{T1} (m^3/s)
R_{C0}	=	original road classification
R_{C-1}	=	reflects the selection of a road classification which is one class less than that determined for the road
S	=	temporal storage or ponding volume (m^3)
S	=	sum of the storage volume of the prism and the wedge (m^3)
T	=	design return period
T_c	=	time of concentration (h)
T_s	=	total time during the routing of the flood when the upstream energy head is more than $1.2D$ (h)
V_{T1}	=	maximum storage volume upstream of the culvert assuming level-pool routing conditions and an inflow hydrograph with a peak flow rate of Q_{T1} and a triangular distribution with a base width of $3T_c$ and the peak discharge occurring at T_c (m^3)
V_{storm}	=	calculated storm volume based on the assumption of an inflow hydrograph with a peak flow rate of Q_{T1} and a triangular distribution with a base width of $3T_c$ and the peak discharge occurring at T_c (m^3)
x	=	a dimensionless weighting factor indicating the relative importance of the inflow (I) and the outflow (O) in determining the storage (S) in the reach
ΔS	=	change in storage volume (m^3)
Δt	=	time step that is used (s)

Chapter 11

A	=	cross sectional flow area (m)
B	=	top width (m)
dy	=	change in water depth (m)
dx	=	distance over which change occurs (m)
E_{sc}	=	specific minimum energy (m)
Fr	=	Froude number
g	=	gravitational acceleration (m/s^2)
h	=	stage height (m)
Q	=	flow rate (m^3/s)
S	=	bed slope (m/m)
S_c	=	critical slope (m/m)
S_f	=	represents the slope of the total energy line
S_0	=	bed slope (m/m)
\bar{V}	=	mean cross-sectional velocity
y	=	flow depth (m)
y_c	=	critical flow depth (m)
y_n	=	normal flow depth (m)
α	=	velocity coefficient
ΔE_s	=	specific energy (m)

Chapter 12

A	=	surface area (m^2)
A_g	=	geotextile area available for flow (m^2)
A_t	=	total geotextile area (m^2)
AOS	=	apparent opening size (mm)
B	=	a coefficient (dimensionless)
B	=	width of collector drain (m)
C_u	=	the uniformity coefficient

d	=	diameter of pipe (m)
D ₈₅	=	soil particle size for which 85% of openings are smaller (mm)
D _x	=	the sieve size through which x% of the material passes (mm)
g	=	longitudinal slope of the road (m/m)
i	=	hydraulic gradient (m/m)
I	=	design infiltration rate (mm/h)
k	=	Darcy coefficient of permeability (m/s) and
k _s	=	permeability of material (m/day)
k _b	=	permeability of an open-graded layer (m/day)
k _t	=	permeability of the channel backfill (m/day)
L	=	length of the pipe (m)
L	=	length of paving (1 m wide) subject to infiltration (m)
n	=	Manning's n (s/m ^{1/3})
n _b	=	porosity of an open-graded layer
O ₉₅	=	opening size in geotextile for which 95% of openings are smaller (mm)
P	=	1h duration/1 year return period rainfall intensity (mm/h)
q	=	drainage rate (mm/day)
q	=	discharge per meter width (m ³ /s.m)
S	=	spacing (m)
S	=	cross-slope of a drainage layer (m/m)
S _o	=	slope of the pipe (m/m)
t	=	depth of flow in material (mm)
T	=	drainage period for layer (h)
t _b	=	thickness of drainage layer (mm)
t _b	=	effective thickness of drain layer (mm)
W	=	width of the drainage layer (m)
ψ	=	geotextile permittivity

CHAPTER 1 – INTRODUCTION

1.1 HISTORICAL OVERVIEW

When the *Road Drainage Manual* (RDM) was first published in Afrikaans in 1981^(1.9), its purpose was defined as:

“om nuttige inligting aangaande padderinerings in ‘n bruikbare vorm saam te vat” (to combine useful information on road drainage in a usable format).

It was realised at that stage that many road drainage components were not being designed optimally. This could be attributed largely to the fact that it typically took a designer a while to accumulate enough separate pieces of information, which were required to undertake road drainage design. The large numbers of copies of the RDM that have been sold since then, as well as the large number of persons who have attended courses on the application of the manual, were proof of the need for such a document.

It is especially necessary in the southern African context to provide manuals for the local designers since they have fewer opportunities to consult with specialists. Whilst a Drainage Manual must cater for this reality, it remains true that only persons with the necessary insight and experience may deal with major drainage structures and complex scour phenomena at these structures.

As in the original RDM, recommendations are made regarding methods of calculation, coefficients and design criteria for general use. In contrast with textbooks, theories are only quoted briefly with the emphasis rather on the application of the theories. Wherever possible, available information has been sorted through so that only the most useful information giving reliable answers, is provided in this manual.

1.2 CURRENT POSITION OF SANRAL

The South African National Roads Agency Limited SOC (SANRAL), generally known as SANRAL, was formed on 1 April 1998, as an independent, statutory company registered in terms of the Companies Act.

The South African Government, represented by the Minister of Transport, is the sole shareholder and owner of SANRAL. Its mandate is to develop, maintain and manage South Africa's proclaimed national roads.^(1.1)

In striving to reach the key objectives, SANRAL is being, and has been, pro-active in compiling relevant information, developing manuals and participating in capacitating the role players in the roads industry to ensure a sustainable road infrastructure network.

Compiled SANRAL manuals and standards that have been well accepted and which are widely used include:

- *Procedure for road planning and design*, (2003)^(1.2)
- *Policy in terms of road planning and design*, (2003)^(1.3)
- *Geometric Design Manual*, (2002)^(1.4)
- *Code of procedure for the planning and design of highway and road structures in South Africa*, (2002)^(1.5)

As a result of the core value to be pro-active to the needs of the customers and other stakeholders and the wide use of the earlier *Road Drainage Manual* (1981 – Compiled by the South African Roads Board), SANRAL decided to revise and upgrade this document as a user tool for all persons involved in the design of drainage structures and systems. This document is titled: *Drainage Manual*.

The purpose of the *Drainage Manual* is to provide a reference document with regard to drainage and to demonstrate and reference some software for the modelling and analysis of drainage problems. The *Drainage Manual* covers road drainage in particular detail. Revisions and additions to the original RDM, include:

- Clarifying points, which have proven to be open to misinterpretation.
- Adding new useful local information, which has become available since the publication of the RDM during 1981.
- Addressing identified gaps in information.
- Deleting information which has become obsolete due to changes in policy or practise, and replacing it with material in accordance with new requirements ^(1.5).
- Illustrating hand calculations for verification and reinforcing of the analysis procedures and theories.
- Referring to appropriate computer software.

The *Drainage Manual* therefore contains the following:

- A Road Map at the beginning of each chapter to guide the user to specific sections to indicate typical problems and to provide references to other chapters.
- Theoretical description of the applicable calculations for drainage problems.
- Hand calculations of typical problems.
- Reference to applicable software utilities and user manuals for the programs.

The *Drainage Manual* should be read in conjunction with the *Code of Procedure for the Planning and Design of Highway and Road Structures in South Africa* (February 2002 or later editions). The Code covers the procedures to be followed and design requirements to be met in the planning and design of structures for The South African National Roads Agency Limited SOC (SANRAL), including structures being designed for other authorities, but funded by SANRAL, or structures built for other authorities that are proclaimed national roads.

The reader is also referred to the *Guidelines for the Hydraulic Design and Maintenance of River Crossings* Volumes I to VII ^(1.6), compiled by the Committee of State Road Authorities during the period 1992 – 1994 and published by the Department of Transport, as well as the *Design Manual for Standard Box Culverts* ^(1.7), published by the National Transport Commission and the Natal Provincial Administration in 1981. The content of this *Drainage Manual* takes precedence over the documents indicated above.

1.3 LAYOUT OF THE DRAINAGE MANUAL

The Drainage Manual ^(1.10) has been divided into two separate documents. The first one is referred to as the “Drainage Manual” (this document), which covers the economical -, hydrological -, hydraulic - and practical issues related to road drainage structures and the second document referred to as the “Application Guide” ^(1.11) contains all the step-by-step solutions of typical road drainage problems.

The “Drainage Manual” is distributed as a printed document, whilst the “Application Guide” is distributed as an electronic document. An electronic copy of the Application Guide ^(1.11), supporting documents, software packages and utilities are included on the flash drive/DVD at the back of this document.

The *Drainage Manual* ^(1.10) contains thirteen chapters. These chapters have been structured to provide the user with the relevant theoretical bases, worked examples as reinforcement of the application of the theory, as well as design procedures and reference to utility software. Photographs of different aspects of drainage and drainage structures have also been included to provide further background to the topics covered in this document. The focuses in the different chapters are:






- Chapter 1: (This chapter): Provides an introduction to the *Drainage Manual*.
- Chapter 2: Reviews the planning, economic and legal considerations.
- Chapter 3: Discusses the methods that can be used to calculate floods for different recurrence intervals.
- Chapter 4: Reflects procedures for hydraulic calculations.
- Chapter 5: Discusses surface drainage design.
- Chapter 6: Includes details of low-level crossings.
- Chapter 7: Contains design information for lesser culverts and storm water pipes.
- Chapter 8: Focuses on bridges and major culverts and scour at these structures.
- Chapter 9: Discusses storm water analyses and design issues.
- Chapter 10: Assessment of the hydraulic capacity of existing drainage structures, application of flood routing and the value of maintenance.
- Chapter 11: Modelling of free surface flow and flood calculations.
- Chapter 12: Discusses sub-surface drainage.
- Chapter 13: Reflects relevant web links and refers to supporting software for drainage.






The calculation procedures for typical drainage related problems for each of the chapters are provided in the *Drainage Manual - Application Guide*.




At the start of each chapter a “Road Map” is included. This Road Map reflects the topics covered in the chapter, provides a quick reference to other topics, refers to typical problems and hand calculations and contains reference to utility programs. **Table 1.1** (Road Map 1) provides the road map for the *Drainage Manual* and reflects the different aspects covered in this publication.

It is trusted that the document will provide valuable assistance in the design of drainage systems. Users are invited to comment on any aspect that they feel should be extended or reviewed. Supporting drainage utility software and user manuals for this software are available on the flash drive/DVD ^(1,8).

Table 1.1: Overview of the Road Maps

ROAD MAP 1		
Road Map	Topic	Schematic
1	Chapter 1 - Introduction	
2	Chapter 2 - Economic analysis procedures and legal aspects with regard to road drainage	
3	Chapter 3 - Flood hydrology	
4	Chapter 4 - Hydraulic calculations	
5	Chapter 5 - Surface drainage	

Road Map	Topic	Schematic
6	Chapter 6 - Low-level crossings and causeways	
7	Chapter 7 - Lesser culverts and storm water pipes	
8	Chapter 8 - Bridges and major culverts	
9	Chapter 9 - Storm water analyses and design	
10	Chapter 10 - Assessment of the hydraulic capacity of existing drainage structures and the application of flood routing.	

Road Map	Topic	Schematic
11	Chapter 11 - Modelling of free surface flow and flood line calculations	
12	Chapter 12 - Sub-surface drainage	
13	Chapter 13 - Web-based links and supporting software	

1.4 REFERENCES

- 1.1 South African National Roads Authority Limited (SANRAL), *Annual Report 2003*. (2003). [Online]. Available: <http://www.nra.co.za> [30 November 2012]
- 1.2 SANRAL. *Procedure for Road Planning and Design*. (2003). [Online]. Available: <http://www.nra.co.za> [30 November 2012]
- 1.3 SANRAL. *Policy in terms of Road Planning and Design*. (2003). [Online]. Available: <http://www.nra.co.za> [30 November 2012]
- 1.4 SANRAL. *Geometric Design Manual*. (2002). [Online]. Available: <http://www.nra.co.za> [30 November 2012]
- 1.5 SANRAL, *Code of Procedure for the Planning and Design of Highway and Road Structures in South Africa*. (2002).
- 1.6 Committee of State Road Authorities. (1994). *Guidelines for the Hydraulic Design and Maintenance of River Crossings*. Volumes I to VII, 1992 to 1994.
- 1.7 National Transport Commission and the Natal Provincial Administration. (1981). *Design Manual for Standard Box Culverts*.
- 1.8 Van Vuuren S.J. and Van Dijk, M. (2012). *Utility Programs for Drainage*. [Online]. Available: <http://www.sinotechcc.co.za> [30 November 2012]
- 1.9 Rooseboom, A., Basson, M.S., Loots, C.H., Wiggett, J.H. and Bosman, J. (1983). *National Transport Commission road drainage manual*. Second edition. Pretoria: Director-General: Transport. Chief Directorate: National Roads.
- 1.10 Kruger, E.J. (Editor), Van Vuuren, S.J., Gomes, N., Van Dijk, M., Jansen van Vuuren, A.M., Smithers, J.C., Rooseboom, A., Pienaar, W.J., Pienaar, P.A., James, G.M., Maastrecht, J. and Stipp, D.W. (2012). *Drainage Manual – Application Guide*. 6th Fully revised. The South African National Roads Agency SOC Ltd.

Notes:

Lined area for notes.

CHAPTER 2 - ECONOMIC EVALUATION OF DRAINAGE SYSTEMS AND LEGAL ASPECTS PERTAINING TO DRAINAGE SYSTEMS

WJ Pienaar and SJ van Vuuren

2.1 INTRODUCTION

The aim of this chapter is to provide comprehensive guidelines for the economic evaluation of drainage systems and hydraulic structures for road projects by practising transport engineers and transport economists. In this respect the guidelines should achieve the following objectives:

- Ensure that the results of evaluations conform to an acceptable degree of accuracy;
- Standardise the approaches without prescribing the extent of investigations and the levels of detail of reports thereon; and
- Offer systematic techniques for testing the proposed projects in terms of quantified technical and economic efficiency criteria.

As is the case with any other infrastructure improvement project, the economic evaluation of drainage systems and hydraulic structures measures costs and benefits from the point of view of society as a whole. It therefore requires a precise identification, quantification and evaluation of all the costs and benefits associated with a project. It further requires ascertaining whether the scale, the scope and the timing of project implementation are adequate to ensure the most appropriate use of the country's resources. Another aspect of the economic evaluation is that it can provide an input during the design phase of a project and thus contribute to optimisation of the project design.

The project evaluation process as conceptualised in this chapter is primarily concerned with methodological and quantitative consistency and standards of the analysis. At the same time it addresses, to the maximum possible extent, the basic practical aspects with the aim of achieving an acceptable degree of uniformity in approach and comparability of results when the project evaluation is carried out by different professional entities and/or in different regions of the country.

Given the serious consequences that inadequate drainage designs might have, the legal issues are of major importance. Designers need to be aware of the basic legal principles, and should seek expert legal advice when justified. It is appropriate that the legal aspects are covered, together with economic evaluations, as the risk that is accepted in design, is increasingly being determined by budget constraints.

Aspects, which are covered, include:

- Legislation[#];
- Wrongfulness and negligence;
- Court judgements; and
- Professional liability.

Note: [#] *An earlier document on Legal Aspects by T J Scott, has been appended electronically on attached flash drive/DVD.*

Table 2.1 contains the Road Map that provides a reference to the aspects that are covered in this chapter.

Table 2.1 Road Map for economic evaluation of drainage systems and legal aspects

ROAD MAP 2			
Typical problems	Par	Input variables	Hand calculations *
Determination of the economic value of a project	2.2.1	Economic value of the resource, future inflation, base date, time value of money, discounting procedures	In the <i>Application Guide</i> a number of problems with their solutions have been included which demonstrate the principles.
Economic evaluation techniques	2.3	Present worth Net present value Benefit/Cost ratio Internal rate of return	
Risk of flood damage	2.5	Design standard, maintenance and operation costs and other additional costs relating to the reinstatement of the project	
Economic selection of project alternatives	2.7	Mutually exclusive projects	Par 2.7.2
		Independent projects	Par 2.7.3
		Mutually exclusive and Independent projects	Par 2.7.4

Note: * Supporting utility software known as UPD could be used to determine the NPV, IRR and conduct a Life Cycle Cost Analysis (LCCA).

2.2 BASIC PRINCIPLES OF ECONOMIC EVALUATION

2.2.1 Economic value of resources

2.2.1.1 Need for shadow pricing

In order to assess the economic efficiency of the application of resources, an economic evaluation, based on the consideration of social cost, has to be conducted. Social cost is the *opportunity cost* to society of the resources it uses. It is equal to the value of whatever society forgoes by using resources for a certain purpose instead of another. This involves determining the *scarcity value* of inputs in a project and of the outputs produced as a consequence.

The prices obtained under perfectly competitive market forces are indicators of peoples' willingness to pay for different goods and services and thus serve as a measure of value to society. Competitive market prices are signals between producers and consumers that, in the absence of any market failure, mediate the efficient (i.e. optimal) allocation of resources. In reality, markets are of course different: governments (acting on behalf of societies) distort prices for all kinds of reasons, and market failure does occur.

When goods and services, appearing in a *cost-benefit analysis*, are traded in a competitive market with few distortions and failures, their market prices are a relatively good guide of the willingness to pay for the goods and services, and are usually accepted and used in the evaluation as they stand. When they are not so traded, the economic price can either be estimated directly by finding out what people would be willing to pay if there was an effectively working market, or by taking the distorted market price and adjusting it by *shadow pricing*.

An economic evaluation of transport projects must be based on shadow prices, due to the following:

- Whenever (i) transaction prices in the market do not reflect the social opportunity cost of resources exchanged, and (ii) non-market items (such as life, comfort, convenience and the external effects of activities) are assessed, shadow prices need to be determined that represent, or act as proxy for, their scarcity value. (In economics literature shadow prices of market items are sometimes referred to as factor costs or accounting costs or economic costs, while the shadow prices of non-market items are sometimes labelled *surrogate prices*).
- Double counting will occur if those government levies included in the price of vehicle operating inputs, and used by the government for investment in and maintenance of infrastructure, are treated as if they form part of vehicle running costs.
- Cost exaggeration will occur if indirect tax serving as general state revenue (e.g. value-added tax and customs and excise duties that the government might opt to spend on non-infrastructure related items) is included in the economic cost of a transport project.
- Indirect taxation will lead to a distorted cost comparison if modes or projects are compared and their inputs are not taxed proportionately, or if the inputs of some are not taxed at all.

2.2.1.2 *Shadow pricing of market items*

The shadow price of a market item is equal to its transaction price, minus indirect taxes and user charges, plus subsidies and other refinements that reflect the effect of price distortions in order to represent the item's economic (or resource) cost. The *transaction price* includes the normal profit, and not above-normal profit that will be realised in a competitive market. The *distortions* result from market and government regulatory failures.

Taxes and subsidies do not represent economic resources but simply involve transfers of funds between the public and private sectors. Benefits and/or costs may be under- or over-emphasised if user charges, indirect taxes and subsidies are not excluded from an analysis of public projects.

Transfer payments are financial payments between different parties within the defined entity on whose behalf an evaluation is performed, for example, a nation in the case of a cost-benefit analysis. From the point of view of a nation as a whole, domestic transfer payments have no significance. Individuals, households, firms and other sub-groups may experience these costs and benefits, but for the national economy they are like funds transferred internally from one accounting category to another within a firm. So transfer payments within a nation, whether linked with costs or with benefits, should be omitted from any cost-benefit analysis. One could compare it with cash being moved from one's left pocket to one's right pocket.

In a financial evaluation for an entity that pays taxes or duties or receives subsidies, **the income and payments should be considered as inflows and outflows** like any other revenues and expenditures, and should be included in the financial evaluation. In a cost-benefit analysis, however, where the defined entity is a nation, or society as a whole, taxes and subsidies and other international transfer payments should not be counted.

The government is only a sub-group within the nation or society as a whole, and these transfers between the government and particular citizens do not increase or decrease the welfare of the nation, because they do not represent the *opportunity cost* of specific resources sacrificed or gained.

2.2.1.3 Shadow pricing of non-market items

The *shadow price of a non-market item* (or an intangible item, such as comfort, convenience and time) represents the utility gained through its beneficial effects and/or the disutility suffered in the form of external costs created by its supply and use. This is defined by what consumers are willing to pay or sacrifice for its benefits, and what they are willing to pay not to suffer its disutility. (As mentioned above this type of shadow price is sometimes called a surrogate price.)

2.2.2 Future inflation

Based on the assumption that the relative scarcity of the resources used in the supply and operation of a facility will not change in the long run, it is customary to disregard inflation in cost-benefit analysis and to base all future values in real value on a specific base date.

2.2.3 The evaluation base date

In economic evaluation, the principle is to express the value of all costs and benefits in a common unit, usually referred to as *constant pricing*. To avoid problems the analyst should use the price levels pertaining to a defined base date, which should be stated, for example "rands at mid-2004 prices" or "rands at the prices of 1 January 2005". All costs and benefits should be expressed in real terms with respect to a base date, whatever the future periods they are expected to occur. The defined base date itself can be fixed according to the analyst's convenience, for instance the date on which most of the cost estimating was finalised. The base date for inflation is independent of "year zero" (the present time when the analysis is performed) for discounting. However, for easy value interpretation and present relevance it is desirable that the base date should be set as close to year zero as is possible (i.e. as recently as possible). Setting the base date at some point in the future, i.e. after year zero, should be avoided. Firstly, estimating future values is more prone to error than estimating present or recent values of resources. Secondly, the convention of assuming that no differential inflation will occur in the future makes the choice of a future base date meaningless.

2.2.4 The time value of money

In order to evaluate and compare different projects on an economic basis, it is necessary that benefits and costs be assessed on a common time basis, since money has a time value. An amount X would be more valuable now than say in a year's time if it is assumed that inflation or other factors will result in a change of the monetary value of goods, resources and services. This greater relevance of present power of disposal over funds, compared with eventual power of disposal over the same amount, is referred to as the *time preference propensity*.

Time preference is the tendency to prefer desirable things to happen sooner rather than later and undesirable things later rather than sooner. This may be ascribed to three aspects:

- uncertainty;
- decreasing *marginal utility*; and
- greed.

Goods now may be preferred to goods in future decades, because of uncertainty as to whether one will be alive to enjoy them; because one expects one's total income to be higher than at present so that the expected addition to utility from an equal addition to consumption is less; or through impatience.

Although the prevalence of inflation influences the intensity of individuals' time preference propensity for money, inflation itself is not the only reason why money has a time value. Even in non-inflationary periods, people value present consumption more highly than identical consumption in the future. The intensity of this time preference is related to a society's average income that it receives on its capital (i.e. all savings and investments). The average time preference of an amount may, therefore, be equated with its opportunity or alternative cost, as reflected in the average or expected return on capital over a period.

One can observe people's behaviour and deduce approximately what their individual time preference rate, or unconscious discount rate, is. When decisions are made on behalf of a large number of people, as a society, there is again an observable time preference rate: this collective societal rate is called the social time preference rate.

Because of the time preference attached to the power of disposal over money, the present worth of benefits achieved and costs incurred several years into the future become increasingly smaller as the evaluation process incorporates values that lie further and further in the future. An economic assessment is meaningful only after all future values have been expressed in equivalent terms; in other words after being reduced to their worth at a common point in time by means of a *social discount rate*.

There are three broad approaches toward the determination of the social discount rate, i.e.:

- The first approach emphasises the social time preference rate.
- The second takes cognisance of the social opportunity cost of capital.
- The third is a synthesis of the above two.

The social time preference rate is not equal to the social opportunity cost of capital, because of imperfections in the capital market and because individuals' collective behaviour toward the future differs from their behaviour as individuals.

The social time preference rate is generally lower than the time preference rate of individuals acting in a market situation. Society as a whole, or the government as its agent, is more aware of desirable goods and services that a free market cannot provide without government mediation, and is conscious, although perhaps only vaguely, of the ethical rights of future generations.

Governments are responsible firstly for reflecting this difference between individual rates and collective rates, and secondly for representing the interests of future generations. This implies taking a long-term view. Therefore, the social time preference rate is generally lower than the time preference rate of individuals.

By applying the opportunity cost principle to discounting; it may be argued that the social discount rate ought to reflect what society forgoes elsewhere if it uses resources for a period of time in a certain project. In theory, this is the return on the last (i.e. marginal) investment that consumes the last of society's available capital. This is the real rate that would reflect the choice made by society between present and future investment returns. The real interest is also known as the social opportunity cost of capital.

The specific rate of discount used in economic evaluation will influence the balance between the cost of investment, which takes place early in the analysis period, and the value of the benefits achieved in future. For example, the present worth of benefits may exceed the present worth of an investment using a low rate of discount and vice versa using a high rate. The rate of discount used is thus significant in the outcome of an economic evaluation. Although economic efficiency requires that the rate of discount should reflect the social opportunity cost, the choice is usually a political one. Therefore, the decision maker normally prescribes the social discount rate.

2.2.5 The discounting procedure

The basic formula for discounting a single future amount to its present worth becomes more comprehensible if discounting is regarded as the reverse of compound interest computation; in other words the conversion of present worth into future worth by making use of a specific rate of interest.

If, for instance, the time value of an amount = i percent per annum, its present worth (PW) in a year's time will increase to $PW(1 + i/100)$.

After two years its worth would equal $PW(1 + i/100)(1 + i/100) = PW(1 + i/100)^2$.

After three years the PW would have increased to an amount equalling $PW(1 + i/100)^3$, and so on, until after n years it would equal $PW(1 + i/100)^n$.

Since discounting is the reciprocal of interest or future amount computation, the calculation applied to determine the future amount $PW(1 + i/100)^n$ for a number of years (n) at an interest rate of i percent, would have to be inverted. In other words, one would have to multiply the future value by $1/(1 + i/100)^n$ to obtain its present worth.

The term $(1 + i/100)^n$ is known as the interest function, whereas its reciprocal, namely $1/(1 + i/100)^n$, is known as the discount function or the present worth factor.

The following formula is used to compute the PW of a future amount (FA) at the end of year n at a discount rate of i percent per annum:

$$PW = \frac{FA}{(1 + i)^n} \quad \dots(2.1)$$

where:

PW	=	present worth (value in year zero)
FA	=	future amount at the end of year n
i	=	annual discount rate as a decimal fraction
n	=	discount period in years

2.3 ECONOMIC EVALUATION TECHNIQUES

2.2.6 Introduction

Various techniques, all based on the principle of discounted cash flows, can be used for cost-benefit analysis. The four most commonly applied techniques are:

- Present worth of cost (*PWOC*) technique;
- Net present value (*NPV*) technique;
- Benefit/cost ratio (*B/C*) technique; and
- Internal rate of return (*IRR*) technique.

Use of these four techniques in the economic choice of projects is discussed in Section 2.7 below.

2.2.7 Present Worth of Cost (PWOC) technique

This technique selects the lowest cost alternative among mutually exclusive projects. All economic costs (i.e. the opportunity costs) associated with the provision, management, maintenance and use of each possible alternative project are discounted to their present worth. Given the objective of economic efficiency the alternative that yields the lowest *PWOC* is regarded as the most cost-effective (beneficial) proposal. This method can be expressed as follows:

$$PWOC = C_A + PW(M + U) \quad \dots(2.2)$$

where:

- PWOC = present worth of cost
- C_A = all costs incurred in establishing a facility (i.e. the opportunity cost of the investment)
- $PW(M + U)$ = present worth of all facility maintenance costs and user costs.

[Note that in the case of the null alternative (i.e. the existing facility whose possible replacement or upgrading is being investigated, and against which the other mutually exclusive alternatives are measured), $PWOC = PW(M + U)$]

When a proposed project will, because of lower user cost, induce additional traffic over and above normal-growth traffic, the abovementioned criterion of lowest total transport cost presents a contradiction in terms. Any induced traffic will inflate the facility's *PWOC*, thus defeating the objective of minimum cost.

2.2.8 Net Present Value (NPV) technique

This technique provides an economic performance measure that is used to:

- select the best alternative among the mutually exclusive projects; and
- to help establish an overall economic viability of independent projects.

Net present value (*NPV*) is a technique whereby the present worth of investment cost is subtracted from the present worth of all the future project benefits. The present worth of both costs and benefits is calculated by using an official (social) discount rate. All projects reflecting a positive *NPV* are economically viable, while the project alternative with the highest such value is most suitable for implementation, as this will maximise the net benefit for the society as a whole.

The technique may be expressed thus:

$$NPV = PW(M_0 + U_0) - PW(M_A + U_A) + PW(CS_A) - C_A \quad \dots(2.3)$$

where:

- NPV = net present value of benefits
- $PW(M_0 + U_0)$ = the present worth of facility maintenance costs and user costs of the null alternative
- $PW(M_A + U_A)$ = the present worth of facility maintenance costs and user costs of a proposed alternative
- $PW(CS_A)$ = consumer surplus gained through additional usage induced by the proposed alternative. This is equal to one-half of the benefit accruing to each existing journey multiplied by the number of induced trips.
- C_A = investment (capital) cost that is required to implement the alternative A

If the $NPV > 0$ then the project should be implemented, but should the $NPV < 0$ the investment does not provide an acceptable return.

2.2.9 Benefit/Cost Ratio (B/C) technique

This technique provides an economic performance measure used for the selection of the most advantageous independent project(s) by determining the ratio between the present worth of the future project benefits and the present worth of the project investment costs.

The future project benefits are associated with the annual savings, relative to the null alternative, plus the consumer surplus gained through additional usage induced by the proposed facility.

The ratio between the sum of the discounted benefits and the sum of the project investment costs is obtained by dividing the former by the latter. All proposals with a ratio value greater than one are viable, while the one with the highest ratio value is economically the most advantageous. However, when mutually exclusive projects are compared, incremental analysis should be used to identify the best alternative.

The method may be expressed as follows:

$$B/C = \frac{PW(M_0 + U_0) - PW(M_A + U_A) + PW(CS_A)}{C_A} \quad \dots(2.4)$$

where:

B/C = benefit/cost ratio

2.2.10 Internal Rate of Return (IRR) technique

This technique provides an economic performance measure used for the selection of the most advantageous independent project(s). The distinctive feature of this technique is that its application does not entail a singular discounting procedure with one official rate only. Future benefits ("returns") for the period under review are discounted to the beginning of the period. The benefit of each year is calculated in the same manner as with the *NPV* and *B/C* techniques. The sum of these discounted amounts is compared with the discounted project investment cost. Different rates of discount are selected iteratively and applied until at a certain rate the sum of the annual discounted returns equals discounted investment costs. This rate is then referred to as the internal rate of return.

The project with the highest internal rate of return can be regarded as the most advantageous, although the actual criterion is to compare the rate thus obtained with the opportunity cost of capital as represented by the prevailing real discount rate.

If the prevailing real discount rate exceeds the prevailing social discount rate, the alternative is economically viable. However, when mutually exclusive projects are compared, incremental analysis should be used to identify the best alternative. The method could be expressed as follows:

$$IRR = r$$

When

$$PW(M_0 + U_0) - PW(M_A + U_A) + PW(CS_A) = C_A \quad \dots(2.5)$$

where:

IRR = internal rate of return
r = rate at which the left-hand and right-hand sides of the equation are equal, resulting in a NPV of zero.

2.3 DESCRIPTION OF THE EVALUATION PROCESS

2.3.1 Overview of the evaluation process

The economic evaluation process of drainage systems and hydraulic structures is a process of investigation and reasoning designed to assist decision makers in reaching an informed and rational choice. The process involves engineering and economic considerations, organised in a number of defined activities. The activities involved in the project evaluation process can be broadly divided into the following tasks:

- Define the purpose of the economic analysis (Section 2.4.2);
- Select the appropriate economic evaluation techniques (Section 2.4.3);
- Identify project alternatives (Section 2.4.4);
- Calculate recurring user costs/project benefits (Section 2.4.5);
- Estimate project implementation and maintenance costs (Section 2.4.6);
- Incorporate the cost of abnormal flood damage (Section 2.5);
- Calculate the economic performance by means of one or more of the economic evaluation techniques (Section 2.3);
- Undertake sensitivity and risk analyses (Section 2.6);
- Identify other considerations (Section 2.4.6.5);
- Choose between mutually exclusive alternatives and independent projects (Section 2.7); and
- Presentation of the results.

2.3.2 Establish the purpose of the economic evaluation

The economic evaluation of drainage systems and hydraulic structures could be performed at the following levels:

- LEVEL 1: To determine the economic viability.
- LEVEL 2: To establish specific design criteria/details of a specific project.

2.3.2.1 LEVEL 1 – Determination of the economic viability of the project

The objectives of this type of evaluation are twofold:

- To inform the decision maker whether or not to proceed with detailed design and/or implementation of a project
- To provide a basis for prioritising independent projects.

This type of evaluation is usually undertaken for a specified road section, including ancillary services and structures. Drainage systems and hydraulic structures are in most cases considered to be an integral component of the road, and would thus not be evaluated separately from the rest of the road. However, there may be instances where major hydraulic structures, such as bridges and viaducts, may be evaluated as stand-alone projects. There are cases where an existing bridge, for example, is considered for replacement because of structural failure, capacity constraints or improved road alignment. In such instances the bridge and the corresponding road realignment should be economically justified in its own right.

2.3.2.2 LEVEL 2 – Defining the specific design criteria/details of a specific project

This type of evaluation is usually undertaken to compare different design and route alignment options in order to select the most appropriate route alignment, or to optimise the efficiency of the design. Drainage systems and hydraulic structures may be subjected to this type of evaluation to ensure selection of the most appropriate design criteria that will in turn ensure the greatest total net benefit.

2.3.3 Selection of appropriate economic evaluation technique(s)

The individual economic evaluation techniques establish the economic viability of prospective projects on the basis of either:

- Minimum total costs, which can be determined through the present worth of cost (*PWOC*) technique. This technique is suitable for a LEVEL 2 evaluation.
- Net benefit, which is determined by the net present value (*NPV*) technique. This technique is suitable for a LEVEL 1 evaluation.

- Relative benefit, which is usually determined either by (i) the benefit/cost ratio (B/C) technique or (ii) the internal rate of return (IRR) technique. This technique is suitable for a LEVEL 1 evaluation.

These techniques could be classified into two groups on the basis of their underlying philosophy. For the first group (first bullet above), only the cost of each alternative is calculated; the argument being that the alternative with the lowest cost would be superior. The *PWOC* technique falls into this group. In working with the second group of techniques (the second and third bullet above), both benefits and investment costs of alternatives are calculated.

2.3.4 Definition of project alternatives

2.3.4.1 Define the null alternative (Alternative 0)

The null alternative is usually defined as the do-nothing alternative, which represents the existing facility that road users currently use. In the definition of this alternative one usually assumes that no further improvements other than normal routine and periodic maintenance are performed over the evaluation period.

Sometimes the do-minimum option, instead of using the do-nothing option, is used as the basis for evaluating the proposed project. In such cases the do-minimum option becomes the null alternative. The do-minimum option is used when a certain minimum level of expenditure is required for the facility to continue to perform its function to an acceptable standard. It is not compulsory to define an Alternative 0 when a Level 2 evaluation is undertaken.

2.3.4.2 Define the project alternative(s) (Alternative 1 through n)

For the definition of project alternatives, a range of possible solutions should be examined to ensure that the best possible solution is arrived at, given the various applicable physical, economic and other constraints. Preliminary screening may be necessary, with a limited number of alternatives evaluated in depth.

In a climate of economic stringency, this part of the process is particularly important. Creative low-cost solutions, even where these depart from ideal standards, may facilitate the improvement of traffic conditions where full-scale road construction may have to be deferred. Such low-cost solutions could be considered as separate alternatives.

Staging and phasing of project implementation, and also its appropriate timing on grounds of both technical and economic considerations, should be carefully assessed.

Staging of implementation or delayed implementation of a project may commend itself as a possible solution worth evaluating only after the initial project evaluation has been carried out. Whilst it is obviously preferable to attempt to identify staging or deferring of implementation as a project alternative at an early stage in the evaluation process, an iterative process may well assist in arriving at the most suitable approach to implementation from an economic perspective.

2.3.5 Calculate recurring user costs / project benefits

2.3.5.1 General

Benefits are defined as savings in user costs of existing, normal-growth, diverted and transferred traffic, and facility recurring costs relative to the null alternative (i.e. the existing situation or present facility of which the improvement or replacement is being investigated), plus the consumer surplus gained through additional (i.e. induced) usage generated and/or developed by the proposed facility.

The underlying philosophy of techniques falling into this group is that an alternative will be economically viable if benefits exceed its investment costs. The investment cost of a project can be defined as the opportunity cost of the economic resources sacrificed in establishing the project.

Transport infrastructure provides access and facilitates mobility. In areas that lack adequate accessibility and mobility, the supply of new transport facilities is consequently often used as an instrument of development by activating investment in and business interaction between economically dormant areas or regions. However, when transport facilities are built primarily with a view to improving existing mobility (such as in already developed areas) the prime objective is to reduce user costs (i.e. vehicle running costs, accident costs and travel time, including any other disutility resulting from poor quality of service when travelling). In order to determine how efficiently proposed facilities will fulfil their intended role, it is necessary that their provision should be subject to economic evaluation.

The total costs of transport infrastructure supply and usage comprise one-off and recurring costs. One-off costs comprise the investment or initial costs. Recurring costs are incurred continuously throughout the service life of a facility, and consist of the facility user costs and facility maintenance costs. An increase in one-off costs (i.e. greater investment) generally gives rise to a decrease in recurring costs, and vice versa. Determining the optimum trade-off between investments and recurring costs could, therefore, achieve minimisation of total societal cost per trip undertaken.

In a societal sense transport cost is composed of the total costs involved in transport operations and the provision of infrastructure that makes transport possible. The word "cost" is used here in its widest possible sense, and includes all the negative side-effects of transport operations, whether or not they are measurable in monetary terms.

2.3.5.2 User cost classification

User costs could be categorised as reflected in **Table 2.2**.

Table 2.2: Categories of user costs

Cost category	Related to cost elements	Parameters which influence the related cost elements
Vehicle running costs	Existing traffic	No details
	Additional traffic	Normal-growth traffic
		Diverted traffic
		Transferred traffic
		Development traffic
		Generated traffic
Travel time cost	Individual road user	No details
	Vehicles	
Accident cost	People (road users)	
	Vehicles	
	Goods and other property	
Cost of abnormal floods	Loss of life	
	Road user costs	
	Road infrastructure and damage to other property elements	

To determine the benefits accruing to the various categories of users under vehicle running costs, it is necessary to differentiate between the following components of the anticipated traffic:

Existing traffic is the current traffic on a facility that is due to be replaced or improved. When a new transport facility is to be introduced, without any changes to the existing transport network in the area, the existing traffic equals zero. When a new facility replaces an existing one, the current traffic of the existing facility is taken as the existing traffic of the new facility.

Normal-growth traffic is traffic growth that would have occurred in spite of the creation of the new facility. The growth may be attributable to the following factors:

- general population growth;
- an increase in the per capita ownership of vehicles; and
- an increase in average use per vehicle.

Diverted traffic is traffic of the same transport mode diverted from other facilities because of the opening of a new facility. When a new facility is introduced without any changes to existing facilities in the network, all the traffic transferred from the existing facilities to the new facility is regarded as diverted traffic.

Transferred traffic is traffic attracted from other modes to a new or improved facility.

Development traffic is traffic developed after implementation of a new facility because of any changing use of the land served by the facility. The supply of new transport facilities in a developing region usually stimulates economic development and settlement as a result of greater accessibility. Improved access generally results in changed and more intensive land use, which in turn attracts and "develops" more traffic to the corridor through which the facility passes. The volume of development traffic can be estimated by means of appropriate trip attraction and trip development indices for the new land uses.

Generated traffic is traffic that did not exist previously and is generated solely through a reduction of the disutility of travel, brought about by lower user costs and higher service quality offered by the improvement or provision of the transport facility.

Generated traffic consists of previously potential transport users who have been encouraged to join the traffic as a result of the reduction of the generalised cost of travel to below the price they are willing to pay for travelling. This puts new destinations within their reach.

(**Development traffic** and **generated traffic** are collectively known as **induced traffic**. Whereas development traffic is attributable to improved accessibility, generated traffic is attributable to the easing of mobility).

2.3.5.3 *Reduction in vehicle running costs*

Where new transport facilities will not induce a significant volume of additional traffic, savings in running costs attributable to new facilities could normally be measured with a fair degree of accuracy by calculating the difference between vehicle running costs with and without a new or improved facility. Vehicle running costs consist of:

- energy/fuel consumption;
- tyre wear (in the case of road vehicles);
- oil consumption;
- vehicle capital costs; and
- vehicle maintenance costs.

2.3.5.4 *Time savings*

Time savings mean that trip (journey) times using a new facility are shorter compared with trips using the existing facility between the same origin and destination points.

When evaluating the effects of facility improvements, users' travel time savings should be assessed in terms of their alternative value; i.e. the utility that is sacrificed by not being in a position to perform something else than travelling. The question arises whether short time-savings (for example, single minutes or fractions of minutes) have any value. Do sixty savings of one minute each have the same value as a saving of one hour? It is generally accepted that all time-savings, irrespective of whether they are “useful” or not are added up. The reasons for this are firstly that each person would have a different definition of what a useful amount of time is. Secondly, seconds saved whilst travelling on a particular road section under investigation may be insignificant, but the hours saved if the entire route is upgraded would be useful. The fact that time savings on a particular section are disregarded could mean that all time savings are disregarded, which is an underestimation of road improvement benefits.

In recognition:

- that short time-saving incidences may lead to substantially longer and utilisable time opportunities later (as cited in the example above), and
- that a series of short time-saving incidences during a single trip may add up to a long enough period to utilise productively after completion of the trip, it has become customary to assign an economic value to very short time savings.

Time savings in relation to vehicles may be measured from two angles:

- whether the same trip could be covered in less time, or
- whether a longer distance could be covered or more journeys can be made in the same time.

Both have the potential of generating greater income and/or saving money, provided of course that the time saving is used by scheduling additional or longer trips (i.e. market expansion). If time savings are not enough to expand vehicle operations, a benefit can still be gained by using the idle time for maintenance work on the vehicles. These benefits are realised in the form of decreasing vehicle capital cost per kilometre travelled.

2.3.5.5 *Reduction in accident cost*

One of the main objectives in the planning of a new facility or a facility improvement may be to reduce the number and severity of accidents. This particular benefit may even be the deciding consideration in creating a facility, such as a freeway.

To calculate the benefits of accident prevention it is necessary to predict the accident rate and the severity of the accidents (usually on the basis of similar/comparable facility standards and traffic conditions). The cost of the anticipated benefits is then deducted from the current cost of accidents.

The cost of the anticipated benefits poses two problems:

- to what extent are accidents (with respect to number and severity) in fact attributable to poor infrastructure conditions and quality; and
- what value is placed on loss of human life and personal injury?

2.3.5.6 *Cost of abnormal floods*

The cost of abnormal floods is dealt with in Section 2.5.

2.3.5.7 *Calculation of recurring transport infrastructure cost savings*

The establishment of a new or improved transport facility may lead to an increase (negative saving) or a decrease (positive saving) of recurring supply costs. Recurring facility supply costs (notably maintenance cost) will increase when:

- the new facility is an addition to the existing network, and
- when the new facility replaces an old facility but the new one is much more elaborate; for example, when more traffic lanes are added to a road, or a single-carriageway road is replaced by a dual-carriageway road.

An example of obtaining a positive recurring cost saving is when the surface of an unpaved road, which suffers from the onslaught of severe and chronic rainy weather, is replaced with durable weather-proof paving material so that its maintenance cost decreases. (Note that a negative saving is deducted from project benefits and not added to project cost.)

2.3.5.8 *Total project benefit projection for use in cost-benefit analysis*

The benefits of a new facility are estimated by means of a “with” and “without” comparison. Recurring cost is first projected for a continuation of the existing situation. In other words, the analyst assumes that no expenditure will be incurred on improvements other than those related to routine and periodic maintenance.

The potential savings in recurring costs, which may be affected by the introduction of a new facility, can be estimated in the following two ways:

- If the proposed project will replace some existing facilities completely, a projection is made of recurring infrastructure and user costs, assuming (i) a continuation of the existing situation, and (ii) the introduction of the new facility. Savings in recurring costs are estimated by subtracting the proposed facility's projected recurring cost from the existing situation's projected recurring cost.
- If the addition of a new facility to an existing transport network is investigated (in other words, existing routes and transport services are retained), savings in recurring infrastructure and user costs are determined by projecting these costs for a network “with” the additional facility and subtracting the result from projected cost for the existing network “without” the additional facility.

In the cases above, the benefit accruing to induced traffic (i.e. generated plus developed traffic) is not considered. On the assumption that demand for a transport facility is represented by a linear demand schedule, half of the benefit accruing to each existing journey is added to the project benefits for each induced trip. This is based on the additional or extended consumer surplus accruing to existing users (i.e. their saving) and the new consumer surplus created with respect to induced traffic.

The consumer surplus is the difference between the price a consumer or user actually pays for a product (i.e. a good or a service) and the amount that he/she would be willing to pay for the product; i.e. the value he/she attaches to the product. (A user's willingness to pay for a product is reflected by the satisfaction or utility he/she derives from the product, which is taken to be greater than the price actually paid; i.e. the utility sacrificed to obtain the product). In **Figure 2.1** the willingness of users to make use of a transport facility at different prices is represented by the linear demand curve reflected as line UABD. At a generalised user cost per journey (the utility sacrificed plus disutility suffered) of U_0 the traffic volume equals T_0 with a resultant consumer surplus represented by area UAU_0 .




Figure 2.1: Potential user benefits over a specific period in respect of a new or improved facility

If, for example, the facility referred to above is improved so that the user cost for existing traffic is reduced to U_1 and the existing traffic volume is T_0 , the saving for existing users is represented by rectangle U_0ACU_1 in **Figure 2.1**. This rectangle is the area by which the consumer surplus or net utility of the existing users increases. If $T_1 - T_0$ represents the induced traffic volume, the "saving" achieved by induced traffic is not represented by rectangle $AA'BC$; instead, the demand curve halves the "saving" to the area of triangle ABC , which represents the consumer surplus or net utility gained by the induced traffic.

The benefits achieved by each individual traffic component are calculated as follows:

- The savings accruing to existing traffic, normal-growth traffic and diverted traffic are computed by subtracting each traffic component's user cost between origin and destination with the new facility from what it would have been without the new facility.
- The benefit of traffic transferred from other transport modes is calculated by subtracting the cost of transferred journeys from the cost saving effected by those transport modes from which traffic was transferred (This is often a negative saving. For example, in the case of a new freeway between two cities, some commuter rail users may transfer to freeway use, thus adding to road user costs, while the volume of commuter rail patronage lost may not be enough to reduce incrementally the supply of rail commuter services - thus additional costs accrue).
- The benefit accruing to induce traffic is equal to the consumer surplus, created with respect to this traffic component.

2.3.5.9 Treatment of non-user benefits in economic evaluation

Care should be taken not to regard user benefits (savings accruing to users) as total transport benefits. Non-user benefits are an important consideration in many decisions about proposed transport facility construction or improvement, especially when a facility has the potential of stimulating economic activity and development. Non-user benefits do not involve savings as user benefits do, but represent a group of plus factors or returns that are partly the consequence of incentives and investments in other sectors of the economy. They can be seen as general economic benefits, above and beyond the direct user benefits, that contribute to the welfare of everyone within the geographical sphere of influence of the facility.

The developmental or regional economic benefits of a transport facility often amount to a distribution or spatial transfer of economic activities to the location or vicinity of the transport facility. These apparent benefits are not credited to a transport facility in cost-benefit analyses. Even in cases where a transport facility will be instrumental in helping to develop and generate new economic activity (i.e. induced activity that has not been distributed or transferred from elsewhere), the general regional economic returns of such activities are not credited to the facility in a cost-benefit analysis. It should be remembered that additional investment (above and beyond that necessary for the transport facility) is a prerequisite for the realisation of general economic and community benefits.

A road that opens up a water-rich and fertile area for agricultural development, for example, will not be credited in terms of the economic benefit of the agricultural returns in a cost-benefit analysis - it will be regarded as a benefit of the agricultural investment whereby it came into being (above and beyond the investment in the transport facility). Similarly, the additional investment in the non-transport-related sections of a transport facility (such as commercial areas where goods and services not related to transport are traded) will receive the credit for returns from commercial activities that may occur there, and not the investment in the transport facility itself.

2.3.6 Determination of project investment costs

2.3.6.1 General

In economic evaluation, enlargement of the existing consumer surplus through a lowering of user costs, plus the generation and development of new consumer surplus, plus the savings in recurring infrastructure maintenance costs, form the basis for calculating benefits. As opposed to this, the opportunity cost of the investment needed to establish a facility (the so-called one-off cost) is the cost component in economic evaluation.

2.3.6.2 Opportunity cost of investment

The opportunity costs of an investment in transport infrastructure include:

- the costs incurred in direct planning and design (traffic surveys, studies of use and establishing a facility, environmental impact studies, compilation and recording of the construction details, etc.);
- the opportunity costs of the land reserve and preparation of the site for development (demolishing, levelling, reinforcement, etc.); and
- the construction of the facility (including the construction of access links, installation of traffic control devices and other appurtenances as well as landscaping). These costs in their totality are often referred to as project implementation costs.
- Each of the above-mentioned items includes the opportunity costs for materials and equipment used, labour, contractor operating and overhead costs and normal profit as well as the costs of the needed project management. The actual scarcity value of all inputs that are inevitably or unavoidably needed to create the facility and to link it to the existing transport network (that is, to supply it complete and ready for use).

Care should be taken to include in the analysis only the costs of that part of the facility that is necessary for the functioning of the facility for transport purposes. Constructions that are used for commercial activities and entertainment, for example, are non-transport economic considerations and the costs associated with them are omitted from the evaluation.

The shadow price of existing constructions/buildings used as part of the evaluated project should be calculated on an opportunity-cost (i.e. alternative-use) basis and that of new constructions/buildings on the basis of construction/building costs.

Where building costs serve as a basis for these calculations, adjustments have to be made for indirect taxes and distorted labour prices that serve as an input.

In developed countries the labour market is often fairly unrestricted, and shadow pricing of the labour component of costs is seldom considered necessary. However, in developing countries, such as in South Africa and neighbouring countries, the market price for labour, especially unskilled labour, is usually a poor guide to the economic price because of minimum wage legislation and restrictive practices. A more reliable guide to the economic cost of labour may then be obtained from the opportunity-cost principle, based on its use in alternative revenue-earning opportunities. At times of high unemployment this value would be low, probably equal to the minimum living level wage at which people will find it worthwhile to endure the disutility of working for a subsistence wage.

The shadow wage of semi-skilled and skilled workers (excluding professionals and managers) should be based on the minimum living level wage determined for the lowest paid workers in the study area concerned. In general it is unlikely that a lower shadow wage will apply, so that the possibility of over-estimating the opportunity cost of the labour involved is small. Even under conditions of unemployment the labour of professionals and managers should still be valued at market prices.

Under conditions of full employment the market price of labour is used, although full employment remains a theoretical possibility only.

2.3.6.3 *Sunk cost*

All costs related to a project's implementation incurred in the past should be taken into account at the value of their respective present alternative application possibilities, should these exist.

Costs incurred prior to the evaluation of items that have no alternative use are regarded as sunk costs, and are disregarded in the economic analysis. If work on a project was abandoned and the question is whether the project should be completed, only future costs - the cost of resources needed to complete the project - are relevant for the economic analysis, if the assets reflected in the work already done have no alternative uses. For example, in an economic evaluation of a road of which the location falls within a road reserve which has already been purchased and that is denied alternative application, the opportunity cost of such land is zero, and thus it is excluded from the analysis.

Similarly, planning, design and other project development costs incurred prior to the time of evaluation (i.e. before year zero) are excluded from the analysis as their dedication to the project is irreversible - they cannot be avoided or salvaged by trading them or using them elsewhere. This is also the reason why no initial cost is assigned to the null alternative in a cost-benefit analysis.

2.3.6.4 *Analysis period and service life*

For each cost-benefit analysis a choice has to be made regarding the period to be analysed. In principle this is related to the expected lifetime of the project being evaluated. In practice this principle may not always be of much help, since many transport facilities can last almost indefinitely. With effective maintenance (the cost of which is counted in an evaluation) many bridges, viaducts, tunnels, retaining walls and such like might physically be able to serve for many decades, though their use may cease earlier for economic reasons.

The opportunity cost principle excludes the possibility of a transport facility, such as an arched bridge spanning a ravine, possessing an additional value over and above the best alternative application opportunity of its land reserve during its service life. The reason is that investment in transport facilities is regarded as sunken; i.e. it is taken that the development itself has no possible alternative application. For this reason it is desirable that the analysis period should stretch over the entire design period or planned lifespan of a facility. However, there are practical reasons why the analysis period should sometimes be shorter than the intended service life.

A pragmatic way to decide on an analysis period for most economic evaluations is to note that, unless the discount rate is very low, benefits (and disbenefits) in the distant future will make little difference to the outcome of the analysis. At a discount rate of ten percent per annum, a stream of benefits valued at R1 million per year will have a present value of R8,514 million if discounted for the next 20 years, while the corresponding figure for discounting over 30 years is R9,427 million, for 40 years R9,779 million, for 50 years R9,915 million, for 100 years R9,999 million, or R10 million if discounted indefinitely. This illustrates that at a discount rate of ten percent per annum, for periods longer than 30 years, the diminishing discounted value of costs and benefits becomes negligible. Since the estimates of annual net benefits usually contain uncertainties at least in the order of five percent, the accuracy of an evaluation is hardly affected if the discounting is terminated after 30 years, even if the benefits really continue much longer. For discount rates higher than ten percent, this period will be shorter than 30 years and vice versa for discount rates lower than ten percent.

Because of uncertainties, all forecasts are speculative owing to the difficulty of predicting future traffic volumes, changes in technology, land use, demographic features, etc. The reliability of projections that extend beyond two decades is always doubtful. For this reason decision-makers often request that analysis periods must not exceed 20 years, even though the logical solutions to certain transport problems may be durable and indivisible projects with service lives substantially longer than 20 years. To be fair when considering such projects, a departure is then often made from the opportunity cost rule by introducing a second best valuation convention in the form of a residual value. This value purports to represent an artificial opportunity cost of a project during its service life.

If it is foreseen during the planning of a facility that the site on which it is to be erected will be permanently allocated to accommodating a transport facility, the site naturally has no terminal (or end) value. This is so because the site will be reserved from being used for an alternative application and thus will have no opportunity cost at the end of the facility's service life.

However, as the service periods for roads extend over several decades, it is unlikely that one could establish with certainty at the time of an economic evaluation for what purpose a facility's site will be used after its service period had come to an end. For this reason it is recommended that, in dealing with terminal value in an economic evaluation, two sensitivity analyses be executed: one in which the terminal value is equal to the current opportunity cost of the land occupied, and one in which the terminal value is equal to nil, (i.e. there is no alternative application opportunity).

The end value of other facility remnants on the site should be regarded as nil in all cases because they cannot be expected to have any alternative application possibilities: on the one hand, the structure is a specialised transport facility that excludes alternative non-transport-related use and, on the other hand, at the end of its service life it is by definition functionally completely worn-out, which makes re-use of structural components impractical.

When the analysis period of a proposed project is shorter than its expected lifespan, the estimate of residual value is more complicated than the estimate of terminal value. The reason is that the facility's implementation cost needs to be apportioned between the expired part of the expected service life at the end the analysis period and the unexpired portion of the expected service life.

Assuming that the expected service life of a transport facility, such as an arched bridge, is 50 years and the analysis period is 20 years; its structure will have a residual value at the end of the analysis period of approximately $30/50 \times$ initial cost, since it will still be serviceable for 30 years more. The residual value in this example is based on the assumption that structural deterioration of the bridge will progress linearly as time passes.

If different alternatives are investigated for an existing facility (referred to as the null alternative), the same period of analysis should be used in each case, since consistency ensures equal treatment of all the alternatives under consideration. A low-cost solution generally has a short service life, soon necessitating additional capital investment in a replacement project, while a costly structure may ensure an extended benefit period before reconstruction or replacement becomes essential.

If a number of mutually exclusive alternatives are investigated and the analysis period is (say) 20 years, provision should be made for replacement within the period of analysis of projects with a service life of less than 20 years (necessitating a second set of capital expenditures) to permit comparison with projects that have a service life of more than 20 years.

Note that the **time when the evaluation is carried out is referred to as year zero**. If the project requires a construction period of two years subsequent to year zero and if the period of analysis is 20 years, the service life of the facility under consideration is only 18 years. The shorter the construction period, the sooner benefits can begin to accumulate and the sooner problems created by the existing facility can be eliminated.

2.3.6.5 *Unforeseen expenses*

In dealing with implementation costs of a project, a provision may have to be made for unforeseen expenses. There are two instances of possible corrections in this regard:

- The actual costs may be higher than those estimated during the design, particularly in view of the complexity of works involved (for example, in the case of cost of drainage systems and hydraulic structures). In order to eliminate the possibility of under-estimating the investment cost in project evaluation, a provision is made in terms of a physical contingency. The amount to be added to the project implementation costs in this regard is usually taken as a percentage of design costs, varying between 5 and 15 percent, depending on the level of design (conceptual, preliminary or final) and the related level of confidence in the estimated costs.
- The actual costs may be higher than the estimated costs in cases where the project design has been completed sometime before the project evaluation takes place. In such cases estimated costs must be brought up to the date of conducting the project evaluation (the base date) by means of applying an inflation rate for the intervening period. However, it is incorrect to make provision for cost escalation on account of inflation during the analysis period; i.e. for future years (the period beyond the base date).

2.3.6.6 *Interest payable on the investment amount*

Interest payable on the investment amount (or on any other borrowed funds) should not be included in the economic cost of a project. It is sometimes included when a project is financed by loans, but is excluded when a project is financed from allocations from general state income. However, the manner in which a project is financed has no relation to its economic cost, as the alternative application possibilities of the resources actually used are the same regardless of the method of finance.

2.4 **INCORPORATING THE RISK OF FLOOD DAMAGE**

2.4.1 **Overview of the flood damage evaluation procedure**

The optimal design of drainage systems and hydraulic structures could be defined as that which maintains a proper balance between the cost of the project and the cost of potential flood damage (economic risk). In Section 8.2 a discussion is provided on the selection of freeboard for bridges, reflecting the need to conduct a risk assessment. The optimal design would thus be that with the lowest total PWOC. The following object function is proposed for determining the PWOC of a particular design alternative:

$$PWOC^x = C_A + PW[AF + M] \quad \dots(2.6)$$

where:

$$\begin{aligned} PWOC^x &= \text{present Worth of Cost of alternative } x \\ C_A &= \text{the construction cost of alternative } x \end{aligned}$$

AF	=	the damage cost of abnormal floods
M	=	the normal annual cost of maintenance and operation of alternative x

The following steps are proposed for calculating $PWOC^x$ in the economic evaluation of drainage systems and hydraulic structures:

1. Establish the minimum design standard of the structure based on the design flood (Q_D).
2. Establish the regional maximum flood (RMF) for the particular area where the structure is planned.
3. Define all technically feasible mutually exclusive alternatives, each representing a technically feasible structure option, ranging from a structure that is designed according to the design flood (Q_D) (Step 1) to a structure that will withstand the RMF.
4. Estimate the implementation cost of each of the alternatives defined in Step 3.
5. Estimate the normal routine and periodic maintenance and operating cost of each of the alternatives defined in Step 3.
6. Calculate the average annual damage cost of an abnormal flood for each of the alternatives identified in Step 3.
7. Perform the economic analysis.

A detailed discussion of each of the above steps follows in Sections 2.5.2 through 2.5.7.

2.4.2 The minimum design standard

It is established practice to design a facility for a specific flood event, commonly referred to as the “standard design flood” or “design flood” (Q_D). The minimum design life of the structure is determined by the choice of Q_D . A structure is designed to withstand a maximum flow expected with a 10-, 20-, 50- or 100-year return period and the expectancy is determined by analysis of records of past rainfalls and flows. From an economic perspective the minimum design standard should be based on the return period that corresponds to the design life of the road.

The reason is that the majority of culverts and bridges become obsolete long before they are worn out by corrosion or erosion. This obsolescence could be ascribed to:

- increased traffic volumes exceeding their traffic carrying capacity;
- road design standards that change, particularly with regard to lane and shoulder width; and
- realignment of the road to provide more favourable geometric characteristics, or to shorten travel distance.

The design flood (Q_D) may be estimated by means of the following methodology. Standard flood frequencies are used for various structures, which from years of experience; more or less represent the optimum design values. Numerous inconsistencies are found if the type and span of the structure, the stream cross-sectional area, or catchment size are used to classify design frequencies. The rate of flow varies very little over short distances along a watercourse, and constitutes the most significant parameter in quantifying the amount of damage done to a road as well as the extent of traffic obstruction.

For this reason the peak flow calculated for a flood with a return period of 20 years (frequency = 1:20) is used as the basis for selection of the appropriate design return period.

Roads are classified into six classes. These definitions correspond to the “Road Infrastructure Strategic Framework for South Africa”^(2.5). A detailed description is provided in **Chapter 8**, paragraph 8.2.

The design return periods are adapted where necessary in accordance with the Risk Category, as obtained from **Table 2.3**. It remains the responsibility of the designer to motivate the design return period to be used in the planning stage by allowing for the influence of possible future developments, such as urbanisation and afforestation on the flood peak.

If the potential damage and the impact of disruption, due to failure of the structure are high (Category 3 in **Table 2.3**), the design flood should be enlarged as deemed necessary based on local incidences in the past. In the case of Risk Category 1 consideration might be given to alter the design return period after full consideration of all relevant aspects, and the motivation for alteration is accepted by the appropriate authority.

Where important structures are concerned, the possible influence of particularly large floods (such as the probable maximum flood) should also be taken into consideration. There are far fewer factors influencing the design return period in road surface drainage, and some guidance is given in **Chapter 5**.

Table 2.3: Factors to be considered to determine the risk category of the structure, which is then used to determine the design flood

FACTORS TO BE CONSIDERED	RISK CATEGORY		
	1	2	3
Extent of possible damage			
Potential damage to the road and associated cost of repairs	Low	Medium	High
Potential other damage such as saturation of agricultural land, etc.	Low	Medium	High
Extent of loss of use			
Time needed for repairs to make route trafficable again	Short	Medium	Long
Availability of detours	Good	Medium	None
Obstruction of traffic flow			
Period of flooding	Short	Medium	Long
Traffic density	Low	Medium	High
Depth and velocity of floodwaters	Low	Medium	High
Strategic and economic importance of route			
Strategic and economic importance: military, police, fire brigade, medical services, etc.	Low	Medium	High
Economic importance	Low	Medium	High

2.4.3 Construction cost estimates

The estimate of construction cost (C_A) of each of the alternatives follows the approach described in Section 2.3.6 above.

2.4.4 Maintenance and operation cost

The estimate of normal maintenance and operation cost (M) of the structure designed for the specified return period of each of the alternatives follows the approach described in Section 2.4.6 above. These costs may include minor damage to the structure that would occur with expected minor flood damage associated with the design flood, Q_D , of the specified return period. Such damage is regarded as part of the normal routine and periodic maintenance.

2.4.5 Additional costs associated with abnormal floods

The following additional costs are associated with abnormal flood damage (AF):

- External costs, such as damage to private property, upstream and downstream of the structure. It should be noted that these costs can be attributed directly or indirectly to the failure of the structure. It consequently excludes costs which would have occurred as a result of the flood if the structure had not been there.
- Capital and maintenance expenses, including damage to road pavement, shoulders, culverts and other roadway items. The capital and maintenance dependent on the discharge past the structure and the capacity of the culvert or span of the bridge (e.g. operational expenses for flagmen, barricades, signage and the marking of traffic detours).
- Road user costs as a result of the disruption, including VOC for travel along the detour and stopping, travel time cost for lower travel speed and longer travel distance, and accident costs as a result of conflict at and along detours, and also caused by unexpected obstructions and hazards.

Some approaches suggest that the average annual damage to a particular structure should be based on the flood damage cost in a particular year and the probability of a flood in that year. However, these respective approaches require that both the risk and damage cost of all sizes of floods (from a RMF down to a two-year design flood, Q_2) in a particular year be determined for each of the mutually exclusive design alternatives. Such a detailed approach is cumbersome and is not practical for the evaluation of a large number of design alternatives.

The approach proposed in these guidelines is much simpler, without sacrificing a significant degree of accuracy. Instead of calculating flood damage for all return periods, all structure designs that do not conform to the SDF of the minimum return period (which corresponds to the design life of the roadway) are discarded, thus reducing the distance between the outer limits of the probability function. For the remaining structure designs, i.e. those that fall within the limits of withstanding a RMF and the Q_D of the minimum return period, the damage cost of the RMF (AF_{RMF}) is determined. The annual expected damage cost is the area **abc** below the Damage-Flood Probability curve in **Figure 2.2**, where P_{RMF} and P_{SDF} reflect the probability of an RMF and design flood, Q_D , respectively in a particular evaluation year. By reducing the distance between the outer limits, this curve can be adequately represented by a straight-line function, as the minimum requirement is for the structure to withstand the design flood, Q_D . A flood of this magnitude would cause no damage to any of the structure alternatives, which are not accounted for under normal routine and periodic maintenance. As mentioned above, all operational and maintenance costs of structures not attributable to abnormal floods are regarded as normal.




Figure 2.2: Damage-flood probability curve

The damage cost of a structure design alternative in a particular year can be expressed by the following equation:

$$AF_n^x = (PQ_D - P_{RMF}) \left[\frac{(AF_{RMF} + AFQ_D)}{2} \right] \quad \dots(2.7)$$

where:

- AF_n^x = damage cost of an abnormal flood to design alternative X in year n .
- PQ_D = probability of an SDF in year n , i.e. $(1/T_{SDF})$, where T_{SDF} is the return period of the SDF
- P_{RMF} = probability of an RMF in year n , i.e. $(1/T_{RMF})$, where T_{RMF} is the return period of the RMF
- AF_{RMF} = damage cost of an RMF
- AFQ_D = damage cost of a design flood, Q_D . (This would normally be zero, as the standard structure would be designed according to the return period of Q_D . The return period of the Q_D would be equal to the design life of the road.)

2.4.6 Economic evaluation

The incorporation of the flood damage cost procedure can serve either as an input to a Level 1 economic evaluation in order to optimise the economic viability of a road or major structure, or it can be a stand-alone Level 2 evaluation to refine the design of an already approved project.

In the case of a Level 1 evaluation the additional cost of flood damage (AF) for a particular alternative is calculated and added to the recurring cost of that alternative for each year of the evaluation period (Section 2.4.5.6). In this way it is incorporated in the net benefit stream for the purpose of calculating the economic performance measures (NPV, IRR or B/C Ratio).

In the case of a Level 2 evaluation, the PWOC of each alternative is calculated by means of equation 2.6. The alternative with the lowest PWOC is selected as the most efficient design among those that are being evaluated. The economically optimum design could be determined by plotting the PWOC for the evaluated alternatives. A curve may be fitted through the PWOC data points (Figure 2.3). The theoretical optimum design is found where the PWOC is at its lowest.




Figure 2.3: Optimum design curve

2.5 RISK AND UNCERTAINTY OF INPUT DATA

All aspects of project evaluation involve uncertainty and risk. Not only are data collected in the field subject to a certain degree of error, but long term projections of 20 years and longer also suggest that unforeseen factors could cause major deviations from the projections.

Projects should consequently not only be appraised with the recognition of uncertainty, but the designs of a project should be approached so as to optimise the total cost of the project. Sensitivity analysis is undertaken to test the sensitivity of the evaluation results for possible deviations in the input parameters. Sensitivity analysis usually considers the variations of input parameters independent from one another. Risk analysis is more specific and involves a formal probability analysis of a likely range of outcomes, where several parameters are identified of which the estimated accuracy is critical to the outcome of the project.

Sensitivity analyses are conducted as found appropriate within the context of the evaluated project. These analyses are carried out for the purpose of testing the sensitivity of the findings and results obtained in the basic evaluation scenario, to changes in some of the initially used basic parameters or assumptions (particularly those for which the level of confidence is lower), or where more than one approach may reasonably be argued and applied. They usually include:

- Combining the VOC savings separately with time cost savings and with accident cost savings.
- Variations in traffic growth rates for the combined savings.
- Variations in the base year AADT.
- Variations in construction costs, depending on the level of design of the investigated project.
- Postponement of project implementation if the basic evaluation scenario indicates that the project is non-viable, or is a marginally viable proposition for immediate implementation.
- Impact of complementary projects.
- Impact of the project on stimulating new developments.

Not all of these sensitivity analyses are always absolutely necessary. It is up to the best judgement of the professional evaluator and/or the client as to what should be included. Care should be taken to limit sensitivity analyses to relevant concerns, in order to inform the decision maker. Attempts to be exhaustive may cause confusion.

2.6 ECONOMIC SELECTION OF PROJECTS OR ALTERNATIVES

2.6.1 Selection criteria

Candidate transport projects should not only be evaluated economically, but those chosen for implementation also need to be selected in such a fashion that net social benefit is maximised. The question is how to compile an investment budget of a given size; i.e. how to allocate a fixed sum of funds between alternative and independent projects. There is also the more complex issue of determining the appropriate size of the investment budget when projects are indivisible, as most transport projects are.

The selection and prioritisation of projects on an economic basis usually takes place with reference to the following general criteria:

- The economic principles need to be strictly observed during evaluation.
- All projects must be evaluated in the same manner.
- All alternatives, i.e. the whole range of technically feasible substitute projects, should be evaluated.
- The benefits of a project should exceed its investment cost.
- The financial investment cost of any chosen project must be within the scope of the capital budget.

Proposed projects to be evaluated could be divided into two groups, namely mutually exclusive proposals and independent projects.

Mutually exclusive proposals are substitutes, i.e. alternative methods of fulfilling the same function. The choice of any one of the proposals will, therefore, exclude all the others. The cost-benefit analysis of mutually exclusive proposals involves the selection of the most efficient, i.e. most cost-effective, alternative. Independent projects fulfil different functions and are consequently not alternatives or substitutes for one another. Examples of independent projects are a proposed embankment and retaining wall in area X, a proposed bridge in area Y, and a proposed viaduct in area Z.

More than one independent project may be selected for implementation. In fact, it is possible that all independent projects may be selected if they are all economically justified and sufficient funds are available. The economic evaluation of independent projects involves the ranking of the economically justified projects in terms of their economic merit. The economic choice of a specific project for implementation involves two steps, namely, project selection and project prioritisation.

- Project selection involves the selection of the best (in economic terms) of the mutually exclusive projects, or in other words, the most advantageous way of solving a specific problem. If there are three routes by which to link the two points, the selection of one will exclude the implementation of the other two.
- Project prioritisation is the arrangement of all functionally independent projects in an order of priority according to their respective degrees of economic viability. The choice of one independent project could at most postpone, but not exclude, the choice of another. The projects will be prioritised from most to least attractive up to the point where the capital budget has been exhausted.

A project that yields a B/C ratio value greater than one, always has a positive NPV and an IRR that exceeds its opportunity cost of capital. Provided the initial costs of projects do not differ, any one of the four evaluation techniques discussed may be used to select the best alternative among a number of mutually exclusive projects. When the initial costs of projects do not differ, the alternative with the smallest $PWOC$ will have the highest B/C ratio, the highest IRR and the highest NPV . However, if the initial costs differ significantly (which is generally the case), incremental analysis should be used to identify the most suitable alternative.

The $PWOC$ and NPV techniques cannot be used to prioritise independent projects. The absolute value of a project's benefits depends on its scope. The benefits of a large project may, for instance, have a larger absolute value than the benefits of a smaller project, whereas the relative return of the larger project may be considerably lower than that of the small project. Hence, it is better to use the IRR and B/C ratio techniques for the prioritisation of independent projects, also taking into account the results of the investment timing analyses. The reduction of generalised travel cost afforded by new and improved transport facilities may induce additional traffic over and above normal-growth traffic. In such cases the criterion of lowest total social transport cost presents a contradiction in terms that complicates the interpretation of the answer indicated by the $PWOC$ technique (equation 2.2).

Furthermore, this answer does not give an indication of the size of the economic benefit offered by an alternative, unless the answer is subtracted from the *PWOC* of the null alternative. The latter difference is equal to an alternative's *NPV*. However, use of the *PWOC* technique is appropriate in project selection when a chosen alternative:

- will not induce additional usage, and
- a null alternative does not exist.

Examples of the latter situation are when the construction of a new airport on vacant land is contemplated or when the establishment of a new seaport at a presently inaccessible wetland location on the coastline is being considered, and the most economic ways of linking these facilities to an adjacent urban region have to be evaluated. Under these circumstances, the *PWOC* of each alternative transport link may be calculated using equation 2.2, as the complication that occurs with the treatment of induced traffic is not present.

2.6.2 Mutually exclusive projects

Whenever the opportunity occurs to solve a specific problem when the investment timing of the solution project is not challenged by any independent projects elsewhere, the *NPV* measure is the preferred selection criterion.

Suppose, for example that:

- an amount of R5 million has been allocated to rectify a specific problem situation,
- unused funds cannot be transferred to other projects, and
- a choice has to be made among the three economically viable alternatives shown in **Table 2.4**.

Table 2.4: Present value of benefits and investment costs for three alternative projects

Project	Present value of benefits (R'000)	Present value of investment cost (R'000)	Net present value of benefits (NPV) (R'000)	B/C ratio
A	5 400	3 000	2 400	1,80
B	7 000	4 000	3 000	1,75
C	8 100	5 000	3 100	1,62

Regardless of the fact that alternative C shows the smallest relative return, it maximises welfare by having the greatest *NPV*. Incremental *B/C* analysis using **Table 2.4** shows that a move from alternative A to alternative B, as well as a move from alternative B to alternative C will both be beneficial:

$$(B/C)_{B:A} = \frac{(7\,000\,000 - 5\,400\,000)}{(4\,000\,000 - 3\,000\,000)} = 1,6; \quad \text{and}$$

$$(B/C)_{C:B} = \frac{(8\,100\,000 - 7\,000\,000)}{(5\,000\,000 - 4\,000\,000)} = 1,1$$

Thus a move from alternative A to alternative C will yield the greatest net benefit. Note that in a mutually exclusive situation, incremental analysis will always indicate that the alternative with the greatest *NPV* is the best project.

2.6.3 Independent projects

When a choice has to be made among a number of independent projects, given a fixed budget, the *B/C* ratio measure is the preferred criterion. Suppose, for example, a roads authority with a fixed budget of R10 million has to make a choice among 14 independent projects, five of which are indicated in **Table 2.5**.

Table 2.5: Present value of benefits and costs for a number of independent projects

Project	Present value of benefits (R'000)	Present value of investment cost (R'000)	Net present value of benefits (NPV) (R'000)	B/C ratio
A	700	300	400	2,33
B	2 700	1 500	1 200	1,80
C	840	450	390	1,87
D	1 280	600	680	2,13
.
.
N	1 800	900	900	2,00

In this situation the *B/C* ratio criterion is the preferred measure to apply, because selection of those projects that yield the highest relative return on capital invested will ensure that total benefit is maximised. The project with the highest *B/C* value is selected first, followed by the one with the second highest *B/C* value, and so on until the budget is exhausted. Thus the five projects in **Table 2.5** will be chosen in the order A, D, N, C and B. In this way the benefit per rand spent is maximised.

2.6.4 Mutually exclusive and independent projects

Suppose the objective of the decision-maker is to maximise social benefit subject to the restriction of a fixed budget and that both mutually exclusive and independent projects are under consideration. A method of project assessment based on the incremental principle is recommended. The method consists of the following seven steps:

1. Determine the size of the budget. Where there is some degree of latitude as to the total amount available, the amount can be expanded incrementally, and the incremental benefits compared with the incremental expenditure to determine whether any expansion of the budget is justified.
2. Eliminate all projects that exceed the budget limit and all projects that do not satisfy the minimum acceptance criteria as set out above.
3. Determine which project has the highest *B/C* ratio within each group of mutually exclusive alternatives and then leave out the rest of the possible projects in the group.
4. From the projects under consideration choose the one with the highest *B/C* ratio.
5. Review the choice of the best project in each group of mutually exclusive projects by, firstly, reconsidering all the more expensive projects and noting the incremental *B/C* ratios. Within each group of mutually exclusive projects the project with the highest incremental *B/C* ratio is identified and compared with the rest of the independent projects. Secondly, the available budget is adjusted to reflect the effect of the projects already chosen, and all remaining projects that exceed the balance of the budget are omitted.
6. Repeat steps 4 and 5 for as long as possible. The iteration process ends when the budget is exhausted or when no acceptable projects remain for consideration.
7. Consider adjustments to chosen projects when the budget is not completely exhausted and a small adjustment in a chosen project may provide incremental benefits.

The following example demonstrates this procedure. Suppose an agency has R5 million to spend. The projects under consideration are summarised in **Table 2.6**. Projects A₁ to A₆ are six mutually exclusive projects; B₁ and B₂ are mutually exclusive; D₁ to D₃ are mutually exclusive; and F₁ to F₄ are mutually exclusive. Groups A, B, C, D, E and F are independent.

Table 2.6: PVOC, Benefits and cost-benefit ratios of a number of projects

Project	Present value of investment cost (R'000)	Present value of benefits (R'000)	B/C
A ₁	500	880	1,76
A ₂	1 000	1 920	1,92
A ₃	1 500	2 680	1,79
A ₄	2 000	3 320	1,66
A ₅	2 500	4 120	1,65
A ₆	3 000	4 680	1,56
B ₁	550	700	1,27
B ₂	750	940	1,25
C	750	1 000	1,33
D ₁	1 250	1 260	1,01
D ₂	1 400	1 620	1,16
D ₃	3 000	3 560	1,19
E	300	560	1,87
F ₁	675	1 120	1,66
F ₂	850	1 480	1,74
F ₃	1 050	1 760	1,68
F ₄	1 350	2 120	1,57

There is no project that exceeds the budget limit of R5 million and, furthermore, there is no project with a B/C ratio of less than one. All projects are, therefore, included in further analyses. In Step 3 the best projects are chosen from groups A, B, D and F, and the projects that enjoy consideration in the next step, are reduced to the following:

Project	Present cost	Present benefit	B/C ratio
A ₂	1 000	1 920	1,92
B ₁	550	700	1,27
C	750	1 000	1,33
D ₃	3 000	3 560	1,19
E	300	560	1,87
F ₂	850	1 480	1,74

A₂ is chosen from these six projects. The more expensive projects in group A, are now considered in terms of their incremental B/C ratios. The incremental B/C ratios of the four projects more expensive than A₂ are as follows:

Project	Incremental cost	Incremental benefit	Incremental B/C ratio
A ₃ .A ₂	500	760	1,52
A ₄ .A ₂	1 000	1 400	1,40
A ₅ .A ₂	1 500	2 200	1,47
A ₆ .A ₂	2 000	2 760	1,38

The greatest incremental benefit is achieved by replacing A₂ with A₃. This replacement within group A should now be considered together with the other projects. There is now R4 000 000 left and none of the projects exceeds this limit. The six alternatives now under consideration are as follows:

Project	Present cost	Present benefit	B/C ratio
A ₃ .A ₂	500	760	1,52
B ₁	550	700	1,27
C	750	1 000	1,33
D ₃	3 000	3 560	1,19
E	300	560	1,87
F ₂	850	1 480	1,74

Project E is consequently chosen and R3 700 000 of the budget is left. The next project to include is F₂, which immediately places the more expensive projects in group F under the spotlight. The relevant incremental *B/C* ratios are as follows: $F_3.F_2 = 1,40$ and $F_4.F_2 = 1,28$. The former *B/C* ratio is compared with the remaining projects. There is R2 850 000 left to spend, and this eliminates project D₃, that is more expensive. D₂ takes the place of D₃ on the basis of the *B/C* ratio criterion. The list under consideration is now as follows:

Project	Present cost	Present benefit	B/C ratio
A ₃ .A ₂	500	760	1,52
B ₁	550	700	1,27
C	750	1 000	1,33
D ₂	1 400	1 620	1,16
F ₃ .F ₂	200	280	1,40

A₃.A₂ has the best *B/C* ratio and A₃ replaces A₂ as chosen project. This costs an additional R500 000, leaving R2 350 000, for spending. The incremental *B/C* ratios within group A are as follows: $A_4.A_3 = 1,28$, $A_5.A_3 = 1,44$ and $A_6.A_3 = 1,33$. The list of competing projects is now as follows:

Project	Present cost	Present benefit	B/C ratio
A ₅ .A ₃	1 000	1 440	1,44
B ₁	550	700	1,27
C	750	1000	1,33
D ₂	1 400	1 620	1,16
F ₃ .F ₂	200	280	1,40

Project A₅.A₃ has the largest *B/C* ratio, which means that A₃ is replaced at a cost of R1 000 000. This leaves only R1 350 000, and means that D₁ now replaces D₂ on the list of competing projects.

Project	Present cost	Present benefit	B/C ratio
A ₆ .A ₅	500	560	1,12
B ₁	550	700	1,27
C	750	1000	1,33
D ₁	1 250	1 260	1,01
F ₃ .F ₂	200	280	1,40

Project F₃ is chosen to replace project F₂, which leaves R1 150 000, and eliminates D₁. The following projects remain for consideration:

Project	Present cost	Present benefit	B/C ratio
A ₆ .A ₅	500	560	1,12
B ₁	550	700	1,27
C	750	1 000	1,33
F ₄ .F ₃	300	360	1,20

Project C is now chosen, leaving R400 000. Since only F₄.F₃ falls within this limit, F₄ replaces F₃, leaving another R100 000 in the budget. Therefore, it is decided to fund A₅, C, E and F₄ at a total cost of R4 900 000. Benefits to the value of R7 800 000 are gained in the process.

In the last step small adjustments are made to increase the total benefits. The most attractive project eliminated on the grounds of the budget limit was B_1 . Sufficient funds may be acquired to pay for B_1 if F_2 is funded instead of F_4 . This leaves R60 000 of additional benefits at R50 000 of additional cost, and the final list of projects is thus A_5 , B_1 , C, E and F_2 .

Underlying this selection procedure is the notion that the decision-maker should try to achieve the greatest possible benefit for every Rand spent.

2.6.5 Timing of project implementation

Unfortunately project viability itself does not reveal the optimum timing of project implementation. For the timing of project implementation, the project should be analysed with a range of investment timings to ascertain which one would yield maximum viability. The question posed here is not "whether" but "when". A project may pass the test of showing a positive net present value, but it may be a better project if it were delayed by one year. Delaying implementation would defer the capital expenditures but lose a year's benefit.

When benefits are expected to grow continuously in the future, the **First-Year Rate of Return (FYRR)** could be applied as an investment-timing criterion. If the benefits accruing in the first year of operation exceed the time cost of the investment, i.e. the FYRR is higher than the prescribed discount rate, the project is timely and should go ahead right away. If the FYRR is lower than the prescribed discount rate, but the NPV is positive, commencement of project implementation should be postponed. If budgetary constraints limit the construction programme, the FYRR can be used as an aid to prioritising the projects showing similar degrees of economic viability. The FYRR is calculated by dividing the sum of the benefits accruing in the first year of operation (i.e. the year subsequent to project completion) by the worth of the project's investment cost at the time of project completion, expressed as a percentage.

Alternatively defined the FYRR is the year-one worth of the benefits of a project accruing in the first year of operation expressed as a percentage of the present worth of its investment costs.

2.7 LEGAL ASPECTS RELATED TO WATER INFRASTRUCTURE

2.7.1 Introduction

The verdict in the leading case of Administrator, Natal v Stanley Motors (1960 1 SA 699 (A)) has been of major concern to designers of bridges and roads. The finding that:

“anyone who designs and constructs a bridge and its approaches is under a duty to members of the public to do so in such a manner that it will be capable of resisting all the violence of the weather which may be expected to occur - although perhaps rarely”

has placed a serious question mark behind designs that have been based on design floods with limited return periods.

In order to clarify the legal aspects related to the hydrological and hydraulic design and maintenance of river crossings, Prof TJ Scott prepared a document (Committee of State Road Authorities, TRH 25 : 1994) in which he addresses the typical concerns which confront designers. This useful document titled, “Guidelines for the Hydraulic Design and Maintenance of River Crossings – Volume II: Legal aspects,”^(2.4) reflects an overview of the legal aspects and cases are provided to reflect an understanding of the issues involved. **A copy of the said document is included in an electronic format on the accompanying flash drive/DVD, which is attached to this publication.**

The most important developments since 1994 concerning the legal aspects of drainage have been the implementation of the new National Water Act of 1998 as well as the Environmental Conservation Act of 1989.

2.7.2 The National Water Act (Act No 36 of 1998)

The Department of Water Affairs and Forestry has published general authorisations, which establish when licenses are required for activities that may have impacts by ^(2.2):

- impeding or diverting the flow of water in a watercourse
- altering the bed, banks or characteristics of a watercourse
- removing, discharging or disposing of water found underground if it is necessary for the efficient continuation of an activity or for the safety of people.

2.7.3 The Environmental Conservation Act (Act No 73 of 1989)

This Act ^(2.3) applies *inter alia* to:

The construction and upgrading of roads, railways, airfields and associated structures outside the borders of town planning schemes.

Schedules have been prepared, but not finalised, with respect to:

- identification of geographic areas in which specified activities require environmental authorisation;
- activities that require environmental impact assessment; and
- activities that require initial assessment.

Until the schedules have been finalised provincial governments are dealing with all applications.

2.7.4 Geoscience Amendment Act

The Geoscience Amendment Act No 26, 2010 reflects the responsibilities and obligations related to the development of structures with a potential geo-hazard. In this regard the development of hydraulic structures which could result in temporal storage in Dolomitic areas should be reviewed against the requirements of the Act.

2.7.5 Documents included in an electronic format

The following documents are included on the attached flash drive/DVD:

- The National Water Act (Act No 36 of 1998);
- The Environmental Conservation Act of 1989;
- Geoscience Amendment Act 16 of 2010; and
- “Guidelines for the Hydraulic Design and Maintenance of River Crossings – Volume II: Legal aspects ^(2.4).

2.8 REFERENCES

- 2.1 SANRAL. (2002). The South African National Road Agency Limited. *Code of Procedure for the Planning and Design of Highway and Road Structures in South Africa*.
- 2.2 Department of Water Affairs and Forestry. (1998). *National Water Act*. Act No 36 of 1998.
- 2.3 Department of Environmental Affairs and Tourism. (1989). *Environmental Conservation Act*. Act No 73 of 1989.

- 2.4 CSRA. (1994). Committee of State Road Authority. *Guidelines for the Hydraulic Design and Maintenance of River Crossings – Volume II: Legal aspects*.
- 2.5 Department of Transport. (2005). *Road Infrastructure Strategic Framework for South Africa*. RISFSA.

Notes:

CHAPTER 3 - FLOOD CALCULATIONS

M van Dijk, SJ van Vuuren and JC Smithers

3.1 OVERVIEW OF THIS CHAPTER

This chapter covers the procedures that could be used to determine design flood peaks for specific return periods in order to design hydraulic structures. To be able to use these procedures a theoretical introduction is given which is then reinforced by worked examples.

Table 3.1 provides a Road Map for this chapter.

Table 3.1: Road Map for flood calculations

ROAD MAP 3						
Typical problems		Input information	Worked examples in <i>Application Guide</i>	Supporting software	Other topics	
Topic	Par.				Topic	Chapter
Calculate flood peaks for a small catchment area	3.5.1, 3.5.2, 3.5.3 & 3.5.4	Catchment area, slopes, run-off characteristics, mean annual rainfall	3.1	Utility Programs for Drainage, Visual SCS-SA	Design of lesser culverts or storm water conduits	7
					Design of surface drainage structures or components	5
					Flood line determination	11
					Flood routing	10
Calculate flood peaks for a large catchment area	3.4, 3.5.1, 3.5.2, 3.5.3 & 3.6	Catchment area, slopes, historical flood records, mean annual precipitation	3.2	Utility Programs for Drainage, HEC-SPP	Design of bridges and major culverts	8
					Scour estimation at major structures	11
Back calculating of a flood event's return period	3.4, 3.5 & 3.6	Flood event detail, river characteristics, catchment area, slopes, run-off characteristics, mean annual precipitation	-	Utility Programs for Drainage & HEC-RAS	Risk and legal aspects	2

3.2 INTRODUCTION

3.2.1 Terminology

The run-off that is generated within a catchment through precipitation will depend on the:

- characteristics of the storm event;
- the response characteristics of the catchment; and
- the influence of temporal storage within the catchment on the run-off.

The temporal distribution of the run-off is reflected in a hydrograph, such as plotted in **Figure 3.1**. The flood peak (Q_p) is reached when the entire catchment contributes to the flood at the catchment outlet, which is also referred to as the time of concentration (T_C).




Figure 3.1: Typical flood hydrograph

The potential damage that a flood could cause may be related to one or more of the following parameters:

- **High flood level (HFL)** - the maximum water level reached at a given point during the flood.
- **Peak discharge (Q_p)** - the maximum flow rate during the flood.
- **Maximum flow velocity** - the maximum calculated flow velocity associated with a given flow rate.
- **Flood volume** - the volume of water that is released from a catchment, responding to a given storm event and catchment characteristics.
- **Flood duration** - the period of time during which the discharge does not drop below a given limit.

Peak discharge is the most useful parameter in the calculation of the required cross-sectional area to convey a flood and to determine the backwater effect (upstream influence) of any structure that influences the normal flow conditions. The peak discharge is directly related to the characteristics of the storm event and response of the contributing catchment area.

Although the peak discharge does not remain constant as the flood progresses along a watercourse, changes are fairly gradual where there are no tributaries or local temporary storage. It could, therefore, be postulated that the peak discharge is independent of local changes in the watercourse, such as bed slope and cross-sectional shape. With the peak discharge having been determined, the high-flood level (flood line) and associated flow velocities may be determined by means of hydraulic calculations (uniform or gradually varied flow relationships). The flood volume and temporal variance of the flow rate can be derived from the hydrograph.

3.2.2 Different methods in use for the calculation of flood peaks

The various approaches to flood estimation in South Africa can best be illustrated with a diagrammatic summary shown in **Figure 3.2**. The different methods are either based on rainfall data or runoff data.




Figure 3.2: Flood estimation in South Africa

There are different hydrological calculation methods in use that can be applied to road drainage although it depends on the available information. The proven and most used methods in Southern Africa have been selected for inclusion in this Manual, and they are:

- Statistical methods
- Rational methods
- Unit Hydrograph method
- Standard Design Flood (SDF) method
- SCS-SA method
- Empirical methods

It is good practice in the determination of design floods for bridges or large culverts to use more than one of the above methods, and if historical run-off data are available it should be analysed as well. **No weighting of the different flood calculation methods to determine the design floods should be done.** The results of the various methods need to be compared and the most appropriate one selected to determine the design flood. It is always required to use the SDF method and compare with the other applicable methods. Where large discrepancies occur, an assessment should be conducted to motivate the selected design flood.

These methods have been developed by various institutions, and are either based on measured data (statistical); or on a deterministic basis (Rational, Unit Hydrograph, SDF and SCS-SA methods); or are empirical relationships. Except for the statistical method, the methods were “calibrated” for certain regions and flood events, and are limited in terms of the size of the catchment areas on which they could be applied. **Table 3.2** lists the methods, input data requirements, maximum recommended catchment area for which each procedure can be used and references related to the procedures.

Table 3.2: Applications and limitation of flood calculation methods

Method	Input data	Recommended maximum area (km ²)	Return period of floods that could be determined (years)	Reference paragraph
Statistical method	Historical flood peak records	No limitation (larger areas)	2 – 200 (depending on the record length)	3.4
Rational methods	Catchment area, watercourse length, average slope, catchment characteristics, design rainfall intensity (3 alternative methods)	Usually < 15, depends on method of calculating rainfall intensity	2 – 200, PMF	3.5.1
Unit Hydrograph method	Design rainfall, catchment area, watercourse length, length to catchment centroid (centre), mean annual rainfall, veld type and synthetic regional unit hydrographs	15 to 5000	2 – 100, PMF	3.5.2
Standard Design Flood method	Catchment area, watercourse length, slope and SDF basin number	No limitation	2 – 200	3.5.3
SCS-SA method	Design rainfall depth, catchment area, Curve Number=f(soils, land cover), catchment lag	< 30	2 - 100	3.5.4
Empirical methods	Catchment area, watercourse length, distance to catchment centroid, mean annual rainfall	No limitation (larger areas)	10 – 100, RMF	3.6

Methods that are not included in this manual are the Run hydrograph method, Regional Estimation of Extreme Flood Peaks by Selective Statistical Analyses (REFSSA)^(3.53 & 3.54) method and Joint Peak-Volume (JPV) Design Flood Hydrograph Methodology^(3.55) (see Section 3.7).

Statistical methods (Section 3.4) involve the use of historical data to determine the flood for a given return period. Their use is thus limited to catchments for which suitable flow records are available, or adjacent catchments which could be analysed for comparison purposes, as described in detail in Section 3.4. Where accurate records covering a long period are available, statistical methods are the best and recommended method to determine flood peaks, especially for long return periods. The method lends itself to extrapolation to determine flood magnitudes for return periods longer than the period of available record, but it is recommended that the estimated return periods should be limited to less than double the length of record.

The **Rational Method** (Section 3.5.1) is based on a simplified representation of the law of conservation of mass. Rainfall intensity is an important input in the calculations. Because uniform spatial and temporal distributions of rainfall are assumed, the method is normally only recommended for catchments smaller than approximately 15 km². There are some historical methods of determining the rainfall intensity, depth-duration –frequency relationships, or the modified recalibrated Hershfield equation as proposed by Alexander^(3.1) for storm durations up to 6 hours, and the Department of Water Affairs' Technical Report TR102 for durations from 1 to 7 days. These methods have been retained in this document as well as the inclusion of the preferred method using the Design Rainfall estimation methodology developed by Smithers and Schulze (2003), to determine the point design rainfall for the catchment, referred to as Alternative 3^(3.48). Only flood peaks and synthetic hydrographs can be determined by means of the Rational Method. Judgement and experience on the part of the user with regard to the selection of run-off coefficient is important in this method. However, with improved estimation methods, subjective judgement is becoming less important. Because there are three alternative methods of calculating the rainfall intensity the designer should clearly indicate what method was used.

The **Unit Hydrograph method** (Section 3.5.2) is suitable for the determination of flood peaks as well as hydrographs for medium-sized rural catchments (15 to 5 000 km²). The method is based mainly on regional analyses of historical data, and is independent of personal judgement. The results are generally reliable, although some natural variability in the hydrological occurrences is lost through the broad regional divisions and the averaged form of the hydrographs. This is especially true in the case of catchments smaller than about 100 km² in size.

The **Standard Design Flood (SDF) method** (Section 3.5.3) was developed by Alexander^(3.14) to provide a uniform approach to flood calculations. The method is based on calibrated discharge coefficients for recurrence periods of 2 and 100 years. Calibrated discharge parameters are based on historical data and were determined for 29 homogeneous basins in South Africa.

The **SCS - SA method** (Section 3.5.4)^(3.16) is particularly suitable for computing flood peaks and run-off volumes for catchments smaller than 30 km² and with slopes of less than 30 per cent. It is mainly applicable to rural catchments but may also be used for urban areas^(3.17). The SCS - SA method takes into account most of the factors that affect run-off, such as quantity and temporal distribution of rainfall, land use, soil type, prevailing soil moisture conditions, and size and characteristics of the catchment. An advantage of the SCS-SA method is that it enables synthetic hydrographs to be estimated.

Empirical methods (Section 3.6) require a combination of experience, historical data and/or the results of other methods. Empirical methods are more suited to check the order of magnitude of the results obtained by means of the other methods.

3.3 FACTORS AFFECTING RUN-OFF

In flood hydrology it is essential to be familiar with and to understand the influence of the various factors affecting run-off before an attempt is made to undertake hydrological calculations. Such factors may be broadly classified as:

- topographical factors;
- antecedent soil moisture conditions;
- developmental influences; and
- climatological variables.

These factors are mutually dependent. Some of these important factors in the above mentioned groups are discussed below.

The use of Geographical Information Systems (GIS) has permeated almost every field in the engineering, natural and social sciences. GIS do not inherently have all the hydrological simulation capabilities that complex hydrological models do, but are used to determine many of the catchment parameters that hydrological models or design flood estimation methods require^(3.57). As a start the topographic map data in a digital form presents a very useful database for the development of GIS. In a GIS environment one could manually for instance delineates the watershed based on the contours (i.e. create a polygon shape file, and carefully draw the catchment). However numerous algorithms exist for deriving watersheds from digital elevation models. Some are built into the Spatial Analyst extensions usually found in GIS applications. Delineating for example a watershed in ArcGIS requires the user to use a sequence of hydrologic tools that create new output rasters at each step.

- Step 1 - Fill the depressions in the DEM
- Step 2 - Calculate flow directions
- Step 3 - Delineate the catchment and derive its area
 - Choose Pour Point
 - Delineate Watershed
 - Calculate Area

As described by Gericke and Du Plessis (2012) in hydrological catchment parameter analyses, a Digital Elevation Model (DEM) and spatial data sets represent the two fundamental data sets initially required. The DEM contains raster information of the catchment and surrounding areas, while the spatial data sets contain the spatial information which originates from other sources than the DEM. The DEM is used to do a complete catchment parameter analysis, including the determination of flow directions, catchment areas, land surface and river channel characteristics. The spatial data sets contain layers of combined spatial information used to analyse the spatial distribution and associated attributes of geology, soil, land use and vegetation^(3.57).

3.3.1 Topographical factors

3.3.1.1 Size of catchment

The size of a catchment has an important influence on the rainfall/run-off relationship, and consequently on the suitability of calculation methods. In small catchments for example, the relationship between rainfall intensity and infiltration rate of the soil is very important, whereas in large catchments the quantity of rainfall relative to the water storage capacity of the soil is more important. The peak discharges of small streams within the same geographical area are approximately proportionate to the sizes of the catchments (catchment area < 10 km²). As the catchment becomes large, the peak run-off becomes proportionate to \sqrt{A} . The effect of other factors, however, often decreases the influence of catchment size alone.

Topographical maps (1: 50 000) are usually used to determine the area of a catchment. However, for small catchments the accuracy and contour intervals on these maps are not acceptable and topographic detail on a smaller scale, say 1: 10 000, should be obtained. Ortho-photographs should be used, if available. It is considered essential for the designer to visit a catchment personally to obtain an impression of developments and other important characteristics of the catchment. As described above DEM and spatial data sets can also be used in a GIS environment to delineate the catchment area.

3.3.1.2 Catchment shape

As illustrated in **Figure 3.3**, even if all other characteristics are the same, fan-shaped catchments (Storm 1) will give rise to higher peak flows than long, narrow catchments (Storm 2). The slope of the main watercourse and other factors may, however, neutralise this influence. When reduction factors are used to adjust rainfall intensities, the movement and intensity of a storm passing over the catchment should be considered, since using only the size of the catchment could be misleading as is illustrated in **Figure 3.3**.




Figure 3.3: Catchments of the same size, but producing different peak discharges

3.3.1.3 Catchment slope

The slope of a catchment is a very important characteristic in the determination of flood peaks. Steep slopes cause water to flow faster and to shorten the critical duration of a flood-causing storm, thus leading to the use of higher rainfall intensities in the run-off formulae. On steep slopes the vegetation is generally less dense, soil layers are shallower, and there are fewer depressions, which cause water to run off more rapidly. The result is that infiltration is reduced and flood peaks are consequently even higher.

Generally there is a good correlation between the slopes of the main watercourse, tributaries and the surrounding landscape. The slope of the main watercourse is usually determined using DEM and GIS or from topographical maps or in the manner described in paragraph 3.5.1.3.

3.3.1.4 Stream patterns

Well-drained catchments have shorter times of concentration and consequently give rise to larger peak flows. The hydraulic effectiveness of a watercourse, whether natural or man-made, affects the flow rates and, therefore, has to be taken into account.

Some streams have numerous tributaries, and others may have only one main watercourse, which receives run-off from overland flow. The meandering of watercourses, marshes and flows outside of river banks affect the flood's progress and increase attenuation of flood peaks.

3.3.1.5 *Infiltration*

Infiltration is the movement of water through the ground surface into the soil. Usually the infiltration rate is considerably higher at the start of a precipitation event than a few hours later. Soil moisture tension in the upper layers beneath the surface initially reinforces the effect of gravity to draw water into the soil. In time, however, the soil becomes increasingly saturated so that the tension decreases, capillary spaces become filled with water and infiltration takes place more slowly. Once the soil has become saturated, the surface infiltration rate becomes equal to the deeper infiltration rate to ground water (with interflow and evapotranspiration not considered).

3.3.1.6 *Soil type and geology*

Soil type has an important influence on the run-off, mainly because of the effect of the infiltration rate. The effect of the soil type also often depends on the volume, duration and intensity of rainfall. The condition of the soil at the onset of a storm will affect run-off. Freshly ploughed or unsaturated soil, for example, will produce a smaller run-off volume and peak discharge than compacted or saturated soil of the same type.

Underlying rock formations and other geological factors, such as riverine deposits, may have significant effects on run-off. Medium to large catchments with underlying dolomite, for instance, result in considerably reduced run-offs.

3.3.1.7 *Seasonal effects of vegetation*

Seasonal vegetation and falling leaves retard the flow of water and increase infiltration. Normally no provision is made in flood calculations for such seasonal effects. Variation in catchment cover can vary significantly as shown in **Photograph 3.1**.



Photograph 3.1: Variation in catchment cover

3.3.2 Antecedent soil moisture conditions

Antecedent moisture is a term that describes the relative wetness or dryness of a catchment area. Antecedent moisture conditions change continuously and can have a very significant effect on the flow responses in these systems during wet weather. The effect is evident in most hydrologic systems including stormwater runoff with inflow and infiltration.

Rainfall/runoff relationships are well defined within the field of hydrology. Surface runoff in hydrologic systems is generally conceptualized as occurring from pervious and impervious areas. It is the pervious runoff that is affected by antecedent moisture conditions, as runoff from impervious surfaces such as roads, sidewalks and roofs will not be significantly affected by preceding moisture levels. Pervious surfaces, such as fields, agricultural lands, grassed areas and open areas are highly affected by antecedent moisture conditions, as they will produce a greater rate of runoff when they are wet than when they are dry.

Antecedent moisture conditions are highly affected by preceding rainfall levels. However, preceding rainfall is not the only condition that affects antecedent moisture, and many other variables in the hydrologic process can have a significant impact. For example, air temperature, wind speed and humidity levels affect evaporation rates, which can significantly change antecedent moisture conditions. Additional effects may include evapotranspiration, presence or absence of tree canopy and snow and ice melting effects. The assumptions made in determining the influence of the antecedent soil moisture conditions in each of the flood calculation methods are described under each method.

3.3.3 Developmental influences

3.3.3.1 Land use

Since human activities has a considerable effect on the run-off characteristics of a catchment, present and future conditions should be properly taken into account when estimating design floods, particularly with regard to urbanisation, see **Photograph 3.2**. The effect of urbanisation depends on the percentage of the surface area that is made impermeable and on changes in the drainage pattern caused by storm water systems. Urbanisation usually increases the size of flood peaks by 20 to 50 per cent of those under natural conditions. Where there is industrial or other high-density building development, this figure may rise to 100 per cent or more. Examples of the influence of urbanisation on the peak discharge from a catchment as a function of impermeable surface area, return period and percentage area with storm water drainage are given in **Table 3.3** and **Table 3.4**^(3.2). The type of urban development in South Africa, where wall boundaries are common could, however, reduce the peak discharge rate while it increases the flow volume. Recent studies support this conclusion^(3.33). This is, however, dependent on the topographical characteristics as discussed in Section 3.3.1 and is site specific.

Table 3.3: Possible influence of % of impermeable surface area on peak flow, for different return periods, expressed as multiples^(3.2)

Return period (years)	Percentage area consisting of man-made impermeable surfaces				
	1	10	25	50	80
2	1,0	1,8	2,2	2,6	3,0
5	1,0	1,6	2,0	2,4	2,6
10	1,0	1,6	1,9	2,2	2,4
25	1,0	1,5	1,8	2,0	2,2
50	1,0	1,4	1,7	1,9	2,0
100	1,0	1,4	1,6	1,7	1,8

Table 3.4: Possible influences on peak flow of % of impermeable surface area and % area with storm water drainage, expressed as multiples ^(3.2)

Percentage area with storm water drainage	Percentage of impermeable surface area					
	0	20	40	60	80	100
0	1,0	1,3	1,5	1,8	2,0	2,4
20	1,3	1,5	2,1	2,5	2,9	3,7
40	1,4	2,1	2,5	2,9	3,7	4,7
60	1,5	2,2	2,8	3,6	4,5	5,5
80	1,6	2,3	3,0	4,2	5,0	6,2
100	1,7	2,4	3,2	4,4	5,6	6,8



Photograph 3.2: Developmental influences (Loftus/University of Pretoria area)

3.3.3.2 Storage

Storage in a catchment occurs as surface and depression storage (the filling up of small depressions on the ground surface), storage in overland (sheet) and river flows, as well as in pans, lakes, vleis and marshes. Storage could have a considerable effect on the attenuation and translation of flood peaks. Flood attenuation is discussed in **Chapter 7**.

3.3.3.3 Reservoirs

Reservoirs may intercept large volumes of run-off and thus considerably reduce peak flows. Generally it is realistic to assume that reservoirs would be reasonably full when conditions that favour large floods (generally from large catchments) occur. The effect of interception by reservoirs can be investigated by assuming that the reservoir is full and conducting routing calculations. **Chapter 7** refers to the procedures (flood routing) that can be employed to undertake these calculations. Uncertainty regarding the operation of sluice gates during a flood, or prior to a flood event, to create storage volume for flood attenuation, complicates the assessment. The operational guidelines and policy for the release strategy should be investigated. A general assumption, however, is that the maximum controlled release from a dam should not be higher than the inflow peak.

3.3.4 Climatological variables

3.3.4.1 Climate

Climate has an important influence on many of the factors that affect run-off. Vegetation growth and soil formation, for example, are strongly influenced by rainfall and temperature.

There is a clear relationship between rainfall intensity and mean annual precipitation in different regions of South Africa. The wetter parts of the country generally experience higher rainfall intensities. Areas with high rainfall generally also have wetter antecedent soil moisture conditions with correspondingly higher run-off from rainfall.

3.3.4.2 *Rainfall as a flood parameter*

In South Africa, rainfall is the most important form of precipitation, and together with hail, is mainly responsible for flood run-off. Snow does not contribute significantly to floods in SA but, hydrologically speaking, contributes to low flows in certain regions. In large catchments the quantity, intensity and distribution of rainfall are important factors, but in the determination of flood run-off for small catchments, rainfall intensity remains the dominant factor.

The relationship between rainfall and run-off depends on many factors, which will be discussed later, and consequently cannot be simplified. Although the correlation between the rainfall return period and the resulting flood peak is poor, it has been found that when the peak run-off and rainfall are considered separately, the relationship between peak run-off for a given period and the rainfall intensity for the same return period remains reasonably constant for different return periods^(3.3). Rainfall could thus be used to determine design floods, although a rainstorm with a given return period very seldom results in a flood peak with the same return period.

3.3.4.3 *Temporal and spatial distribution of rain storms*

The run-off from a catchment depends not only on the intensity and quantity of rain, but is also affected by the duration, size, uniformity, velocity and direction of any storm passing over the catchment. Rain rarely falls evenly over a catchment, with the result that the rainfall and run-off vary across a catchment. The point-to-point differences in the area and temporal distribution of rainfall depend, in turn, on the type of rain, for example, convection, orographic, frontal, see **Photograph 3.3**, or cyclonic rain.

Convection rain, **Photograph 3.4**, occurs in the form of thunderstorms and tends to be extremely uneven and unpredictable; orographic rain also shows significant point-to-point differences but the distribution is more predictable; frontal rain is fairly evenly distributed along the longitudinal direction of the front, but there are marked differences in the direction of movement.

In contrast, cyclonic rains show fairly even distributions with the heaviest precipitation and intensity at the centre. The type of rain that would cause floods depends largely on the location and size of the catchment.

In most of the methods of calculation used in road drainage, it is assumed that the flood-causing storm has a precipitation duration just long enough to allow run-off from all parts of the catchment to contribute simultaneously to the flood peak at the catchment outlet, hence the relationship between the critical duration of a storm and the so-called time of concentration (T_C) as well as other methods used to measure catchment response time. In large catchments, heavy rainfall over only a part of the area may also cause flooding, but the design floods for large catchments are mainly obtained via statistical analyses of measured discharges.

Storms that move over a catchment in the downstream direction often cause larger flood peaks than stationary or other storms, since in effect they shorten the time of concentration. Where the prevailing direction of storms is usually downstream, particularly within a long catchment, an indication of the possible effect of such storms could theoretically be obtained by shortening the time of concentration by the time the storm takes to move across the catchment. Whilst storms may move at speeds of up to 50 km/h, it is difficult to determine a design speed. Storms also rarely move in a straight line. Such adjustments are generally not made in practice.



Photograph 3.3: Rainfall over catchment (frontal)



Photograph 3.4: Convection rain

3.4 STATISTICAL METHODS

3.4.1 Applicability of statistical methods

Statistical methods are generally based on the fitting of probability distributions to measured values of maximum annual flood peaks. The accuracy of these methods depends a great deal on the reliability of the measured values, particularly the accuracy with which flow rates are measured, and on the length of the historical record. The latter should preferably be longer than half of the design return period, and should include both wet and dry periods. Statistical methods are reliable only when applied to a catchment of the same stream or at least of the same-hydro meteorological region (possessing the same flood-causing characteristics and factors) as those on which the statistical fitting was done. The more compatible the catchment characteristics of the monitored catchment and those of the catchment under consideration, the more reliable the calculations are likely to be.

Since statistical methods are based on the use of historical events to estimate the probability of future floods, any changes in the flood-causing factors within a catchment will also affect the reliability of the methods. Such changes should consequently be investigated and, where possible, be accounted for.

In South Africa measured flow records for the hydrological years (October to September) are available from the Department of Water Affairs (www.dwa.gov.za), some local authorities, institutions such as Water Boards and some Universities. However generally, the measurements usually pertain to large catchments, and the statistical methods are thus usually only applicable to such areas.

3.4.2 Annual maximum and partial duration series

An annual maximum series is formed when the largest discharge value for every year during the recorded period is used as a basis for calculation. For a 20-year period there would thus be 20 values, representing the highest peak in every hydrological year, but not necessarily representing the 20 highest peaks.

In a partial series, all the recorded flood peaks are ranked in a descending order all the events which exceed a give threshold are included in the series. When the number of events extracted is equal to the number of years of data, and then the series is called an exceedance series. This selection procedure means that some of the annual peaks may not be included in the series, whereas more than one flood peak from some years may be included.

In road design, annual maximum series are usually used even though they give considerably lower flood peak values for small return periods in comparison with partial series (**Figure 3.4**). The economic considerations are, however, based on annual maximum series so that the prescribed return periods implicitly allow for the differences.




Figure 3.4: Comparison between annual and partial series

3.4.3 Overview of probabilities

The return period (T) is the average period over a large number of years during which an event (peak flow) repeats or exceeds itself. The annual probability of the exceedance probability (P) of an event having a T -year return period is:

$$P = \left(\frac{1}{T} \right) \quad \dots (3.1)$$

The probability of an event with a return period of T to occur over a given design life of n years may be determined as follows^(3.4):

$$P_1 = 1 - \left(1 - \frac{1}{T} \right)^n \quad \dots (3.2)$$

where:

P_1	=	probability of at least one exceedance during the design life
n	=	design life in years
T	=	return period in years

P_x is the probability of x exceedences over the design life (n), and can be determined as follows:

$$P_x = n^c x P^x (1 - P)^{n-x} \qquad \dots (3.3)$$

or
$$P_x = n^c x P^x \left(1 - \frac{1}{T}\right)^{n-x} \qquad \dots (3.4)$$

where:

x = number of exceedences
 $n^c x$ = number of combinations of n events taken x at a time
$$n^c x = \frac{n!}{x! (n - x)!} \qquad \dots (3.5)$$

A summary of the design return periods needed in order not to exceed an allowable risk of occurrence is given in **Table 3.5**.

Table 3.5: Return periods needed in order not to exceed given probabilities of occurrence for different design lives

Probability of exceedance (%)	Life of project (years)				
	1	10	25	50	100
1	100	995	2488	4975	9950
10	10	95	238	475	950
25	4	35	87	174	348
50	2	15	37	73	145
75	1,3	8	19	37	73
99	1,0	2,7	6	11	22

3.4.4 Methods of calculation used in statistical analysis

There are various statistical distribution functions that could be applied in the analysis of extreme values (rainfall or flood peaks). It is recommended that the graphical method should be used in conjunction with the fitting of distributions to the data. The graphical method can be used to detect any anomalies in the data and can also be used to select the best fitting probability distribution. The method aims to represent the distribution functions as a linear relationship on paper by means of specific divisions on the horizontal axis of the graph paper. Special graph paper is available for Normal and Gumbel distributions. The vertical scale may be linear or logarithmic.

Log-normal distribution functions are usually suitable for distributions in most parts of South Africa. However, for analysing flood peaks the Gumbel distribution functions (a special case of the General Extreme Value (GEV) distribution functions) ^(3.1) yield better results in areas with relatively regular and high rainfall, such as the eastern parts of the country and the South and South-Western Cape.

The position in which every point in the annual maximum series should be plotted on the graph is calculated using a particular plotting position formula such as defined in Equation 3.6 with values for the constants a and b provided in **Table 3.6**.

$$T = \frac{n_l + a}{m - b} \qquad \dots (3.6)$$

where:

T = return period in years
 n_l = length of record in years
 m = rank of annual peaks, ranked in descending order of magnitude
 a = constant (see **Table 3.6**)
 b = constant (see **Table 3.6**)

If the horizontal axis has a probability classification, the probability (P) is calculated as:

$$P = \frac{1}{T}$$

... (3.7)

Once the points have been plotted, a line is fitted through them to obtain the best fit (as depicted in **Figure 3.5**). If it is not possible to obtain a good fit, another type of probability distribution could be used. It is recommended that more than one type be tried to determine which type fits the historical data best. Generally poor fits may occur as a result of changes that have taken place over time in the catchment, or because of the unsuitability of the method being used. If the differences are explainable, correction factors should, where possible, be applied to the data on a deterministic basis. Otherwise alternative distributions such as the Log-Pearson Type III (standard in the USA) or the "General Extreme Value" method (UK Flood Studies)^(3.23) should be considered. Some of the commonly used plotting positions recommended for use in hydrological analyses are given in **Table 3.6**. If several probability distributions are plotted on a single graph then the general purpose Cunane plotting position should be used.

Table 3.6: Commonly used plotting positions^(3.1)

Type	Plotting position	Probability Distribution
Weibull (1939)	a = 1 & b = 0	Normal, Pearson 3
Blom (1958)	a = 0,25 & b = 0,375	Normal
Gringorten (1963)	a = 0,12 & b = 0,44	Exponential, EV1 & GEV
Cunane (1978) average of above two	a = 0,2 & b = 0,4	General purpose
Beard (1962)	a = 0,4 & b = 0,3	Pearson 3
Greenwood (1979)	a = 0 & b = 0,35	Wakeby, GEV

Detailed descriptions of direct statistical analysis methods are provided in Alexander’s book *Flood Risk Reduction Measures*^(3.1) (also see **Appendix 3A**). The reliability and accuracy of the historical record is extremely important, as well as the selection of the probability distribution function that best fits the data, taking into account the outliers (high and low), zero flows, missing data and trends. **Figure 3.5** represents a typical example of a fitted distribution function. In this example the Cunane plotting position was used to plot the annual maximum series and the log-Pearson Type 3 distribution was fitted to the data and plotted on the same axes.

If different statistical methods provide conflicting results for medium and large catchments where the impact in terms of the flood size is significant, it is recommended that an independent investigation by an experienced person be undertaken. The annual maximum series is a small sample of the entire population and that the selected best fitting distribution is assumed to represent the distribution of the population and hence is used to estimate design events.




Figure 3.5: Example of graphical frequency analysis plot

3.4.5 Use of short records in statistical analysis

Where the available flow records cover only a short period (± 5 years), these records could be extrapolated if reliable records from neighbouring measuring station(s) with much longer records are available. It is good practice to limit the extrapolation of flow records to a maximum of two to three times that of the observed period.

For example if two flood records are available, record A with a limited record length and record B with a substantial length, then record A may be extrapolated by considering the partial series of all floods above a prescribed minimum for the short record (A) and for the corresponding period of the long record (B). In order to obtain a larger sample, all floods above the prescribed minimum are used, instead of simply a number equal to the number of years. The values of corresponding ranked order numbers are then plotted against one another on double logarithmic paper, and a straight line is fitted to show the relationship between flood peaks for stations A and B. The peak discharge of the desired return period is then computed for the long record in the usual manner, and is transferred to the station with the short record by using the determined logarithmic relationship between flow record A and B. **Figure 3.6** displays the logarithmic relationship between the two records used to obtain flow peaks for station A for longer recurrence intervals.

For greater reliability, relationships could be determined with more than one long-term record.




Figure 3.6: Example of extrapolation of record

3.5 DETERMINISTIC METHODS

3.5.1 Rational methods

3.5.1.1 Background and principles

This method was first proposed in 1851 by the Irish engineer, Mulvaney. Since then it has become one of the best-known, and apparently the most widely used methods for determining peak flows from small catchments.

The basis of the relationship is the law of the conservation of mass and the hypothesis that the flow rate is directly proportional to the size of the contributing area and the rainfall intensity, with the latter a function of the return period. The peak flow is obtained from the following relationship:

$$Q = \frac{CIA}{3,6} \quad \dots (3.8)$$

where: Q = peak flow (m^3/s)
 C = run-off coefficient (dimensionless)
 I = average rainfall intensity over catchment (mm/hour)
 A = effective area of catchment (km^2)
 $3,6$ = conversion factor

The rational formula represents outflow in the hydraulic continuity equation, and its application is based on the following assumptions:

- The rainfall has a uniform areal distribution across the total contributing catchment.
- The rainfall has a uniform temporal distribution for at least a duration equal to the time of concentration (T_C).
- The peak discharge occurs when the total catchment contributes to the flow at the exit, which occurs at the end of the critical storm duration, or time of concentration (T_C).
- The run-off coefficient, C remains constant throughout the duration of the storm.
- The return period of the peak flow, T , is the same as that of the rainfall intensity.

Despite this method's shortcomings and widespread criticism, it provides realistic results if it is used circumspectly, and it has generally provide good results in studies when compared with other methods. Although it is generally recommended that the method should only be applied to catchments smaller than 15 km², it can in some cases be used by experienced engineers for larger catchments^(3,25).

Many of the assumptions listed above are to a greater or lesser degree also applicable to other deterministic methods of flood calculation.

3.5.1.2 Run-off coefficient (C)

3.5.1.2.1 Recommended C values

The run-off coefficient in the rational method is an integrated value representing the most significant factors influencing the rainfall-run-off relationship. It reflects the part of the storm rainfall contributing to the peak flood run-off at the outlet of the catchment. There is no objective theoretical method for determining C, and as a result the subjective elements of experience and engineering judgement play a very important part in the successful application of this method.

Table 3.7^(3,5) provides a description of recommended values of C.

Table 3.7: Recommended values of run-off factor C for use in the Rational method

Rural (C ₁)					Urban (C ₂)	
Component	Classification	Mean annual rainfall (mm)			Use	Factor
		< 600	600 - 900	> 900		
Surface slope (C _s)	Vleis and pans (<3%)	0,01	0,03	0,05	<i>Lawns</i>	
	Flat areas (3 to 10%)	0,06	0,08	0,11	- Sandy, flat (<2%)	0,05 – 0,10
	Hilly (10 to 30%)	0,12	0,16	0,20	- Sandy, steep (>7%)	0,15 – 0,20
	Steep areas (>30%)	0,22	0,26	0,30	- Heavy soil, flat (<2%)	0,13 – 0,17
Permeability (C _p)					- Heavy soil, steep (>7%)	0,25 – 0,35
	Very permeable	0,03	0,04	0,05	<i>Residential areas</i>	
	Permeable	0,06	0,08	0,10	- Houses	0,30 – 0,50
	Semi-permeable	0,12	0,16	0,20	- Flats	0,50 – 0,70
Vegetation (C _v)	Impermeable	0,21	0,26	0,30	<i>Industry</i>	
					- Light industry	0,50 – 0,80
	Thick bush and plantation	0,03	0,04	0,05	- Heavy industry	0,60 – 0,90
	Light bush and farm lands	0,07	0,11	0,15	<i>Business</i>	
	Grasslands	0,17	0,21	0,25	- City centre	0,70 – 0,95
	No vegetation	0,26	0,28	0,30	- Suburban	0,50 – 0,70
					- Streets	0,70 – 0,95
					- Maximum flood	1,00

3.5.1.2.2 Rural areas

In rural areas there are five main factors affecting the value of C, namely catchment slope, permeability of the soil, vegetation, mean annual rainfall and return period.

Accurate and time-consuming calculation of the slope is not necessary. It may be determined with sufficient accuracy by selecting a representative part of the catchment on a contour map and determining a slope according to these contours. Steeper slopes give rise to higher run-off percentages.

The following classification could be used as a qualitative guide to the permeability of the soil:

- Very permeable - gravel, coarse sand
- Permeable - sandy, sandy loam
- Semi-permeable - silt, loam, clayey sand
- Impermeable - clay, peat rock

The classification could be made from a visual inspection of the terrain and/or by using the soil maps, available from the South African Government Printers or obtaining from the Institute for Soil, Climate and Water (ISCW) whom have soil and related natural resource maps available for the whole country ^(3,60). Where dolomite occurs, the following reduction factors are recommended for the dolomitic parts of a catchment to be applied to C_1 in **Table 3.7** on a pro rata basis (based on catchment slopes):

- Steep areas (slopes > 30%) - 0,50
- Hilly (10 to 30%) - 0,35
- Flat areas (3 to 10%) - 0,20
- Vleis and pans (slopes < 3%) - 0,10

Vegetation could be classified as follows:

- Forestry plantations
- Dense bush or bushveld
- Light bush and cultivated lands
- Grasslands
- No vegetation

As described in Section 3.3, the run-off increases as the density of the vegetation decreases. The vegetation should be determined by inspections *in loco*, although the publication by Acocks ^(3,6), "*Veld types of South Africa*" may also be useful.

Where the periodic felling of trees in forestry plantations could have a considerable influence on the run-off from a specific catchment, the C value should be increased by taking into account the proportionate part that would be left without effective plant cover. Where this proportionate part is greater than approximately 30 per cent of the catchment area covered with trees, the return period should be re-determined.

The mean annual rainfall also affects the run-off, as discussed previously. Recommended values of the catchment's response influenced by the slope C_s , permeability C_p and vegetation C_v are given in **Table 3.7** for different classes of mean annual rainfall.

The return period has an important effect on the run-off percentage. The relationship between rainfall and run-off is not linear and a catchment is often more saturated for a storm with a long return period than is the case with storms of shorter return periods. It is thus recommended that the C value $C_1 = C_s + C_p + C_v$ be multiplied by the appropriate factor (F_t) from **Table 3.8**.

The influence of initial saturation is, however, also dependent on the catchment characteristics. The influence of the return period will thus be smaller for steep and impermeable catchments than for flat permeable catchments. For these cases the factors are given in **Table 3.8**.

Table 3.8: Adjustment factors for value of C_1

Return period (years)	2	5	10	20	50	100
Factor (F_t) for steep and impermeable catchments	0,75	0,80	0,85	0,90	0,95	1,00
Factor (F_t) for flat and permeable catchments	0,50	0,55	0,60	0,67	0,83	1,00

For the probable maximum flood (PMF), $C_1 = C_s + C_{pmax} + C_{vmax}$; $C_2 = 1$; and $F_t = 1$, where C_{pmax} and C_{vmax} are the maximum values from **Table 3.7**.

3.5.1.2.3 Urban areas

Recommended values of C for urban areas are given in **Table 3.7**. As a result of the relatively large percentages of impermeable surface area in urban areas, it is normally not necessary to adjust the C -value according to the return period. Adjustment is, however, possible in accordance with **Table 3.8**.

3.5.1.3 Rainfall intensity (I)

The intensity of a design storm increases as the return period becomes longer and as the duration of the storm decreases. To obtain the largest possible peak discharge for a given return period using the Rational method, the storm rainfall should have a duration equal to the time required for the whole catchment to contribute to run-off at the outlet, defined as the time of concentration, T_C . If the storm has a shorter duration, it will not be possible for all the parts of the catchment to contribute simultaneously to run-off at the point of measurement. Consequently, the effective catchment area would be smaller than the actual area of the catchment.

The mean annual precipitation could be obtained from the simplified **Figure 3.7**^(3.29) or from the Weather Service^(3.8) as well as other alternative sources^(3.9 & 3.25).

In road drainage the volume of water that runs off as a result of a storm of less than 15 minutes duration is usually not large, and much of this run-off is absorbed in filling of the watercourses. Times of concentration of less than 15 minutes are thus generally not significant, and the maximum intensity is assumed to occur at approximately this time. It is difficult to calculate the rainfall intensity for storms less than 15 minutes (i.e. time of concentration of less than 15 minutes) and thus the intensity is based on the assumption that the storm duration is 15 minutes. However, advances in logging of rainfall data allows recording of rainfall intensity directly and at a much smaller time resolution (< 1 minute). Where such data is available this should be used. Utilising the design rainfall from the Design Rainfall Estimation software provides estimation of 5 minute point rainfall durations^(3.48).

Historically there have been a number of ways in which the rainfall intensity could be determined. The methods which have been included in this document are:

- **Alternative 1** - Using a Depth-Duration-Frequency Diagram (a shortcoming of this procedure is that it is based on a short, aged rainfall database published in 1978^(3.25)).
- **Alternative 2** - The TR102 representative rainfall data and the modified Hershfield equation is used (similar shortcoming with an outdated rainfall database published in 1981^(3.15)).
- **Alternative 3** - This alternative stems from a WRC research project where the available rainfall database up to the year 2000 was used in determining the design rainfall^(3.48). Data from 1806 rainfall stations in South Africa which have at least 40 years of quality controlled daily records were utilised to estimate design rainfalls. Design rainfall for durations ranging from 5 minutes to 7 days and for 2 to 200 year return periods at any 1' latitude x 1' longitude point in South Africa is determined.

All three alternative methods have been retained in this document although the latest method using the free Design Rainfall Estimation Software is recommended (Alternative 3). Because of the aged data Alternative 1 is effectively no longer used. Because of the three alternatives always indicate what method was used in the analysis.

3.5.1.3.1 Alternative 1 – Original method using Depth-Duration-Frequency Diagram

Apart from the duration and return period, the intensity of rainfall is also related to the mean annual precipitation and to the rainfall region. The “depth-duration-frequency” relationship depicted in **Figure 3.8**^(3.7) may be used to determine point rainfall, which is then converted to intensity by dividing the point rainfall by the time of concentration ($P_{IT} = P_T / T_C$).

Figure 3.8 was obtained from HRU Report 2/78, *A Depth-Duration-Frequency Diagram for Point Rainfall in Southern Africa* (1978), which is an update from a similar diagram published in HRU Report 1/72, *Design Flood Determination in South Africa* in 1972 ^(3.7 & 3.25).




Figure 3.7: Mean Annual Precipitation in South Africa ^(3.29)




Figure 3.8: Depth-Duration-Frequency diagram for point rainfall

3.5.1.3.2 **Alternative 2** – The TR102 representative rainfall data and the modified Hershfield equation is used

Historically this has been referred to as the Alternative Rational Method. This approach uses the modified recalibrated Hershfield equation as proposed by Alexander^(3.1) for storm durations of up to 6 hours, and the Department of Water Affairs’ technical report TR102^(3.15) for duration of 1 to 7 days.

The intensity of rainfall is related to the mean annual precipitation and to the rainfall region. The modified and recalibrated Hershfield relationship ^(3.1) is used to determine point rainfall, which is then converted to intensity by dividing the point rainfall by the time of concentration for storm durations of up to 6 hours.

$$P_{t,T} = 1,13(0,41 + 0,64\ln T)(-0,11 + 0,27\ln t)(0,79M^{0,69}R^{0,20})$$

...(3.9)

- where:
- $P_{t,T}$ = precipitation depth for a duration of t minutes and a return period of T years
 - t = duration in minutes
 - T = return period
 - M = 2-year return period daily rainfall from TR102 ^(3.15)
 - R = average number of days per year on which thunder was heard **(Figure 3.9)** ^(3.28)

For storm durations between 6 and 24 hours, linear interpolation is used between the calculated point rainfall from the modified Hershfield equation and the 1-day point rainfall from TR102^(3.15). For storm durations longer than 24 hours, linear interpolation is used between n-day rainfall values from TR102. Because two different methods are used to derive the point rainfall values, the calculated 6-hour rainfall value may be higher than the 24-hour value (from TR102). If the time of concentration is less than 24 hours and the Hershfield value is higher than the 24-hour value (from TR102), then it is reduced to equal the 24-hour value. This assumption is realistic as the storm precipitation mechanisms are such that short duration rainfalls exceeding 4 hours are often close to the 24-hour value.

A typical weather service station’s particulars, together with data as provided in TR102, are shown in **Table 3.9** below with the rainfall station number reference grid shown in **Figure 3.10**.

Table 3.9: Typical format of the TR102 rainfall data

Weather Service station		Pretoria (Waterkloof)					
Weather Service station no		513437					
Mean annual precipitation		761 mm					
Coordinates		25° 47' & 28° 15'					
Duration (days)	Return period						
	2	5	10	20	50	100	200
1 day	69	98	121	146	183	215	250
2 days	86	121	149	178	222	259	301
3 days	96	137	169	204	255	299	347
7 days	120	170	208	247	305	353	405

Detailed information on the number of days on which thunder was heard can be obtained from *Climate tables of South Africa (WB42)*^(3.28).




Figure 3.9: Average number of days per year on which thunder was heard (Alexander ^(3.1))




Figure 3.10: South African Weather Service rainfall station numbers (reference grid) ^(3.15)

Note: The reference grid refers to the first couple of digits of the rainfall station number

The areal reduction factor may be determined using a graphical relationship (**Figure 3.11**) proposed by Alexander ^(3.1), or calculated utilizing Equation 3.10, which is based on the UK Flood Studies Report ^(in 3.1).

$$ARF = (90000 - 12800 \ln A + 9830 \ln(60T_C))^{0.4} \quad \dots(3.10)$$

where:

- ARF = areal reduction factor as a percentage (should be less than 100%)
- A = catchment area (km²)
- T_C = time of concentration (hours)

The areal reduction factor may also be calculated based on the adjustment curves for point rainfall shown in **Figure 3.25** and **Figure 3.26**.

The peak flow rate is obtained using the Rational method equation, Equation 3.8.




Figure 3.11: Area reduction factors (Alexander ^(3.1))

3.5.1.3.3 Alternative 3 – The Design Rainfall Estimation Software (Recommended method)


The design rainfall from the Design Rainfall Estimation software is the recommended method to determine the point design rainfall of a catchment, see **Figure 3.12** ^(3.48). Utilising the Design Rainfall Estimation in South Africa software application the representative weather station or coordinates as shown in **Figure 3.13** can be entered. A summary of all the closest rainfall stations as well as the n-day rainfall values as shown in **Figure 3.14** is obtained. The software enables the estimation of design rainfall for durations ranging from 5 minutes to 7 days and for 2 to 200 year return periods at any 1' latitude x 1' longitude point in South Africa.

SAWB NUMBER	Station Name	Latitude (°)(')	Longitude (°)(')	MAP (mm)	Altitude (m)	Years (days)	Return Period (years)																							
							2			5			10			20			50			100			200					
							L	D	U	L	D	U	L	D	U	L	D	U	L	D	U	L	D	U	L	D	U			
0001517 A	DANGER POINT - VRT.	34	37	19	18	463	46	73	1	38	38	39	54	54	55	65	66	68	77	79	83	93	98	106	107	115	127	122	133	151
		2	50	51	52	70	71	73	84	86	89	97	101	106	114	122	132	127	139	154	141	156	178							
		3	57	58	59	80	81	83	95	98	101	110	114	120	129	137	148	143	155	171	158	174	198							
		4	62	64	65	87	88	89	102	105	107	116	121	126	135	144	154	148	162	177	169	180	201							
		5	65	66	68	90	91	93	105	108	111	120	125	131	139	148	159	152	166	182	164	185	207							
		6	67	69	70	93	94	96	109	112	115	124	129	135	142	152	163	155	170	186	168	188	212							
		7	70	72	73	96	98	99	112	115	118	127	132	137	146	155	165	159	173	188	171	190	211							
0001517 W	DANGER POINT (VRT)	34	37	19	18	463	46	93	1	37	38	38	53	53	54	64	65	67	76	78	82	92	97	104	105	113	125	121	131	149
		2	48	49	50	67	68	70	80	82	85	93	97	102	109	117	126	122	133	147	135	150	171							
		3	55	56	56	76	77	79	91	93	96	105	109	114	123	131	141	136	148	163	150	166	188							
		4	58	60	61	81	82	84	95	98	101	109	114	119	127	135	145	139	152	166	151	169	189							
		5	61	62	64	84	86	87	99	102	104	113	118	122	130	139	149	142	156	171	154	173	195							
		6	63	65	66	87	89	90	102	105	108	116	122	127	134	143	153	146	160	175	158	177	198							
		7	66	68	69	90	92	93	105	108	111	119	125	129	137	146	155	150	162	176	161	179	199							
0001605 W	GANSBAAI	34	35	19	21	543	17	72	1	38	38	39	53	54	55	65	66	68	76	79	83	93	98	106	107	115	126	122	133	151
		2	49	50	50	68	69	70	81	83	86	94	98	103	111	118	128	123	134	149	137	152	173							
		3	55	56	57	77	78	80	92	94	97	106	110	115	124	132	142	138	150	165	152	168	190							
		4	59	60	62	82	84	85	97	100	102	111	115	120	128	137	146	141	154	168	153	171	191							
		5	62	63	64	85	87	88	100	103	105	114	119	124	132	141	151	144	158	173	156	175	197							
		6	64	66	67	88	90	92	104	107	109	118	123	128	136	145	155	148	162	177	160	179	201							
		7	66	68	69	90	92	93	105	109	111	120	125	130	137	146	155	150	163	177	161	179	199							
0001726 W	UILENKRAAL (BOS)	34	36	19	25	530	9	32	1	37	38	38	53	53	54	64	65	67	75	78	81	92	97	104	105	113	125	120	131	149
		2	46	47	48	65	66	67	78	80	82	90	93	98	106	113	122	118	128	142	130	145	165							
		3	53	54	55	75	76	77	88	91	93	102	106	111	120	127	137	133	144	159	147	162	184							
		4	59	60	61	82	83	84	96	99	101	110	114	119	127	136	145	139	152	166	151	169	190							
		5	62	63	64	85	86	88	100	103	105	114	119	124	131	141	150	144	158	173	155	175	196							
		6	64	66	67	88	90	92	104	107	109	118	123	128	136	145	155	148	162	177	160	179	201							
		7	67	68	70	92	93	95	107	110	113	121	126	131	139	148	157	152	164	179	163	181	201							
0002069 W	PETERS GATE	34	39	19	32	588	20	35	1	39	39	40	57	58	58	71	72	73	85	88	90	106	111	117	124	131	140	144	154	167
		2	54	55	55	79	80	80	98	99	101	116	120	123	143	149	157	165	174	186	189	201	219							
		3	60	61	61	88	89	89	108	109	111	128	131	135	157	163	171	180	190	202	205	219	236							
		4	64	65	65	93	94	94	115	116	117	136	139	141	166	171	176	191	199	207	217	228	241							
		5	68	68	68	98	98	99	119	121	122	142	144	147	173	178	183	199	206	215	227	237	250							
		6	70	70	71	100	100	101	121	123	124	143	146	149	173	180	186	198	207	218	225	238	253							
		7	74	74	75	105	105	106	127	128	130	148	152	156	179	186	194	204	214	227	231	245	262							
0002256 W	QUOIN POINT (BOS)	34	46	19	39	571	15	25	1	45	45	46	66	66	67	82	83	84	98	101	104	123	128	135	143	151	161	167	177	193
		2	57	58	58	84	84	85	103	105	106	122	126	130	151	158	165	174	184	196	200	213	231							
		3	63	63	64	91	92	93	112	114	115	133	137	140	163	170	177	187	197	210	213	227	246							
		4	67	68	68	98	98	99	120	121	122	143	145	148	174	179	185	200	208	217	228	239	252							
		5	70	70	71	101	101	102	123	124	126	146	149	151	178	184	189	205	213	222	234	244	258							
		6	74	74	74	105	106	106	127	129	131	151	154	157	183	189	196	209	219	230	237	250	267							
		7	76	76	77	108	108	109	130	132	134	153	157	160	184	192	199	210	220	233	237	252	270							
0002456 W	ELIM (POL)	34	35	19	45	532	53	61	1	39	39	40	57	58	58	71	72	73	85	88	90	107	111	117	125	131	141	145	154	168
		2	51	51	52	75	75	76	92	93	95	109	112	116	134	140	147	155	164	175	178	190	206							
		3	57	58	58	84	84	85	102	104	106	121	125	128	149	155	162	171	180	192	195	208	225							
		4	62	62	62	90	90	90	110	111	112	131	133	135	160	164	169	183	191	198	209	219	231							
		5	65	65	66	93	94	94	114	115	116	136	138	140	165	170	175	190	197	206	217	227	239							
		6	68	68	69	97	97	98	117	119	121	139	142	145	168	174	181	192	201	212	219	231	246							
		7	70	70	71	99	100	100	120	122	123	141	144	148	170	177	184	194	203	215	219	232	249							

1

L=lower 90% error bound (mm); D=design rainfall depth (mm); U=upper 90% error bound (mm)

Figure 3.12: Extract of output from design rainfall estimation software



Design Rainfall Estimation in South Africa

About

Search Method

☐ Search by Latitude and Longitude

☒ Search by Rainfall Station

Help

Rainfall Station Search

Help

☐ Station Name

☒ SAWS Number

0513529

Duration

Help

☐ 5 min ☐ 4 hour ☐ 1 day
☐ 10 min ☐ 6 hour ☐ 2 day
☐ 15 min ☐ 8 hour ☐ 3 day
☐ 30 min ☐ 10 hour ☐ 4 day
☐ 45 min ☐ 12 hour ☐ 5 day
☐ 1 hour ☐ 16 hour ☐ 6 day
☐ 1.5 hour ☐ 20 hour ☐ 7 day
☐ 2 hour ☐ 24 hour ☒ All

Return Period

Help

☐ 2 Year
☐ 5 Year
☐ 10 Year
☐ 20 Year
☐ 50 Year
☐ 100 Year
☐ 200 Year
☒ All

Block Size

Help

3

Proceed

Exit

Figure 3.13: Design Rainfall estimation software

Moretele Spruit.txt - Notepad

File Edit Format View Help

User selection has the following criteria:

Station Number: 0513529

Durations requested: 5 m, 10 m, 15 m, 30 m, 45 m, 1 h, 1.5 h, 2 h, 4 h, 6 h, 8 h, 10 h, 12 h, 16 h, 20 h, 24 h, 1 d, 2 d, 3 d, 4 d, 5 d, 6 d

Return Periods requested: 2 yr, 5 yr, 10 yr, 20 yr, 50 yr, 100 yr, 200 yr

Block Size requested: 3 minutes

Data extracted from Daily Rainfall Estimate Database File

The station selected and the five closest stations are listed

Station Name	SAWS Number	Distance (km)	Record (Years)	Latitude (°)	Longitude (°)	MAP (mm)	Altitude (m)	Duration (m/h/d)	Return 2	Period (years)	2L	2U	5	
GARSTFONTEIN	0513529_W	0.0	34	25	49	28	17	741	1440	1 d	55.9	55.6	56.2	77.2
										2 d	73.3	72.8	73.8	101.6
										3 d	82.0	81.6	82.3	112.9
										4 d	90.1	89.7	90.5	122.9
										5 d	95.7	95.3	96.2	130.2
										6 d	102.9	102.5	103.7	139.8
										7 d	108.3	107.8	108.8	146.6
RIETVLEI-AGR.	0513531_A	4.0	21	25	51	28	18	743	1510	1 d	61.4	61.1	61.7	84.8
										2 d	71.8	71.4	72.3	99.6
										3 d	78.5	78.2	78.9	108.2
										4 d	85.5	85.2	85.9	116.7
										5 d	92.6	92.2	93.1	126.0
										6 d	97.4	96.9	98.1	132.2
										7 d	101.7	101.3	102.2	137.7
PRETORIA-LYNNWOOD	0513496_W	5.4	55	25	46	28	17	706	1360	1 d	57.4	57.1	57.6	79.2
										2 d	70.3	69.9	70.8	97.6
										3 d	79.1	78.7	79.4	109.0
										4 d	85.7	85.3	86.0	116.9
										5 d	92.5	92.1	93.0	125.8
										6 d	99.5	99.1	100.3	135.2
										7 d	105.1	104.7	105.6	142.3
PRETORIA-WATERKLOOF-CNT	RY 0513437_W	6.5	81	25	47	28	14	741	1470	1 d	62.3	62.0	62.6	86.0
										2 d	78.4	77.9	78.9	108.7
										3 d	86.5	86.1	86.9	119.2
										4 d	93.2	92.8	93.6	127.2
										5 d	100.1	99.7	100.7	136.2
										6 d	106.3	105.9	107.2	144.4
										7 d	110.7	110.2	111.1	149.8
PTA-UNIV-PROEFPLAAS.	0513465_A	7.4	50	25	45	28	16	687	1360	1 d	57.8	57.5	58.0	79.8
										2 d	70.1	69.6	70.6	97.2
										3 d	78.6	78.2	78.9	108.3
										4 d	86.1	85.7	86.4	117.4
										5 d	94.6	94.2	95.1	128.7
										6 d	101.4	101.0	102.2	137.7
										7 d	108.1	107.6	108.6	146.4
PRETORIA-BROOKLYN-3	0513405_W	7.6	31	25	46	28	14	692	1400	1 d	62.2	61.9	62.5	85.9
										2 d	75.6	75.1	76.1	104.9
										3 d	85.3	84.9	85.7	117.5
										4 d	93.4	93.0	93.8	127.5
										5 d	100.1	99.7	100.7	136.2
										6 d	104.7	104.2	105.5	142.2
										7 d	111.5	111.0	112.0	150.9

Figure 3.14: Design Rainfall estimation results

3.5.1.4 Time of concentration (T_C)

The time of concentration, T_C , is defined as the required time for a storm of uniform area and temporal distribution to contribute to the run-off from the catchment. In calculating the time of concentration, distinction is made between overland flow (sheet flow) and flow in defined watercourses. The formulae provided below have historically been used in South Africa although it is acknowledged that there are other acceptable methods available for calculating the time of concentration and the average slope.

(i) Calculation of the time of concentration for overland flow

This type of flow usually occurs in small, flat catchments or in upper reaches of catchments, where there is no clearly defined watercourse. Run-off, then, is in the form of thin layers of water flowing slowly over the fairly uneven ground surface. The Kerby formula is recommended for the calculation of T_C in this case. It is only applicable to parts where the slope is fairly even.

$$T_C = 0,604 \left(\frac{rL}{S^{0.5}} \right)^{0.467} \quad \dots(3.11)$$

where:

T_C = time of concentration (hours)

r = roughness coefficient obtained from **Table 3.10**


L = hydraulic length of catchment, measured along flow path from the catchment boundary to the point where the flood needs to be determined (km)

S = slope of the catchment $S = \frac{H}{1000 L}$ (m/m) (see **Figure 3.15**)

H = height of most remote point above outlet of catchment (m)

Table 3.10: Recommended values of r

Surface description	Recommended value of r
Paved areas	0,02
Clean compacted soil, no stones	0,1
Sparse grass over fairly rough surface	0,3
Medium grass cover	0,4
Thick grass cover	0,8


**Figure 3.15: Slope definition for overland flow**(ii) Calculation of time of concentration for a defined watercourse

In a defined watercourse, channel flow occurs. The recommended empirical formula for calculating the time of concentration in natural channels was developed by the US Soil Conservation Service.

$$T_C = \left(\frac{0,87L^2}{1\,000 S_{av}} \right)^{0,385} \quad \dots(3.12)$$

where: T_C = time of concentration (hours)
 L = hydraulic length of catchment, measured along flow path from the catchment boundary to the point where the flood needs to be determined (km)
 S_{av} = average slope (m/m)

The average slope may be determined graphically in two ways. The first procedure is based on the balance of areas obtained by balancing the areas above and below the line of average slope, as shown in **Figure 3.16**. Alternatively the formula developed by the US Geological Survey, and referred to as the 1085-slope method could be used (**Figure 3.17**).

**Figure 3.16: Slope according to weighted area method**

In most cases the longest water path includes both overland and channel flow. In large catchments the channel flow is usually dominant, but in small catchments it may be necessary to determine T_C as the sum of the flow times, for overland and channel flow. To obtain a broad indication, it may usually be accepted that a defined watercourse exists when the average slope of the catchment is greater than 5 per cent, and the catchment itself is larger than 5 km².




Figure 3.17: 1085-Slope according to “US Geological survey”

The formula for determining the slope according to the 1085 slope method is as follows:

$$S_{av} = \frac{H_{0,85L} - H_{0,10L}}{(1\,000)(0,75L)} \quad \text{or} \quad S_{av} = \frac{H}{(1\,000)(0,75L)} \quad \dots(3.13)$$

where:

S_{av}	=	average slope (m/m)
$H_{0,10L}$	=	elevation height at 10% of the length of the watercourse (m)
$H_{0,85L}$	=	elevation height at 85% of the length of the watercourse (m)
L	=	length of watercourse (km)
H	=	$H_{0,85L} - H_{0,10L}$ (m)

The height of waterfalls and high rapids are subtracted from the gross H value.

(iii) Calculation of the time of concentration for urban areas

In urban areas the time of concentration should be determined, where applicable, by means of the flow velocities according to the Chezy or Manning equation for uniform flow through representative cross-sections with representative slopes.

In road drainage the volume of water that runs off as a result of a storm of less than 15 minutes' duration is usually not large, and much of this run-off is absorbed in filling of the watercourses. Times of concentration of less than 15 minutes are thus generally not significant.

It is sound practice to calculate the average flow velocity ($v = L/T_C$) after determining T_C in order to ensure that it falls within realistic limits. Typical values of the flow velocity range from 0,1 to 4 m/s, depending on the natural conditions.

3.5.1.5 *Effective catchment area (A)*

The effective area is that part of the total catchment which would contribute to the peak flow. Pans or areas that are artificially cut off should consequently be excluded.

3.5.1.6 Simplified hydrograph for the Rational method

Although the Rational method is not strictly suitable for determining hydrographs, a simple triangular hydrograph can be used for low-risk application, such as flood routing through a culvert or the determination of the run-off volume. A typical triangular hydrograph is shown in **Figure 3.18**.




Figure 3.18: Simplified (triangular) hydrograph for the rational method

This is a highly idealised hydrograph with a shape, which is only approached in a long catchment of uniform slope and width. It should also be noted that the run-off volume is greater than the storm rainfall that runs off during the time of concentration. As a result, real storms are usually of lower intensity both before and after their theoretical durations.

3.5.2 Unit Hydrograph method

3.5.2.1 Background

Unit hydrographs are applicable to catchments of between 15 and 5000 km². The specific recommended method is described in detail in Report 1/72 of the Hydrological Research Unit, University of the Witwatersrand ^(3.7). Although the concept could also be extended to catchments larger than 5 000 km², this should be done only by engineers with the necessary skill and experience. In large catchments the physical characteristics become increasingly complex and difficult to describe empirically. As discussed in Section 3.3, the significance of the characteristics of a catchment change in importance as the size of the catchment increases.

By using the concept of a unit hydrograph, the constant unique physical parameters of a catchment are established in the typical form of a hydrograph, and the size and duration may be further determined by considering the intensity and duration of rainfall. A unit hydrograph is a characteristic run-off response from a specific catchment, and is defined in metric terms as the hydrograph resulting from one millimetre of run-off following rainfall of unit duration with uniform spatial and time distribution over the catchment. The duration of the hydrograph is thus proportional to the duration of the rainfall and the volume of the hydrograph is proportional to the intensity of the rainfall.




Figure 3.19: Unit Hydrograph with confidence bands

The Hydrological Research Unit has used historical data to derive unit hydrographs for 96 river measuring stations in South Africa. From these 96 unit hydrographs, nine synthetic hydrographs have been derived for nine regions in South Africa with similar catchment characteristics such as topography, soil type, vegetation and rainfall. A typical regional unit hydrograph with confidence bands is shown in **Figure 3.19** and the regional division in **Figure 3.20**^(3.7).

3.5.2.2 Lag time and catchment index

Because of the general complexity of medium to large catchments, the lag time is not calculated arithmetically, but according to empirical curves. The ratios of lag time to catchment area indexes for the nine different regions are given in **Figure 3.21** based on veld type^(3.7). The catchment index is calculated by means of the following formula:

$$\text{Index} = \frac{L L_c}{\sqrt{S}} \quad \dots(3.14)$$

where:

- L = hydraulic length of catchment (km)
- L_c = distance between outlet and centroid of the catchment area (km)
- S = average slope of stream as for the rational method (m/m)




Figure 3.20: Regions with generalised veld types in South Africa




Figure 3.21: Ratio of lag time to catchment index

3.5.2.3 Rainfall input

The average annual precipitation for the area should be obtained from the South African Weather Service or from the simplified southern Africa rainfall map (**Figure 3.7**), which is based on the most up to date rainfall values (Lynch, 2004)^(3.29). The duration of storms that cause the maximum peak flows are obtained by a trial and error method. Design point rainfall for various durations, normally shorter than or equal to the lag time, are obtained using any of the 3 alternative approaches as described in Paragraph 3.5.1.3.

To calculate the probable maximum flood, the point rainfall could be obtained from **Figure 3.22** and **Figure 3.23**, and the maximum effective run-off from **Figure 3.19**^(3.7). However, where the probable maximum flood is of greater importance, it is best to use the more accurate methods as described in paragraph 4.4(iii) of Report 1/72^(3.7).




Figure 3.22: Maximum observed point rainfall in South Africa

Note: Regions in Figure 3.22 are according to Figure 3.23^(3.7)




Figure 3.23: Areas experiencing similar extreme point rainfalls




Figure 3.24: Expected maximum run-off percentage of storm rainfall

Due to the large sizes of the catchments for which the unit hydrographs are applicable, and also because of the areal distribution characteristics of rainfall, the point rainfall should be adjusted to be representative for a catchment. A further distinction could be drawn between storms in small areas, smaller than 800 km², and storms in medium-sized areas, between 800 and 5 000 km². Adjustment curves for point rainfall, or so-called area reduction factors, are given in **Figure 3.25** for small and in **Figure 3.26**^(3.7) for medium and large areas.

The percentage run-off from rainfall is not calculated empirically, but is determined from historical data for each region. The ratio between storm rainfall and percentage run-off for the different regions is given in **Figure 3.27**^(3.7).

It should be noted that run-off as determined by means of the Unit Hydrograph method applies mostly to undisturbed rural areas. The percentage run-off as determined with the aid of **Figure 3.28**, and which is analogous to the rational C value, would thus have to be proportionately adjusted where considerable changes take place in the hydrological characteristics of a catchment.

3.5.2.4 Calculation of the flood peak with the Unit Hydrograph procedure

The K_U value is obtained from **Table 3.11**^(3.7) for calculating the peak flow of the unit hydrograph using the formula:

$$Q_p = K_u \frac{A}{T_L}$$

...(3.15)

where:

- Q_p

=

unit hydrograph peak discharge (m³/s)
- A

=

size of catchment (km²)
- T_L

=

lag time (hours)

Table 3.11: Values of K_U for various veld types

Regional number (Figure 3.20)	Generalised veld type	Factor K_u
1	Coastal tropical forest	0,261
2	Schlerophyllous bush	0,306
3	Mountain sourveld	0,277
4	Grasslands of interior plateau	0,386
5	Highland sourveld and Dohne sourveld	0,351
5a	As for Zone 5 – but soils weakly developed	0,488
6	Karoo	0,265
7	False Karoo	0,315
8	Bushveld	0,367
9	Tall sourveld	0,321

The appropriate unit hydrograph is obtained from the regional classification in **Table 3.12**^(3.7). The unit hydrograph may then be dimensionalised by using the values of Q_p and T_L .




Figure 3.25: Expected percentage run-off as a function of point intensity (small areas), ARF




Figure 3.26: Expected percentage run-off as a function of storm duration (medium to large areas), ARF




Figure 3.27: Average storm losses

Table 3.12: Dimensionless one hour unit hydrographs for various veld zone regions

Time as T/T _L	Run-off as Q/Q _P for veld-type regions									
	1	2	3	4	5	5a	6	7	8	9
0	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
0.05	0.035	0.012	0.010	0.011	0.018	0.004	0.024	0.006	0.006	0.011
0.10	0.070	0.024	0.023	0.024	0.038	0.011	0.052	0.014	0.014	0.027
0.15	0.112	0.036	0.039	0.038	0.063	0.019	0.087	0.024	0.025	0.043
0.20	0.163	0.052	0.057	0.041	0.095	0.027	0.140	0.032	0.035	0.065
0.25	0.228	0.072	0.074	0.070	0.142	0.037	0.260	0.044	0.050	0.093
0.30	0.306	0.091	0.106	0.089	0.220	0.05	0.700	0.058	0.069	0.142
0.35	0.414	0.121	0.139	0.111	0.315	0.064	0.983	0.074	0.100	0.225
0.40	0.524	0.152	0.184	0.138	0.500	0.083	1.000	0.095	0.150	0.350
0.45	0.709	0.198	0.261	0.175	0.685	0.107	0.970	0.121	0.245	0.570
0.50	0.921	0.258	0.376	0.220	0.810	0.140	0.915	0.160	0.655	0.772
0.55	0.983	0.342	0.518	0.350	0.936	0.210	0.848	0.275	0.905	0.930
0.60	0.996	0.472	0.670	0.700	0.985	0.425	0.795	0.480	0.980	0.982
0.65	0.998	0.676	0.809	0.980	1.000	0.885	0.754	0.700	0.994	1.000
0.70	0.964	0.940	0.970	1.000	0.960	0.958	0.714	0.950	0.991	0.985
0.75	0.893	0.991	1.000	0.987	0.800	0.993	0.678	0.975	0.966	0.945
0.80	0.826	0.995	0.990	0.885	0.675	0.991	0.641	0.993	0.860	0.900
0.85	0.758	0.973	0.935	0.760	0.588	0.955	0.605	1.000	0.755	0.814
0.90	0.700	0.888	0.840	0.670	0.524	0.740	0.572	0.995	0.655	0.750
0.95	0.652	0.807	0.755	0.580	0.473	0.535	0.540	0.980	0.565	0.670
1.00	0.605	0.741	0.675	0.530	0.432	0.440	0.514	0.900	0.500	0.600
1.05	0.563	0.678	0.612	0.470	0.397	0.385	0.488	0.805	0.440	0.530
1.10	0.525	0.622	0.546	0.430	0.365	0.340	0.465	0.730	0.392	0.472
1.15	0.491	0.567	0.500	0.393	0.340	0.300	0.443	0.655	0.355	0.413
1.20	0.463	0.513	0.460	0.364	0.315	0.265	0.422	0.590	0.322	0.364
1.25	0.437	0.467	0.424	0.336	0.295	0.235	0.402	0.530	0.294	0.316
1.30	0.411	0.425	0.395	0.310	0.276	0.209	0.382	0.477	0.270	0.280
1.35	0.387	0.394	0.368	0.288	0.260	0.187	0.365	0.432	0.250	0.260
1.40	0.362	0.364	0.347	0.271	0.242	0.169	0.347	0.388	0.231	0.241
1.45	0.341	0.338	0.325	0.252	0.228	0.152	0.330	0.350	0.215	0.225
1.50	0.321	0.313	0.305	0.235	0.214	0.140	0.315	0.308	0.200	0.210
1.55	0.302	0.291	0.290	0.218	0.200	0.128	0.300	0.280	0.186	0.198
1.60	0.283	0.272	0.276	0.201	0.187	0.116	0.287	0.255	0.174	0.188
1.65	0.265	0.253	0.264	0.187	0.174	0.105	0.274	0.232	0.164	0.176
1.70	0.252	0.236	0.252	0.172	0.163	0.097	0.260	0.211	0.155	0.168
1.75	0.238	0.220	0.238	0.159	0.152	0.088	0.249	0.194	0.146	0.158
1.80	0.226	0.206	0.228	0.147	0.143	0.081	0.237	0.177	0.137	0.151
1.85	0.215	0.192	0.216	0.136	0.134	0.074	0.225	0.164	0.130	0.144
1.90	0.204	0.181	0.208	0.125	0.126	0.067	0.214	0.152	0.122	0.137
1.95	0.194	0.171	0.200	0.115	0.120	0.061	0.203	0.140	0.115	0.131
2.00	0.183	0.160	0.194	0.108	0.112	0.055	0.193	0.130	0.110	0.124
2.05	0.174	0.152	0.186	0.098	0.106	0.050	0.183	0.120	0.103	0.119
2.10	0.165	0.143	0.178	0.089	0.100	0.046	0.173	0.111	0.098	0.113
2.15	0.157	0.136	0.171	0.081	0.094	0.041	0.164	0.102	0.091	0.108
2.20	0.149	0.130	0.165	0.074	0.088	0.038	0.155	0.094	0.086	0.103
2.25	0.142	0.123	0.158	0.068	0.084	0.034	0.147	0.087	0.081	0.097
2.30	0.135	0.118	0.152	0.062	0.079	0.031	0.138	0.081	0.075	0.093
2.35	0.128	0.114	0.147	0.056	0.074	0.028	0.130	0.075	0.070	0.087
2.40	0.121	0.108	0.142	0.052	0.070	0.025	0.122	0.069	0.066	0.085
2.45	0.116	0.104	0.139	0.047	0.066	0.023	0.115	0.063	0.062	0.079
2.50	0.110	0.100	0.132	0.043	0.062	0.021	0.109	0.058	0.058	0.075
2.55	0.105	0.096	0.128	0.039	0.058	0.019	0.102	0.053	0.054	0.071
2.60	0.100	0.093	0.124	0.035	0.055	0.017	0.097	0.049	0.050	0.070
2.65	0.096	0.089	0.120	0.032	0.051	0.015	0.090	0.045	0.047	0.063
2.70	0.091	0.085	0.114	0.029	0.048	0.013	0.085	0.041	0.044	0.061
2.75	0.087	0.081	0.111	0.026	0.045	0.012	0.080	0.039	0.041	0.055
2.80	0.082	0.078	0.107	0.023	0.042	0.011	0.075	0.036	0.038	0.053
2.85	0.078	0.074	0.103	0.021	0.039	0.010	0.069	0.033	0.035	0.049
2.90	0.074	0.070	0.099	0.019	0.036	0.009	0.064	0.030	0.032	0.045
2.95	0.070	0.066	0.095	0.017	0.033	0.008	0.059	0.029	0.029	0.041
3.00	0.066	0.063	0.091	0.016	0.030	0.006	0.054	0.026	0.026	0.038
3.05	0.062	0.060	0.087	0.012	0.027	0.004	0.049	0.023	0.024	0.035
3.10	0.057	0.056	0.084	0.011	0.025	0.003	0.044	0.021	0.022	0.030
3.15	0.054	0.053	0.081	0.009	0.022	0.002	0.040	0.019	0.020	0.027
3.20	0.050	0.050	0.078	0.008	0.020	0.001	0.036	0.017	0.019	0.022
3.25	0.047	0.047	0.075	0.006	0.018	0.000	0.031	0.015	0.017	0.018
3.30	0.043	0.044	0.071	0.004	0.016	0.000	0.027	0.013	0.015	0.014
3.35	0.039	0.040	0.068	0.003	0.013	0.000	0.022	0.011	0.013	0.010
3.40	0.036	0.037	0.064	0.002	0.011	0.000	0.018	0.010	0.011	0.007
3.45	0.032	0.034	0.062	0.001	0.010	0.000	0.013	0.008	0.009	0.004
3.50	0.029	0.031	0.059	0.000	0.008	0.000	0.010	0.006	0.007	0.002
3.55	0.025	0.027	0.056	0.000	0.006	0.000	0.005	0.005	0.005	0.000
3.60	0.022	0.024	0.051	0.000	0.004	0.000	0.000	0.004	0.004	0.000
3.65	0.019	0.021	0.048	0.000	0.002	0.000	0.000	0.001	0.002	0.000
3.70	0.016	0.018	0.046	0.000	0.001	0.000	0.000	0.000	0.001	0.000
3.75	0.012	0.015	0.043	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3.80	0.009	0.011	0.040	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3.85	0.005	0.008	0.037	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3.90	0.003	0.005	0.035	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3.95	0.000	0.002	0.032	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4.00	0.000	0.000	0.029	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4.05	0.000	0.000	0.027	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4.10	0.000	0.000	0.024	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4.15	0.000	0.000	0.021	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4.20	0.000	0.000	0.011	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4.25	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

3.5.2.5 Changes in hydrograph duration

Since the standard duration of a unit hydrograph is one hour (from the one-hour rainfall), the duration should be increased or decreased to make provision for other rainfall durations.

To increase the duration of a unit hydrograph, a one-hour hydrograph may be added to a second (similar) hydrograph, with the second hydrograph's origin starting one hour later on the time scale. The resulting added values should then be divided by two to obtain a two-hour unit hydrograph. The principle is illustrated in **Figure 3.28** and may also be applied to other multiples of whole numbers.




Figure 3.28: Increasing unit hydrograph duration

However, when the duration has to be decreased, or increased in fractions of the original unit hydrograph duration, the S-curve technique should be used. An S-curve is obtained by staggering/lagging a number of unit hydrographs by the unit duration and then summing them as shown in **Figure 3.29**.

In practice there are often oscillations of the summed values of the unit hydrograph compiling the S-curve. These fluctuations result from $(\Delta Q_1 - \Delta Q_2)_{\Delta t} < 0$ (see Example 3.2 in *Application Guide*). This can normally be ascribed to time intervals being too large for accurate calculation, or to the duration of the unit hydrograph being too long in relation to the lag in the catchment.

Once the S-curve is known, a unit hydrograph of any duration (D) could be calculated by staggering/lagging a second S-curve by the new duration (D) and then subtracting the one from the other. The resulting values then only have to be multiplied by a proportionate factor to obtain the unit hydrograph for the new duration (D). This unit hydrograph may then again be dimensionalised using the values of Q_P and T_L .

Usually the method is applied arithmetically rather than graphically. It is consequently advisable to calculate the run-off values for the original unit hydrograph at such time intervals that the duration of the required hydrographs would be divisible by these time intervals.




Figure 3.29: Illustration of S-curve

3.5.2.6 Determination of design hydrographs

Once the hydrographs of different durations have been dimensionalised, the peak discharge can be determined for each duration. The dimensionalised unit hydrograph is then multiplied by the design rainfall to estimate the catchment run-off. A curve of peak discharges vs durations should then be plotted, and the turning point determined, which also represents the peak discharge. If a turning point is not reached, hydrographs with other durations should also be considered. By setting the storm duration equal to the lag time, an approximation of the peak discharge can usually be obtained. Storm durations shorter and longer than the lag time should, however, be evaluated. Where only the peak discharge is important, it is sufficient to dimensionalise the unit hydrographs only in the vicinity of the peak of the unit hydrograph.

With flood attenuation, both peak discharge and flood volume are important. To obtain the highest resultant flow rate, consequently not only the hydrograph with the highest peak discharge, but also those of shorter and longer duration should be used in the routing calculations.

A standard form for calculations involved in the application of the unit hydrograph method is given in **Appendix 3C**^(3.5).

3.5.3 Standard Design Flood Method

3.5.3.1 Introduction

The unacceptably frequent severe damage to civil engineering structures by floods in South Africa is largely due to the wide band of uncertainty around all estimates of the flood magnitude-frequency relationship, combined with steep increases in flood magnitudes with an increase in return periods. These uncertainties are not always accommodated in current design flood estimation procedures, and hence the Standard Design Flood Method (SDF), which is a simple and robust method, has been developed^(3.14). The SDF Method relieves one from having to evaluate the relative applicability of alternative methods for determining the design flood. It encourages one to use engineering factors of safety to accommodate uncertainties in the hydrological analyses, rather than investigate, evaluate and apply alternative hydrological procedures^(3.14).

The method is based on historical data that sufficiently define the flood frequency relationships. The river flow and rainfall records used for the development and calibration of the method are sufficiently long and extensive to provide stable values for the parameters of C (discharge coefficient) and rainfall intensity.

3.5.3.2 Theoretical base of the SDF method

3.5.3.2.1 General

The different flood calculation methods were reviewed, and it was found that the Rational method, which was developed in 1850 and which is the most widely used method in South Africa and abroad, should be the basis for the SDF.

The conventional rational, unit hydrograph and other rainfall run-off methods rest on the assumption that catchment characteristics play a dominant role in the flood magnitude-frequency relationship. It is apparent that destructive floods in South Africa are caused by rainfall events that have durations well in excess of the catchment response times for all but the largest catchments. Heavy rainfall during the first part of the storm brings the catchment close to saturation, and streams and rivers commence flowing strongly as the heavy rainfall continues. It has also been observed that the severe rainfall events are often preceded by above normal seasonal rainfall. In these circumstances catchment characteristics have only a minor influence on flood magnitude.

The rational formula, which has been discussed in Section 3.5.1, reads:

$$Q = \frac{CIA}{3,6} \quad \dots(3.16)$$

In the conventional rational method the run-off coefficient C is determined by giving numerical values to the catchment characteristics that influence run-off. In the SDF method the run-off coefficient is a calibrated value, based on the statistical analysis of recorded data within the region. This makes the run-off coefficient a regional parameter and not a site-specific value.

The SDF is an empirical regionally calibrated version of the Rational method. The only information required for its application is the area of the catchment, the length and slope of the main stream, and the drainage basin in which it is located, determined from Figure 3.30.

3.5.3.2.2 Regional definition of the run-off coefficient

A major component in the development of the SDF was the identification of regions with homogeneous flood-producing characteristics. The geographical requirement was that the boundaries had to follow catchment watersheds.

This ensured that they could be readily identified on topographical maps of any scale, and could be related to the Department of Water Affairs and Forestry's (DWAF) drainage region numbering system.

The regions were called 'basins' to avoid confusion with the DWAF's drainage regions, and the South African Weather Service's rainfall districts. The second requirement was that, where possible, each basin should contain at least one gauging station from the DWAF publication "Catalogue of hydrological catchment parameters"^(3.26). This publication contains a list of selected representative flow-gauging stations.

The delineation of the drainage basins was based on the need for homogeneous flood-producing characteristics. A number of experience-based criteria were used for this identification. **One representative rainfall station from TR102 was then selected for each basin** ^(3.15). Average values may superficially appear to be preferable, but there are hydrological reasons for choosing representativeness rather than averages. There was no need to update the TR102 data for the same reason. The 29 drainage basins are shown in **Figure 3.30**.




Figure 3.30: Standard Design Flood drainage basins

3.5.3.3 The development of the SDF method

Substantial studies were undertaken with the planning and design objectives in mind. All relevant hydrological and meteorological records were assembled in a standard computer-readable format. These included annual flood maxima at 152 representative flow-gauging stations with a combined record of 6 728 years. They had an average record length of more than 40 years and several records approached 100 years in length. There were a number of stations with intermittently observed maxima dating back to the 1840s.

The 29 daily rainfall stations in **Table 3B.1** (in **Appendix 3B**) were selected from the 2 400 sites in the Department of Environment Affairs (now Department of Water Affairs and Forestry) technical report TR102, *Southern African storm rainfall*. These are the representative rainfall stations for the 29 basins.

Many of the flow records have single, and occasionally more, exceptionally high values that appear as high outliers on probability plots. Other records at sites within regions vulnerable to these severe events have not yet experienced these. The calculated frequency-magnitude relationships at the sites with and without these high outliers are very different. This creates conceptual problems with both statistical analysis methods as well as with rainfall run-off models.

The remaining components that are unique to each drainage basin are listed in **Tables 3B.1** and **3B.2**. These are the statistical properties of the daily rainfall at the representative rainfall station for each drainage basin derived from TR102, and the representative percentage run-off coefficients C_2 and C_{100} for return periods of 2 and 100 years respectively. The run-off coefficients for other return periods are derived by interpolation between these two values.

Large values of C_2 and C_{100} pairs indicate that a large proportion of the representative rainfall contributes to the flood peak. Large proportional differences between C_2 and C_{100} indicate the presence of factors - principally antecedent soil moisture status - that introduce additional variability (coefficient of variation) into the rainfall run-off process.

There are many factors that influence the rainfall run-off relationship. Factors that have a large influence on the SDF and need the designer's consideration, are catchments in dolomitic areas where the flood run-off may be less than half of the SDF values, and catchments in the south-western Cape such as the Breë River, that have very flat growth curves; i.e. low coefficients of variation. In these rivers the SDF may appreciably over-estimate the flood magnitude for long return periods. Otherwise, the SDF produced satisfactorily conservative results in the representative catchments used in the development of the method. The method is amenable to hand calculation.

3.5.3.4 Design hydrograph form

Similar to the rational method, it is assumed that the SDF has a fixed triangular hydrograph shape with the duration of the rising limb equal to the time of concentration, T_C , the peak value equal to the estimated flood peak; and the duration of the falling limb equal to twice the time of concentration.

3.5.3.5 SDF calculation procedure

Refer to **Tables 3B.1** and **3B.2** (in **Appendix 3B**) for the information required for the calculation of flood magnitudes with the SDF method.

The second and third columns in **Table 3B.1** are the SAWS station identification numbers from TR102. This publication provides the information required for determining the point rainfall for the specified return period and the calculated time of concentration in step 6 below. M is the average of the annual daily maximum rainfalls, and R is the average number of days per year on which thunder was heard. These two values are used in the modified Hershfield equation (step 6). C_2 and C_{100} are the run-off coefficients as used in the equation in Step 8. MAP is the mean annual precipitation and MAE is the mean annual Symons Pan evaporation. These two values are supplied for information only, and are not used in the analysis. They indicate the substantial role played by antecedent evaporation in the flood rainfall run-off process, and how annual evaporation varies inversely with annual rainfall.

The calculation sequence is as follows:

- Step 1 - Identify the drainage basin in which the site is located from **Figure 3.30**.
- Step 2 - Identify the site on a topographical map, preferably 1:50 000 scale, and demarcate the catchment boundary. Copy the boundary onto tracing paper and place over 5mm or similar squared paper. Count the number of squares within the catchment including squares more than halfway into the catchment. Apply a factor to convert the number of squares to the catchment area A (km^2). GIS software packages or a planimeter can also be used to determine the catchment area.
- Step 3 - Identify the main channel on the map from the site to the catchment boundary, and measure its length using dividers set at 0,2 km, (1,0 km on a 1:250 000 map) or use a wheel. In the latter case multiply the length by a scale factor of 1,2 to compensate for the loss of resolution. Derive the length of the main channel L (km).

Step 4 - Determine the elevation of the main channel in metres at two points located at 10% and 85% of the main channel length upstream of the site. Divide the difference in elevation between these two sites by 75% of the main channel length. This is the 1085-slope S (m/km).

Step 5 - Apply the US Soil Conservation Service formula to determine the time of concentration T_C (hours) as suggested in HRU1/72 ^(3.23).

$$T_C = \left[\frac{0,87L^2}{1000S_{av}} \right]^{0,385} \quad \dots(3.17)$$

where:

$$\begin{aligned} T_C &= \text{time of concentration (hours)} \\ L &= \text{watercourse length (km)} \\ S_{av} &= \text{average slope (m/m)} \end{aligned}$$

Step 6 - Convert T_C (hours) to t (minutes). Determine the point precipitation depth $P_{t,T}$ (mm) for the time of concentration t (min) and the return period T (years). If the time of concentration is more than 24 hours use linear interpolation of the values for the reference rainfall station from TR102 listed in **Table 3B.2**. Otherwise use the modified Hershfield equation or durations less than 6 hours. Linear interpolation, between the modified Hershfield and the TR102 values can be used for T_C 's between 6 and 24 hours.

$$P_{t,T} = 1,13(0,41 + 0,64\ln T)(-0,11 + 0,27\ln t)(0,79M^{0,69}R^{0,20}) \quad \dots(3.18)$$

where:

$$\begin{aligned} M &= \text{mean of the annual daily maxima from Table 3B.1.} \\ R &= \text{average number of days per year on which thunder was heard from Table 3B.1.} \end{aligned}$$

Step 7 - Multiply the point precipitation depth $P_{t,T}$ (mm) by the area reduction factor ARF (%) to determine the average rainfall over the catchment for the required return period T (years). The corresponding rainfall intensity I_T (mm/h) is obtained by dividing this value by the time of concentration.

$$ARF = (90000 - 12800\ln A + 9830\ln t)^{0,4} \quad \dots (3.19)$$

Step 8 - The above steps constitute the standard procedure used in the conventional rational method. The SDF uses calibrated run-off coefficients C_2 (2-year return period) and C_{100} (100-year return period) from **Table 3B.1** instead of determining them from catchment characteristics. The run-off coefficients for the range of return periods T (years) are derived by applying the return period factors Y_T in **Table 3.13**, using the relationship in the equation below:

Table 3.13: Return period factors

T =	2	5	10	20	50	100	200
Y_T =	0	0,84	1,28	1,64	2,05	2,33	2,58

$$C_T = \frac{C_2}{100} + \left(\frac{Y_T}{2,33} \right) \left(\frac{C_{100}}{100} - \frac{C_2}{100} \right) \quad \dots(3.20)$$

Step 9 - Finally, the flood peak Q_T (m³/s) for the required return period T is calculated from:

$$Q_T = \frac{C_T I_T A}{3,6} \quad \dots(3.21)$$

which is the standard format used in the rational method.

Step 10 - The SDF hydrograph is triangular in shape with the duration of the rising limb equal to the time of concentration T_C (hours), and that of the falling limb equal to twice the time of concentration. Use linear interpolation between these values.

Note: It is essential that the above procedure and equations be used to determine the SDF. Under no circumstances should alternative sources of information or equations be used, as these would invalidate the calibration and verification procedures on which they are based.

3.5.3.6 Additional SDF comparison

Given the limited experience with the SDF method at the time of publication (5th Edition), the authors requested an independent review of records that had not been used by the developer of the SDF method. Five additional stations in each of the 29 basins were selected and significant differences in some of the basins between the fitted distribution function (LP3) values, based on the recorded data and those calculated by means of the SDF method were found. The differences did not follow clear patterns. It is believed that these results can serve as valuable additional information in the application of the SDF method and the report has been included on the supporting flash drive/DVD.

A number of researcher have evaluated the SDF method since the publication of the 5th Edition of the Drainage Manual and these studies have provided some insight into the application of the SDF method.

In a study by Gericke^(3.56 & 3.58), the SDF method was evaluated by establishing the accuracy of the regionalised SDF runoff coefficients, taking both the areal extent and homogeneous hydrological catchment responses into consideration. The SDF runoff coefficients were evaluated, calibrated and verified at a quaternary catchment level in SDF basin 9 (primary study area) and in 19 of the other 29 SDF basins in South Africa (secondary study areas) by establishing catchment parameters and evaluating the ratios between the results obtained through the SDF method and probabilistic analysis. The results of this study showed that the original SDF method overestimated the magnitude and frequency (return period) of flood peaks in all the basins under consideration, while the verification results confirmed that the calibrated/verified SDF method, based on quaternary runoff coefficients, significantly improves the accuracy in comparison with the probabilistic analysis results. The result confirmed that the probabilistic-based approach of the original SDF method does not have the ability to overcome the deficiencies evident in the other design flood estimation techniques used in South Africa. It was suggested that a revision of the runoff coefficients at a quaternary catchment level is performed.

Another study by Hogan^(3.59) entitled: *Design flood peak determination in the rural catchments of the Eastern Cape, South Africa* concluded that: "The SDF method was the most consistently performing deterministic method for all sized catchments in RIs above 1:10 years, estimating runoff values similar to the LP3/MM distribution."

3.5.4 SCS-SA method

3.5.4.1 Background

The United States Department of Agriculture's Soil Conservation Service (SCS) based techniques for the estimation of design flood volume and peak discharge from small catchments (i.e. $< 30 \text{ km}^2$) were originally adapted in 1979 for use in southern Africa by Schulze and Arnold^(3.17, 3.50). Based on extensive research over many years and the development of extended databases, an updated version of the 1979 SCS design manual was produced in 1987 in the form of three reports published by the Water Research Commission^(3.42, 3.38, 3.35), viz.

- (i) an extended theory-based "Flood volume and peak discharge from small catchments in southern Africa, based on the SCS technique"^(3.39),

- (ii) a "User Manual for SCS-based design runoff estimation in southern Africa" ^(3.40), and
- (iii) appendices to the above reports ^(3.41).

The above manually based method was computerised and the method is now widely used for the estimation of design floods from small catchments in South Africa ^(3.45, 3.46). The adaptations to the original SCS method for southern Africa, termed SCS-SA, include the following:

- (ii) refinements to the soils classification to cater for soils in southern Africa and the linking of these to the local (Binomial and Taxonomic) soil classification systems,
- (iii) the development of methods to account for regional differences in median antecedent soil moisture conditions prior to large rainfall events and for the joint association between rainfall and runoff,
- (iv) the estimation of design rainfall and typical storm distributions for southern Africa, and
- (v) the development of an empirical equation to estimate catchment lag from small catchments in southern Africa.

3.5.4.2 Estimation of Runoff Volume

3.5.4.2.1 SCS stormflow equation

Stormflow is defined as the direct runoff response to a given rainfall event, and consists of both surface runoff and subsurface flows, but excludes baseflow (i.e. the delayed sub-surface response). Stormflow depth is calculated in the SCS model using Equation 3.22.

$$Q = \frac{(P - I_a)^2}{P - I_a + S} \quad \text{for } P > I_a \quad \dots(3.22)$$

where

Q	=	stormflow depth (mm),
P	=	daily rainfall depth (mm), usually input as a one-day design rainfall for a given return period,
S	=	potential maximum soil water retention (mm),
	≡	index of the wetness of the catchment's soil prior to a rainfall event,
I _a	=	initial losses (abstractions) prior to the commencement of stormflow, comprising of depression storage, interception and initial infiltration (mm)
	=	0,1S (recommended for use in South Africa)

Stormflow depth represents a uniform depth over the catchment and may be converted to volume by introducing catchment area.

Initial losses were estimated in the original SCS model as $I_a = 0,2 S$ ^(3.50). From regression analyses of available data, Schulze found that $I_a = 0,12 S$ was the best linear model and Schmidt and Schulze recommend that $I_a = 0,1S$ be used for the estimation of design stormflow ^(3.52).

The potential maximum soil water retention, S, is related to hydrological soil properties, land cover and land management conditions as well as to the soil moisture status of the catchment prior to a rainfall event, and finds expression through a dimensionless response index termed the catchment's Curve Number (CN). The CN and S are related as shown in Equation 3.23.

$$S = \frac{25400}{CN} - 254 \quad \dots(3.23)$$

The determination of inputs to Equations 3.22 and 3.23, viz. the Curve Number and rainfall depth, are discussed in the sections which follow.

3.5.4.2.2 Initial Curve Numbers

The Curve Number (CN) is an index expressing a catchment's stormflow response to a rainfall event. The characteristics considered in determining a CN for a catchment are:

- (i) hydrological soil properties
- (ii) land cover properties (including land use, its treatment and hydrological conditions) and the
- (iii) catchment antecedent soil moisture status, i.e. the soil's relative wetness or dryness just prior to the rainfall event.

Curve Numbers are determined initially according to soils and land cover properties only, with no regard to soil moisture conditions. These initial (also erroneously termed "average") Curve Numbers are designated CN-II, and values are given for a wide range of land cover and treatment classes, stormflow potentials and hydrological soil groups in **Table 3E.3 (Appendix 3E)**. The initial Curve Number may be adjusted up (i.e. increased, for a relatively "wet" catchment) or down (i.e. decreased to a lower final CN, for a relatively "dry" catchment) according to the catchment's soil moisture status typically prevailing before design events occur, following the procedures given in Sections 3.5.4.2.5 to 3.5.4.2.7

3.5.4.2.3 Hydrological soil groupings

- (a) SCS hydrological soils groups

Soil properties have been categorised hydrologically by the SCS into four basic soil groups, viz. A, B, C and D soils. Their characteristics are summarised in **Table 3.14**. Typically soils with a high clay content produce a higher stormflow response than soils with a low clay content. Soils that are well drained produce lower stormflow response than poorly drained soils. Soils with a shallow water table tend to produce high stormflow responses, as do soils that have a surface crust. Deep soils generally have lower stormflow responses than shallow soils, unless restrictions in the soil horizons are present. In studying **Table 3.14** it is important to read the notes accompanying the table.

Table 3.14: Characteristics of the four basic SCS hydrological soil groups

Soil Group A	<i>Low stormflow potential.</i> Infiltration is high and permeability is rapid in this group. Overall drainage is excessive to well-drained (Final infiltration rate ≈ 25 mm/h. Permeability rate $> 7,6$ mm/h).
Soil Group B	<i>Moderately low stormflow potential.</i> The soils of this group are characterised by moderate infiltration rates, effective depth and drainage. Permeability is slightly restricted (Final infiltration rate ≈ 13 mm/h. Permeability rate $3,8$ to $7,6$ mm/h).
Soil Group C	<i>Moderately high stormflow potential.</i> The rate of infiltration is slow or deteriorates rapidly in this group. Permeability is restricted. Soil depth tends to be shallow (Final infiltration rate ≈ 6 mm/h. Permeability rate $1,3$ to $3,8$ mm/h).
Soil Group D	<i>High stormflow potential.</i> Soils in this group are characterised by very low infiltration rates and severely restricted permeability. Very shallow soils and those of high shrink-swell potential are included in this group (Final infiltration rate ≈ 3 mm/h. Permeability rate $< 1,3$ mm/h).
Notes <ol style="list-style-type: none"> For southern Africa intermediate soil groups (i.e. A/B; B/C; C/D) have been identified and should be used in the classification into soil groups. The typical final infiltration and permeability rates given above both refer to a saturated soil. Final infiltration rates refer to soils with a short grass cover. Infiltration rate is controlled by surface conditions whereas permeability rates are controlled by properties of the soil profile. Infiltration or percolation tests, following standard procedures may be conducted at a number of sites in the catchment to assist in soil group selection ^(3.33). 	

(b) Southern African hydrological soils groupings

Soils in southern Africa have been divided taxonomically by the Soil Classification Working Group into 73 *soil forms*, each identified by a sequence of diagnostic soil horizons ^(3.47). Each of these soil forms in turn is sub-divided into *soil families* on the basis of soil physical and chemical properties. Also still in use in southern Africa, and important in that the national soils maps have been produced on this basis, is the *binomial* soil classification in which 41 soil forms are subdivided (again on the basis of physical and chemical characteristics) into *soil series*, of which 501 have been identified and described by MacVicar *et al.* ^(3.37).

Schulze, Angus and Guy have described the hydrological interrelationships between soil forms, families and series ^(3.44). Each soil family has been assigned a corresponding soil series and all the 501 soil series identified have been designated to an SCS hydrological soil group, i.e. A, B, C or D, or to intermediate groups, *viz.* A/B, B/C and C/D. Extracts from the taxonomic and binomial classification of soils in southern Africa into hydrological soil groups are shown in **Table 3E.1 (Appendix E)** and **Table E3.2** with the complete classification available in the *Visual SCS-SA User Manual* on the supporting flash drive/DVD.

The major source of mapped soils information in South Africa consists of detailed soils Land Type images produced by the Agricultural Research Council's Institute for Soil, Climate and Water (ISCW) and which may, together with accompanying documentation, be purchased from the Institute. A Land Type is a mapping unit, each of which has, in turn, been sub-divided into terrain units consisting of the scarp, crest, midslope, footslope and valley bottom. However, the spatially dominant terrain unit is usually taken to represent the Land Type.

(c) Procedures for determining hydrological soil groups

Where information on soil form and soil family (with its associated texture class) or alternatively soil form and series is known, the SCS soil groupings associated with each soil series, with extracts shown in **Table 3E.1** and **Table 3E.2** respectively, should be adopted. Alternatively, the hydrological soil group category A to D should be deduced from fieldwork and from the description given in **Table 3E.1 (Appendix E)**. A third option is to derive a generalised soil group from **Figure 3.31** in which the soil groups have been mapped for South Africa at the resolution of the 5 838 so-called Quinary catchments making up the country. Computed stormflow is highly sensitive to the hydrological soil group selected and every effort should therefore be made to determine accurately the appropriate group and to become familiar with currently prevailing soil classification procedures for southern Africa. Available soil maps and Land Type maps should be consulted in this regard and a field inspection of soils is strongly recommended.




Figure 3.31: Generalised SCS soil grouping classification for South Africa

(d) Adjustment of soil groups in the field

Because of the variable nature of soil properties even within a specific series, some further guidelines for adjustment of soil groups in the field are given:

- (i) *Soil depth*
Where typically deep soils are in the shallow phase, for example on steep slopes, they should be downgraded one group (e.g. B becomes B/C)
- (ii) *Surface sealing*
Where surface sealing is evident *in loco*, soils should be downgraded one group.
- (iii) *Topographical position*
Generally series in bottomlands may be downgraded (e.g. B to B/C) and series formed on uplands upgraded (e.g. B to A/B) one group.
- (iv) *Parent material*
Identical series derived from different parent materials may require re-grouping, e.g. series derived from Table Mountain sandstones would be upgraded relative to the same soil series derived from more clayey Dwyka tillites.

3.5.4.2.4 Land cover grouping

In the SCS procedure the effects of surface conditions of a catchment are evaluated by means of assessing the land cover, land treatment and stormflow potential.

(a) Land cover

Land *cover* defines the primary catchment cover which can comprise a range of annual and perennial crops, veld and forest as well as non-agricultural cover such as water surfaces and urban or suburban conditions.

(b) Land treatment

Land *treatment* applies mainly to agricultural land uses and includes primarily mechanical practices such as conservation structures (e.g. contours, terraces) and management practices such as grazing control and rotation of crops.

(c) Stormflow Potential

Stormflow *potential* is influenced by management practices. Three categories of stormflow potential are given, viz. *high*, *moderate* and *low*. In the context of agricultural crops the use of conservation practices (e.g. minimum tillage) results in crop residue being left on the soil surface, which will result in a low stormflow potential. In the context of pasture or veld, a high stormflow potential would occur as a result of heavy grazing or recent burning (cover less than 50 % of the area), while a low stormflow potential is associated with light grazing or plant cover on > 75 % of the area. Under forest conditions, a high stormflow potential exists when undergrowth is sparse and there is a compact, shallow organic and litter layer (humus < 50 mm deep), while a low stormflow potential exists when undergrowth is dense and there is a loose, deep organic and litter layer (humus > 100 mm deep).

The following points should be noted when determining the Curve Number:

- The Curve Number values given in **Table 3E.3** are based on work conducted in the USA and do not cover all land use characteristics found typically in southern Africa. Interpolation from similar land cover classes given in **Table 3E.3** must be resorted to in such instances.
- The Curve Numbers represent soil/land cover combinations for initial conditions of so-called "average" catchment wetness just prior to an event.
- The user should attempt to establish the land cover/treatment conditions likely to prevail in the catchment during the design life of the structure. Thus the felling/cutting cycle of forest plantations or sugarcane would determine the percentage of the catchment area represented by a chosen Curve Number. Similarly urban growth or projected changes in land cover and use should be accounted for in deriving the catchment Curve Number.
- Owing to future changes in land cover and use which may result in an increase in design stormflow, caution should be exercised when using a value of *CN* which is less than 50.
- Because of the heterogeneous nature of the soils and land cover in a catchment, there could be a marked variation in Curve Number between sub-areas of a catchment. Such variations in Curve Number must be accounted for by delineating a catchment into sub-catchments, each with relatively homogeneous soil/land cover response characteristics. Curve Numbers from the sub-catchments should not be averaged and the runoff volume from the individual sub-catchments must be summed to obtain the total catchment runoff.
- The user is referred to Schmidt and Schulze (1987a) for more detail on the classification of land cover ^(3.39).

3.5.4.2.5 Adjustment of initial Curve Numbers

The Curve Number assigned to a particular soil and land cover condition is an index of stormflow response prior to consideration of catchment soil moisture conditions. Since stormflow response is highly sensitive to the catchment's wetness, adjustments to Curve Numbers can be made for soil moisture status.

Actual soil moisture conditions just prior to a rainfall event will depend upon the interrelationship of rainfall, drainage and evaporation amounts for a selected antecedent period preceding the rainfall event.

Soil moisture conditions will thus be influenced by those properties of the soil which affect absorption of rainfall, the retention and redistribution of soil water as well as those characteristics of vegetation which affect the drying out of the soil due to evaporation of water from the soil and plant transpiration.

Adjusting initial Curve Numbers to be more representative of conditions prior to design rainfall events in southern Africa will therefore have to consider regional climatic characteristics in conjunction with combinations of soil and vegetation properties.

Climatic records (rainfall and temperature) representative of 712 relatively homogeneous climatic and hydrological response zones delineated in southern Africa were analysed with the *ACRU* daily soil water budgeting model for a combination of soil and vegetation conditions, to determine typical soil moisture status prior to design storms ^(3.34, 3.43). Three soil depth categories (*viz.* deep, intermediate and shallow), three soil textural classes (*viz.* sand, loam and clay) and three vegetation cover conditions (*viz.* dense, intermediate and sparse) were used to categorise 27 soil/land cover combinations. **Table 3.15** contains a summarised description of each category. More details regarding the methods used to adjust CN for prevailing soil moisture prior to rainfall events are given in Schmidt and Schulze ^(3.40).

Based on the climatic data base for the 712 zones and the 27 soil/land cover combinations, typical soil moisture related adjustments to the Curve Number can be made in one of two ways, *viz.* the

- (i) *Median Condition Method*, which computes the soil moisture status that can be expected (statistically) to occur most frequently (i.e. the median condition) prior to a design rainfall event in southern Africa, and the
- (ii) *Joint Association Method*, which accounts for simulated soil moisture conditions preceding those individual rainfall events which are considered for a design series of simulated stormflows in southern Africa.

Table 3.15: Description of soil depth/texture classes and land cover conditions used in soil moisture status analyses (simplified after Schmidt and Schulze) ^(3.39)

moisture status analyses (simplified after Schmidt and Scholze)			
Soil depth categories and their assumed properties			
Category	Topsoil Horizon Depth (m)	Subsoil Horizon Depth (m)	Total Depth (m)
a) Deep	0,30	0,80	1,10
b) Intermediate	0,25	0,50	0,75
c) Shallow	0,15	0,15	0,30
Soil texture categories and their assumed properties			
a) Sand (coarse textured)	-	Well drained, low stormflow response	
b) Loam (medium textured)	-	Intermediately drained, intermediate stormflow response	
c) Clay (fine textured)	-	Poorly drained, high stormflow response	
Land cover categories and their assumed properties			
a) Dense cover	-	Dense canopy cover, high potential transpiration rates, deep rooted	
b) Intermediate	-	Intermediate canopy cover, medium potential transpiration rates, intermediate rooting depth	
c) Sparse cover	-	Sparse canopy cover, low potential transpiration rates, shallow roots	

3.5.4.2.6 Median condition method

The median soil moisture status (i.e. that soil moisture content just prior to a selected storm event, the value of which is equalled or exceeded for 50 % of the selected storm events) was determined using the five largest independent daily rainfall totals in each year of record. From this median soil moisture storage, a change from an initially assumed soil moisture storage was computed, viz. ΔS . The initial Curve Number CN-II from **Table 3E.3 (Appendix E3)** was then adjusted to a *final* Curve Number, CN_f , based on the respective ΔS , by the equation:

$$CN_f = \frac{1100}{\frac{1100}{CN - II} - \frac{\Delta S}{25,4}} \quad \dots(3.24)$$

3.5.4.2.7 Joint association method

The adjustment for a median antecedent soil moisture condition based on a large number of storms does not account for the effect that the event by event variation of soil moisture status can have when estimating design runoff response. The "joint association" between rainfall amount and catchment moisture status may result in the second, third or even the fourth largest rainfall event of a year producing the largest flood, as a result of specific moist soil conditions prevailing just prior to the rainfall event. To account for this "joint association" between rainfall and catchment moisture status the Curve Number adjustment procedures discussed in Section 3.5.4.2.6 above were applied to the five highest independent daily rainfall events for each year of record for the rainfall stations representing each of the 712 climatic/hydrological response zones of southern Africa.

The stormflow response to each selected rainfall event for a range of initial Curve Numbers (CN-II) was computed after adjusting CN-II for prevailing soil moisture conditions prior to the specific event for each of the 27 soil/land cover combinations. A frequency analysis was performed on the resulting series of annual maximum daily stormflow depths to indicate the 50, 80, 90 and 95 percentile values of non-exceedence. These percentile values approximate the 2, 5, 10 and 20 year return period daily stormflow depths respectively.

The results provide a direct estimate of stormflow depth, and hence volume, having already accounted for the joint association of rainfall depth and catchment moisture status.

Stormflow series thus derived used the daily rainfall records of the station representing each climate response zone. Although most zones had a representative station with more than 50 years of daily rainfall record, a number of zones had stations with only a 30 year record. The frequency analyses were therefore presented only to the 95 percentile value (i.e. approximating the 20 year return period) and extrapolation beyond this return period is not recommended.

From the above it is therefore recommended that the Joint Association Method be used only for estimating floods not exceeding the 20 year return period. The Median Condition Method is recommended for use when the design return period exceeds 20 years.

3.5.4.2.8 Adjusted Curve Numbers for near-saturated catchment conditions

While the SCS model was not developed as a method to compute the Probable Maximum Flood (PMF) it may, with due caution, be used to estimate a value of PMF. PMF may be derived from a probable maximum precipitation amount (values of which must be obtained from other sources) falling on a saturated or near-saturated catchment. Equation 3.25 was derived to adjust an initial Curve Number CN-II to one for wet conditions, CN_w , viz ^(3.49).

$$CN_w = \frac{CN - II}{0,4036 + 0,0059CN - II} \quad \dots(3.25)$$

This CN_w would then be used in Equation 3.23 to compute Q from Equation 3.22.

3.5.4.2.9 One-day design rainfall depth

In the SCS method one-day rainfall depth is used to compute daily stormflow depth. This makes the SCS method particularly attractive to users since daily rainfall data are widely available in southern Africa. Rainfall intensity, also an important characteristic especially with respect to estimating peak discharge, is discussed in Section 3.5.4.3.2.

Maps depicting one-day rainfall depth over southern Africa, for various return periods, are presented **Figure 3E.1** to **Figure 3E.6** in **Appendix E**. These maps were produced using one-day design rainfall information derived using the Regional L-moment and Scale Invariance (RLMA&SI) approach developed by Smithers and Schulze to estimate design rainfalls in South Africa at 1' x 1' of a degree spatial resolution and for durations from 5 minutes to 7 days and return periods from 2 to 200 years^(3.48). The software and manuals to estimate design rainfall using the RLMA&SI approach are supplied on the supporting flash drive/DVD.

There are a number of different methods incorporated to obtain the one-day design rainfall i.e. using values estimated by the user directly from rain gauge data, or estimated using three different approaches, although the first two approaches utilise datasets over 20 years old and are therefore not recommended for hydrological designs:

- (i) Using at-site design rainfall calculated by Adamson^(3.15) for over 2 200 rainfall stations in southern Africa.
- (ii) Using at-site design rainfall calculated from the representative rainfall stations used to represent the rainfall in each of the 712 hydrological zones.
- (iii) Using the regional, scale invariance approach developed by Smithers and Schulze and presented as a *Design rainfall and flood estimation in South Africa* tool available on the supporting flash drive/DVD. Using this approach, design rainfalls may be estimated at any 1-minute x 1-minute grid point in South Africa for return periods ranging from 2 to 200 years and for durations ranging from 5 minutes to 7 days^(3.48).

The one-day design rainfall for a chosen frequency of recurrence is substituted as P into Equation 3.22 to compute the resulting design stormflow depth. The maps presented in **Figures 3E.1** to **3E.6** are generalised maps which should be used with caution in areas where there is a marked change in design rainfall depth over a short distance (e.g. areas of rapid change in topography), and users should thus preferably use the RLMA&SI method to estimate design rainfall as incorporated in the *Visual SCS-SA* software.

3.5.4.3 Estimation of Peak Discharge

3.5.4.3.1 SCS peak discharge equation

The calculation of peak discharge by SCS techniques is based on the triangular unit hydrograph concept. This unit hydrograph represents the temporal distribution of stormflow for an incremental unit depth of stormflow, ΔQ , occurring in a unit duration of time, ΔD .

Assuming a triangular shaped hydrograph with time to peak being 3/8 of the total hydrograph duration, the peak discharge for a storm with a uniform rainfall distribution with respect to time may be derived to be:

$$q_p = \frac{0,2083AQ}{D/2 + L} \quad \dots(3.26)$$

where

q_p	=	peak discharge (m^3/s),
A	=	catchment area (km^2),
Q	=	stormflow depth (mm),
D	=	effective storm duration (h), and
L	=	catchment lag (h), an index of the catchment's response time to the peak discharge.

The effective storm duration is related to catchment response time, i.e. lag (Equation 3.29), and Equation 3.26 may be simplified to:

$$q_p = \frac{0,2083AQ}{1,83L} \quad \dots(3.27)$$

In order to account for the non-uniformity of rainfall intensity during a storm event, it is necessary to divide the storm into increments of shorter duration (ΔD) and to compute the corresponding increment of runoff, as shown in Equation 3.28.

$$\Delta q_p = \frac{0,2083A\Delta Q}{\Delta D/2 + L} \quad \dots(3.28)$$

where

Δq_p	=	peak discharge of incremental unit hydrograph (m^3/s),
ΔQ	=	incremental stormflow depth (mm) , and
ΔD	=	unit duration of time (h), used with the distribution of daily rainfall to account for rainfall intensity variations.

To determine the hydrograph response to a given rainfall total, incremental hydrographs are superimposed according to the distribution of stormflow over time, as determined from the time distribution of rainfall intensity and the stormflow response characteristics of the catchment. This approach can only be realistically applied using detailed spreadsheets or by using the *Visual SCS-SA* software.

The determination of the two unknowns in Equation 3.28, viz. the time distribution of design rainfall intensity and catchment response time, are discussed in the sections which follow.

3.5.4.3.2 Time distribution of design rainfall intensity

Rainfall intensity has a marked effect on the timing and magnitude of the peak discharge on small catchments. Catchment response time will determine what storm duration, and hence rainfall intensity, is likely to produce the critical flood peak. A small catchment with a short response time will have critical flood peaks usually produced by short, high intensity storms, while a large catchment with a long response time will have critical flood peaks produced by longer duration storms which are generally of lower intensity.

The SCS model makes use of one-day design rainfall depth (Section 3.5.4.2.9) to compute total stormflow depth. This design rainfall depth is distributed over time in the course of a day. This time distribution depends on the synoptic conditions and rainfall mechanisms typically producing design storms in southern Africa. Four general types of time distribution curves of rainfall intensity have been determined for southern Africa from recording rain gauge data ^(3.51). These synthetic time distribution curves are termed Types 1, 2, 3 and 4 and **Figure 3.32** illustrates the spatial variation of the four synthetic time distribution curves over southern Africa.




Figure 3.32: Design rainfall intensity distribution types over southern Africa ^(3.51)

The use of the synthetic time distributions of rainfall intensity assumes the total depth of one-day rainfall for any duration to conform to the intensity-duration relationship for the region regardless of that duration. This allows for the use of the appropriate synthetic distribution for all catchments, regardless of response time. An element of conservatism (i.e. a tendency to rather overestimate the peak discharge slightly) has been built into the procedures by which these time distribution curves were derived, since it is unlikely that, for different durations, individual rainfall intensities will correspond to the design rainfall intensities ^(3.39).

In the regionalisation of the four synthetic time distributions of rainfall intensity (**Figure 3.32**) the Type 1 distribution contains the lowest design intensities, representing rainfall produced often by a frontal or wide-spread rain situation while the Type 4 distribution contains the highest design intensities, typifying convective thunderstorms in which virtually all the day's design rain falls in a short duration.

3.5.4.3.3 Catchment response time

Catchment response time, which is an index of the rate at which the stormflow which has been generated moves through a catchment, is an important factor in determining the timing and magnitude of the peak discharge, and hence the hydrograph shape. In SCS procedures the index of the catchment's response time is termed *catchment lag*, which is defined as the time from the centre of mass of effective or stormflow producing rainfall ($P-I_a$) to the peak discharge ^(3.39). Four options are available to estimate this lag, viz. by

- (i) Time of Concentration,
- (ii) the summation of travel times along flow path reaches,
- (iii) the SCS lag equation, and
- (iv) the Schmidt-Schulze lag equation

(a) Time of Concentration

The Time of Concentration (T_c), is an index of lag frequently used to define a catchment's response time. The Time of Concentration is the time it takes for stormflow to travel from the hydraulically most distant point of the catchment (i.e. point of longest water travel time) to the point of reference. The SCS lag time, L , is related to T_c by the following equation

$$L = 0,6T_c \quad \dots(3.29)$$

(b) Summation of travel times along flow path reaches

Time of Concentration may be estimated by summing the flow travel times along the various reaches comprising the flow path of water from the hydraulically most distant point to the catchment outlet. These flow paths comprise overland flow, shallow channel flow as the water converges and finally concentrated flow in well-defined channels, which can be either natural or constructed. The travel time in each flow phase is determined for each reach by dividing reach length (m) by flow velocity (in m/s) as determined from uniform flow equations (e.g. Manning's equation) for full flow conditions. Flow velocities can also be estimated from **Figure 3.33** using the so-called Uplands nomograph. The Time of Concentration is determined by adding flow times (converted to hours) down each channel reach. Lag can then be calculated from Equation 3.29.

When the flow phases contributing to the hydraulically most distant point are not defined clearly, one of the following two empirical equations may be used to compute catchment lag time.




Figure 3.33: The Uplands nomograph for estimating flow velocities ^(3.17)

(c) SCS lag equation

$$L = \frac{1^{0.8}(S'+25,4)^{0.7}}{7069y^{0.5}} \quad \dots(3.30)$$

where

$$\begin{aligned} L &= \text{catchment lag time (h)} \\ l &= \text{hydraulic length of catchment along the main channel (m)} \\ y &= \text{average catchment slope (\%)} \\ S' &= \frac{25400}{\text{CN} - \text{II}} - 254 \end{aligned}$$

with

$$\text{CN-II} = \text{retardance factor approximated by the initial Curve Number unadjusted for antecedent soil moisture (i.e. CN-II, Table 3E.3 in Appendix E3)}$$

The hydraulic length, l , of the catchment is the length of the main (i.e. longest) stream to the furthest catchment divide, as measured from a contour map.

Average catchment slope, $y(\%)$, may be determined from Equation 3.31 below, viz.

$$y(\%) = \frac{M \cdot N \cdot 10^{-4}}{A} \quad \dots(3.31)$$

where

$$\begin{aligned} M &= \text{total length of all contour lines (m) within the catchment, according to the scale of the map} \\ N &= \text{contour interval (m)} \\ A &= \text{catchment area (km}^2\text{)} \end{aligned}$$

(d) Schmidt-Schulze lag equation

Developed by Schmidt and Schulze in 1984^(3.38), this equation gives

$$L = \frac{A^{0.35} \text{MAP}^{1.1}}{41.67y^{0.3} \bar{I}_{30}^{0.87}} \quad \dots(3.32)$$

where

$$\begin{aligned} L &= \text{catchment lag time (h)} \\ A &= \text{catchment area (km}^2\text{)} \\ \text{MAP} &= \text{mean annual precipitation (mm)} \\ y &= \text{average catchment slope (\%)} \\ f_{30} &= \text{30-minute rainfall intensity (mm/h) for the 2-year return period} \end{aligned}$$

The value of f_{30} may be estimated in South Africa using **Figure 3.34** or by multiplying the 2-year return period one-day rainfall depth, for example derived from **Figure 3E.1**, by an intensity multiplication factor given in **Table 3.16**.

Table 3.16: Multiplication factors used in the determination of f_{30} in southern Africa

Rainfall distribution zone	1	2	3	4
Factor	0,433	0,664	0,974	1,236




Figure 3.34: Distribution of 2 year return period, 30 minute (f_{30}) rainfall in mm/h over South Africa

The MAP may be determined from a generalised map of MAP for South Africa as shown in **Figure 3.7** (3.29 & 3.36).

(e) General comments on catchment lag estimation options

The use of empirical equations should be restricted to catchments where hydraulic calculations of flow velocity for various reaches cannot be made. Equation 3.32 should be used in preference to Equation 3.30 when stormflow response is comprised not only of surface runoff, but also of a subsurface component, as occurs frequently in areas of relatively high mean annual precipitation, or on natural catchments with good surface cover. Equation 3.30 has been found to be more suited for use in semi-arid and arid areas of limited vegetation cover and shallow soils.

3.6 EMPIRICAL METHODS

3.6.1 General

Empirical methods are mostly based on simple correlations between peak flow rates and other catchment characteristics derived in order to establish general regional parameters. The peak discharges determined according to these methods are thus likely to be less accurate than those obtained by using statistical or deterministic methods.

The reliability of empirical methods depends largely on the realistic demarcation of comparable flood-producing areas. Parameters for every region should preferably be based on historical data for the same region. Since the characteristics of a given catchment often differ markedly from the general conditions in the region, the results should be adjusted subjectively according to the indications provided in Section 3.3.

These methods are based mainly on flow measurements at measuring stations covering catchments that are seldom smaller than 10 km² and usually larger than 100 km². Consequently these methods are only applicable to medium and large catchments. As more data become available, the methods may be improved or replaced by new methods.

3.6.2 Empirical peak flow calculations for rural areas

From a study of the frequency distribution of annual maximum flood peaks at 83 measuring stations in South Africa, Midgley and Pitman ^(3.10) compiled regional curves of flood peaks, with the size of the catchment and the return period as variables. **This method is suitable for rural catchments larger than 100 km².** The following relationship was determined:

$$Q_T = K_{RP} A^{0.5} \quad \dots(3.33)$$

where:

- Q_T = peak flow for T-year return period (m³/s)
- K_{RP} = constant for T-year return period (Original text referred to K_T but resulted in confusion with K_T used in Equation 3.34). The value of K_{RP} can be back calculated from **Figure 3.36** by obtaining the Q_T value and substituting in Equation 3.33
- A = size of catchment (km²)

To establish the temporal flow rate variation it was required to include other characteristics of the catchment. Considering the topography, rainfall characteristics, soils, drainage patterns and plant cover, the country was divided into seven homogeneous flood regions with similar K values. The regional distribution according to homogeneous flood characteristics is shown in **Figure 3.35**, and the flood peak probability curves in **Figure 3.36** ^(3.7).

Although the 83 measuring stations represent only a small sample, and the frequency distributions also contain inaccuracies, this method generally yields good estimates of the peak discharges in undeveloped areas. It is particularly **suitable for obtaining an advance indication of the order of magnitude of peak discharges, or to serve as a rough check on the results of non-statistical methods.**

3.6.3 Empirical deterministic peak discharge formula for return periods of up to 100 years

Peak discharges for **return periods less than or equal to 100 years** may be determined by means of an empirical deterministic method developed by Midgley and Pitman ^(3.10, 3.11). The formula reads:

$$Q_T = 0,0377 K_T P A^{0.6} C^{0.2} \quad \dots(3.34)$$

- where: Q_T = peak flow for T-year return period (m³/s)
- K_T = constant for T-year return period (obtained from **Table 3.17**)
- A = size of catchment (km²)
- P = mean annual rainfall over catchment (mm/a) (see **Figure 3.7**)
- and

$$C = \frac{A \sqrt{S}}{L L_C} \quad \text{(catchment parameter with regard to reaction time)} \quad \dots(3.35)$$

and where:

- S = average slope of stream (m/m)
- L = hydraulic length of catchment (km)
- L_C = distance between outlet and the centroid of the catchment (km)

Values of K_T have been compiled for the different veld-type regions of South Africa, shown in **Figure 3.20** and in **Table 3.17** ^(3.5).

Table 3.17: Constant values of K_T for different veld types

Return period T in years			10	20	50	100
Zone number and Generalized Veld type (Figure 3.20)	1	Coastal tropical forest	0,17	0,23	0,32	0,40
	2	Winter	0,42	0,52	0,68	0,80
		All year	0,83	1,04	1,36	1,60
	3	Mountain sourveld	0,29	0,40	0,55	0,70
	4	Grasslands of interior plateau	0,59	0,68	0,95	1,20
	5	Highland sourveld and Dohne sourveld	0,59	0,80	1,11	1,40
	5A	As for Zone 5 – but soils weakly developed	0,59	0,68	0,95	1,20
	6	Winter	0,33	0,45	0,63	0,80
		All year	0,67	0,91	1,26	1,60
	7	False Karoo	0,67	0,91	1,26	1,60
	8	Bushveld	0,42	0,57	0,79	1,00
	9	Tall sourveld	0,50	0,68	0,95	1,20

Equation 3.34 usually yields results that are comparable to those of the synthetic hydrograph method. It should **preferably be applied to catchments larger than 100 km²**, but could be applied with caution to catchments larger than 10 km².




Figure 3.35: Homogeneous flood regions in South Africa




Figure 3.36: Peak discharge probability diagram

3.6.4 Experience curves of maximum flood peaks for the calculation of flood peaks for return periods of more than 100 years

In road drainage, floods with return periods of more than 100 years are rarely required. However, it is sometimes desirable or necessary to obtain realistic values for extreme peak floods and the accompanying water levels; particularly where human lives may be endangered and/or valuable property may be damaged.

Most of the existing methods fail to accurately predict flood peaks for return periods in excess of 100 years. When using the statistical methods poor fits of statistical distributions and insufficient historical recorded data lengths are problematic. With deterministic methods, such as the unit hydrograph method, the problem arises that there is very little information available on area reduction factors for extreme rainfall, and the relative importance of the factors influencing run-off also changes. This lack of information consequently affects the reliability of the methods.

In an investigation for the Directorate of Water Affairs, Kovács^(3.11) studied the approximately 300 highest flood peaks observed in South Africa between 1894 and 1979. The information was processed using the Francou-Rodier relationship^(3.12), and five regional curves with confidence bands were compiled. The Francou-Rodier relationship, which is used to determine the regional maximum flood (RMF), is shown in Equation 3.36:

$$Q_{\text{RMF}} = 10^6 \left(\frac{A}{10^8} \right)^{1-0,1K} \quad \dots(3.36)$$

where:

- Q_{RMF} = regional maximum flood peak flow rate (m³/s)
- K = regional constant (Obtainable from the regional classification detailed in **Figure 3.37** and simplified in **Table 3.18**)
- 10^6 = total world MAR (m³/s)
- 10^8 = total world catchment area (km²)

The values of K vary from 0 to 6 with the latter value being the K value that envelopes world recorded floods, which have occurred in the high-rainfall cyclone-ravaged areas. The formula was also tested on more than one thousand reliably measured floods from all over the world.

The regional classification for maximum peak discharges in South Africa are named Kovács regions **K1 – K8 in this publication**, and are depicted in **Figure 3.37**^(3.13). This regional classification of Kovács regions supersedes the earlier work done by Kovács where only 5 regions were identified with linked K -values.

Table 3.18: RMF region classification in southern Africa

Kovács region	K *	Number of floods #	Transition zone		Flood zone	
			Area range (km ²)	Q_{RMF} (m ³ /s)	Area range (km ²)	Q_{RMF} (m ³ /s)
K1	2,8	6	1 – 500	$30A^{0,262}$	500 – 500 000	$1,74A^{0,72}$
K2	3,4	12	1 – 300	$50A^{0,265}$	300 – 500 000	$5,25A^{0,66}$
K3	4,0	26	1 – 300	$70A^{0,34}$	300 – 300 000	$15,9A^{0,60}$
K4	4,6	55	1 – 100	$100A^{0,38}$	100 – 100 000	$47,9A^{0,54}$
K5	5,0	155	1 – 100	$100A^{0,50}$	100 – 100 000	$100A^{0,50}$
K6	5,2	61	1 – 100	$100A^{0,56}$	100 – 30 000	$145A^{0,48}$
K7	5,4	34	1 – 100	$100A^{0,62}$	100 – 20 000	$209A^{0,46}$
K8	5,6	25	1 – 100	$100A^{0,68}$	100 – 10 000	$302A^{0,44}$

Notes: * RMF K value as used in Equation 3.35

Recorded flood data are reflected in the DWAF report TR105 – Maximum flood peak discharges in South Africa: An empirical approach

There are two regions where the K value used in Equation 3.36, is smaller than K1 and K2. For these regions Equation 3.36 should be used with a K value less than 2,8 for the region designated as “<K1” (Central Botswana) and a K-value less than 3,4 for the region “< K2” (West Coast of Namibia), see **Figure 3.37**.

Certain river reaches of major rivers have particular K values different to that of the Kovács region it flows through. For a detailed description of these rivers consult the *Regional maximum flood peaks in southern Africa, Technical report No 137* ^(3.13). Rivers which flow across several Kovács regions have distinct flood characteristics which may differ substantially from those of the region. In the lower reaches of such rivers the flood peak reduction is often very important because of storage in the wide flood plains. Here the prominent feature of extreme floods are rather the flood volume and duration than flood peak which is limited by the inundations. In Lesotho, where the catchment is wet and steep, K is fairly constant. In South Africa it is gradually reduced as the effects of decreasing mean annual rainfall and flatter catchment become apparent.

In using the values obtained from **Table 3.18**, it should be borne in mind that they represent the upper realistic limits for every region. For a specific catchment with much lower run-off characteristics than the average for the region, the K-value may be adjusted downwards. The following conditions may, for example, be present in a catchment:

- (i) An unusually flat catchment with wide flood plains and pans.
- (ii) A very permeable surface or dolomite.
- (iii) Dense bush or plantations, different from the rest of the area.
- (iv) A clear decrease in the mean annual rainfall in the downstream direction of catchments larger than 1 000 km².

Such conditions occur in all the regions, except for region K1. As a rule of thumb it may be stated that the K-value should not be adjusted any lower than the value for the following region. Where catchments fall within two regions, the peak discharge should be adjusted proportionately, or the highest value may be accepted. For urban areas and catchments smaller than 10 km², it is better to determine the probable maximum flood by means of other methods as discussed in Section 3.5.

In both the small and large catchments one is confronted with the inherent weakness of all regionally based methods, namely that the particular characteristics of these catchments cannot be easily expressed by one common regional factor, in this case K. TR137 ^(3.13) (included on supporting flash drive/DVD) provide recommendations that may help to tackle various problems in the application of the method such as smaller catchments, a site located in a given region extending into other regions etc.

Knowledge of 50 to 200 year peak discharges is required in practice for the design of bridges and dams. According to Kovács ^(3.13) a simple unorthodox analysis of the K-value and the representative return period of entirely independent flood peaks has provided coefficients which represent the 50 to 200 year peaks as fractions of RMF. These Q_T/Q_{RMF} ratios are provided in **Appendix 3D** (**Tables 3D.1** and **3D.2**) and are dependent on the region as well as the effective catchment area.




Figure 3.37: Maximum flood peak regions in southern Africa from Kovács (1988)^(3.13)

3.7 METHODS THAT ARE NOT INCLUDED IN THIS MANUAL

3.7.1 Run Hydrograph method

The Run Hydrograph method is based mainly on statistical regional analyses of historical data. A number of hydrographs with the same return period, but with different run-off volumes and peak discharges, may be calculated by means of this method. The method is not widely used and its application to road drainage is mainly as an alternative to or checks on the unit hydrograph method.

The run hydrograph theory was originally developed for determining average compound hydrographs with known return periods from records of river flow. For every given return period, however, there is a group of hydrographs with different run-off volumes and peak flows that fulfil this criterion. Hiemstra and Francis^(3.20) give a detailed description of this method in a publication^(3.20) obtainable from the Water Research Commission and a full description of the method is consequently not repeated here.

The results are similar to those obtained by means of the unit hydrograph method. However, the latter method tends to belong to the deterministic group of methods, whereas the run hydrograph method is statistically orientated. The run hydrograph method is generally more applicable to larger catchments than the synthetic hydrograph method.

Hydrographs with different peak discharge and run-off volumes, but with the same return period are required particularly for flood routing calculations for average and large catchments.

3.7.2 REFSSA method

The REFSSA or '*Regional Estimation of Extreme Flood Peaks by Selective Statistical Analyses*' method was first described in 2010^(3.53) with the objective to improve estimation of extreme flood peaks with annual exceedance probabilities (AEPs) between 1/200 and 1/10 000, in order to assist with the selection of design and safety evaluation flood peaks for dams. The method was refined in 2012^(3.54). Unlike current '*regional flood frequency analysis*' (RFFA) methods, the REFSSA method analyses mainly '*record maximum flood peak*' data (one maximum value per independent site over the full observation period), thus excluding lesser annual maximum flood peak data, which are included in most RFFA methods. The REFSSA method is especially suitable in climates containing outliers, and where records of annual maximum flood peaks are limited.

Suitability of the method has provisionally been demonstrated for the estimation of extreme flood peaks with annual exceedance probabilities (AEPs) between 0,005 (1/200) and 0,0001 (1/10 000) for three '*similar hydrological regions*' in South Africa (Kovács regions K4 to K6), and for catchment sizes between 100 km² and 10 000 km². Applicability of the method for catchments outside the aforementioned regions and catchment sizes has not been tested due to a shortage of verified data. Excellent results have been obtained so far, with high correlation coefficients (r) between record maximum flood peak data and regression lines (r better than 0,99 and skewness coefficients approaching zero on log-Normal scale). Although it is an upper-bound method because the record maximum flood peak data reflect the most severe flood generating catchments within a '*similar hydrological region*', estimates for extreme flood peaks are often significantly less than results obtained by other methods, for example the SDF method.

The REFSSA method was developed and tested on the basis of verified data in the catalogue of record maximum flood peaks published by Kovács in 1988^(3.13). This catalogue provides a reasonably good statistical sample of record maximum flood peaks for some regions of say the last 100 years. Collectively, the catalogue represents 5 000+ station-years against which estimates of extreme floods can be tested. Improvements can be made if this catalogue is expanded and updated.

3.7.3 The Joint Peak-Volume Hydrograph Procedure (JPV)

The empirical relationships between flood peak and flood volume, on a conditional basis, have been researched and this new approach is called the Joint Peak-Volume (JPV) Design Flood Hydrograph Methodology ^(3.55). The objective of the JPV approach was to provide the design flood hydrology practitioner with modernised procedures and tools that link the empirical frequency of flood volume exceedence to flood peak magnitude in a regional context. This enables the designer to determine on a regionally pooled basis, for any given design flood peak, the exceedence frequency of any design flood hydrograph volume, regardless of the methodology used to estimate the flood peak. JPV method supersedes the Run Hydrograph method.

From primary stage records provided by the DWAF, 139 flow-gauging stations, as well as the inflowing flood peaks and volumes for more than 80 dams across South Africa were appropriately standardised to facilitate examination in various alternative regionally pooled groupings. In total 12 000+ joint peak-volume (JPV) pairs and 9 000+ flood hydrographs were extracted

For analysis purposes the joint peak-volume data pairs, as well as typical standardised observed flood hydrographs, were organised in "pooling-groups" according to two alternative regionalisation schemas that are well-established in South African design flood practice. These are the Veld Type Zones proposed in HRU ^(3.25) and the K-Value regions for the Regional Maximum Flood approach proposed by Kovačs ^(3.11).

Exceedence percentiles of "standardised volumes conditional on standardised on a peak over-threshold (POT) peaks" were derived for each of the regional pooling options. The locus of each of these exceedence percentiles in joint peak-volume space displayed a fundamentally linear character. Therefore, the JPV design tools developed include, inter alia, a set of linear functions that describe the exceedence relationships of standardised flood volumes conditional on standardised POT flood peaks for two alternative sets of regionally pooled catchments.

The JPV approach also includes a regional pooling method that allows the estimation of design flood peaks and volumes at ungauged sites for any given RI, based either on the two sets of large-scale pooling-groups outlined earlier, or on customised localised groupings of "hydrologically similar" catchments. These two pooling approaches were called "wide pooling" and "narrow pooling", respectively.

3.8 REFERENCES

- 3.1 Alexander, W.J.R. (2001). *Flood Risk Reduction Measures incorporating Flood Hydrology for Southern Africa*. S.A. National Committee on Large Dams. Pretoria.
- 3.2 Todd, D.K. (1974). Lecture notes. University of California.
- 3.3 Schaake, J.C., Geyer, J.C. and Knapp, J.W. (1967). *Experimental Examination of the Rational Method*. Journal of the Hydrology Division, Volume 93, No HY6.
- 3.4 Riggs, H.C. (1961). *Frequency of Natural Events*. Journal of the Hydrology Division, Volume 87, No HY1.
- 3.5 Directorate of Water Affairs. *Standard calculation forms*. Pretoria.
- 3.6 Acocks, J.P.H. (1953). *Veld Types of South Africa*. Botanical Research Institute. Department of Agriculture. Pretoria.
- 3.7 Hydrological Research Unit. (1979). *Design flood determination in South Africa*. Report 1/72. Original edition in 1972. University of Witwatersrand. Johannesburg.

- 3.8 Weather Bureau. *Climate of South Africa*. Weather Bureau 22 Part 4, Dept of Trans. Pretoria.
- 3.9 Van Heerden, W.M. (1978). *Standaard intensiteitskrommes vir reënval van kort duurtes*. Siviele Ingenieurswese in Suid-Afrika, Volume 20, No 10.
- 3.10 Pitman, W.V. and Midgley, D.C. (1971). *Amendments to design flood manual HRU 4/69*. Report No 1/71, University of Witwatersrand. Johannesburg.
- 3.11 Kovács, Z.P. (1980). *Maximum flood peak discharges in South Africa: An empirical approach*. Technical report No 105. Department of Water Affairs and Forestry.
- 3.12 Francou, T. Rodier, J.A. (1967). *Essai de classification des crues maximales*. Proceedings of the Leningrad Symposium on floods and their computation, UNESCO.
- 3.13 Kovács, Z.P. (1988). *Regional maximum flood peaks in southern Africa*. Technical report No 137. Department of Water Affairs and Forestry.
- 3.14 Alexander, W.J.R. (2002). *The standard design flood*. Journal of the South African Institution of Civil Engineering. Volume 44, No 1. SAICE.
- 3.15 Adamson, P.T. (1981). *Southern African Storm Rainfall*. Department of Water Affairs and Forestry. Technical Report No. TR102. Pretoria.
- 3.16 US Department of Agriculture, Soil Conservation Service. (1972). *National Engineering Handbook – Hydrology*. Washington DC.
- 3.17 Schulze, R.E. and Arnold, H. (1979). *Estimation of Volume and Rate of Runoff in Small Catchments in South Africa*. ACRU Report No. 8, Department of Agricultural Engineering, University of Natal, Pietermaritzburg, RSA .
- 3.18 Smithers, J.C. and Schulze, R.E. (2000). *Development and evaluation of techniques for estimating short duration design rainfall in South Africa*. WRC Report No 681/1/00. Pretoria.
- 3.19 Schulze, R.E. (1980). *Potential flood producing rainfall of medium and long duration in Southern Africa*. Water Research Commission of South Africa.
- 3.20 Hiemstra, L.A.V. and Francis, D.M. (1979). *The Run Hydrograph*. Theory and application for flood prediction. University of Natal, Pietermaritzburg.
- 3.21 Midgley, D.C., Pitman, WV and Middleton, B.J. (1990). *Surface Water Resources of Southern Africa*. WRC Report No 298/1.1/94. Water Research Commission. Pretoria.
- 3.22 Department of Water Affairs. Internet website <http://www.dwa.gov.za>.
- 3.23 Alexander, W.J.R. (1976). *Flood frequency estimation methods*. Technical note 65. Department of Water Affairs and Forestry.
- 3.24 Campbell G.V., Ward, A.D. and Middleton, B.J. (1987). *An evaluation of hydrological techniques for making flood estimations on small ungauged catchments*. WRC Report No. 139/2/87. Water Research Commission. Pretoria.
- 3.25 Hydrological Research Unit. (1978). *A Depth-Duration-Frequency Diagram for Point Rainfall in southern Africa*. Report 2/78. University of Witwatersrand. Johannesburg.
- 3.26 Petras V. and Du Plessis P.H. (1987). *Catalogue of hydrological catchment parameters*. Department of Water Affairs and Forestry. Division of Hydrology. Technical Note No 6.

- 3.27 Schulze, B.R. (1965). *Climate of SA. Part 8: General survey (WB28)*. SAWB, Pretoria.
- 3.28 Weather Bureau. (1992). *Climate tables of South Africa (WB42)*. SAWB, Pretoria.
- 3.29 Lynch, S.D. (2004). *Development of a raster database of annual, monthly and daily rainfall for southern Africa*. WRC Report No. 1156/1/04. Water Research Commission. Pretoria.
- 3.30 Schulze, R.E. (1997). *South African Atlas of Agrohydrology and Climatology*. WRC Report No. TT 82/96. Water Research Commission, Pretoria.
- 3.31 Schulze, R.E., Schmidt, E.J. and Smithers, J.C. (2004). *Visual SCS-SA User Manual (Version 1.0)*. ACRUcons Report No. 52. UKZN, Pietermaritzburg.
- 3.32 Van Vuuren, S.J. (2012). *Influence of Catchment Development on Peak Urban Runoff*. WRC Report No. 1752/1/12. Water Research Commission, Pretoria.
- 3.33 Bouwer, H. (1986). *Intake rate: Cylinder infiltrometer*. In: Klute, A. (Ed.), *Methods of soil analysis, Part 1: Physical and mineralogical methods*. ASA, Madison, USA.
- 3.34 Dent, M.C., Schulze, R.E. and Angus, G.R. (1988). *An analysis of regional crop water requirements for irrigation planning in southern Africa*. ACRU Report, 28, Department of Agricultural Engineering, University of Natal, Pietermaritzburg, RSA.
- 3.35 Dunsmore, S.J., Schmidt, E.J. and Schulze, R.E. (1986). *Antecedent soil moisture in design runoff volume estimation*. WRC Report No. 155/1/86, Water Research Commission, Pretoria, RSA.
- 3.36 Kunz, R.P. (2004). *Daily Rainfall Data Extraction Utility: User Manual v 1.0*, Institute for Commercial Forestry Research, Pietermaritzburg, RSA.
- 3.37 Macvicar, C.N., de Villiers, J.M., Loxton, R.F., Verster, E., Lamprechts, J.J.N., Merryweather, F.R., le Roux, J., van Rooyen, T.H., Harmse and H.J.v.M. (1977). *Soil Classification - a Binomial System for South Africa*, Department of Agricultural Technical Services, Pretoria, RSA.
- 3.38 Schmidt, E.J. and Schulze, R.E. (1984). *Improved estimates of peak flow rates using modified SCS lag equations*. WRC Report No. 63/1/84, Water Research Commission, Pretoria, RSA.
- 3.39 Schmidt, E.J. and Schulze, R.E. (1987a). *Flood volume and peak discharge from small catchments in Southern Africa based on the SCS technique*. WRC Report TT 31/87, Water Research Commission, Pretoria, RSA.
- 3.40 Schmidt, E.J. and Schulze, R.E. (1987b). *User manual for SCS-based design runoff estimation in Southern Africa*. WRC Report TT 31/87, Water Research Commission, Pretoria, RSA.
- 3.41 Schmidt, E.J., Schulze, R.E. and Dent, M.C. (1987). *Flood volume and peak discharge from small catchments in Southern Africa based on the SCS technique: Appendices*. WRC Report TT 31/87, Water Research Commission, Pretoria, RSA.
- 3.42 Schulze, R.E. (1982). *Adapting the SCS stormflow equation for application to specific events by soil moisture budgeting*. ACRU Report No. 15, Department of Agricultural Engineering, University of Natal, Pietermaritzburg, RSA.
- 3.43 Schulze, R.E. (1989). *ACRU: Background, concepts and theory*. WRC Report 154/1/89, Water Research Commission, Pretoria, South Africa.

- 3.44 Schulze, R.E., Angus, G.R. and Guy, R.M., (1991). *Making the most of soils information: A hydrological interpretation of southern African soil classifications and data bases*, 5th South African National Hydrological Symposium. SANCIAHS, Stellenbosch, South Africa, pp. 3B-2-1 to 3B-2-12.
- 3.45 Schulze, R.E., Schmidt, E.J. and Smithers, J.C. (1992). *PC-Based SCS design flood estimates for small catchments in southern Africa*. ACRU Report 40, Department of Agricultural Engineering, University of Natal, Pietermaritzburg, RSA.
- 3.46 Schulze, R.E., Schmidt, E.J. and Smithers, J.C. (2004). *Visual SCS-SA User Manual (Version 1.0)*. ACRUcons Report No. 52, School of Bioresources Engineering and Environmental Hydrology, University of KwaZulu-Natal, Pietermaritzburg, RSA.
- 3.47 SCWG. (1991). *Soil classification - a taxonomic system for South Africa*. Soil Classification Working Group, Soils and Irrigation Research Institute, Agricultural Research Council, Pretoria, RSA
- 3.48 Smithers, J.C. and Schulze, R.E. (2003). *Design rainfall and flood estimation in South Africa*. WRC Report No. 1060/01/03, Water Research Commission, Pretoria, RSA.
- 3.49 Sobhani, G. (1976). *A review of selected watershed design methods for possible adaptation to Iranian conditions*. Unpublished M.Sc. Thesis, Utah State University, Logan, Utah, USA.
- 3.50 USDA. (1972). *National Engineering Handbook*. Section 4: Hydrology. Soil Conservation Service, United States Department of Agriculture, Washington, DC, USA.
- 3.51 Weddepohl, J.P. (1988). *Design rainfall distributions for Southern Africa*. Unpublished MSc. Dissertation Thesis, University of Natal, Pietermaritzburg, South Africa.
- 3.52 Schulze, R.E., George, W.J., Arnold, H., Mitchell, J.K. (1984). *The coefficient of initial abstraction in the SCS model as a variable* (Chapter 4). In: Schulze, R.E. (Ed.), *Hydrological models for Application to Small Rural Catchments in Southern Africa: Refinements and Development*. Water Research Commission, Pretoria, RSA, pp. 52-81.
- 3.53 Nortje, J.H. (2010). *Estimation of Extreme Flood Peaks by Selective Statistical Analyses of Relevant Flood Peak Data within Similar Hydrological Regions*. Journal of SA Institution of Civil Engineering, 52(2): 48-57, South Africa.
- 3.54 Nortje, J.H. (2012). *Upper Bound Estimation of Extreme Flood Peaks by Statistical Analyses of Regional Record Maximum Flood Peaks*. 24th ICOLD Congress, Kyoto, Japan.
- 3.55 Görgens, A. (2007). *Joint Peak-Volume (JPV) design flood hydrographs for South Africa*. WRC Report No. 1420/3/07, Water Research Commission, Pretoria, South Africa.
- 3.56 Gericke, O.J. and Du Plessis, J.A. (2012). *Evaluation of the standard design flood method in selected basins in South Africa*. Journal of SA Institution of Civil Engineering, 54(2): 2-14, South Africa.
- 3.57 Gericke, O.J. and Du Plessis, J.A. (2012). *Catchment parameter analysis in flood hydrology using GIS applications*. Journal of SA Institution of Civil Engineering, 54(2): 15-26, South Africa.

- Notes:

Lined area for handwritten notes or calculations.

APPENDIX 3A STATISTICAL ANALYSIS

SINGLE STATION DIRECT STATISTICAL ANALYSIS

The following frequency distributions are discussed for untransformed and \log_{10} -transformed data:

- **Untransformed data**
Normal, Extreme Value Type I and General Extreme Value
- **\log_{10} -transformed data**
Log-Normal, Log-Gumbel and Log-Pearson Type III

Step 1: Determine the mean, standard deviation and skewness coefficient of the raw data and the \log_{10} transformed data as follows:

$$\text{Mean} \quad \bar{x} = \frac{\sum x}{N} \quad \dots(3A.1)$$

$$\text{Standard deviation} \quad s = \left[\frac{\sum (x - \bar{x})^2}{N - 1} \right]^{0.5} \quad \dots(3A.2)$$

$$\text{Skewness coefficient} \quad g = \left(\frac{N}{(N-1)(N-2)} \right) \left(\frac{\sum (x - \bar{x})^3}{s^3} \right) \quad \dots(3A.3)$$

$$\text{Coefficient of variation} \quad c_v = \frac{s}{\bar{x}} \quad \dots(3A.4)$$

where:

- x = observed value (or of the logarithm of the observed value for the log distributions)
- \bar{x} = mean of observed values (or of the logarithm of the observed value for the log distributions)
- N = the total number of observations
- s = the standard deviation of the observed values (or of the logarithm of the observed values)
- g = skewness coefficient
- c_v = coefficient of variation

Step 2: The peak value for the desired return period and assumed distribution function can be derived for each of the frequency distributions as follows:

- **Normal distribution**

The normal distribution is applicable where the observed values represent the effects of a large number of independent processes. The distribution is symmetrical about the mean and is therefore only suitable for data where the skewness coefficient (g) is equal to, or close to zero. The spread about the mean is a function of the coefficient of variation, Alexander^(3.1). For high coefficient of variation values, the bottom tail may extend below zero and may result in negative flows being generated when the distribution is applied to untransformed data.

The standardized normal distribution has a cumulative distribution function:

$$G(y) = \int_{-\infty}^y \frac{1}{\sqrt{2\pi}} e^{-0.5[y^2]} dy \quad \dots(3A.5)$$

where y is the standardized variable and is related to x by:

$$y = \frac{(x - \bar{x})}{s} \quad \dots(3A.6)$$

The value of y for a given value of $G(y)$ cannot be solved directly from Equation 3A.4, and hence published tables have to be used. Based on the return period, read from **Table 3A.1b** the value of $G(y)$ and obtain y from **Table 3A.1a**.

$$Q_T = \bar{x} + sy \quad \dots(3A.7)$$

- **Extreme Value Type 1 (EV1/MM) distribution**

From **Table 3A.4** ($g = 1,14$) read the value of W_T for the required return period. Calculate Q_T directly using:

$$Q_T = \bar{x} + s(0,780W_T - 0,450) \quad \dots(3A.8)$$

- **General Extreme Value (GEV/MM) distribution**

For the known value of the skewness coefficient (g) read off the value W_T from **Table 3A.4** and the values of k , $E(y)$ and $\text{var}(y)$ from **Table 3A.2** by using linear interpolation.

For EV2 distribution:

$$Q_T = \bar{x} + \sqrt{\frac{s^2}{\text{var}(y)}} (1 - E(y) - kW_T) \quad \dots(3A.9)$$

For EV3 distribution:

$$Q_T = \bar{x} + \sqrt{\frac{s^2}{\text{var}(y)}} (-1 - E(y) + kW_T) \quad \dots(3A.10)$$

- **Log-normal (LN/MM) distribution**

For this distribution, the logarithms of the data are assumed to be normally distributed. Based on the skewness coefficient (g), obtain the value W_T for the required return period from **Table 3A.3**.

$$Q_T = \text{antilog}[\overline{\log(x)} + s_{\log} W_T] \quad \dots(3A.11)$$

where:

s_{\log} = the standard deviation of the logarithms of the observed values as shown in equation 3A.11

$$s_{\log} = \left[\frac{\sum (\log(x) - \overline{\log(x)})^2}{N - 1} \right]^{0,5} \quad \dots(3A.12)$$

and

$\overline{\log(x)}$ = the logarithm of the mean of the observed values

Confidence bands

The confidence, with which the values of the magnitude-return period relationships are estimated, depends on the number of observations contained in the data set. The greater the number of observations, the greater the degree of assurance, and subsequently the narrower the confidence band ^(3.1). The displacement of the two-sided 95% confidence band about the estimated value can be read from **Table 3A.3** where N is the number of observations. The 95% confidence limits are:

$$Q_{T(95\%)} = \text{antilog}[\overline{\log(x)} + s_{\log} (W_T \pm W_{\alpha})] \quad \dots(3A.13)$$

where:

W_α = displacement of the confidence band (column 5 in **Table 3A.3**)

- **Log-Gumbel (Log-Extreme Value Type 1) (LEV1/MM) distribution**

From **Table 3A.4** ($g = 1,14$) read the value of W_T for the required return period. Calculate Q_T directly using:

$$Q_T = \text{antilog}[\overline{\log(x)} + s_{\log} (0,780W_T - 0,450)] \quad \dots(3A.14)$$

- **Log-Pearson Type III (LP3/MM) distribution**

From **Table 3A.3** determine the value of W_T for the known skewness coefficient (g) of the log-transformed data by linear interpolation.

$$Q_T = \text{antilog}[\overline{\log(x)} + s_{\log} W_T] \quad \dots(3A.15)$$

Based on an example from *Flood Risk Reduction Measures* by WJR Alexander^(3.1) the incorporation of the influence of historical information, missing data and outliers is required to determine the confidence of the results.

It is thus required to calculate the historically weighted mean (\bar{x}_h), standard deviation (s_h) and skewness coefficient (g_h).

$$\bar{x}_h = \frac{((WT)\sum x_b + \sum x_a)}{(YT - (WT)(LW))} \quad \dots(3A.16)$$

$$s_h = \left[\frac{((WT)\sum d_b^2 + \sum d_a^2)}{(YT - (WT)(LW) - 1)} \right]^{0,5} \quad \dots(3A.17)$$

$$g_h = \left[\frac{(YT - (WT)(LW))((WT)\sum d_b^3 + \sum d_a^3)}{s_h^3 (YT - (LW)(WT) - 1)(YT - (WT)(LW) - 2)} \right] \quad \dots(3A.18)$$

where:

YT = total time span (= NA + NB + NC)
 WT = weight applied to data = (YT - NA) / NB
 NA = floods equal to or above the high threshold
 NB = floods between high and low thresholds
 NC = missing data
 LW = low outliers including zero flows
 ZR = zero flows

and where: x_a = is the value of a peak equal to or above the high threshold
 x_b = is the value of a peak below the high threshold
 d_a and d_b = are deviations of $x_a + x_b$ from \bar{x}_h

All values being the logarithms of the data.

These historically weighted values of the mean, standard deviation and the skewness coefficient are then used in the equations for the LN/MM, LP3/MM, EV1/MM and GEV/MM distribution in the usual way^(3.1).

For a detailed description of the adjustment required when:

- low outliers are removed from the data;
- gauged zero flows exist; or
- how to handle missing data;

see *Flood Risk Reduction Measures* by Alexander ^(3.1).

Step 3: Graphical representation of historical data

Arrange the observed data in descending order of magnitude and assign to each value a rank number starting from one. Determine the plotting position (return period) for each value using the Weibull formula. The general equation is given below and the values for the constants a and b are provided in **Table 3A.7**.

$$T = \frac{n + a}{m - b} \quad \dots (3A.19)$$

where:

T	=	return period in years
n	=	length of record in years
m	=	number, in descending order, of the ranked annual peak floods
a	=	constant (see Table 3A.7)
b	=	constant (see Table 3A.7)

If the horizontal axis has a probability classification, the probability (P) is calculated as:

$$P = \frac{1}{T} \quad \dots (3A.20)$$

Some of the commonly used plotting positions recommended for use in hydrological analyses are given in **Table 3A.7**. If several distributions are plotted on a single graph, then the general purpose Cunane plotting position should be used.

Table 3A.7: Commonly used plotting positions ^(3.1)

Type	Plotting position	Distribution
Weibull (1939)	$a = 1$ & $b = 0$	Normal, Pearson 3
Blom (1958)	$a = 0,25$ & $b = 0,375$	Normal
Gringorten (1963)	$a = 0,12$ & $b = 0,44$	Exponential, EV1 & GEV
Cunane (1978) average of above two	$a = 0,2$ & $b = 0,4$	General purpose
Beard (1962)	$a = 0,4$ & $b = 0,3$	Pearson 3
Greenwood (1979)	$a = 0$ & $b = 0,35$	Wakeby, GEV

Plot the values against their estimated return periods on log-probability paper; draw the best fitting straight line through the plotted points and extrapolate to determine the estimated maximum value for the required return period.

Table 3A.1: Properties of the standardized normal distribution

Table 3A.1a

Standardized normal distribution			
y	G(y)%		G(y)%
0,00	50,00	-0,00	50,00
0,05	51,99	-0,05	48,01
0,10	53,98	-0,10	46,02
0,15	55,96	-0,15	44,04
0,20	57,93	-0,20	42,07
0,25	59,87	-0,25	40,13
0,30	61,79	-0,30	38,21
0,35	63,68	-0,35	36,32
0,40	65,54	-0,40	34,46
0,45	67,36	-0,45	32,64
0,50	69,14	-0,50	30,86
0,55	70,88	-0,55	29,12
0,60	72,57	-0,60	27,43
0,65	74,22	-0,65	25,78
0,70	75,81	-0,70	24,19
0,75	77,34	-0,75	22,66
0,80	78,81	-0,80	21,19
0,85	80,24	-0,85	19,76
0,90	81,59	-0,90	18,41
0,95	82,89	-0,95	17,11
1,00	84,13	-1,00	15,87
1,05	85,31	-1,05	14,69
1,10	86,43	-1,10	13,57
1,15	87,49	-1,15	12,51
1,20	88,49	-1,20	11,51
1,25	89,44	-1,25	10,56
1,30	90,32	-1,30	9,68
1,35	91,15	-1,35	8,85
1,40	91,26	-1,40	8,08
1,45	92,65	-1,45	7,35
1,50	93,32	-1,50	6,68
1,55	93,94	-1,55	6,06
1,60	94,52	-1,60	5,48
1,65	95,05	-1,65	4,95
1,70	95,54	-1,70	4,46
1,75	95,99	-1,75	4,01
1,80	96,41	-1,80	3,59
1,85	96,78	-1,85	3,22
1,90	97,13	-1,90	2,87
1,95	97,44	-1,95	2,56
2,00	97,72	-2,00	2,28
2,05	97,98	-2,05	2,02
2,10	98,21	-2,10	1,79
2,15	98,43	-2,15	1,57
2,20	98,61	-2,20	1,39
2,25	98,78	-2,25	1,22
2,30	98,93	-2,30	1,07
2,35	99,06	-2,35	0,94
2,40	99,18	-2,40	0,82
2,45	99,29	-2,45	0,71
2,50	99,38	-2,50	0,62
2,55	99,46	-2,55	0,54
2,60	99,53	-2,60	0,47
2,65	99,60	-2,65	0,40
2,70	99,65	-2,70	0,35
2,75	99,70	-2,75	0,30
2,80	99,74	-2,80	0,26
2,85	99,78	-2,85	0,22
2,90	99,81	-2,90	0,19
2,95	99,84	-2,95	0,16
3,00	99,86	-3,00	0,14
3,05	99,88	-3,05	0,16
3,10	99,90	-3,10	0,10
3,15	99,92	-3,15	0,08
3,20	99,93	-3,20	0,07
3,25	99,94	-3,25	0,06
3,30	99,95	-3,30	0,05
3,35	99,96	-3,35	0,04
3,40	99,97	-3,40	0,03
3,45	99,97	-3,45	0,03
3,50	99,98	-3,50	0,02
3,55	99,98	-3,55	0,02
3,60	99,98	-3,60	0,02
3,65	99,99	-3,65	0,01
3,70	99,99	-3,70	0,01
3,75	99,99	-3,75	0,01

Table 3A.1b

Standardized normal distribution		
T	G(y)%	W _T
1000	0,1	-3,09
500	0,2	-2,88
200	0,5	-2,58
100	1,0	-2,33
50	2,0	-2,05
20	5,0	-1,64
10	10,0	-1,28
5	20,0	-0,84
2	50,0	0,00
5	80,0	0,84
10	90,0	1,28
20	95,0	1,64
50	98,0	2,05
100	99,0	2,33
200	99,5	2,58
500	99,8	2,88
1000	99,9	3,09
5000	99,98	3,55
10000	99,99	3,72

Table 3A.2: Parameters of the standardized general extreme value distribution

Standardized general extreme value distribution			
g	k	E(y)	var(y)
-2,000	1,406	-1,247	3,204
-1,900	1,321	-1,182	2,505
-1,800	1,240	-1,127	1,984
-1,700	1,163	-1,080	1,590
-1,600	1,089	-1,041	1,287
-1,500	1,018	-1,008	1,052
-1,400	0,950	-0,980	0,868
-1,300	0,885	-0,957	0,721
-1,200	0,824	-0,938	0,602
-1,100	0,765	-0,922	0,507
-1,000	0,708	-0,910	0,428
-0,900	0,655	-0,901	0,362
-0,800	0,604	-0,894	0,307
-0,700	0,555	-0,889	0,261
-0,600	0,509	-0,887	0,222
-0,500	0,465	-0,886	0,188
-0,400	0,424	-0,886	0,159
-0,300	0,384	-0,888	0,134
-0,200	0,346	-0,892	0,112
-0,100	0,311	-0,896	0,094
0,000	0,277	-0,901	0,077
0,100	0,245	-0,907	0,063
0,200	0,215	-0,914	0,050
0,300	0,187	-0,922	0,039
0,400	0,160	-0,930	0,030
0,500	0,134	-0,938	0,022
0,600	0,110	-0,947	0,016
0,700	0,088	-0,956	0,010
0,800	0,067	-0,966	0,006
0,900	0,047	-0,975	0,003
1,000	0,028	-0,985	0,001
1,100	0,010	-0,994	0,000
1,200	-0,006	1,004	0,000
1,300	-0,022	1,013	0,001
1,400	-0,037	1,023	0,002
1,500	-0,050	1,032	0,005
1,600	-0,063	1,041	0,008
1,700	-0,075	1,049	0,011
1,800	-0,086	1,058	0,016
1,900	-0,097	1,066	0,021
2,000	-0,107	1,074	0,026
2,100	-0,116	1,082	0,032
2,200	-0,125	1,089	0,038
2,300	-0,133	1,097	0,044
2,400	-0,140	1,104	0,051
2,500	-0,148	1,110	0,058
2,600	-0,154	1,116	0,065
2,700	-0,160	1,123	0,072
2,800	-0,166	1,128	0,080
2,900	-0,172	1,134	0,087
3,000	-0,177	1,139	0,094
3,100	-0,182	1,145	0,102
3,200	-0,187	1,150	0,110
3,300	-0,191	1,154	0,117
3,400	-0,195	1,159	0,125
3,500	-0,199	1,163	0,132
3,600	-0,203	1,168	0,140
3,700	-0,207	1,172	0,148
3,800	-0,210	1,176	0,155
3,900	-0,213	1,180	0,163
4,000	-0,217	1,183	0,170
4,100	-0,220	1,187	0,178
4,200	-0,223	1,191	0,186
4,300	-0,225	1,194	0,193
4,400	-0,228	1,197	0,201
4,500	-0,231	1,201	0,208
4,600	-0,233	1,204	0,215
4,700	-0,236	1,207	0,223
4,800	-0,238	1,210	0,230
4,900	-0,240	1,213	0,237
5,000	-0,242	1,215	0,244

Table 3A.3a: Values of the standardized variate W_T for the normal and exponential distributions

Return period (years)	Non-exceedance probability	Normal distribution			Exponential distribution
		W _T	Confidence limits W _α		
			75%	95%	
2	0,50	0,00	1,63/√2N	2,77/√2N	0,69
5	0,80	0,84	1,89/√2N	3,23/√2N	1,61
10	0,90	1,28	2,20/√2N	3,74/√2N	2,30
20	0,95	1,64	2,49/√2N	4,25/√2N	3,00
50	0,98	2,05	2,87/√2N	4,89/√2N	3,91
100	0,99	2,33	3,13/√2N	5,34/√2N	4,61
200	0,995	2,58	3,38/√2N	5,76/√2N	5,30
500	0,998	2,88	3,69/√2N	6,27/√2N	6,21
1000	0,999	3,09	3,91/√2N	6,66/√2N	6,91
10000	0,9999	3,72	4,58/√2N	7,80/√2N	9,21

Table 3A.3b: Values of the standardized variate W_T for the Pearson Type III distribution

Return period (years)	Pearson Type III distribution (Values of W_T)										
	g										
	-1,0	-0,8	-0,6	-0,4	-0,2	0,0	0,2	0,4	0,6	0,8	1,0
2	0,16	0,13	0,10	0,07	0,03	0,00	-0,03	-0,70	-0,10	-0,13	-0,16
5	0,85	0,87	0,86	0,86	0,85	0,84	0,83	0,82	0,80	0,78	0,76
10	1,13	1,17	1,20	1,23	1,26	1,28	1,30	1,32	1,33	1,34	1,34
20	1,32	1,39	1,46	1,52	1,59	1,64	1,70	1,75	1,80	1,84	1,88
50	1,49	1,61	1,72	1,83	1,94	2,05	2,16	2,26	2,36	2,45	2,54
100	1,59	1,73	1,88	2,03	2,18	2,33	2,47	2,62	2,76	2,89	3,02
200	1,66	1,84	2,02	2,20	2,39	2,58	2,76	2,95	3,13	3,31	3,49
500						2,88					
1000	1,79	2,02	2,27	2,53	2,81	3,09	3,38	3,67	3,96	4,24	4,53
10000	1,88	2,18	2,53	2,90	3,30	3,72	4,15	4,60	5,05	5,50	5,96

Table 3A.4a: Values of the standardized variate W_T for the general extreme value distribution (EV1 & EV2)

Return period (years)	General extreme value (Values of W_T)													
	g													
	1,14	1,2	1,4	1,6	1,8	2,0	2,5	3,0	3,5	4,0	4,5	5,0	5,5	6,0
	EV1	EV2												
2	0,37	0,37	0,37	0,37	0,37	0,37	0,38	0,38	0,38	0,38	0,38	0,38	0,38	0,38
5	1,50	1,51	1,55	1,58	1,60	1,63	1,68	1,72	1,75	1,77	1,79	1,80	1,82	1,83
10	2,25	2,28	2,35	2,43	2,49	2,55	2,67	2,76	2,84	2,90	2,94	2,98	3,01	3,04
20	2,97	3,01	3,15	3,28	3,40	3,50	3,73	3,91	4,05	4,16	4,25	4,33	4,39	4,45
50	3,90	3,97	4,22	4,45	4,66	4,86	5,28	5,62	5,89	6,12	6,30	6,46	6,59	6,70
100	4,60	4,71	5,05	5,38	5,68	5,97	6,59	7,10	7,52	7,86	8,15	8,39	8,59	8,77
200	5,30	5,44	5,90	6,34	6,76	7,16	8,04	8,77	9,38	9,89	10,31	10,67	10,97	11,24
500	6,21	6,41	7,05	7,68	8,29	8,87	10,19	11,32	12,26	13,06	13,74	14,32	14,81	15,24
1000	6,91	7,15	7,95	8,75	9,53	10,29	12,02	13,53	14,82	15,92	16,86	17,66	18,36	18,96
10000	9,21	9,64	11,13	12,68	14,25	15,82	19,65	23,19	26,34	29,13	31,58	33,73	35,63	37,31

Table 3A.4b: Values of the standardized variate W_T for the general extreme value distribution (EV3)

Return period (years)	General extreme value (Values of W_T)										
	g										
	-1,0	-0,8	-0,6	-0,4	-0,2	0,0	0,2	0,4	0,6	0,8	1,0
	EV3										
2		0,33	0,34	0,34	0,34	0,35	0,35	0,36	0,36	0,36	0,37
5		1,01	1,06	1,12	1,17	1,23	1,28	1,33	1,38	1,43	1,47
10		1,28	1,37	1,46	1,57	1,67	1,78	1,89	2,00	2,10	2,19
20		1,44	1,57	1,71	1,86	2,02	2,19	2,37	2,54	2,71	2,86
50		1,58	1,74	1,93	2,15	2,38	2,64	2,90	3,18	3,45	3,72
100		1,64	1,83	2,05	2,31	2,60	2,92	3,26	3,62	3,99	4,35
200		1,68	1,89	2,14	2,44	2,77	3,16	3,58	4,02	4,49	4,97
500		1,72	1,95	2,23	2,56	2,96	3,42	3,94	4,51	5,13	5,76
1000		1,74	1,98	2,27	2,64	3,07	3,59	4,19	4,86	5,58	6,35
10000		1,76	2,02	2,36	2,78	3,32	4,00	4,83	5,81	6,96	8,24

APPENDIX 3B STANDARD DESIGN FLOOD METHOD

Table 3B.1: Information required for the calculation of the SDF

Basin	SAWS station number	SAWS site	M (mm)	R (days)	C ₂ (%)	C ₁₀₀ (%)	MAP (mm)	MAE (mm)
1	546 204	Struan	56	30	10	40	550	1800
2	675 125	Autoriteit	62	44	5	30	450	1900
3	760 324	Siloam	64	28	5	40	470	1700
4	553 351	Waterval	58	20	10	50	630	1600
5	680 059	Leydsdorp	78	10	15	70	620	1700
6	369 030	Siloam	51	54	15	60	670	1500
7	328 726	Olivine	49	39	15	60	510	1700
8	322 071	Danielskuil	47	39	5	20	380	2100
9	258 452	Jacobsdal	43	47	15	60	380	1800
10	233 049	Wonderboom	54	55	10	50	560	1600
11	236 521	Mashai	39	66	40	80	430	1400
12	143 258	Scheurfontein	39	52	5	30	290	2100
13	284 361	Wilgenhoutsdrif	40	55	5	15	70	2600
14	110 385	Middelpos	25	13	10	30	140	2400
15	157 874	Garies	22	11	5	20	130	2100
16	160 807	Loeriesfontein	28	11	10	40	210	1900
17	84 558	Elandspoort	45	1	40	80	500	1500
18	22 113	La Motte	59	4	30	60	810	1400
19	69 483	Letjiesbos	34	16	10	35	160	2200
20	34 762	Uitenhage	53	12	15	60	480	1600
21	76 884	Albertvale	45	23	10	35	460	1700
22	80 569	Umzoniana	84	26	15	60	820	1200
23	180 439	Insizwa	60	45	10	80	890	1200
24	240 269	Newlands	76	15	15	80	910	1200
25	239 138	Whitson	55	9	10	80	830	1200
26	336 283	Nqutu	61	17	15	50	760	1500
27	339 415	Hill Farm	85	17	30	80	890	1400
28	483 193	Maliba Ranch	75	54	15	60	740	1400
29	556 088	Mayfern	66	11	15	50	740	1600

Table 3B.2: Daily rainfall from TR102

Basin number	Station number	Name	Latitude	Longitude	Years of record	Mean annual rainfall (mm)	Duration (days)	Minimum annual recorded	Maximum annual recorded	Maxima for return periods (years for the duration) (mm)						
										2	5	10	20	50	100	200
1	546204	STRUAN	25°24'	26°07'	48	549	1	23	111	56	80	99	119	150	177	206
							2	32	155	71	105	132	161	205	243	286
							3	42	216	80	117	146	177	224	263	308
							7	42	284	102	154	196	242	310	369	435
2	675125	AUTORITEIT	23°35'	28°05'	45	452	1	24	178	62	93	117	145	187	223	264
							2	32	216	74	111	140	173	222	265	313
							3	32	254	80	122	156	193	250	300	355
							7	37	254	94	144	183	225	289	344	405
3	766324	SILOAM	22°54'	30°11'	46	472	1	25	188	64	95	119	146	187	222	262
							2	32	268	76	112	142	174	221	263	309
							3	33	329	84	129	165	205	266	319	378
							7	36	381	103	165	215	271	356	432	517
4	553351	WATERVAL	25°21'	29°42'	51	627	1	36	100	58	76	89	102	122	138	155
							2	40	140	69	90	106	123	146	165	185
							3	45	140	76	99	115	132	156	175	195
							7	53	184	98	131	154	178	211	238	266
5	680059	LEYSDORP	23°59'	30°22'	45	625	1	23	195	78	116	146	181	233	279	331
							2	23	330	99	156	203	257	341	416	503
							3	27	357	105	165	215	271	358	435	524
							7	27	377	135	225	301	389	528	653	798
6	369030	SYLVAN	28°00'	29°01'	44	668	1	37	92	51	65	74	84	97	108	120
							2	42	115	64	85	99	113	133	149	166
							3	42	134	74	98	116	134	160	181	204
							7	50	145	92	121	142	164	193	217	242
7	328726	OLIVINE	28°06'	26°55'	45	507	1	22	103	49	68	82	96	118	137	157
							2	25	110	62	87	107	128	158	184	213
							3	34	119	68	94	115	136	167	193	221
							7	39	150	84	118	144	172	211	243	279
8	322071	DANIELSKUIL	28°11'	23°33'	61	377	1	11	116	47	69	86	104	132	156	183
							2	21	156	60	91	116	144	187	224	267
							3	21	186	65	100	128	160	208	250	297
							7	22	245	79	126	164	207	272	329	393
9	258458	JACOBSDAL	29°08'	24°46'	86	376	1	16	99	43	61	75	91	114	133	155
							2	20	141	54	78	98	119	151	179	210
							3	20	181	59	87	109	134	171	203	238
							7	27	239	70	104	131	160	203	240	280

Table 3B.2: Daily rainfall from TR102 (continued)

Basin number	Station number	Name	Latitude	Longitude	Years of record	Mean annual rainfall (mm)	Duration (days)	Minimum annual recorded	Maximum annual recorded	Maxima for return periods (years for the duration) (mm)						
										2	5	10	20	50	100	200
10	233049	WONDERBOOM	29°49'	27°02'	66	560	1	23	127	54	73	88	103	124	143	162
							2	37	148	66	88	105	122	146	166	188
							3	37	169	75	102	123	144	175	200	227
							7	37	238	97	140	172	206	256	298	343
11	236521	MASHAI	29°41'	28°48'	45	429	1	9	160	39	53	64	75	92	106	122
							2	15	160	47	65	79	93	113	130	149
							3	15	160	53	73	88	104	127	147	167
							7	15	160	69	97	118	141	173	199	228
12	143258	SCHEURFONTEIN	31°18'	24°09'	64	288	1	16	84	39	54	66	79	97	112	129
							2	17	116	47	67	82	99	123	143	165
							3	17	130	51	75	93	113	143	168	195
							7	26	179	62	92	116	141	179	218	245
13	284361	WILGENHOUTSDRIFT	28°31'	21°43'	40	270	1	9	117	40	59	73	90	115	135	159
							2	10	117	49	75	97	120	157	188	224
							3	10	132	52	82	106	133	175	212	250
							7	11	218	62	99	129	163	213	257	301
14	110385	MIDDELPOS	31°55'	20°13'	65	143	1	9	71	25	38	50	62	82	99	118
							2	9	71	30	49	65	84	113	139	170
							3	9	71	31	51	68	88	119	147	179
							7	10	87	34	57	76	98	131	161	196
15	157874	GARIES	30°34'	18°00'	63	130	1	5	58	22	32	39	46	57	66	76
							2	5	61	26	37	46	55	69	80	93
							3	5	61	27	40	50	61	78	92	107
							7	9	69	30	45	57	70	88	104	122
16	160807	LOERIESFONTEIN	30°57'	19°27'	47	212	1	13	66	28	39	48	57	70	81	93
							2	16	93	35	48	58	69	84	97	110
							3	16	93	37	51	63	74	91	105	120
							7	16	106	43	60	73	85	104	118	134
17	84558	ELANDSFONTEIN	32°18'	18°49'	51	498	1	26	101	45	59	69	80	96	108	122
							2	29	137	60	83	101	119	146	169	193
							3	31	149	68	96	118	141	174	202	234
							7	44	179	86	126	157	190	240	281	328
18	22113	LA MOTTE	33°53'	19°04'	58	812	1	35	180	59	77	91	105	125	142	160
							2	48	230	82	111	134	158	193	223	254
							3	50	277	93	129	155	184	225	260	297
							7	64	418	126	183	227	275	345	405	471
19	69483	LETJIESBOS	32°33'	22°17'	62	165	1	5	183	34	55	72	92	124	152	185
							2	8	200	38	64	87	112	153	190	233
							3	8	203	40	68	93	121	166	206	254
							7	8	225	45	79	110	145	202	254	315

Table 3B.2: Daily rainfall from TR102 (continued)

Basin number	Station number	Name	Latitude	Longitude	Years of record	Mean annual rainfall (mm)	Duration (days)	Minimum annual recorded	Maximum annual recorded	Maxima for return periods (years for the duration) (mm)						
										2	5	10	20	50	100	200
20	34762	UITENHAGE	33°42'	25°26'	61	475	1	22	191	53	80	103	129	170	206	248
							2	26	204	65	102	132	167	221	269	325
							3	26	204	70	110	144	182	242	296	358
							7	26	228	82	131	171	217	287	350	422
21	76884	ALBERTVALE	32°44'	26°00'	73	457	1	22	163	45	64	80	97	123	145	170
							2	23	199	56	82	102	126	161	191	225
							3	27	228	60	86	107	130	165	194	227
							7	30	256	71	104	130	158	199	234	273
22	80569	UNZONIANA	32°59'	27°49'	57	821	1	24	386	84	134	178	229	312	389	480
							2	29	638	109	182	248	326	455	576	721
							3	36	733	121	205	280	371	521	661	830
							7	39	866	140	227	302	385	523	661	830
23	180439	INSIZWA	30°49'	29°15'	63	890	1	28	124	60	80	95	111	135	154	175
							2	39	173	76	102	121	140	169	193	218
							3	44	173	85	113	134	156	187	212	240
							7	60	205	108	141	165	189	222	249	277
24	240269	NEWLANDS	29°59'	30°39'	58	912	1	34	242	76	114	145	181	235	284	340
							2	45	288	95	142	181	224	290	348	415
							3	51	314	105	154	192	235	298	354	415
							7	64	315	126	179	219	262	325	378	436
25	239138	WHITSON	29°48'	30°05'	42	829	1	36	179	55	71	83	95	113	127	143
							2	45	230	71	94	111	129	155	176	199
							3	50	245	80	108	129	150	181	207	235
							7	60	257	104	138	162	187	221	250	279
26	336283	NQUTU	28°13'	30°40'	52	760	1	28	124	61	84	102	121	150	175	202
							2	35	133	76	105	128	152	187	217	250
							3	35	148	84	117	141	168	205	237	272
							7	44	198	108	151	182	215	263	302	345
27	339415	HILL FARM	28°25'	32°14'	56	893	1	26	376	85	130	167	210	278	339	410
							2	35	395	107	167	218	277	369	453	550
							3	36	397	119	188	246	314	420	517	628
							7	39	407	143	223	290	364	480	581	698
28	483193	MILIBA RANCH	26°13'	31°37'	40	740	1	34	237	75	104	127	151	187	218	252
							2	40	281	89	126	154	185	230	268	310
							3	40	281	99	142	175	212	265	311	361
							7	58	353	122	171	209	248	305	353	405
29	556088	MAYFERN	25°28'	31°03'	46	737	1	31	333	66	93	113	135	168	196	227
							2	39	352	78	108	130	154	189	218	250
							3	44	360	89	125	153	183	227	265	306
							7	45	416	113	159	194	232	286	331	380

APPENDIX 3C
STANDARD FLOOD CALCULATION FORMS

RATIONAL METHOD (ALTERNATIVE 1)									
Description of catchment									
River detail									
Calculated by							Date		
Physical characteristics									
Size of catchment (A)				km ²		Rainfall region			
Longest watercourse (L)				km		Area distribution factors			
Average slope (S _{av})				m/m		Rural (α)		Urban (β)	
Dolomite area (D%)				%					
Mean annual precipitation (MAP)⑥				mm					
Rural①				Urban②					
Surface slope	%	Factor	C _s	Description	%	Factor	C ₂		
Wetlands and pans				Lawns					
Flat areas				Sandy, flat (<2%)					
Hilly				Sandy, steep (>7%)					
Steep areas				Heavy soil, flat (<2%)					
Total	100	-		Heavy soil, steep (>7%)					
Permeability	%	Factor	C _p	Residential areas					
Very permeable				Houses					
Permeable				Flats					
Semi-permeable				Industry					
Impermeable				Light industry					
Total	100	-		Heavy industry					
Vegetation	%	Factor	C _v	Business					
Thick bush and plantation				City centre					
Light bush and farm-lands				Suburban					
Grasslands				Streets					
No vegetation				Maximum flood					
Total	100	-		Total (C ₂)	100	-			
Time of concentration (T _C)				Notes:					
Overland flow③		Defined watercourse							
$T_C = 0,604 \left(\frac{rL}{\sqrt{S_{av}}} \right)^{0,467}$		$T_C = \left(\frac{0,87L^2}{1000S_{av}} \right)^{0,385}$							
hours		hours							
Run-off coefficient									
Return period (years), T	2	5	10	20	50	100	Max		
Run-off coefficient, C ₁ (C ₁ = C _s + C _p + C _v)									
Adjusted for dolomitic areas, C _{1D} (= C ₁ (1 - D%) + C ₁ D%(Σ(D _{factor} x C _{S%})))④									
Adjustment factor for initial saturation, F _i ⑤									
Adjusted run-off coefficient, C _{1T} (= C _{1D} x F _i)									
Combined run-off coefficient C _T (= αC _{1T} + βC ₂ + γC ₃)									
Rainfall									
Return period (years), T	2	5	10	20	50	100	Max		
Point rainfall (mm), P _T ⑥									
Point intensity (mm/hour), P _{IT} (= P _T /T _C)									
Area reduction factor (%), ARF _T ⑦									
Average intensity (mm/hour), I _T (= P _{IT} x ARF _T)									
Return period (years), T	2	5	10	20	50	100	Max		
Peak flow (m ³ /s), Q _T = $\frac{C_T I_T A}{3,6}$									

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

R1 - Page 1/2

RATIONAL METHOD (ALTERNATIVE 1)

LEGEND TABLE Rational method (Alt 1)	
ID	Reference
①	Figure 3.7 or SA Weather Services
①	Table 3C.1
②	Table 3C.2
③	Table 3C.3
④	Table 3C.4
⑤	Table 3C.5
⑥	Figure 3.8
⑦	Figure 3.25 or 3.26

Table 3C.1				
Rural (C_1)				
Component	Classification	Mean annual rainfall (mm)		
		600	600 - 900	900
Surface slope (C_s)	Wetlands and pans (<3%)	0,01	0,03	0,05
	Flat areas (3 to 10%)	0,06	0,08	0,11
	Hilly (10 to 30%)	0,12	0,16	0,20
	Steep areas (>30%)	0,22	0,26	0,30
Permeability (C_p)	Very permeable	0,03	0,04	0,05
	Permeable	0,06	0,08	0,10
	Semi-permeable	0,12	0,16	0,20
	Impermeable	0,21	0,26	0,30
Vegetation (C_v)	Thick bush and plantation	0,03	0,04	0,05
	Light bush and farm-lands	0,07	0,11	0,15
	Grasslands	0,17	0,21	0,25
	No vegetation	0,26	0,28	0,30

Table 3C.2	
Urban (C_2)	
Use	Factor
Lawns	
Sandy, flat (< 2%)	0,05 - 0,10
Sandy, steep (>7%)	0,15 - 0,20
Heavy soil, flat (< 2%)	0,13 - 0,17
Heavy soil, steep (>7%)	0,25 - 0,35
Residential areas	
Houses	0,30 - 0,50
Flats	0,50 - 0,70
Industry	
Light industry	0,50 - 0,80
Heavy industry	0,60 - 0,90
Business	
City centre	0,70 - 0,95
Suburban	0,50 - 0,70
Streets	0,70 - 0,95
Maximum flood	1,00

Table 3C.3	
Surface description	Recommended value of r
Paved areas	0,02
Clean compacted soil, no stones	0,1
Sparse grass over fairly rough surface	0,3
Medium grass cover	0,4
Thick grass cover	0,8

Table 3C.4	
Adjustment factor to C_s	
Surface slope classification	D_{factor}
Steep areas (slopes >30%)	0,50
Hilly (10 to 30%)	0,35
Flat areas (3 to 10%)	0,20
Wetlands and pans (slopes <3%)	0,10

Table 3C.5						
Return period (years)	2	5	10	20	50	100
Adjustment factor (F_t) for steep and impermeable catchments	0,75	0,80	0,85	0,90	0,95	1,00
Adjustment factor (F_t) for flat and permeable catchments	0,50	0,55	0,60	0,67	0,83	1,00

RATIONAL METHOD (ALTERNATIVE 2)									
Description of catchment									
River detail									
Calculated by							Date		
Physical characteristics									
Size of catchment (A)				km ²		Days of thunder per year (R)②			
Longest watercourse (L)				km		Weather Service station⑩			
Average slope (S _{av})				m/m		Weather Service number⑩			
Dolomite area (D%)				%		Area distribution factors			
Mean annual precipitation (MAP)⑥				mm		Rural (α)		Urban (β)	
2-year return period rainfall (M) ①				mm					
Rural③					Urban④				
Surface slope		%	Factor	C _s	Description		%	Factor	C ₂
Wetlands and pans					Lawns				
Flat areas					Sandy, flat (<2%)				
Hilly					Sandy, steep (>7%)				
Steep areas					Heavy soil, flat (<2%)				
Total		100	-		Heavy soil, steep (>7%)				
Permeability		%	Factor	C _p	Residential areas				
Very permeable					Houses				
Permeable					Flats				
Semi-permeable					Industry				
Impermeable					Light industry				
Total		100	-		Heavy industry				
Vegetation		%	Factor	C _v	Business				
Thick bush and plantation					City centre				
Light bush and farm-lands					Suburban				
Grasslands					Streets				
No vegetation					Maximum flood				
Total		100	-		Total (C ₂)		100	-	
Time of concentration (T _C)				Notes:					
Overland flow⑤		Defined watercourse							
$T_C = 0,604 \left(\frac{rL}{\sqrt{S_{av}}} \right)^{0,467}$		$T_C = \left(\frac{0,87L^2}{1000S_{av}} \right)^{0,385}$							
hours		hours							
Run-off coefficient									
Return period (years), T		2	5	10	20	50	100	Max	
Run-off coefficient, C ₁ (C ₁ = C _s + C _p + C _v)									
Adjusted for dolomitic areas, C _{1D} (= C ₁ (1 - D%) + C ₁ D%(Σ(D _{factor} x C _{S%})))⑥									
Adjustment factor for initial saturation, F _i ⑦									
Adjusted run-off coefficient, C _{1T} (= C _{1D} x F _i)									
Combined run-off coefficient C _T (= αC _{1T} + βC ₂ + γC ₃)									
Rainfall									
Return period (years), T		2	5	10	20	50	100	Max	
Point rainfall (mm), P _T ⑧									
Point intensity (mm/hour), P _{IT} (= P _T /T _C)									
Area reduction factor (%), ARF _T ⑨									
Average intensity (mm/hour), I _T (= P _{IT} x ARF _T)									
Peak flow (m ³ /s) Q _T = $\frac{C_T I_T A}{3,6}$									

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

R2 – Page 1/2

RATIONAL METHOD (ALTERNATIVE 2)

LEGEND TABLE Rational method (Alt 2)	
ID	Reference
①	Figure 3.7 or SA Weather Services
①	TR102 ^(3.15) or other
②	Figure 3.9 ^(3.28)
③	Table 3C.1
④	Table 3C.2
⑤	Table 3C.3
⑥	Table 3C.4
⑦	Table 3C.5
⑧	Table 3C.6
⑨	Figure 3.11
⑩	Figure 3.10, TR102 ^(3.15) or other

n-day rainfall data							
Weather Service station							
Weather Service station number							
Mean annual precipitation (MAP)						mm	
Coordinates				&			
Duration (days)	Return period (years), T						
	2	5	10	20	50	100	200
1 day							
2 days							
3 days							
7 days							

Table 3C.6	
Selection criteria	Calculation method
$T_C < 6$ hours	Modified Hershfield equation $P_{t,T} = 1,13(0,41 + 0,64\ln T)(-0,11 + 0,27\ln t)(0,79M^{0,69}R^{0,20})$
$6 \text{ hours} \leq T_C < 24$ hours	Linear interpolation between calculated modified Hershfield equation point rainfall and 1-day point rainfall from TR102
$T_C \geq 24$ hours	Linear interpolation between n-day point rainfall values from TR102

RATIONAL METHOD (ALTERNATIVE 3)									
Description of catchment									
River detail									
Calculated by							Date		
Physical characteristics									
Size of catchment (A)				km ²		Weather Service Station®			
Longest watercourse (L)				km		Weather Service number®			
Average slope (S _{av})				m/m		Area distribution factors			
Dolomite area (D%)				%		Rural (α)		Urban (β)	
Mean annual precipitation (MAP)®#				mm					
Rural①				Urban②					
Surface slope	%	Factor	C _s	Description	%	Factor	C ₂		
Wetlands and pans				Lawns					
Flat areas				Sandy, flat (<2%)					
Hilly				Sandy, steep (>7%)					
Steep areas				Heavy soil, flat (<2%)					
Total	100	-		Heavy soil, steep (>7%)					
Permeability	%	Factor	C _p	Residential areas					
Very permeable				Houses					
Permeable				Flats					
Semi-permeable				Industry					
Impermeable				Light industry					
Total	100	-		Heavy industry					
Vegetation	%	Factor	C _v	Business					
Thick bush and plantation				City centre					
Light bush and farm-lands				Suburban					
Grasslands				Streets					
No vegetation				Maximum flood					
Total	100	-		Total (C ₂)	100	-			
Time of concentration (T _C)				Notes:					
Overland flow③		Defined watercourse							
$T_C = 0,604 \left(\frac{rL}{\sqrt{S_{av}}} \right)^{0,467}$		$T_C = \left(\frac{0,87L^2}{1000S_{av}} \right)^{0,385}$							
hours		hours							
Run-off coefficient									
Return period (years), T	2	5	10	20	50	100	Max		
Run-off coefficient, C ₁ (C ₁ = C _s + C _p + C _v)									
Adjusted for dolomitic areas, C _{1D} (= C ₁ (1 - D%) + C ₁ D%(Σ(D _{factor} x C _{S%})))④									
Adjustment factor for initial saturation, F _i ⑤									
Adjusted run-off coefficient, C _{1T} (= C _{1D} x F _i)									
Combined run-off coefficient C _T (= αC _{1T} + βC ₂ + γC ₃)									
Rainfall									
Return period (years), T	2	5	10	20	50	100	Max		
Point rainfall (mm), P _T ⑥									
Point intensity (mm/hour), P _{IT} (= P _T /T _C)									
Area reduction factor (%), ARF _T ⑦									
Average intensity (mm/hour), I _T (= P _{IT} x ARF _T)									
Return period (years), T	2	5	10	20	50	100	Max		
Peak flow (m ³ /s), Q _T = $\frac{C_T I_T A}{3,6}$									

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

R3 - Page 1/2

RATIONAL METHOD (ALTERNATIVE 3)

LEGEND TABLE Rational method (Alt 3)		Table 3C.7				
ID	Reference	Rural (C ₁)				
		Component	Classification	Mean annual rainfall (mm)		
				600	600 - 900	900
①	Figure 3.7 or SA Weather Services	Surface slope (C _s)	Wetlands and pans (<3%)	0,01	0,03	0,05
②	Table 3C.7		Flat areas (3 to 10%)	0,06	0,08	0,11
③	Table 3C.8		Hilly (10 to 30%)	0,12	0,16	0,20
④	Table 3C.9		Steep areas (>30%)	0,22	0,26	0,30
⑤	Table 3C.10		Permeability (C _p)	Very permeable	0,03	0,04
⑥ [#]	Figure 3.13 and 3.14	Permeable		0,06	0,08	0,10
⑦	Figure 3.25 or 3.26	Semi-permeable		0,12	0,16	0,20
⑧	Figure 3.10, Figure 3.13 or other	Impermeable		0,21	0,26	0,30
		Vegetation (C _v)	Thick bush and plantation	0,03	0,04	0,05
			Light bush and farm-lands	0,07	0,11	0,15
			Grasslands	0,17	0,21	0,25
			No vegetation	0,26	0,28	0,30

Table 3C.8	
Urban (C_2)	
Use	Factor
Lawns	
Sandy, flat (< 2%)	0,05 - 0,10
Sandy, steep (>7%)	0,15 - 0,20
Heavy soil, flat (< 2%)	0,13 - 0,17
Heavy soil, steep (>7%)	0,25 - 0,35
Residential areas	
Houses	0,30 - 0,50
Flats	0,50 - 0,70
Industry	
Light industry	0,50 - 0,80
Heavy industry	0,60 - 0,90
Business	
City centre	0,70 - 0,95
Suburban	0,50 - 0,70
Streets	0,70 - 0,95
Maximum flood	1,00

Table 3C.9	
Surface description	Recommended value of r
Paved areas	0,02
Clean compacted soil, no stones	0,1
Sparse grass over fairly rough surface	0,3
Medium grass cover	0,4
Thick grass cover	0,8

Table 3C.10	
Adjustment factor to C_s	
Surface slope classification	D_{factor}
Steep areas (slopes >30%)	0,50
Hilly (10 to 30%)	0,35
Flat areas (3 to 10%)	0,20
Wetlands and pans (slopes <3%)	0,10

Table 3C.11						
Return period (years)	2	5	10	20	50	100
Adjustment factor (F_t) for steep and impermeable catchments	0,75	0,80	0,85	0,90	0,95	1,00
Adjustment factor (F_t) for flat and permeable catchments	0,50	0,55	0,60	0,67	0,83	1,00

Note: # Calculate the point intensity rainfall by making use of the provided *Design Rainfall* estimation software. The exact point intensity can be calculated by means of linear interpolation between two consecutive values considering the time of concentration.

[illegible]

<p style="text-align: center;">LEGEND TABLE Unit Hydrograph method</p>			
ID	Reference	ID	Reference
①	Figure 3.7	⑤	Figure 3.25 or 3.26
①	Figure 3.20	⑥	Figure 3.27
②	Figure 3.21	⑦	Table 3.12
③	Table 3.11	⑧	Paragraph 3.5.2.5
④	Design rainfall database or Figure 3.8	⑨	$Q_{pIT} = Q_p \times [(S_1 - S_{2T})/T_{SD}]_{\max}$

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

STANDARD DESIGN FLOOD METHOD								
Description of catchment								
River detail								
Calculated by					Date			
Physical characteristics								
Size of catchment (A)		km ²	Time of concentration (T _C)		$T_C = \left(\frac{0,87L^2}{1000S_{av}} \right)^{0,385}$		hours	
Longest watercourse (L)		km						
Average slope (S _{av})		m/m						
SDF basin① [#]			Time of concentration, t (= 60T _C)			minutes		
2-year return period rainfall (M)①		mm	Days of thunder per year (R)①			days/year		
TR102 n-day rainfall data								
Weather Service station				Mean annual precipitation (MAP)			mm	
Weather Service station no.				Coordinates		&		
Duration (days)		Return period (years)						
		2	5	10	20	50	100	200
1 day								
2 days								
3 days								
7 days								
Rainfall								
Return period (years), T		2	5	10	20	50	100	200
Point precipitation depth (mm), P _{t,T} ②								
Area reduction factor (%), ARF (= (90000 – 12800lnA + 9830lnt) ^{0,4})								
Average intensity (mm/hour), I _T (= P _{t,T} x ARF / T _C)								
Run-off coefficients								
Calibration factors①	C ₂ (2-year return period) (%)		C ₁₀₀ (100-year return period) (%)					
Return period (years)		2	5	10	20	50	100	200
Return period factors (Y _T)		0	0,84	1,28	1,64	2,05	2,33	2,58
Run-off coefficient (C _T), $C_T = \frac{C_2}{100} + \left(\frac{Y_T}{2,33} \right) \left(\frac{C_{100}}{100} - \frac{C_2}{100} \right)$								
Peak flow (m ³ /s), Q _T = $\frac{C_T I_T A}{3,6}$								

LEGEND TABLE			
Standard Design Flood method			
ID	Reference	ID	Reference
①	Figure 3.30	②	Table 3C.12
①	Table 3B.1		

Table 3C.12	
Criteria	Calculation method
T _C < 6 hours	Modified Hershfield equation $P_{t,T} = 1,13(0,41 + 0,64\ln T)(-0,11 + 0,27\ln t)(0,79M^{0,69}R^{0,20})$
6 hours ≤ T _C < 24 hours	Linear interpolation between calculated modified Hershfield equation point rainfall and 1-day point rainfall from TR102
T _C ≥ 24 hours	Linear interpolation between n-day point rainfall values from TR102

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

S - Page 1/1

SCS-SA METHOD										
Description of catchment										
River detail										
Calculated by							Date			
Physical characteristics										
Size of catchment (A)			km ²	Time of Concentration (T _C)						
				Defined watercourse			hours			
Longest watercourse (L)			km	$T_C = \left(\frac{0,87L^2}{1000S_{av}} \right)^{0,385}$						
Average slope (S _{av})			m/m							
Lag estimation		L = 0,6T _c		hours	$T_C = 0,604 \left(\frac{rL}{\sqrt{S_{av}}} \right)^{0,467}$					
Return period (years)		1:2	1:5	1:10	1:20	1:50	1:100			
Daily rainfall depth (one-day design rainfall, P) (mm) ①										
Area reduction factor (only applied for large catchments, ARF) (%) ①										
Catchment design rainfall (P x ARF/100) (mm)										
HRU	Area (A _i) (%)	SOIL ②					LAND COVER ③			
		Form	Series	Typical Textural Class	Depth (m)	SCS Grouping	Land Cover Class	Cover Category (S/I/D)	Practice/Treatment	Storm-Flow Potential ④
1										
2										
3										
4										
5										
		HRU 1	HRU 2	HRU 3	HRU 4	HRU 5				
Initial Curve Number (CN) ④										
Final Curve Number ⑤										
Potential maximum soil water retention (S, mm) ⑥										
Initial losses (mm)		I _a = 0,12S								
Return period (years)		1:2	1:5	1:10	1:20	1:50	1:100			
HRU		Design Stormflow depth (Q _i) ⑦								
1										
2										
3										
4										
5										
Total stormflow depth ($\sum \frac{Q_i A_i}{100}$) (mm)										
Total runoff volume (V, m ³ x10 ⁶) ⑧										
Peak discharge (q _p , m ³ /s) ⑨										

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

C - Page 1/2

SCS-SA METHOD

LEGEND TABLE SCS-SA method	
ID	Reference
①	Figure 3.13 or Figure 3E.1 to Figure 3E.6
①	Figure 3.25 or 3.26
②	Table 3E.1 or 3E.2
③	Table 3E.3
④	Table 3E.3
⑤	Table 3C.13
⑥	Table 3C.14
⑦	Table 3C.15
⑧	Table 3C.16
⑨	Table 3C.17

Table 3C.13	
Adjustment of Curve Numbers	
Median Condition Method (3.5.4.2.6)	$CN_f = \frac{1100}{\frac{1100}{CN - II} - \frac{\Delta S}{25,4}}$
Wet/saturated Conditions	$CN_w = \frac{CN - II}{0,4036 + 0,0059CN - II}$

Table 3C.14	
Potential maximum soil water retention	$S = \frac{25400}{CN} - 254$

Table 3C.115	
Stormflow depth	$Q = \frac{(P - I_a)^2}{P - I_a + S} \text{ for } P > I_a$

Table 3C.16	
Stormflow volume	$V = \frac{QA}{1000}$

Table 3C.17	
Peak discharge estimation	$q_p = \frac{0,2083AQ}{1,83L}$

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

C - Page 2/2

EMPIRICAL METHODS						
Description of catchment						
River detail						
Calculated by				Date		
Physical characteristics						
Size of catchment (A)		km ²	Veld type①			
Longest watercourse (L)		km	Catchment parameter (C) with regard to reaction time		$C = \frac{A\sqrt{S}}{L L_c}$	
Length to catchment centroid (L _C)		km				
Average slope (S _{av})		m/m	Kovács region②			
Mean annual precipitation (P)⑥		mm				
Return period (years), T			10	20	50	100
Constant value for K _T ③						
Peak flow (m ³ /s), Q _T based on Midgley & Pitman $Q_T = 0,0377K_T PA^{0,6}C^{0,2}$						
Peak flow (m ³ /s), Q _{RMF} based on Kovács④						
Return period (years), T			50	100	200	
Q _T /Q _{RMF} ratios⑤						
Peak flow (m ³ /s). based on O _T /O _{RMF} ratios						

LEGEND TABLE Empirical methods					
ID	Reference	ID	Reference	ID	Reference
①	Figure 3.7	②	Figure 3.37	④	Table 3C.19
①	Figure 3.35	③	Table 3C.18	⑤	Table 3D.1 or 3D.2

Table 3C.18 Constant values of K _T											
Return period T in years	Veld type (Figure 3.20)										
	1	2		3	4 & 5A	5	6		7	8	9
		Winter	All year				Winter	All year			
10	0,17	0,42	0,83	0,29	0,59	0,59	0,33	0,67	0,67	0,42	0,50
20	0,23	0,52	1,04	0,40	0,68	0,80	0,45	0,91	0,91	0,57	0,68
50	0,32	0,68	1,36	0,55	0,95	1,11	0,63	1,26	1,26	0,79	0,95
100	0,40	0,80	1,60	0,70	1,20	1,40	0,80	1,60	1,60	1,00	1,20

Table 3C.19 RMF region classification in southern Africa						
Kovács region	K *	Number of floods #	Transition zone		Flood zone	
			Area range (km ²)	Q _{RMF} (m ³ /s)	Area range (km ²)	Q _{RMF} (m ³ /s)
K1	2,8	6	1 – 500	30A ^{0,262}	500 – 500 000	1,74A ^{0,72}
K2	3,4	12	1 – 300	50A ^{0,265}	300 – 500 000	5,25A ^{0,66}
K3	4,0	26	1 – 300	70A ^{0,34}	300 – 300 000	15,9A ^{0,60}
K4	4,6	55	1 – 100	100A ^{0,38}	100 – 100 000	47,9A ^{0,54}
K5	5,0	155	1 – 100	100A ^{0,50}	100 – 100 000	100A ^{0,50}
K6	5,2	61	1 – 100	100A ^{0,56}	100 – 30 000	145A ^{0,48}
K7	5,4	34	1 – 100	100A ^{0,62}	100 – 20 000	209A ^{0,46}
K8	5,6	25	1 – 100	100A ^{0,68}	100 – 10 000	302A ^{0,44}
Notes:						
* RMF K value as used in Equation 3.36						
# Recorded flood data are reflected in the DWAF report TR105 – Maximum flood peak discharges in South Africa: An empirical approach						

Note: # Reference to the appropriate figures and tables is made in the legend table of this method.

APPENDIX 3D
 Q_T/Q_{RMF} RATIOS FOR DIFFERENT CATCHMENT AREAS

Table 3D.1: Q_T/Q_{RMF} ratios for different catchment areas in South Africa, Lesotho and Swaziland^(3,13)

Region	Return period (years)	K_T	Effective catchment area - A_e (km ²)									
			$\leq 10^*$	30*	100	300	1 000	3 000	10 000	30 000	100 000	300 000
K8 (5,6)	50	5,06	0,537	0,508	0,474	0,503	0,537	0,570	0,607			
	100	5,25	0,668	0,645	0,617	0,640	0,668	0,695	0,724			
	200	5,41	0,803	0,788	0,769	0,784	0,803	0,821	0,838			
K7 (5,4)	50	4,70	0,447	0,416	0,380	0,411	0,447	0,482	0,523			
	100	4,89	0,556	0,525	0,492	0,523	0,556	0,588	0,623			
	200	5,04	0,661	0,635	0,607	0,633	0,661	0,687	0,716			
K6 (5,2)	50	4,50	0,447	0,416	0,380	0,411	0,447	0,482	0,526	0,566		
	100	4,69	0,556	0,528	0,494	0,524	0,556	0,588	0,626	0,660		
	200	4,86	0,676	0,650	0,624	0,650	0,676	0,701	0,733	0,758		
K5 (5 - except in SW Cape)	50	4,30	0,447	0,416	0,380	0,411	0,447	0,482	0,525	0,567	0,617	
	100	4,48	0,550	0,521	0,488	0,517	0,550	0,582	0,619	0,657	0,699	
	200	4,64	0,661	0,636	0,608	0,633	0,661	0,687	0,718	0,748	0,780	
K5 (5 - G, H in SW Cape)	50	4,45	0,531	0,502	0,468	0,497	0,531	0,564				
	100	4,63	0,654	0,629	0,600	0,625	0,654	0,680				
	200	4,78	0,777	0,758	0,738	0,757	0,777	0,795				
K4 (4,6)	50	3,84	0,416	0,385	0,350	0,381	0,416	0,453	0,496	0,541	0,591	
	100	4,04	0,524	0,495	0,462	0,491	0,524	0,558	0,597	0,636	0,679	
	200	4,20	0,629	0,603	0,576	0,602	0,629	0,660	0,692	0,724	0,758	
K3 (4)	50	3,26	0,426	0,426	0,426	0,390	0,426	0,463	0,506	0,548	0,602	0,651
	100	3,50	0,562	0,562	0,562	0,529	0,562	0,595	0,631	0,666	0,710	0,749
	200	3,68	0,692	0,692	0,692	0,665	0,692	0,718	0,745	0,771	0,804	0,831
K2 (3,4)**	50	2,40	0,317	0,317	0,317	0,281	0,317	0,353	0,398	0,444	0,500	0,560
	100	2,66	0,428	0,428	0,428	0,391	0,428	0,463	0,506	0,549	0,598	0,651
	200	2,91	0,570	0,570	0,570	0,536	0,570	0,600	0,638	0,672	0,710	0,753

Note: * Estimated ratios

** Ratios of this region may also be used in region **K1** (2,8)

Table 3D.2: Q_T/Q_{RMF} ratios for different catchment areas in Namibia and Zimbabwe^(3,13)

Region	Return period (years)	K _T	Effective catchment area - A _e (km ²)									
			≤ 10*	30*	100	300	1 000	3 000	10 000	30 000	100 000	300 000
Namibia												
K5 (5)	50	4,50	0,562	0,534	0,501	0,529	0,562	0,594	0,631			
	100	4,70	0,708	0,686	0,661	0,683	0,708	0,732	0,759			
	200	4,85	0,841	0,828	0,813	0,826	0,841	0,855	0,871			
K4 (4,6)	50	4,14	0,589	0,561	0,530	0,558	0,589	0,620	0,654	0,690	0,727	
	100	4,34	0,741	0,721	0,699	0,719	0,741	0,763	0,787	0,811	0,835	
	200	4,48	0,871	0,860	0,848	0,860	0,871	0,883	0,895	0,909	0,920	
K3 (4)	50	3,50	0,562	0,562	0,562	0,529	0,562	0,595	0,631	0,666	0,710	
	100	3,66	0,676	0,676	0,676	0,648	0,676	0,703	0,731	0,759	0,793	
	200	3,77	0,767	0,767	0,767	0,746	0,767	0,788	0,809	0,829	0,856	
K2 (3,4)	50	2,88	0,550	0,550	0,550	0,517	0,550	0,585	0,619	0,656	0,696	
	100	3,01	0,639	0,639	0,639	0,610	0,639	0,669	0,698	0,729	0,762	
	200	3,13	0,733	0,733	0,733	0,711	0,733	0,758	0,779	0,803	0,828	
Zimbabwe												
K6 (5,2)**	50	4,65	0,531	0,502	0,468	0,497	0,531	0,564	0,603	0,640		
	100	4,86	0,676	0,652	0,625	0,649	0,676	0,702	0,731	0,759		
	200	5,03	0,822	0,807	0,791	0,806	0,822	0,838	0,855	0,871		

Note: * Estimated ratios

** In region **K5** use the same ratios as those applicable to South Africa

APPENDIX 3E
SCS-SA ADDITIONAL INFORMATION

Table 3E.1: Example of classification of soils in southern Africa into hydrological soil groups by soil form, family and textural class (taxonomic classification)

Soil Form	Code	Soil Family	Typical Textural Class	SCS Grouping
ADDO B	Ad 1111	Glenconnor	LmSa	A/B
	Ad 1111	Glenconnor	SaLm	B
	Ad 1111	Glenconnor	SaClLm	B
	Ad 1111	Glenconnor	SaCl	B/C
	Ad 1112	Dalby	LmSa	A/B
	Ad 1112	Dalby	SaLm	B
	Ad 1112	Dalby	SaClLm	B
	Ad 1112	Dalby	SaCl	B/C
	Ad 1121	Centlivres	LmSa	B
	Ad 1121	Centlivres	SaLm	B/C
	Ad 1121	Centlivres	SaClLm	B/C
	Ad 1121	Centlivres	SaCl	C
	Ad 1122	Kentvale	LmSa	B
	Ad 1122	Kentvale	SaLm	B/C
	Ad 1122	Kentvale	SaClLm	B/C
	Ad 1122	Kentvale	SaCl	C
	Ad 1211	Spekboom	LmSa	A/B
	Ad 1211	Spekboom	SaLm	B
	Ad 1211	Spekboom	SaClLm	B
	Ad 1211	Spekboom	SaCl	B/C
	Ad 1212	Gorah	LmSa	A/B
	Ad 1212	Gorah	SaLm	B
	Ad 1212	Gorah	SaClLm	B
	Ad 1212	Gorah	SaCl	B/C
	Ad 1221	Walkraal	LmSa	B
ADDO B	Ad 1221	Walkraal	SaClLm	B/C
	Ad 1221	Walkraal	SaCl	C
	Ad 1222	Sylvania	LmSa	B
	Ad 1222	Sylvania	SaLm	B/C
	Ad 1222	Sylvania	SaClLm	B/C
	Ad 1222	Sylvania	SaCl	C
	Ad 2111	Maurmond	LmSa	A/B
	Ad 2111	Maurmond	SaLm	B
	Ad 2111	Maurmond	SaClLm	B
	Ad 2111	Maurmond	SaCl	B/C
	Ad 2112	Airedale	LmSa	A/B
	Ad 2112	Airedale	SaLm	B
	Ad 2112	Airedale	SaClLm	B
	Ad 2112	Airedale	SaCl	B/C
	Ad 2121	Felsenheim	LmSa	B
	Ad 2121	Felsenheim	SaLm	B/C
	Ad 2121	Felsenheim	SaClLm	B/C
	Ad 2121	Felsenheim	SaCl	C
	Ad 2122	Longhill	LmSa	B
	Ad 2122	Longhill	SaLm	B/C
	Ad 2122	Longhill	SaClLm	B/C
	Ad 2122	Longhill	SaCl	C
	Ad 2211	Mimosa	LmSa	A/B
	Ad 2211	Mimosa	SaLm	B
	Ad 2211	Mimosa	SaClLm	B
	Ad 2211	Mimosa	SaCl	B/C
	Ad 2212	Peperboom	LmSa	A/B
	Ad 2212	Peperboom	SaLm	B
	Ad 2212	Peperboom	SaClLm	B
	Ad 2212	Peperboom	SaCl	B/C
	Ad 2221	Suttondale	LmSa	B
	Ad 2221	Suttondale	SaLm	B/C
	Ad 2221	Suttondale	SaClLm	B/C
	Ad 2221	Suttondale	SaCl	C
	Ad 2222	Tregaron	LmSa	B
	Ad 2222	Tregaron	SaClLm	B/C
	Ad 2222	Tregaron	SaCl	C

Soil Form	Code	Soil Family	Typical Textural Class	SCS Grouping
ARCADIA	Ar 1100	Lonehill	Cl	C/D
C/D	Ar 1100	Lonehill	Cl	C/D
	Ar 1200	Rustenburg	Cl	C/D
	Ar 1200	Rustenburg	Cl	C/D
	Ar 2100	Minerva	Cl	C/D
	Ar 2100	Minerva	Cl	C/D
	Ar 2200	Diepsloot	Cl	C/D
	Ar 2200	Diepsloot	Cl	C/D
	Ar 3100	Bospoort	Cl	C/D
	Ar 3100	Bospoort	Cl	C/D
	Ar 3200	Deercroft	Cl	C/D
	Ar 3200	Deercroft	Cl	C/D
ASKHAM	Ak 1000	Aroab	LmSa	A/B
B	Ak 1000	Aroab	SaLm	B
	Ak 1000	Aroab	SaClLm	B
	Ak 1000	Aroab	SaCl	B/C
	Ak 2000	Noenieput	LmSa	B
	Ak 2000	Noenieput	SaLm	B/C
	Ak 2000	Noenieput	SaClLm	B/C
	Ak 2000	Noenieput	SaCl	B/C
AUGRABIE	Ag 1110	Hefnaar	LmSa	A/B
B	Ag 1110	Hefnaar	SaLm	B
	Ag 1110	Hefnaar	SaClLm	B
	Ag 1110	Hefnaar	SaCl	B/C
	Ag 1120	Giyani	LmSa	B
	Ag 1120	Giyani	SaLm	B/C
	Ag 1120	Giyani	SaClLm	B/C
	Ag 1120	Giyani	SaCl	C
	Ag 1210	Khubus	LmSa	A/B
	Ag 1210	Khubus	SaLm	B
	Ag 1210	Khubus	SaClLm	B
	Ag 1210	Khubus	SaCl	B/C
	Ag 1220	Shilowa	LmSa	B

LEGEND		
A	-	low runoff potential
B	-	moderately low potential
C	-	moderately high potential
D	-	high runoff potential
Sa	-	sand
Cl	-	clay
Lm	-	loam

Table 3E.2: Example of classification of soils in southern Africa into hydrological soil groups by soil form and series (binomial classification)

Soil Form	Code	Soil Series	Typical Textural Class	SCS Grouping	Soil Form	Code	Soil Series	Typical Textural Class	SCS Grouping
ARCADIA C/D	Ar 40	Arcadia	Cl	C/D	BAINSVLEI	Bv 14	Wykeham	SaLm	A/B
	Ar 11	Bloukrans	Cl	C/D	BONHEIM C	Bo 41	Bonheim	LmSa	C/D
	Ar 21	Clerkness	Cl	C/D		Bo 20	Bushman	SaCILm	C
	Ar 41	Eenzaam	Cl	C/D		Bo 30	Dumasi	SaCILm	C
	Ar 20	Gelykvlaakte	Cl	C/D		Bo 31	Glengazi	SaCl	C/D
	Ar 10	Mngazi	Cl	C/D		Bo 10	Kiora	SaCILm	C
	Ar 32	Nagana	Cl	C/D		Bo 21	Rasheni	SaCl	C/D
	Ar 12	Noukloof	Cl	C/D		Bo 11	Stanger	SaCl	C/D
	Ar 31	Rooibraai	Cl	C/D		Bo 40	Weenen	SaCILm	C
	Ar 30	Rydalvale	Cl	C/D	CARTREF C	Cf 10	Amabele	LmSa	B/C
	Ar 42	Wanstead	Cl	C/D		Cf 12	Arrochar	SaCILm	C
	Ar 22	Zwaarkrygen	Cl	C/D		Cf 13	Byrne	SaCl	C/D
AVALON B	Av 13	Ashton	SaLm	A/B		Cf 21	Cartref	SaLm	C
	Av 26	Avalon	SaCILm	B		Cf 22	Cranbrook	SaCILm	C
	Av 12	Banchory	Sa	A		Cf 30	Grovedale	Sa	B/C
	Av 27	Bergville	SaCl	B/C		Cf 31	Kusasa	SaLm	B/C
	Av 37	Bezuidenhout	SaCl	C		Cf 32	Noodhulp	SaCILm	C
	Av 33	Bleeksand	SaLm	B/C		Cf 11	Rutherglen	SaLm	C
	Av 34	Heidelberg	SaLm	B/C		Cf 20	Waterridge	LmSa	B/C
	Av 20	Hobeni	LmSa	A/B	CHAMPAGNE D	Ch 11	Champagne	SaLm	D
	Av 14	Kanhym	SaLm	A/B		Ch 21	Ivanhoe	SaCILm	D
	Av 24	Leksand	SaLm	B		Ch 10	Mposa	SaLm	D
	Av 10	Mastaba	LmSa	A		Ch 20	Stratford	SaCILm	D
AVALON B	Av 32	Middelpos	Sa	B	CLOVELLY A/B	Cv 33	Annandale	SaLm	B
	Av 31	Mooiveld	LmSa	B		Cv 18	Balgowan	Cl	B
	Av 25	Newcastle	SaLm	A/B		Cv 40	Bleskop	LmSa	A
	Av 17	Normandien	SaCl	B		Cv 36	Blinkklip	SaCILm	B
	Av 22	Rossdale	Sa	A/B		Cv 17	Clovelly	SaCl	B
	Av 16	Ruston	SaCILm	B		Cv 28	Clydebank	Cl	B
	Av 36	Soetmelk	SaCILm	B/C		Cv 35	Denhere	SaLm	A/B
	Av 21	Uithoek	LmSa	A/B		Cv 46	Dudfield	SaCILm	A/B
	Av 30	Viljoenskroon	LmSa	B		Cv 11	Geelhout	LmSa	A
	Av 23	Villiers	SaLm	B		Cv 25	Gutu	SaLm	A
	Av 11	Welverdien	LmSa	A		Cv 47	Klippan	SaCl	B
	Av 35	Windmeul	SaLm	B		Cv 38	Klipputs	Cl	B/C
	Av 15	Wolweberg	SaLm	A		Cv 10	Lismore	LmSa	A
BAINSVLEI A/B	Bv 23	Ashkelon	SaLm	A/B	LEGEND				
	Bv 36	Bainsvlei	SaCILm	B	A	-	low stormflow potential		
	Bv 12	Camelot	Sa	A	B	-	moderately low potential		
	Bv 20	Chelsea	LmSa	A	C	-	moderately high potential		
	Bv 30	Delwery	LmSa	A/B	D	-	high stormflow potential		
	Bv 13	Dunkeld	SaLm	A/B	Sa	-	sand		
	Bv 16	Elysium	SaCILm	A/B	Cl	-	clay		
	Bv 10	Hlatini	LmSa	A	Lm	-	loam		
	Bv 34	Kareekuul	SaLm	B					
	Bv 31	Kingston	LmSa	A/B					
	Bv 26	Lonetree	SaCILm	A/B					
	Bv 25	Maanhaar	SaLm	A					
	Bv 11	Makong	LmSa	A					
	Bv 27	Metz	SaCl	B					
	Bv 22	Oosterbeek	Sa	A					
	Bv 37	Ottosdal	SaCl	B/C					
	Bv 24	Redhill	SaLm	A/B					
	Bv 32	Trekboer	Sa	A/B					
	Bv 15	Tygerkloof	SaLm	A					
	Bv 33	Vermaas	SaLm	B					
	Bv 21	Vungama	LmSa	A					
	Bv 35	Wedgewood	SaLm	A/B					
	Bv 17	Wilgenhof	SaCl	B					

Table 3E.3 Initial Curve Numbers for selected land cover and treatment classes, stormflow potentials and hydrological soil groups (various sources)

Land Cover Class	Land Treatment/ Practice/Description	Stormflow Potential	Hydrological Soil Group						
			A	A/B	B	B/C	C	C/D	D
Fallow	1 = Straight row		77	82	86	89	91	93	94
	2 = Straight row + conservation tillage	High	75	80	84	87	89	91	92
	3 = Straight row + conservation tillage	Low	74	79	83	85	87	89	90
Row Crops	1 = Straight row	High	72	77	81	85	88	90	91
	2 = Straight row	Low	67	73	78	82	85	87	89
	3 = Straight row + conservation tillage	High	71	75	79	83	86	88	89
	4 = Straight row + conservation tillage	Low	64	70	75	79	82	84	85
	5 = Planted on contour	High	70	75	79	82	84	86	88
	6 = Planted on contour	Low	65	69	75	79	82	84	86
	7 = Planted on contour + conservation tillage	High	69	74	78	81	83	85	87
	8 = Planted on contour + conservation tillage	Low	64	70	74	78	80	82	84
	9 = Conservation structures	High	66	70	74	77	80	82	82
	10 = Conservation structures	Low	62	67	71	75	78	80	81
	11 = Conservation structures + conservation tillage	High	65	70	73	76	79	80	81
	12 = Conservation structures + conservation tillage	Low	61	66	70	73	76	78	79
Garden Crops	1 = Straight row	Low	45	56	66	72	77	80	83
	2 = Straight row	High	68	71	75	79	81	83	84
Small Grain	1 = Straight row	High	65	71	76	80	84	86	88
	2 = Straight row	Low	63	69	75	79	83	85	87
	3 = Straight row + conservation tillage	High	64	70	74	78	82	84	86
	4 = Straight row + conservation tillage	Low	60	67	72	76	80	82	84
	5 = Planted on contour	High	63	69	74	79	82	84	85
	6 = Planted on contour	Low	61	67	73	78	81	83	84
	7 = Planted on contour + conservation tillage	High	62	68	73	77	81	83	84
	8 = Planted on contour + conservation tillage	Low	60	66	72	76	79	81	82
	9 = Planted on contour - winter rainfall region	Low	63	66	70	75	78	80	81
	10 = Conservation structures	High	61	67	72	76	79	81	82
	11 = Conservation structures	Low	59	65	70	75	78	80	81
	12 = Conservation structures + conservation tillage	High	60	67	71	75	78	80	81
	13 = Conservation structures + conservation tillage	Low	58	64	69	73	76	78	79
Close Seeded Legumes or Rotational Meadow	1 = Straight Row	High	66	72	77	81	85	87	89
	2 = Straight Row	Low	58	65	72	75	81	84	85
	3 = Planted on contour	High	64	70	75	80	83	84	85
	4 = Planted on contour	Low	55	63	69	74	78	81	83
	5 = Conservation structures	High	63	68	73	77	80	82	83
	6 = Conservation structures	Low	51	60	67	72	76	78	80
Sugarcane	1 = Straight row: trash burnt		43	55	65	72	77	80	82
	2 = Straight row: trash mulch		45	56	66	72	77	80	83
	3 = Straight row: limited cover		67	73	78	82	85	87	89
	4 = Straight row: partial cover		49	60	69	73	79	82	84
	5 = Straight row: complete cover		39	50	61	68	74	78	80
	6 = Conservation structures: limited cover		65	70	75	79	82	84	86
	7 = Conservation structures: partial cover		25	46	59	67	75	80	83
	8 = Conservation structures: complete cover		6	14	35	59	70	75	79
Veld (range) and Pasture	1 = Veld/pasture in poor condition	High	68	74	79	83	86	88	89
	2 = Veld/pasture in fair condition	Moderate	49	61	69	75	79	82	84
	3 = Veld/pasture in good condition	Low	39	51	61	68	74	78	80
	4 = Pasture planted on contour	High	47	57	67	75	81	85	88
	5 = Pasture planted on contour	Moderate	25	46	59	67	75	80	83
	6 = Pasture planted on contour	Low	6	14	35	59	70	75	79

Land Cover Class	Land Treatment/ Practice/Description	Stormflow Potential	Hydrological Soil Group						
			A	A/B	B	B/C	C	C/D	D
Irrigated Pasture		Low	35	41	48	57	65	68	70
Meadow		Low	30	45	58	65	71	75	81
Woods and Scrub	1 = Woods	High	45	56	66	72	77	80	83
	2 = Woods	Moderate	36	49	60	68	73	77	79
	3 = Woods	Low	25	47	55	64	70	74	77
	4 = Brush - Winter rainfall region	Low	28	36	44	53	60	64	66
Orchards	1 = Winter rainfall region, understory of crop cover		39	44	53	61	66	69	71
Forests & Plantations	1 = Humus depth 25mm; Compactness:	compact	52	62	72	77	82	85	87
	2 = " " "	moderate	48	58	68	73	78	82	85
	3 = " " "	loose/friable	37	49	60	66	71	74	77
	4 = Humus depth 50mm; Compactness:	compact	48	58	68	73	78	82	85
	5 = " " "	moderate	42	54	65	70	75	78	81
	6 = " " "	loose/friable	32	45	57	62	67	71	74
	7 = Humus depth 100mm; Compactness:	compact	41	53	64	69	74	77	80
	8 = " " "	moderate	34	47	59	64	69	72	75
	9 = " " "	loose/friable	23	37	50	56	61	64	67
	10 = Humus depth 150mm; Compactness:	compact	37	49	60	66	71	74	77
	11 = " " "	moderate	30	43	56	61	66	69	72
	12 = " " "	loose/friable	18	33	47	52	57	61	65
Urban/Sub-urban Land Uses	1 = Open spaces, parks, cemeteries 75% grass cover		39	51	61	68	74	78	80
	2 = Open spaces, parks, cemeteries 75% grass cover		49	61	69	75	79	82	84
	3 = Commercial/business areas 85% grass cover		89	91	92	93	94	95	95
	4 = Industrial districts 72% impervious		81	85	88	90	91	92	93
	5 = Residential: lot size 500m ² 65% impervious		77	81	85	88	90	91	92
	6 = " " 1000m ² 38% impervious		61	69	75	80	83	85	87
	7 = " " 1350m ² 30% impervious		57	65	72	77	81	84	86
	8 = " " 2000m ² 25% impervious		54	63	70	76	80	83	85
	9 = " " 4000m ² 20% impervious		51	61	68	75	78	82	84
	10 = Paved parking lots, roofs, etc.		98	98	98	98	98	98	98
	11 = Streets/roads: tarred, with storm sewers, curbs		98	98	98	98	98	98	98
	12 = " gravel		76	81	85	88	89	90	91
	13 = " dirt		72	77	82	85	87	88	89
	14 = " dirt-hard surface		74	79	84	88	90	91	92




Figure 3E.1: One-day design rainfall distribution over southern Africa for 2 year return period




Figure 3E.2: One-day design rainfall distribution over southern Africa for 5 year return period




Figure 3E.3: One-day design rainfall distribution over southern Africa for 10 year return period




Figure 3E.4: One-day design rainfall distribution over southern Africa for 20 year return period




Figure 3E.5: One-day design rainfall distribution over southern Africa for 50 year return period




Figure 3E.6: One-day design rainfall distribution over southern Africa for 100 year return period

4 CHAPTER 4 - HYDRAULIC CALCULATIONS

SJ van Vuuren and A Rooseboom

4.1 INTRODUCTION

Hydraulic calculations are performed in order to determine the values of variables that describe flow conditions, e.g. flow depths, flow velocities and pressures. Only three fundamental laws or principles are generally applied in hydraulic calculations:

- Conservation of mass (continuity principle);
- Conservation of energy; and
- Conservation of momentum.

Depending on what information is available and what answer is required, every hydraulic calculation involves the application of one or more of these fundamental laws or principles.

This chapter contains the basic equations together with empirical information, as well as guidance on the application of the equations in drainage analyses.

A distinction is made between open-channel flow and pipe flow. These aspects are respectively covered in paragraphs 4.2 and 4.3. In open-channel flow the pressure at the water surface remains atmospheric, whereas a conduit under pipe flow conditions basically flows "full". The pressure varies, and could be higher or lower than atmospheric pressure.

The laws of conservation of energy and momentum are both derived from Newton's second law. They can be transposed and simplified in numerous ways, and care should be taken to ensure that the format being used is indeed valid.

Virtually all calculations involve the law of conservation of mass. The law of conservation of energy is used where energy losses can be calculated, or are small enough to be disregarded. Similarly the law of conservation of momentum may be used to calculate forces that act upon bodies of fluid or to analyse flow conditions where all the forces that act upon a body of fluid may be quantified.

Table 4.1 provides the Road Map for this Chapter, and reflects the different problems and procedures that are covered in this chapter.

Table 4.1: Road Map 4 – Hydraulic calculations

ROAD MAP 4				
Typical problems		Input information	Supporting software	Hand calculation
Topic	Paragraph			Examples included in the Application Guide
Conservation of mass	4.2.3	Discharge and conduit configuration	The supporting Utility Programs for Drainage (UPD), HEC-RAS and EPASWMM	4.1 to 4.6
Conservation of energy	4.2.4			
Controls	4.2.5			4.4 to 4.6
Friction losses	4.2.6	Conduit roughness		4.1 to 4.6
Transmission losses	4.2.7	Discharge and transition geometry		
Conservation of momentum	4.2.9	Available energy or discharge and conduit configuration		
Pipe flow	4.3			4.7

4.2 OPEN CHANNEL FLOW

4.2.1 General design problems in open channel flow

The general design problems in open channel, when the discharge is known, are to:

- Calculate the flow depths and/or velocities at given sections along the flow path, or to
- Calculate the required conduit size to convey the flow.

All hydraulic analyses to determine the flow conditions should always start at a section where the depth of flow and the velocity for the given discharge can be uniquely determined; i.e. at a control.

The following may be used as controls (see paragraph 4.2.5 for a detailed description of hydraulic controls):

- A section where the flow characteristics have been calculated, based on a remote control section;
- A section where the flow changes from subcritical flow upstream ($Fr < 1$) to supercritical flow downstream ($Fr > 1$);
- A section where the flow is uniform, i.e. the average velocity does not change with distance;
- A position where the specific energy, E , for a given discharge is a minimum i.e. $Fr = 1$.

In all other cases where the depth of flow is forced away from the normal (uniform) depth, e.g. with damming upstream of a bridge, the depth of flow cannot be determined directly and needs to be determined from the flow depth at an appropriate control section. At a control there is usually some uncertainty about the appropriate calculation of the depth of flow. Under these conditions it is assumed that:

- the most conservative value (maximum or minimum flow depth) that could realistically be expected may be accepted, or, preferably,
- the maximum and minimum possible values of the depth at the control section may be calculated and then tested to determine whether the effect of the difference has been sufficiently attenuated (reduced) up to the area where the results are important.

In all other cases where the depth of flow is forced away from the normal (uniform) depth, e.g. with damming upstream of a bridge, the depth of flow cannot be determined directly and needs to be determined from the flow depth at an appropriate control section.

The calculation of the unknown flow depth at a section should start at the identified control section from where the calculations are performed upstream in the case of subcritical flow and downstream in the case of supercritical flow.

At a hydraulic control where uniform flow occurs, there is usually some uncertainty about the appropriate calculated of the depth of flow (roughness, slope and cross sectional dimensions) and therefore it is advised that:

- the most conservative flow depth value (maximum or minimum flow depth) that could realistically be expected should be evaluated, and
- it should be ascertained that the influence of these depths on the calculated flow depth at the section where the flow depth is unknown, have been sufficiently attenuated (reduced) i.e. does not significantly change the calculated unknown flow depth (this will be the case if sufficient cross sections exists between the control and the section where the flow depth has to be calculated).

Current state-of-the-art software (e.g. HEC-RAS) for flow profile calculations is:


- able to identify the directions in which control is exercised;
- able to select the correct surface profiles; and
- to perform the appropriate calculations for gradually varied flow.

If flow is supercritical upstream and subcritical downstream, calculations should proceed from both sides to find the position where the transition occurs (hydraulic jump). The hydraulic jump could be analysed by means of the momentum equation.

4.2.2 General definitions associated with open channel flow

Table 4.2 provides a description of the parameters often used in free surface flow.

Table 4.2: Description of the parameters often used in free surface flow

Parameter	Description
Control	Section at which depth of flow for a given flow rate (discharge) can be uniquely determined.
Convergent flow	Downstream cross-sectional area < upstream cross-sectional area.
Critical flow	Flow corresponding with the lowest possible energy level. Characterised by $\frac{Q^2 B}{g A^3} = 1$ with Q representing the discharge, B the width at the water surface and A the cross sectional area.
Divergent flow	Downstream sectional area > upstream sectional area.
(Froude number) ²	$Fr^2 = \frac{Q^2 B}{g A^3}$  <p>(This relationship is applicable to any shape of cross-section).</p>
Flow line	Line tangential to direction of flow at any point. No sustained flow is possible across a flow line.
Friction losses	Represent the application of energy to maintain flow without taking transition losses into account.
Hydrostatic pressure distribution	Pressure intensity increases linearly downwards from zero at a free surface, so that the pressure intensity (p) at a point at depth h equals γh ; with $\gamma = \rho g$, where ρ is the density of the fluid (kg/m^3) and g the gravitational acceleration (m/s^2).
Laminar flow	Occurs at very low velocities. This is rarely encountered in practice. Characterised by $\frac{\bar{v}R}{\nu} < 500$ with \bar{v} the average velocity, R the hydraulic radius and ν the kinematic viscosity ($\nu \approx 1,14 \times 10^{-6} \text{ m}^2/\text{s}$ at 20°C).
Non-uniform flow	Flow conditions change with distance.
Open channel flow	Flow surface open to the atmosphere.
Pipe flow	Full flow conditions. (Pressures normally \geq atmospheric pressure, but could also be $<$ atmospheric pressure).
Sheet flow	Flow in a broad stream of shallow depth.
Steady flow conditions	Flow conditions do not change with time.
Subcritical flow	Downstream control prevails and analyses should be performed in the upstream direction; $Fr < 1$.
Supercritical flow	Upstream control prevails and analyses should be performed in the downstream direction; $Fr > 1$. Super critical flow cannot be dammed without first changing the flow regime to subcritical flow.
Transition losses	Energy losses associated with a change of velocity in magnitude or direction.
Turbulent flow	Most common type of flow in practice; $\frac{\bar{v}R}{\nu} > 5000$.
Uniform flow	Flow conditions do not change with distance.
Unsteady flow	Flow conditions change with time.

In the following paragraphs the continuity of mass, energy and momentum will be discussed.

4.2.3 Principle of continuity of mass (Conservation of mass)

The application of the principle of continuity is usually the least complicated and the most accurate method of calculation and, therefore, forms the cornerstone of most hydraulic calculations.

According to the continuity equation the difference between the sum of the inflows and the sum of the outflows that enter and leave a defined space (control volume) should be equal to the rate of change in the volume of fluid contained within the space.

The complete continuity equation for cases where the flow may be regarded as incompressible (virtually all cases of road drainage) reads:

$$\sum \text{Inflows} - \sum \text{Outflows} = \text{storage accumulation per unit time} = \frac{dV}{dt} \quad \dots (4.1)$$

where:

dV = change of volume (m^3) over a time step, dt (s).

In road drainage the complete equation 4.1 is usually only applied where flood attenuation, e.g. due to temporary storage upstream of culverts, is taken into consideration. In most other cases where no temporal storage occurs the following relationship is valid:

$$\sum \text{Inflows} = \sum \text{Outflows} \quad \dots (4.2)$$

or

$$\sum Q_{\text{In}} = \sum Q_{\text{out}} \quad \dots (4.3)$$

$$Q = \bar{v}A \quad \dots (4.4)$$

where:

Q = flow rate (m^3/s)
 \bar{v} = average flow velocity (m/s)
 A = sectional area (m^2)
 V = volume stored (m^3)

The following rules are important in applying the principle of continuity of mass:

- Choose the boundaries of the problem and define the enclosed three-dimensional space the “control volume”. Mass balance should be satisfied for the control volume.

In defining the control volume the shape should be such that:

- flow sections are taken across flows where discharges are known or have to be calculated;
- flow sections are taken where the flow lines are parallel or almost parallel; and
- flow sections are perpendicular to the flow lines. This means that a section is not necessarily straight. In the case of subcritical sheet flow, for instance, flow lines could be drawn perpendicular to the contour lines and then the principle of continuity should be satisfied between successive flow lines as shown in **Figure 4.1**.




Figure 4.1: Choice of sections, where the direction of the flow changes across a section (Plan view with the flow direction as indicated by the flow lines)

4.2.4 Principle of conservation of energy (Energy principle)

4.2.4.1 Use of the energy principle

The energy principle should always be satisfied, and it is often applied together with the principle of continuity (mass) to:

- determine relationships between velocities and depths at different sections when energy losses are calculable or are small enough to be neglected;
- calculate energy losses between sections where the values of the energy components are known.

In its "complete" form, expressed in terms of energy per unit weight, the Bernoulli equation for open channel flow applies along a flow line. It reads as follows:

$$\frac{\alpha_1 \bar{V}_1^2}{2g} + y_1 \cos \theta_1 + z_1 = \frac{\alpha_2 \bar{V}_2^2}{2g} + y_2 \cos \theta_2 + z_2 + \Sigma h_{f_{1-2}} + \Sigma h_{l_{1-2}} \quad \dots(4.5)$$

where:

α_i	=	coefficient compensating for variations in velocity across a section
\bar{V}_i	=	average velocity across a section (m/s)
g	=	gravitational acceleration (a value of 9,81 m/s ² is generally used for design purposes) (m/s ²)
y_i	=	depth of flow measured perpendicular to the streambed (m)
θ_i	=	longitudinal bed slope angle (°)
z_i	=	bed level at point where depth of flow = y_i (m)
$\Sigma h_{f_{1-2}}$	=	friction losses between sections 1 and 2 (m)
$\Sigma h_{l_{1-2}}$	=	sum of transition losses between 1 and 2 (m)

Subscript 1 refers to the upstream section and subscript 2 to the downstream section.

Each term represents either energy content or energy loss per unit weight, with the resulting dimension being length as illustrated in **Figure 4.2**. It is recommended that in order to obtain a clear picture, the different terms be represented graphically as in **Figure 4.2**.




Figure 4.2: Longitudinal section along the flow path which reflects the different energy components

Depending on the circumstances, the energy equation may take on different forms as discussed in the following paragraphs.

4.2.4.2 Simplifications applied to the energy principle

The first simplification that arises where **slopes are not very steep** ($\theta < 10^\circ$ or $< 1:5$) is that:

$$y \cos \theta \approx y$$

In the case of **complex cross-sections**, α may be assumed to be equal to 1,05 with \bar{V}_m = **average velocity in the main (deepest) channel** :

$$\alpha \approx 1,05$$




Figure 4.3: Complex cross-section

Thus:

$$1,05 \frac{\bar{V}_{m1}^2}{2g} + y_1 + z_1 = 1,05 \frac{\bar{V}_{m2}^2}{2g} + y_2 + z_2 + \sum h_{f1-2} + \sum h_{l1-2} \quad \dots(4.6)$$

$\frac{\alpha \bar{V}_m^2}{2g}$ represents the total kinetic energy with $\frac{\bar{V}_m^2}{2g}$ the translational energy component and

$(\alpha - 1) \frac{\bar{V}_m^2}{2g}$ the rotational energy component^(4.1).

The most accurate estimate of the kinetic energy component is obtained where the highest flow velocity occurs, and the rotational energy component has its lowest value. It is not yet practicable to allow for variations in rotational energy, as well as for the associated curved shape of the water surface across a section. The surface line is assumed to be horizontal across the section.

In the case of **single channels** it is generally assumed that $\alpha = 1$.

$$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + \sum h_{f1-2} + \sum h_{l1-2} \quad \dots(4.7)$$

With **near uniform flow**, where the sectional area does not increase by more than 40% downstream within a distance of 20 times the average hydraulic radius, the transition losses can be neglected, and it follows that:

$$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + \sum h_{f1-2} \quad \dots(4.8)$$

(Refer to Section 4.2.7 for applicable transition energy loss coefficients.)

In the case of **converging flow over a short distance**, the downstream velocity is mainly determined by conversion of potential energy into kinetic energy. Energy losses may be ignored without causing much of an error in the calculation of v_2 and y_2 .




Figure 4.4: Strongly converging flow

In these cases:

$$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 \quad \dots(4.9)$$

or

$$q = C_c w \sqrt{2gy_1 \frac{y_1}{y_1 + y_2}} \quad \dots(4.10)$$

the **orifice formula** with

C_c = contraction coefficient ($\approx 0,6$)

w = vertical sluice opening (m)

When $v_1 = v_2$ (**uniform flow**) then it can be assumed that:

$$z_1 - z_2 = \sum h_{f1-2} \quad \dots(4.11)$$

$$hf_{1-2} = \frac{\bar{v}^2 L}{C^2 R} \text{ (Chézy equation)} \quad \dots(4.12)$$

$$hf_{1-2} = \frac{\lambda \bar{v}^2 L}{2gR} \text{ (Darcy-Weisbach equation)} \quad \dots(4.13)$$

$$hf_{1-2} = \frac{n^2 \bar{v}^2 L}{R^{4/3}} \text{ (Manning equation)} \quad \dots(4.14)$$

In the case of uniform man-made water courses, it is often convenient to define the energy level relative to the bed, and the energy thus defined is the **specific energy, E**:

$$E = y + \alpha \frac{\bar{v}^2}{2g} \quad \dots(4.15)$$

Critical conditions are associated with $\frac{Q^2 B}{gA^3} = 1$

In open channel flow a given discharge cannot move past a section with less specific energy than the critical specific energy. This condition is referred to as “critical” and is characterised by a Froude number = 1. (The condition occurs where the channel’s slope increases from less than the critical slope to larger than the critical slope, and the energy level is drawn down to the lowest possible value).

4.2.5 Defining controls in open channel flow

4.2.5.1 Types of hydraulic controls

All flow calculations should begin at hydraulic controls; i.e. sections at which the energy level for a given discharge is known. The three types of hydraulic controls are identified as:

- sections where the energy level and flow depth can be determined based on the application of the continuity of mass, energy and momentum and starting the calculation at a position of known depth (Hydraulic control – one of the types below);
- obstructions (man-made or natural) that induce flow to change from subcritical flow (upstream) to supercritical flow (downstream) going through critical depth at the control;
- sections where there is uniform open-channel flow (no change in roughness, cross sectional parameters, slope and flow rate along the flow path). At such positions the flow depth can be determined by using the Chézy or Manning equation which sets the energy grade line equal to the channel slope ($S_f = S_0$).

One control could invalidate another in that the local depths of flow may be forced higher or lower. For example, a barrier across a river serves only as a control as long as the downstream water levels are low enough not to increase the water levels higher up in the river by drowning out the control.

The various controls are discussed below and the most basic formulae are given. In important cases, more sophisticated formulae should be used.

4.2.5.2 Points of release

Here the normal (uniform) depth of flow decreases from greater than critical to less than critical; for example at rapids or at the edges of road shoulders. To identify a point of release, determine whether $y_{n1} > y_c > y_{n2}$ (The normal depth, y_n , is determined by means of the Chézy or Manning equation.)




Figure 4.5: Point of release as a control

Just upstream of the point where the slope increases from mild ($y_n > y_c$) to steep ($y_n < y_c$), critical conditions occur, and here:

$$\frac{Q^2 B}{g A^3} = 1 \quad \dots(4.16)$$

4.2.5.3 Broad-crested conditions

Broad-crested conditions ($L > 3H$ with $H = h + \frac{\bar{v}^2}{2g}$) occur for example at fully silted-up weirs in streams or where water flows across an embankment. This condition is equivalent to a release point with a very steep downstream slope.




Figure 4.6: Broad-crested weirs

In this case critical conditions occur near the downstream end, and hence $\frac{Q^2 B}{g A^3} = 1$ at this section.

This control is valid^(4.2) as long as $H^1 < 0,8 h_1$ (not drowned).

With $H_1 = h_1 + \frac{\bar{v}_1^2}{2g}$ and $\bar{v} = \sqrt{g y_c}$, since $Fr = 1$ it follows that:

$$Q = C_D \sqrt{g y_c} A = C_D \sqrt{g} b \left(\frac{2}{3} H_1 \right)^{1,5} \quad \dots(4.17)$$

4.2.5.4 Sharp-crested weir ($b \ll H$)




Figure 4.7: Sharp-crested weirs

This condition occurs where water flows over a thin-walled weir. The discharge for long weirs (wide streams) is given by ^(4.2):

$$q = \frac{2}{3} \left(0,611 + 0,08 \frac{H}{W} \right) \sqrt{2g} H^{\frac{3}{2}} \quad \dots(4.18)$$

where:

q = discharge per unit width ($\text{m}^3/\text{s}/\text{m}$)

With "short" weirs a value of $0,2H$ should be subtracted from the total length of the overflow section (B) to obtain the effective overflow width ($B - 0,2H$). This is a valid control as long as the downstream water surface is below the crest of the weir.

4.2.5.5 Cases between broad-crested and sharp-crested conditions

In such cases one may interpolate between the results of the equations for broad-crested and sharp-crested weirs.

4.2.5.6 Culvert inlets

Culverts with inlet control are discussed in **Chapter 7**. With high damming levels, orifice flow occurs.

4.2.5.7 General contractions

Where a contraction of section occurs (either in width or as a result of a local rising of the bed or through both width reduction and bed rising), a control may be formed. A control comes into being when the upstream energy level is lower than the minimum energy level (critical condition) needed at the contraction to pass the full discharge. Such conditions may be found, for example, at bridges with small openings or at rocky contractions across rivers.

4.2.5.8 Under-outlets (Orifices)

Orifice flow conditions may occur in road drainage at grid inlets (**Chapter 5**) and at culvert inlets (**Chapter 7**).

4.2.5.9 Uniform flow conditions

True uniform conditions only occur in long straight sections of a channel with a uniform cross-section. When a uniform control section needs to be found, one should ensure that uniform flow conditions do in fact prevail. This means that the depth of flow depends only on the local slope, roughness and sectional shape and is not affected by controls or obstructions upstream or downstream.

Either the Chézy or Manning equation is then used to determine the normal depth of flow. With Q (discharge) known, the slope (S), roughness coefficient (k_s or n) and section dimensions should be determined. For this purpose the longest possible "straight" section of the watercourse should be selected so that the slope can be determined with sufficient accuracy.

The cross-section should also be fairly uniform so that the transition losses can be limited between two consecutive cross-sections. In estimating the overall roughness coefficient, greater weight should be given to the roughness along the deeper parts than to the roughness along shallower parts of a cross-section.

Moreover, the minimum and maximum possible values for the variables should be determined so that minimum and maximum possible "uniform" depths of flow may be obtained. Once these depths are known, one may determine the depths upstream ($Fr < 1$) and downstream ($Fr > 1$) at the specific cross-sections of interest. Fortunately, if an incorrect depth is used at the control, the error will diminish with progressive analyses away from the control section. It is thus possible to test whether the maximum and minimum possible control depths eventually give the same results, or whether one should start calculations with the most conservative value.

When the Froude number at the control section is for instance between 0,8 and 1,2, the flow could easily change from subcritical to supercritical or vice versa, and it **cannot simply be accepted that the flow will be purely supercritical or subcritical**. In such a case a conservative value (maximum or minimum) should be accepted for the depth of flow.

4.2.5.10 Combination conditions

An example of a combined control condition that occurs in road drainage is where water flows simultaneously over a road and through a culvert underneath the road.

In this case the flow over the road is analysed according to release conditions, taking energy losses into account, and the culvert flow is analysed separately according to culvert flow formulae. The upstream flow depth is varied until the total flow equals the design discharge.

4.2.6 Friction losses

4.2.6.1 Limitations in the application of the friction loss relationships

Strictly speaking, the various expressions for friction losses are only applicable to uniform flow conditions, but they are used to determine approximate energy losses in gradually changing non-uniform flow.

When analysing friction losses, a distinction must necessarily be made between three different flow conditions. The different conditions are roughly identified according to the Reynolds number, which is defined by:

$$R_e = \frac{\bar{v}R}{\nu} \quad \dots(4.19)$$

with:

- \bar{v} = average flow velocity (m/s)
- R = hydraulic radius (m)
- ν = kinematic viscosity, with a general design value of $1,14 \times 10^{-6} \text{ m}^2/\text{s}$ for water

The value of R_e is then used to define the flow type as follows:

- Laminar flow ($R_e \leq 500$)
- Transition flow ($500 < R_e < 5000$)
- Turbulent flow ($R_e \geq 5000$)

In the following paragraphs relationships are provided to calculate the friction loss for the different flow types.

4.2.6.2 Friction loss calculation for laminar flow ($R_e \leq 500$)

Laminar open channel flow of water occurs only at extremely low velocities, and is only of practical interest where very shallow flow conditions occur; for example with shallow run-off over paved surfaces.

In such cases energy losses have been expressed in terms of the Darcy-Weisbach formula ^(4.3), even though this formula is strictly speaking only applicable to turbulent flow.

$$h_f = \frac{f L \bar{v}^2}{8 g R} \qquad \dots(4.20)$$

where:

- h_f = energy loss over distance L (m)
- f = roughness coefficient
- L = distance (m)
- \bar{v} = average velocity (m/s)
- g = gravitational acceleration (m/s²)
- R = hydraulic radius i.e. area divided by wetted perimeter (m)

In laminar flow the roughness coefficient, f , is expressed in terms of the R_e number and a resistance coefficient K_0

$$f = \frac{K_0}{R_e} \qquad \dots(4.21)$$

Useful values of K_0 for application to drainage are as follows ^(4.3):

Table 4.3: Typical values of K_0	
Surface	K_0
Smooth	24
Concrete and bitumen	24 - 108
Pure sand	30 - 120
Gravel surface	90 - 400
Pure clay or loam	100 - 500
Eroded ground with little vegetation	1 000 - 4 000
Short prairie grass	3 000 - 10 000
Blue-grass	2 000 - 40 000

In interpreting these values it should be borne in mind that an increased value of K_0 mainly represents a decrease in effective flow area.

4.2.6.3 Friction loss calculation for transition conditions ($500 < R_e < 5000$)

It is seldom possible to calculate friction losses for flow accurately in this range. Maximum possible values for losses are obtained by applying the relationships for turbulent flow, and minimum values according to the relationships for laminar flow.

4.2.6.4 Friction loss calculation for turbulent flow ($R_e \geq 5000$)

Complete theoretical analysis ^(4.1), as well as experimentation has shown that the following equation is fundamentally correct and, as reflected here, may be generally applied for design purposes:

$$\bar{v} = 5,75 \sqrt{gRS} \log \frac{12R}{k_s + \frac{3,3\nu}{\sqrt{gRS}}} \quad \dots(4.22)$$

where:

- \bar{v} = average velocity (m/s)
- R = hydraulic radius (m)
- S = energy slope, which is equal to bed slope only when flow is uniform (m/m)
- k_s = roughness coefficient, representing the size of irregularities on bed and sides (m)
- ν = kinematic viscosity ($\approx 1,14 \times 10^{-6} \text{ m}^2/\text{s}$ for water)

As given here the equation is generally applicable to turbulent flow with "rough" or "smooth-wall" conditions.

Since "smooth-wall" conditions rarely occur in open channel flow (only with plastic pipes, etc), the equation can often be applied in the following simplified form:

$$\bar{v} = 5,75 \sqrt{gRS} \log \left(\frac{12R}{k_s} \right) \quad \dots(4.23)$$

which is equivalent to the Chézy equation

$$\bar{v} = C \sqrt{RS} \quad \dots(4.24)$$

with:

$$C = 5,75 \sqrt{g} \log \left(\frac{12R}{k_s} \right) \quad \dots(4.25)$$

or

$$C = 18 \log \left(\frac{12R}{k_s} \right) \quad \dots(4.26)$$

with the units of C being $\text{m}^{0,5}/\text{s}$, if SI units are used.

Another formula that is not fundamentally correct, but which is generally used, is the Manning equation:

$$\bar{v} = \frac{R^{\frac{2}{3}} S^{\frac{1}{2}}}{n} \quad \dots(4.27)$$

where:

- n = roughness coefficient with units of $\text{s}/\text{m}^{1/3}$

Note that the roughness coefficient n is not a constant, but varies in roughness with the change in hydraulic radius.

Information available from various sources on k_s -values and n -values is given in **Figure 4.8**, **Figure 4.9** and **Figure 4.10** for practical use. The descriptions of different conditions are given opposite the applicable average k_s -values. When estimating a k_s -value for practical use, it is useful to bear in mind that the k_s -value represents the effective average size of eddies formed to fit in with the irregularities on the bed. In this way a realistic estimate of extreme k_s -values may be made for any condition. As the velocity equation for "rough-wall" conditions (Equation 4.23) is rather insensitive to changes in the k_s -value, a satisfactory and realistic answer can usually be obtained when calculating the velocity. Where the k_s -value is very low, for example in the case of plastic pipes, one should test to see whether rough-turbulent conditions are indeed present:

$$\frac{\sqrt{gR}k_s}{v} > 30 \quad \dots(4.28)$$

If the value obtained in the above equation is less than 30, the complete Equation 4.22 should be used to calculate the flow velocity.

The Manning equation as such does not compensate sufficiently for changes in the n -value with hydraulic radius. Applicable n -values may be read off **Figure 4.10**.

In cases of extreme roughness, for example where willow trees grow in a river, the Manning and Chézy equations are not strictly applicable, since large-scale transition losses dominate rather than friction losses. In such cases roughness coefficients should be handled carefully.

In sand bedded rivers, roughness could vary greatly as different bed-forms develop. Roughness coefficients in such rivers need to be determined through an iterative process ^(4.5).

Photographs 4.1 to 4.5 reflect some typical roughness values in South African rivers.



Photograph 4.1: River section in the Komati River. Estimated roughness = 0,4 m




Photograph 4.2: River section in the Klip River. Estimated roughness = 0,10 m



Photograph 4.3: River section in the Limpopo River. Estimated roughness = 0,50 m



Photograph 4.4: River section in the Berg River. Estimated roughness = 0,3 m



**Photograph 4.5: Concrete side drain. Estimated roughness = 0,002 m
(Manning n-value = 0,016 s/m^{1/3})**

CHANNELS AND RIVERS	FLOOD PLAINS AND OVERLAND FLOW	STONE, ROCK AND BRICK	
	Dense Willows ($n \sim 0.2$)		10
Very weedy reaches	Heavy stand of timber, stage reaching branches		8
Deep pools in minor streams			
Sluggish reaches, Weedy deep pools	Heavy stand of timber, stage below branches		6
			4
Dense weeds, high as flow depth in channels	Medium to dense bush		2
Mountain streams, cobbles with large boulders	Light brush and trees		
			1
Clean, winding streams, some pools and chutes	Cleared land with tree stumps no sprouts	Jagged and irregular rock cuts	0.8
Dense weeds or aquatic	Mature field crops	Smooth and uniform rock cuts	0.6
Plates in deep channels			
Mountain streams, cobbles and few boulders	Pasture no brush, long grass mature row crops	Rubble or riprap placed above water	0.4
Natural straight streams, no rifts or deep pools	Cultivated area, no crop pasture, no brush, short grass	Hand placed pitching	0.2
Excavated channel with short grass			0.1
Clean uniform gravel section			0.08
		Rubble masonry, cemented	
Excavated or dredged earth channel weathered			0.06
			0.04
	Bare clay loam (Eroded)	Random stone in mortar	
			0.02
Clean, newly excavated earth channel	Graveled surface	Paved invert sewer smooth bottom	
			0.01
		Dressed stone in mortar	
			0.008
			0.006
	Rough asphalt or concrete	Vitrified subdrain with open joint	0.004
		Dressed ashlar brickwork lined with cement mortar	
		Vitrified sewer with manholes, inlets, etc. Sanitary sewers coated with sewage slimes including bends, etc.	0.002
	Smooth concrete or asphalt, bare sand	Vitrified sewer glazed brickwork Common drainage tile	0.001

Figure 4.8: Average roughness coefficients for rough turbulent flow (Refer to Figure 4.10)

CONCRETE AND PLASTER	WOOD AND OTHER	METALS	
			1
			0.8
			0.6
			0.4
		Armco culverts	0.2
			0.1
			0.08
			0.06
Gunite, wavy section Gunite, untreated		Corrugated metal storm drain	0.04
			0.02
Gunite, good section		Corrugated metal subdrain	0.01
			0.008
Concrete unfinished rough wood form	Laminated, treated timber		0.006
Concrete finished with gravel on bottom	Rough asphalt	Steel : Riveted and spiral wrought iron : Galvanised	0.004
Concrete sewer with manholes etc., straight	Plank with battens	Cast iron : Uncoated	0.002
Concrete float finish Concrete unfinished wood form	Sawn timber, joints uneven	Wrought iron : Black	0.001
Precast concrete : mortar not wiped on inside of joint	Unplaned timber	Steel : Strongly corroded Cast iron : Coated Steel : Painted	0.0008
Concrete : Trowel finish mortar Concrete : Unfinished steel form	Asbestos cement Smooth asphalt	Steel : Unpainted	0.0006
Culvert with bends and some debris	Stave Planed timber	Steel : Riveted Steel : Lockbar and welded	0.0004
Concrete : Finished	Planed creosoted timber		0.0002
Concrete : Cast in lubricated steel molds, smoothed seams and joints			
Cement : Neat surface Culvert straight and free of debris		Steel : Riveted with counter sunk heads	
Concrete : Very smooth cast against oiled steel forms	Smooth hardboard		
Concrete : Centrifuged			

Figure 4.9: Average roughness coefficients for rough turbulent flow (Refer to Figure 4.10)




Figure 4.10: Average roughness coefficient for rough turbulent flow

(A copy of this diagram has been included on the flash drive/DVD at the back of this document.)

4.2.7 Transition losses

4.2.7.1 General introduction to transition losses

Transition losses occur where there are changes in the magnitude and/or direction of flow velocities. Unlike friction losses, which represent overall application of energy to maintain flow, transition losses represent energy applied to maintain local eddies in separation zones. These eddies develop locally where the stream breaks away from the solid boundary. There is a particular tendency to break away where the cross-section becomes larger downstream, or where other major changes in flow direction take place, for example at bends. Convergence losses are usually much smaller than divergence losses.

Losses may be diminished by shaping a conduit so as to decrease the size of the separation eddies. Uniform open channel flow along a channel is only possible if the channel bed drops across each transition by a height equal to the local transition loss.

It is much more difficult to quantify transition losses in open channel flow than in pipe flow, due to a range of possible values of the hydraulic radius for given dimensions of the conduit.

The following formulae are recommended for general use, since these are fundamentally correct and usually provide conservative but realistic answers.

4.2.7.2 Divergence losses (downstream section A_2 larger than upstream section A_1)

The recommended equation is applicable to subcritical flow ($Fr < 1$) and reads as follows:

$$h_1 = C_L \frac{\bar{v}_1^2}{2g} \left(1 - \frac{A_1}{A_2} \right)^2 \quad \dots(4.29)$$

where:

- h_1 = transition loss (m)
- C_L = loss coefficient with maximum value = 1 for sudden transitions and a minimum value of 0,3 for gradual transitions (taper of 1:4)
- \bar{v}_1 = upstream average velocity (m/s)
- A_1 = upstream sectional area (m²)
- A_2 = downstream sectional area (m²)

If $C_L = 1$, this implies that there is no recovery of kinetic energy whilst the velocity decreases from v_1 to v_2 . If the value of C_L lies between 0,3 and 1,0, this implies some recovery of energy. A value of 0,3 is only applicable if the taper is at least equal to the optimum practical value of 1:4, as shown in **Figure 4.11**.




Figure 4.11: Divergence loss coefficient

Since supercritical flow is subject to upstream control, it is not able to spread over a short distance or to rapidly change direction without changing to subcritical flow (hydraulic jump). In the latter case the energy losses are very high, and an analysis should be performed by means of the momentum principle rather than the energy principle.

4.2.7.3 Convergence losses (subcritical flow)

The recommended formula reads:

$$h_l = C_L \frac{\bar{v}_2^2}{2g} \quad \dots(4.30)$$

where:

$$\begin{aligned} h_l &= \text{transition loss (m)} \\ \bar{v}_2 &= \text{downstream average velocity (m/s)} \\ C_L &= 0,35 \text{ for sudden contractions (0,18 for rounded contractions)} \end{aligned}$$

4.2.7.4 Bend losses (subcritical flow)

The recommended formula reads ^(4.4):

$$h_l = \frac{2B}{r_c} \frac{\bar{v}^2}{2g} \quad \dots(4.31)$$

where:

$$\begin{aligned} h_l &= \text{transition loss (m)} \\ B &= \text{channel width (m)} \\ r_c &= \text{centre line radius (m)} \\ \bar{v} &= \text{uniform channel average velocity (m/s)} \end{aligned}$$

This equation has been found to be valid for direction changes between 90° and 180° mainly because the losses at bends are concentrated where the stream initially breaks away from the solid boundary. The losses at bends vary very little for directional changes between 90° and 180°. It was also established that the losses at clear direction changes of less than 90° can also be described by this relationship.

4.2.8 Rules for the application of the energy equation

Practical application of the energy equation (together with the continuity principle) typically consists of working in steps along the flow route, starting at a point where flow conditions are known (control) and ending where flow conditions need to be known. Cross-sections are selected so that energy losses can be calculated between successive sections, either as transition losses or as friction losses. It is practicable in the selection of sections to start off by selecting sections just upstream and downstream of significant transition losses, and thereafter to sub-divide the rest of the channel into reaches in between cross-sections, which may be regarded as near uniform.

The following steps may be followed:

- Identify every possible control that may affect the depth of flow in the area of interest.
- In the case of subcritical flow, analyses **may** only be performed upstream and in the case of supercritical flow, only downstream.
- Choose consecutive sections from the control(s) to the end of the area in which the depths of flow are required. Sections are chosen perpendicular to flow lines, and only where the flow lines do not curve sharply. Sections are chosen at controls and otherwise upstream and downstream of areas with significant transition losses. Sections outside regions of transition losses are chosen such that the **sectional areas and hydraulic radii do not vary by more than 40 per cent from one section to the next**. This ensures that friction losses are calculated with sufficient accuracy.

- If the sectional areas do not increase by more than 40 per cent in the stream direction within a distance of 20 times the mean hydraulic radius, there is **no need** to allow for transition losses.
- Start with the most likely control and determine the energy level. (Later ensure that the controls being used are indeed valid.)

With $(y_1 + z_1)$ or $(y_2 + z_2)$ known at the control, estimate the value of:

$$(y_2 + z_2), \text{ if } \left(\frac{Q^2 B}{g A^3} > 1 \right) \text{ or } (y_1 + z_1), \text{ if } \left(\frac{Q^2 B}{g A^3} < 1 \right)$$

Calculate the corresponding energy level at the next section, as well as the energy losses between the two sections. Thereafter test whether the estimated and calculated energy levels agree within say 10 mm. If not, choose an improved value of $(y + z)$ and repeat.




Figure 4.12: Energy components

Choose subsections such that the depth and roughness measure k_s do not vary by more than a factor of 2 across every subsection. Roughness coefficients are obtained from **Figure 4.8** and **Figure 4.9**. Every subsection should be more or less perpendicular to the direction of flow. **Table 4.4** reflects some of the calculation steps required for the application of the conservation of energy law.

Table 4.4: Calculation steps in applying the law of conservation of energy

Subcritical flow ($Fr < 1$)	Supercritical flow ($Fr > 1$)
Determine $z_2 + y_2$ (at control)	Determine $z_1 + y_1$ (at control)
Estimate $z_1 + y_1$ (upstream) ($\approx z_2 + y_2 + \Delta x S_{f_2}$)	Estimate $z_2 + y_2$ (downstream) ($\approx z_1 + y_1 - \Delta x S_{f_1}$)
Calculate $\alpha_1 \frac{\bar{V}_1^2}{2g}$	Calculate $\alpha_2 \frac{\bar{V}_2^2}{2g}$

Test to determine whether Equation 4.5 is satisfied:

$$\frac{\alpha_1 \bar{V}_1^2}{2g} + (z_1 + y_1) = \frac{\alpha_2 \bar{V}_2^2}{2g} + (z_2 + y_2) + \Sigma h_{f1-2} + \Sigma h_{L1-2} \quad \dots(4.32)$$

Single streams

$$\alpha = 1$$

$$\bar{v} = \frac{Q}{A} \quad \dots(4.33)$$

$$R = \frac{A}{P} \quad \dots(4.34)$$

$$h_f = \bar{S}_f \Delta x = \left(\frac{\bar{v}_1^2}{C_1^2 R_1} + \frac{\bar{v}_2^2}{C_2^2 R_2} \right) \frac{\Delta x}{2} \text{ (Chézy)} \quad \dots(4.35)$$

where:

$$C = 18 \log \left(\frac{12R}{k_s} \right) \quad \dots(4.36)$$

or

$$h_f = \left(\frac{\bar{v}_1^2 n_1^2}{R_1^{\frac{4}{3}}} + \frac{\bar{v}_2^2 n_2^2}{R_2^{\frac{4}{3}}} \right) \frac{\Delta x}{2} \text{ (Manning)} \quad \dots(4.37)$$

For k_s and n -values consult **Figure 4.8** and **Figure 4.9**.

Transition losses, h_l approach the value of 0, if $A_2 < 1,4A_1$, and $\Delta x > 20 \bar{R}$. Otherwise see **Section 4.2.7** for the determination of **transition** losses, h_l .

4.2.8.1 Application of the energy principle in complex sections

In complex cross sections, as shown in **Figure 4.13**, the value of α could approach 1,05. Under these conditions the following approach should be considered:

The velocity in each of the sections can be determined as is demonstrated for section c below:

$$\bar{v}_c = C_c \sqrt{R_c S_f} \quad \dots(4.38)$$

Based on this approach the conveyance, K , can be determined if the above relationship is reorganized/rewritten as shown below.




Figure 4.13: Complex section

$$S_f = \left(\frac{\sum Q}{\sum K} \right)^2 \quad \dots(4.39)$$

$$R_c = \frac{A_c}{P_c} \quad \dots(4.40)$$

$$K_c = C_c A_c \sqrt{R_c} \quad (\text{Chezy}) \quad \dots(4.41)$$

$$C_c = \left(18 \log \frac{12 R_c}{k_{sc}} \right) \quad \dots(4.42)$$

or

$$K_c = \frac{A_c R_c^{\frac{2}{3}}}{n} \quad (\text{Manning}) \quad \dots(4.43)$$

$$h_f = \frac{(\sum Q)^2}{(\sum K)^2} \Delta x \quad \dots(4.44)$$

or

$\sum Q$ = Total discharge

$$\sum Q = (K_a + K_b + K_c + \dots) S_f^{1/2} \quad \dots(4.45)$$

4.2.8.2 Application of the energy principle in branched flow channels

When a stream branches into two or more streams for some distance, as illustrated in **Figure 4.14**, an analyses should be performed up to section 2 (if the stream is downstream controlled, $Fr < 1$) or calculate the flow depth at section 1 from the upstream side if supercritical flow is prevailing ($Fr > 1$). Then estimate what fraction of the total flow passes through each branch. Calculate the energy losses for flow through each branch and adjust the flows until the same energy losses are obtained through each branch between section 1 and section 2.




Figure 4.14: Branched Flows

Perform the analysis as before up to just downstream ($Fr < 1$) or upstream ($Fr > 1$) of the division. Then estimate what fraction of the total flow passes through each branch. Calculate the energy losses for flow through each branch and adjust the flows until the same energy losses are obtained through each branch between (1) and (2).

4.2.9 Conservation of momentum (Momentum principle)

The momentum equation can be used to analyse flow conditions where:

- It is necessary to calculate the forces exerted on obstructions, or
- The relationships between flow conditions have to be determined in areas where large unknown energy losses occur, e.g. with hydraulic jumps.

In the general form for steady conditions, the momentum equation for a chosen x direction could be defined as follows:

Sum of all the external force components acting on a flow system (control volume) in the x direction = (Sum of the momentum components of the outflows in the x direction) – (Sum of the momentum components of the inflows in the x direction).

The momentum equation is always applied across a control volume as shown in **Figure 4.15**.




Figure 4.15: Momentum flux ($\rho q \bar{v}$) and the forces ($\rho g \bar{y} A$) acting on the control volume

In the typical case shown above:

x – direction:

$$(\bar{\gamma}\bar{y}_1A_1)_x - (\bar{\gamma}\bar{y}_2A_2)_x - F_x = \rho Q(\bar{v}_{2x} - \bar{v}_{1x}) \quad \dots(4.46)$$

y – direction:

$$(\bar{\gamma}\bar{y}_1A_1)_y - (\bar{\gamma}\bar{y}_2A_2)_y - F_y - Mg = \rho Q(\bar{v}_{2y} - \bar{v}_{1y}) \quad \dots(4.47)$$

where:

$\bar{\gamma}\bar{y}A$	=	external hydrostatic force width
$\bar{\gamma}$	=	specific weight for water ($9,81 \times 10^3 \text{ N/m}^3$)
\bar{y}	=	distance between water surface and centre of gravity of section (m)
A	=	sectional area (m^2)
$(\bar{\gamma}\bar{y}A)_x$	=	force component in x direction
$(\bar{\gamma}\bar{y}A)_y$	=	force component in y direction
\bar{v}_x	=	average velocity component in x direction (m/s)
\bar{v}_y	=	average velocity component in y direction (m/s)
F_x	=	size of force component exerted on flow by the solid boundary and obstructions in x direction (N)
F_y	=	size of force component exerted on flow by the solid boundary and obstructions in y direction (N)
Mg	=	weight of the enclosed fluid mass (N)

4.2.10 Steps to be followed when applying the momentum equation

- Select axes. It is convenient to work with horizontal and vertical axes.
- Choose sections perpendicular to the direction of flow at sections where the flow lines are parallel. The sections are chosen such that either all the external forces operating on the enclosed fluid are known, or so that the body of the fluid is included on which the unknown operating forces have to be determined.
- Identify all external forces, namely:
 - weight of enclosed fluid (control volume);
 - hydrostatic forces exerted on the cross sections (boundaries of the control volume) as a result of the pressure at the sections;
 - forces exerted on fluid by the boundary and obstructions.

In open channel flow it is usually realistic to accept that the variation in pressure is hydrostatic where the flow lines are parallel and/or where the fluid moves very slowly (e.g. break-away eddies). Where supercritical flow penetrates partially right up to an obstruction, the pressure may be greater than hydrostatic, as illustrated ^(4.2) in **Figure 4.16**.




Figure 4.16: Pressure distribution at a step

Once the equations have been compiled one can solve the unknowns. (The momentum equation is generally used with the continuity equation.) It should be remembered that the force components in the momentum equation are those that are exerted on the fluid at the selected cross sections. The force components exerted by the fluid on obstructions are equal and opposite to the calculated values.










Photograph 4.6: Hydraulic jump

4.2.11 Analysis of transition conditions

Table 4.5, **Table 4.6** and **Table 4.7** provide summaries of the most commonly used transition relationships in open channel flow.

Table 4.5: Summary of the analysis of transition conditions (Slope increase, bed drops or the channel widens)









Froude	Longitudinal section		Control	Energy loss h_{1-2}	#
	Slope changes	Section widens			
$Fr_1 < Fr_2 < 1$			Y_2 determined by downstream conditions	$h_{1-2} = C_L \frac{\bar{v}^2}{2g} (1 - \frac{A_1}{A_2})^2$ $0,3 > C_L < 1,0$	1
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$ or equations 4.45 and 4.46 can be used				
$Fr_1 > 1$ $Fr_2 < 1$			Y_2 determined by downstream conditions Y_1 determined by upstream conditions	Large energy loss	2
	Small slopes $(\gamma \bar{y}_1 A_1)_x - (\gamma \bar{y}_2 A_2)_x + F_x = \rho Q(\bar{v}_2 - \bar{v}_1)_x$				
$Fr_1 < 1$ $Fr_2 > 1$		Not possible	Critical conditions at point of release	Small energy loss	3
	$\frac{Q^2 B}{g A^3} = 1$ Critical conditions at the release point $\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2$				
$Fr_1 > 1$ $Fr_2 > 1$			Y_1 determined by upstream conditions	Small energy loss	4
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2$				

Note: #

1. If the downstream channel is long, y_2 will approach y_n .
2. Due to high-energy losses, the momentum equation should be used. At a stable hydraulic jump the forces are balanced.
3. Under conditions where the floor drops and the section widens, the flow might not follow the channel sides.
4. The stream will not always follow the sides or the bottom everywhere.

Possibility of back circulation near the sides might be experienced when the cross-sectional area increases rapidly.





Table 4.6: Summary of the analysis of transition conditions (Slope decreases, bed steps upwards or the channel converges)

Froude	Longitudinal section		Control	Energy loss h_{1-2}	#
	Floor rises	Section converges			
$Fr_1 < 1$ $Fr_2 < 1$			Y_2 determined by downstream conditions	$h_{1-2} = C_L \frac{\bar{v}^2}{2g}$ $0,18 > C_L < 0,35$	5
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$				
$Fr_1 > 1$ $Fr_2 < 1$			Y_2 determined by downstream conditions Y_1 determined by upstream conditions	Large energy loss	6
	$(\gamma \bar{y}_1 A_1)_x - (\gamma \bar{y}_2 A_2)_x + F_x = \rho Q(\bar{v}_2 - \bar{v}_1)_x$ applicable to small slopes. Difficult to determine F_x				
$Fr_1 < 1$ $Fr_2 > 1$			Critical conditions at point of release	$h_{1-2} = C_L \frac{\bar{v}^2}{2g}$ $0,18 > C_L < 0,35$	7
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$				
$Fr_1 > Fr_2 > 1$			Y_1 determined by upstream conditions. Damming can occur when the criteria in Note 8 is met	Energy loss is small unless dammed – then large energy loss will occur across the hydraulic jump	8
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$, for limited damming				

Note: #

5. If the downstream channel is long, y_2 will approach y_n .
6. If $F_x >$ than the hydrostatic force, refer to paragraph 4.2.9
7. Analysis may be conducted upstream and downstream from the critical section. Critical conditions will occur at the section of maximum contraction.
8. Damming occurs when $\frac{\bar{v}_1^2}{2g} + y_1 + z_1 < \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$ or if the force F_x is high.

Table 4.7: Summary of the analysis of transition conditions (Bends in channel sections)

Froude	Longitudinal section		Control	Energy loss h_{1-2}	#
$Fr_1 < 1$ $Fr_2 < 1$			Y_2 determined by downstream conditions	$h_{1-2} = \frac{2b}{r_c} \frac{\bar{v}_1^2}{2g}$	9
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$				
$Fr_1 > 1$ $Fr_2 > 1$			Y_1 determined by upstream conditions	Losses high when damming occurs	10
	$\frac{\bar{v}_1^2}{2g} + y_1 + z_1 = \frac{\bar{v}_2^2}{2g} + y_2 + z_2 + h_{1-2}$				

Note: #

9. Refer to Section 5.4 for the required raising of the channel wall on the outside of the bend.
10. Stream might overtop the channel or a hydraulic jump can be formed. Changing the flow direction under supercritical conditions should be avoided at all times. Experienced persons can conduct the analyses.

4.3 PIPE FLOW**4.3.1 Introduction**

The general design problem reads: given a discharge, what difference in energy level is needed to pass the fluid through a pipe or culvert; or: what size of conduit is needed to convey the fluid with a predetermined difference in energy levels?

Just as with open channel flow, only the continuity, energy and momentum equations are used. Virtually all analyses of flow conditions are done by means of the combination of continuity and energy equations, whereas the momentum equation is used mainly in drainage pipes to determine forces at bends and other transitions.

Flow analyses should again begin at controls; i.e. at sections where the energy levels for given discharges are known and calculations essentially proceed upstream. Since the hydraulic radius can only have one value under full flow conditions, pipe flow analyses are simpler than those for open channel flow.

The most important applications of pipe flow theory in road drainage pertain to culverts and storm water pipes under full-flow conditions.

4.3.2 Principle of continuity

Except where flood attenuation is considered, only the continuity equation for steady incompressible flow is typically of use in drainage.

It reads:

$$\Sigma \text{Inflows} = \Sigma \text{Outflows} \quad \dots(4.48)$$

or

$$\Sigma Q_{\text{in}} = \Sigma Q_{\text{out}} \quad \dots(4.49)$$

Again, sections are taken perpendicular to the direction of flow and only where the flow lines are straight and parallel.

4.3.3 Energy principle

The energy principle is represented by the Bernoulli equation for pipe flow. **Figure 4.17** presents the different energy components associated with close conduit flow.




Figure 4.17: Energy components for pressurized flow in a pipe

$$\frac{\alpha_1 \bar{v}_1^2}{2g} + \frac{p_1}{\gamma} + z_1 = \frac{\alpha_2 \bar{v}_2^2}{2g} + \frac{p_2}{\gamma} + z_2 + h_{f1-2} + h_{\ell1-2} \quad \dots(4.50)$$

where:

- α_i = velocity coefficient with a value of 1 in most practical applications
- \bar{v}_i = average velocity (m/s)
- Q = discharge (m³/s)
- A = cross-sectional area ($\frac{\pi D^2}{4}$ for round pipes with diameter D) (m²)
- p = intensity of pressure at centre-line (Pa)
- γ = specific weight (value for water $9,81 \times 10^3$ N/m³)
- z = centre line elevation (m)
- h_f = friction losses, which may be expressed in terms of the Chézy or Manning equations (m)
- h_ℓ = transition losses occurring where the flow velocity changes in magnitude or direction (m)

4.3.4 Application of the energy equation

Start at a control. The following could be used as controls:

- Energy levels determined by drowned open channel flow conditions; or
- Free outflow where $p/\gamma = 0$ and the energy level may be calculated.

Calculations also begin with a known or estimated conduit size. Friction losses (in the normal case of turbulent flow) could be calculated by means of the Chézy or Manning equations (**Figure 4.8** and **Figure 4.9** provide typical roughness coefficients).

Chézy:

$$h_{f_{1-2}} = \frac{\bar{v}^2 L}{C^2 R} \quad \dots(4.51)$$

where:

$$\bar{v} = 5,75 \sqrt{gRS} \log \frac{12R}{k_s + \frac{3,3\nu}{\sqrt{gRS}}} \quad \dots(4.52)$$

and:

$$\begin{aligned} \bar{v} &= \text{average velocity (discharge divided by area) (m/s)} \\ L &= \text{pipe length (m)} \\ R &= \text{hydraulic radius (m)} \\ R = \frac{A}{P} = \frac{D}{4} &\text{ for circular pipes (m)} \\ k_s &= \text{measure of absolute roughness (from **Figure 4.8**)} \\ \nu &= \text{kinematic viscosity with a design value of } 1,14 \times 10^{-6} \text{ m}^2/\text{s for water} \\ S &= \text{energy gradient} = \frac{h_f}{L} \end{aligned} \quad \dots(4.53)$$

If "rough" pipes are used, i.e. pipes not made of plastic or similar smooth material, the value of C may be calculated as follows:

$$C = 5,75 \sqrt{g} \log \left(\frac{12R}{k_s} \right) \quad \dots(4.54)$$

Manning:

$$h_{f_{1-2}} = \frac{\bar{v}^2 n^2}{R^{\frac{4}{3}}} \quad \dots(4.55)$$

The Manning relationship is only applicable for "rough" conduits and for a given absolute roughness k_s , the Manning roughness n will be influenced by the hydraulic radius as is reflected in **Figure 4.10**.

Figure 4.10 reflects the appropriate n -values as a function of the absolute roughness and the hydraulic radius.

Table 4.8: Transition losses in pipe flows

Description	Sketch	k-value
Inlets $h_1 = \frac{k\bar{v}^2}{2g}$ (\bar{v} = average velocity in conduit)	Protruding Oblique Blunt Well-rounded	0,9 0,7 0,5 0,2
Diverging sections $h_1 = \frac{k(\bar{v}_1 - \bar{v}_2)^2}{2g}$	Sudden Cone $45^\circ < \theta < 180^\circ$ $\theta = 30^\circ$ $\theta = 15^\circ$	1,0 1,0 0,7 0,2
Converging sections $h_1 = \frac{k\bar{v}^2}{2g}$	Sudden Cone	0,5 0,25
Bends $h_1 = \frac{k\bar{v}_2^2}{2g}$	$\theta = 90^\circ$ $\theta = 45^\circ$	0,4 0,3
Outlets $h_1 = \frac{k\bar{v}_1^2}{2g} \left(1 - \frac{A_1}{A_2}\right)^2$	Sudden	1,0

4.3.5 Principle of momentum conservation

Since the principle of momentum conservation has limited application here, only the case in which forces at bends need to be determined is analysed, as shown in **Figure 4.18**.




Figure 4.18: Forces acting on an isolated bend

Analytical procedure for the application of the momentum principle:

Calculate p_1 and p_2 , the values of the intensities of pressure, by means of the Bernoulli equation. Take F_x and F_y as the components of the force exercised on the fluid by the bend (opposite of the force exercised on the bend by the fluid).

Compile equations:

$$\mathbf{x - direction:} \quad -F_x + p_1 A_1 \cos \beta_1 - p_2 A_2 \cos \beta_2 = \rho Q (\bar{v}_2 \cos \beta_2 - \bar{v}_1 \cos \beta_1) \quad \dots(4.56)$$

$$\mathbf{y - direction:} \quad -p_1 A_1 \sin \beta_1 + p_2 A_2 \sin \beta_2 - Mg - F_y = \rho Q (-\bar{v}_2 \sin \beta_2 + \bar{v}_1 \sin \beta_1) \quad \dots(4.57)$$

Where:

p_1 and p_2	=	intensities of pressure on either side of the bend (N/m^2)
A_1 and A_2	=	sectional areas on the upstream and downstream sides (m^2)
F_x and F_y	=	force components exerted by the solid boundary on the water (opposite and equal to the force exercised by the water on the solid boundary) (N)
β_1 and β_2	=	angles of direction ($^\circ$)
ρ	=	mass density = 1 000 kg/m^3 for water
Q	=	discharge (m^3/s)
\bar{v}_1 and \bar{v}_2	=	upstream and downstream average velocities (m/s)
Mg	=	weight of enclosed fluid (N)

Solve F_x and F_y and invert to obtain the force exerted on the bend. (If horizontal forces are considered, the Mg term will, of course, fall away).

Unless the pipe itself and its joints are strong enough, anchors should take up the resulting force components. Concrete anchor blocks are often used for this purpose.

- F_y should be $\leq W$ = weight of the anchor block + weight of the pipe section
- F_x should be $\geq W \tan \delta$ + passive resistance force, where W = weight of the anchor block + weight of the enclosed water volume + weight of the pipe section and δ = friction angle (degrees).

Where the surrounding soil could become saturated, W should be reduced by the weight of an equal volume of water.

4.4 REFERENCES

- 4.1 Rooseboom, A. (1988). *Total Energy Levels in Rivers*. Proc Int Conf on Fluvial Hydraulics. IAHR, Budapest
- 4.2 Henderson, F.M. (1966). *Open Channel Flow*. Macmillan.
- 4.2 Woolhiser, D.A. (1975). *Simulation of Unsteady Overland Flow*. Water Resources Publications, Fort Collins.
- 4.3 Mockmore, C.E. (1944). *Flow Round Bends in Stable Channels*. Trans Am Soc Civ Engrs Vol 109.
- 4.4 Rooseboom A., Le Grange, A. du P. (2000). *The hydraulic resistance of sand streambeds under steady flow condition*. Journal of Hydraulic Research. Vol 38, No1.

Notes:

Lined area for notes.

CHAPTER 5 - SURFACE DRAINAGE

A Rooseboom and SJ van Vuuren

5.1 INTRODUCTION

Surface road drainage systems serve to transfer storm water flows that collect on and along road structures to limiting the risk to:

- road users;
- road structures; and
- the environment.

This chapter deals with the design of components of surface drainage systems, with the exception of culverts, low-level crossings and bridges, which are dealt with in separate chapters. **Table 5.1, Road Map 5**, reflects the aspects that are covered in this chapter. Sub-surface drainage is essentially different from surface drainage and is therefore also covered in **Chapter 9**.

Surface road drainage design commences with the consideration of local precipitation that runs off across a road surface in a thin stream. It ends where each accumulated stream, impacted upon by road works, may be released into an existing natural or man-made waterway without any increased risk of erosion damage or downstream flooding.

Acceptable risk in surface road drainage is often expressed in terms of water surface levels not to be exceeded during flood events with given return periods.

5.2 RUN-OFF ON ROADWAYS AND SHOULDERS

5.2.1 General

The accumulation of run-off on roadways and shoulders constitutes the most common hydraulic road surface risk. Dangerous conditions arise when the pressure within the water contained between a vehicle's wheel and the road surface is equal to the pressure exerted by the wheel. As the water pressure increases, the wheel increasingly loses contact with the road surface, and control over the vehicle diminishes. This condition is known as hydroplaning^(5.1).

In the design of roads, the flow depth of surface run-off across road surfaces is not a primary design variable, because the normal geometric standards would generally ensure that this depth remains within acceptable limits. It is nevertheless important for the designer to be conversant with the variables involved in the assessment of the hydroplaning risk. The most important factors which need to be considered are:

- vehicle speed
- depth of flow
- type of road surface
- wheel load
- type of tyre and
- tyre pressure.

Each of these aspects is briefly discussed hereafter.

5.2.2 Vehicle speed

There is an appropriate design speed for each type of road. This design speed represents the expected vehicle speed at which the risk will be acceptable.

Under wet conditions the safe vehicle speed will reduce due to possible hydroplaning. Hydroplaning rarely occurs if the vehicle speed is lower than 80 km/h.

Table 5.1: Road Map for surface drainage

ROAD MAP 5				
Typical theme		Input information	Hand calculation	
Topic	Par.		Problem	Example
Run-off from roads and shoulders	5.2	Road surface, depth of flow and vehicle speed	Flow depth on road surface	Solutions to these problems are included in the Application Guide of which an electronic copy is included on the memory stick at the back of this Manual.
Kerbs, berms and outlets	5.3	Cross-sectional parameters, hydraulic description and applicable formulae, flow regime	Flow depth in side channel	
Discharge channels	5.4	Freeboard, permissible slopes for erosion protection, slope, roughness and flow rate	Drop grid capacity for subcritical flow Erosion potential	
Discharge chutes	5.5	Flow rate, profile detail and orientation	Dissipation of energy on steep slopes	Design procedure discussed in the text
Discharge pipes	5.6	Available slope, minimum diameter and access	Defining the control and getting the flow into the pipeline	
Erosion protection on steep slopes	5.7	Flow rate, erosion potential of material and slope detail	Select appropriate protection options	Guide indicates the use of plant bundles

5.2.3 Depth of flow

Depth of flow is the primary variable in the analysis of run-off on roadways and shoulders. The following norms are recommended for surface flow on travelled lanes:

- The flow depth during a 1:5-year storm should not exceed 6 mm.
- The minimum slope along the flow path should be 2%. In the case of wide road surfaces, the normal cross-fall may be increased to 2,5%.

It is not possible to apply these guidelines strictly in every case, e.g. where there is a change in super-elevation.

The risk of dynamic aquaplaning is directly proportional to the depth of water on the road. This depth is affected by a wide range of factors that are contributed to by the environment, the geometric design, pavement design, drainage design and maintenance and by the condition of the vehicle ^(5.21).

The flow depths on the road surface for different slopes and rainfall intensities can be obtained graphically from **Figure 5.1**. This method does not include any allowance for pavement texture depth ^(5.21).

5.2.4 Road surface

Road surfaces are given a rough finish to improve road holding and skid resistance without causing excessive tyre wear and road noise. **Figure 5.1** is based on a road surface of average roughness.




Figure 5.1: Depth of sheet flow on road surface (Laminar flow conditions assumed)

5.2.5 Wheel load, tyre type and tyre pressure

Wheel load, the type of tyre and the tyre pressure also affect hydroplaning. Due to the wide variations in the parameters affecting hydroplaning, it is impractical to relate speed limits to different tyre types and therefore these aspects are ignored. The geometric road elements are however considered using typical wheel loads, tyre types and tyre pressures in the assessment.

5.2.6 Further requirements regarding surface drainage

In the design of any drainage element it is essential to consider connected elements and to determine whether such elements will influence each other. Road surface run-off is allowed to discharge freely over the side of an embankment only where the erosion potential is low.

Where the erosion potential is significant, run-off is allowed to accumulate alongside berms or kerbs along the side of a road to be released at regular enough intervals so that the maximum permissible water levels are not exceeded.

In the case of flow over roadways and shoulders, maximum water levels linked to return periods should be determined for flow along berms and side channels. The normal requirements for freeways are defined schematically in **Figure 5.2**.

5.3 KERBS, BERMS AND OUTLETS

5.3.1 General

The purposes of kerbs, berms and outlets are to collect surface run-off and to discharge flows at specific points in a controlled manner to limit traffic risk, as well as to protect erodible areas such as embankment slopes.

5.3.2 Use of kerbs, berms and outlets

Kerbs are rarely found along freeways because they are expensive and may be dangerous to traffic if installed without guardrails. At cross-roads and junctions, as well as on bridges kerbing is used to channel traffic, to prevent vehicles from crossing sidewalks and to form storm water channels.

A **berm** is a small ridge placed at the top of an embankment to prevent erosion by run-off down the side of the embankment. Berms may be temporary (earth) or permanent (asphalt or concrete) and are normally used under the following conditions:

- If surface water could flow down an embankment and cause erosion;
- If the road gradient $> 0,5\%$; and
- If fills are more than 3 m high.

To ensure traffic safety, permanent berms are normally only installed with guardrails. This combination should be aligned so that the wheel of a vehicle cannot be caught between the guardrail and the berm.

Outlets in berms and kerbs should be spaced to ensure that:

- the requirements with regard to the permissible flow depths in **Figure 5.2** are satisfied;
- adequate freeboard is allowed along each kerb or berm;
- deep, rapid flow along the road shoulder is prevented;
- intermediate outlets intercept at least 80% of oncoming flows, and the lowest outlet may accommodate 100%;

- the total cost of the combination of outlets plus discharge chutes (lengths are important) is kept to a minimum; and
- unnecessary concentration of water is prevented. As a rule of thumb the following spacing should not be exceeded between outlets:
 - side channels and median drains - 200 m
 - channels above cuttings - 300 m

It is important that the drainage system should always be considered as a whole; for example the placing of an outlet above a culvert means lower expenditure on the discharge chute and exit structure.

It is also important that the shape and layout of kerbs, berms and outlets are hydraulically functional to ensure satisfactory operation of drainage systems.




Figure 5.2: Maximum permissible depths of flow alongside surfaced roads

5.3.3 Hydraulics of kerb and berm flows

Kerb and berm flows are open channel type flows as described in **Chapter 4**. The limits in terms of maximum depths of flow are shown in **Figure 5.2**.

The known variables are usually the cross-section of the kerb or berm, the road cross-fall and the longitudinal slope. The unknown variables are the maximum capacity of the kerb or berm and the catchment that would yield this maximum discharge.

Cross-sectional details of some of the typical kerbs are shown in **Figure 5.3**. For these typical cross-sections, the nomogram in **Figure 5.4** could be used for determining the hydraulic discharge capacities through triangular channel sections. The catchments that would yield these discharges could then be determined through hydrological calculations, e.g. Rational method or other procedures as discussed in **Chapter 3**.




Figure 5.3: Typical triangular cross-sectional details of kerbs

The nomogram in **Figure 5.4** is used as follows:

- Connect the values of the Z/n Ratio (n represents Manning's roughness parameter – **Figure 4.8**) and the slope with a straight line.
- Use the intersection of this line with the turning line to determine the discharge, Q for a given flow depth y , or alternatively determine the flow depth y for a given discharge Q .

By adding and subtracting the discharges for triangular sub-areas, the discharges for composite sections can also be calculated (**Worked examples are demonstrated in the Application Guide of which an electronic copy is included on the memory stick at the back of this Manual**).

In the case of a triangular channel section (**Figure 5.3(b)**) the value of $Z = T/Y$.

5.3.4 Kerb and berm outlets

Outlets along kerbs and berms are divided into two main groups: drop outlets and side outlets. Two types of side outlets are identified, giving a total of three types of outlets that differ in terms of hydraulic design (**Table 5.2**). The hydraulics of outlets is covered in the sections that follow.







Figure 5.4: Nomogram for flow in triangular channels ^(5.2)

Table 5.2: Some physical details of the outlet types

Typical layout types	Remarks
<div><p>I Drop outlet</p><p>Long Section</p></div>	Special provision to be made for high oncoming velocities
<div><p>II Side outlet (Overspill section)</p><p>Plan</p></div>	Not practical to discharge full oncoming flows at high velocities
<div><p>III Side outlet (With bend)</p><p>Plan</p></div>	Radius of bend dependent on change in direction, cross fall and Froude-number of oncoming flow

Drop outlets (Type I) feed oncoming flows downwards into underground drainage systems.

Side outlets with overspill sections (Type II) discharge oncoming flows sideways (past berms or kerbs) into collector channels and/or chutes.

Side outlets with bends (Type III) steer oncoming flows past kerbs or berms to be released some distance away where erosion can be limited.

Photographs 5.1 and 5.2 show typical kerb inlets.



Photograph 5.1: Detail of a typical kerb outlet with a transition section (Type III)



Photograph 5.2: Kerb outlet with deposited debris (Type III)

5.3.5 Hydraulic design of drop outlets (grid outlets)

5.3.5.1 General

Drop outlets (Type I outlets) discharge storm water downwards into an underground drainage system and the outlets are made safe for pedestrians and traffic by placing grids over the openings. Such outlets are thus also known as grid outlets (**Photograph 5.3**).

Drop outlets function either under subcritical approach flow conditions or under supercritical approach flow conditions. In the case of supercritical approach conditions the outlets should be free, preventing a hydraulic jump to be introduced which will potentially increase the flow depth on the road.

To determine whether the oncoming flow is subcritical or supercritical, the Froude number (Fr) needs to be calculated, as was indicated in **Chapter 4**.

The discharge Q is calculated by means of hydrological methods (**Chapter 3**) and the flow depth for a given uniform flow section could be calculated by using the Manning or Chézy equation.

5.3.5.2 Subcritical approach flows

Outflows may be either free-flow or drowned.

Free outflow conditions: These conditions are reflected in **Figure 5.5** and may be analysed by applying the broad-crested weir formula as described below.




Figure 5.5: Section through drop outlet with a free outflow and subcritical approach flow conditions

Broad-crested weir formula:

$$Q = C_D b H \sqrt{gH} \quad \dots(5.1)$$

$$Q = 1,7 b H^{\frac{3}{2}} \quad \dots(5.2)$$

This is a theoretical relationship for critical conditions along the crest and a contraction coefficient, C_D of 0,6, where:

- Q = flow rate (m³/s)
- C_D = discharge coefficient
- b = total flow width (m)
- H = energy head \approx flow depth for upstream conditions (m)

With allowance for sideways contraction of oncoming flows the formula becomes:

$$Q = 1,45 b H^{\frac{3}{2}} \quad \dots(5.3)$$

Subcritical submerged flow conditions: Such conditions (**Figure 5.6**) are analysed by applying the orifice formula (refer to **Figure 5.8**).




Figure 5.6: Section through outlet: Drowned conditions

$$Q = CFA\sqrt{2gH} \quad \dots(5.4)$$

where:

- C = inlet coefficient (0,6 for sharp edges or 0,8 for rounded edges)
- F = blockage factor (say 0,5)
- A = effective cross-sectional plan area of the opening (m²)
- H = total energy head above grid (m)

Supercritical approach conditions: These conditions are dealt with basically by providing an opening in the direction of flow of at least the same area as the sectional area of the oncoming stream. The higher the Froude number of the oncoming flow, and the greater the change in direction that this flow has to undergo, the greater the deviation from the simplified approach shown in **Figure 5.7**.




Figure 5.7: Drop outlet for supercritical approach flow

In practice, dealing with supercritical approach flows is not always simple, especially if a grid has to be placed across the flow or a change in direction needs to be accommodated. Furthermore, the grid is not always as wide as the channel.

Figure 5.8 (subcritical) and **Figure 5.9** (supercritical) were prepared for the design of grid inlets with sub- and supercritical approach flows respectively. The following should be borne in mind when a drop outlet is designed:

Under conditions of subcritical flow towards a drop outlet:

- **Figure 5.8** applies to subcritical oncoming flows and horizontal grids;
- The direction of the bars relative to the flow direction of the oncoming water is not very important if flow velocities are low (subcritical). However, with high velocities the bars should be placed in the flow direction; and
- In the case of the quoted broad-crested weir formula no blockage factor is included.

When **supercritical flow conditions** prevail, **Figure 5.9** (based on physical modelling) should be used to determine the discharge capacity and the following aspects need to be kept in mind:

- The graph to the left of **Figure 5.9** was developed for supercritical oncoming flows as a dimensionless $Fr : \frac{100d}{D}$ graph (The discharge Q for a d -value is determined via the Manning or Chezy equation);
- The graph with discharges given in l/s only applies to standard 900 mm x 900 mm grids;
- The layout is such that the bed slope of the channel increases to 1:10 just upstream of the grid, to increase the specific energy of the flow without changing the overall slope of the channel;
- The experimental assessments were conducted using a square grid;
- The experimental graph was converted into a $Q:s$ graph for a specific grid and channel shape. **When changes of direction occur, or if the flow section is changed significantly, the graph in Figure 5.9 should not be used;**
- No blockage factor was taken into account; and
- In the case of supercritical flow it is very important for **grid bars to be placed in the direction of flow.**

***Note:** In all cases it should be emphasised that a problem should be viewed as a whole; for example, in the case of supercritical flow through an outlet that is, say, 50% blocked, and where flow is contained by a berm, damming could occur. This damming could then change the conditions from supercritical to subcritical.*

5.3.6 Hydraulic design of side outlets

Side outlets (Types II and III) discharge stormwater into drainage systems above or below ground level. Typical side outlets are berm outlets, kerb outlets and outlets at the lowest points of side channels.

Hydraulically, side outlets are not as effective as drop outlets, especially for the discharge of supercritical flow. These outlets are in general use, however, and have practical advantages such as low blockage risks. In addition, in some cases they are cheaper than drop outlets.

Subcritical flow (Type II)

The calculations to be performed for different flow conditions are indicated below:

- For subcritical flow conditions an approximate assessment can be done by applying the broad-crested weir formula; and
- For supercritical flow conditions **Figure 5.11** and **Figure 5.12** should be used because these relationships are based on experimental results on full-scale tests ^(5.3).

Supercritical flow (Type II or Type III)

A side outlet for supercritical flow may be one of two types, i.e. (see **Table 5.2**):

Type II - Energy is dissipated in a collecting trough and changes in flow direction are brought about where subcritical conditions occur (**Figure 5.10**).

Type III - The direction of flow is changed by means of a gradual horizontal curve so that water does not spill over the side of the channel.

The left half of **Figure 5.11** provides depths of flow alongside berms for a 2% cross-slope. The depths of flow thus obtained on the vertical axis can be transposed to the right hand figure to obtain the minimum length of side opening required to pass either 80% or 100% of oncoming flow over the side.

It is generally economical to allow some 20% of the oncoming flow to pass if there is a lower outlet further along the kerb or berm. A lowest outlet should accommodate all the flow, and no water flowing alongside the kerb or berm may flow over the road, ramp or crossroad, nor flow freely over the embankment.

The radii recommended for **Type III** outlets are shown in **Figure 5.14**. This type of outlet is typically found at the end of a cutting. A drop outlet or stilling basin may be used to finish off this type of outlet to limit erosion downstream.

The most **important differences between Type II and Type III outlets** are as follows:

- Type II is often hydraulically less effective than Type III;
- The design of a Type II outlet is less critical because direction change occurs under subcritical conditions; and
- In the case of embankments where space is limited, it is easier to accommodate Type II outlets.

Type II outlets should be used on high embankments, and either **Type II** or **III** may be used in other positions such as at the end of a cutting or on a low embankment. The design of discharge chutes and pipes is discussed in **Section 5.5** and **Section 5.6**. Since outlet water velocities tend to be high in both cases, the necessary erosion protection measures should be considered downstream.

5.3.7 Kerb inlets with transitions

Figure 5.12 may be used to design any type of side outlet where a minimum length of overspill is required as in the case of box inlets. Box inlets that are strong enough to withstand traffic wheel loads are expensive and hence less costly transitions were developed. These transitions are to be used in conjunction with shorter box sections to provide the long overspill lengths which are required for discharging water on steep slopes (**Figure 5.13**). Grobler^(5.3) has expanded on earlier work^(5.4,5.5,5.6) and has improved on the accuracy of earlier results (**Figure 5.11**) by performing full-scale tests. A single diagram (**Figure 5.12**), which can be used to design outlets with transitions, was developed^(5.3). It was established that the capacities of Type II outlets are not sensitive to variations in cross-slope, and **Figure 5.11** and **Figure 5.12** may be used for a wide range of conditions.

Figure 5.13 contains detailed drawings of the Pretoria-type outlets, which have been widely used. **Photographs 5.3** and **5.4** show some grid inlets.



Photograph 5.3: Concrete side drain with grid inlet



Photograph 5.4: View of a combined grid inlet and kerb inlet




Figure 5.8: Drop outlet: Capacity for subcritical approach flow




Figure 5.9: Grid capacities for supercritical flow




Figure 5.10: Details of Type II side outlets




Figure 5.11: Required total side outlet lengths for Type II kerb outlet ^(5.3, 5.4)




Figure 5.12: Design curves for Type II kerb outlets with transitions ^(5.3)




Figure 5.13: Pretoria Type II outlets
(This standard drawing is available in electronic format on the flash drive/DVD at the back of this document)




Figure 5.14: Maximum radii for Type III kerb outlets

5.4 DISCHARGE CHANNELS

5.4.1 Introduction

Discharge channels are open waterways, typically with longitudinal slopes of less than 10%. Such channels are excavated canals or natural gullies, and are often protected against scour by grassing, concrete linings, stone pitching, and so on.

It is sometimes necessary to use linings even if scour is not a problem, e.g. in the case of culvert outlets where lush growth of vegetation may obstruct the outflow. When it is important for channels to retain the same position and depth after cleaning, and where sedimentation is a problem, lining should be considered.

Although, from theoretical hydraulics and considerations of erosion, the ideal channel section would have an approximately parabolic form, other considerations generally result in the use of trapezoidal sections, except where the width has to be restricted, in which case rectangular sections are often used.

To calculate the capacity of a channel, the freeboard as well as permissible slopes and velocities should be determined.

5.4.2 Freeboard and provision for wave action

Where there are no other restrictions, the following minimum values for freeboard ^(5.7) are recommended for road drainage as is depicted in **Table 5.3**:

Table 5.3: Freeboard: Straight portions of channels

Channel Section	Fr < 1	Fr > 1
Rectangular	0,15 E	0,25 y
Trapezoidal	0,20 E	0,30 y

$$\text{where: } Fr = \text{Froude number} = \sqrt{\frac{Q^2 B}{g A^3}} \quad \dots(5.5)$$

E = specific energy (m)

$$E = y + \frac{\bar{v}^2}{2g} \quad (\text{m}) \quad \dots(5.6)$$

y = depth of flow at deepest point (m)

\bar{v} = average velocity (m/s)

If the Froude number lies between about 0,8 and 1,2, flow conditions are unstable and both the normal depth of flow and the freeboard height should be calculated conservatively.

In addition to the freeboard indicated above, the following additional freeboard should be provided at curves to allow for surging and wave action as shown in **Table 5.4**.

Table 5.4: Additional freeboard around bends

Channel section	Fr < 1	Fr > 1
Rectangular	$\frac{3\bar{v}^2 b}{4gr}$	$\frac{1,2\bar{v}^2 b}{gr}$
Trapezoidal	$\frac{\bar{v}^2 (b + 2Ky)}{2(gr - 2K\bar{v}^2)}$	$\frac{\bar{v}^2 (b + 2Ky)}{gr - 2K\bar{v}^2}$

Where:

- \bar{v} = average velocity in straight portion of channel (m/s)
- b = width of channel bed (m)
- r = centreline radius of channel (r should not be smaller than three times the width at the water surface) (m)
- K = co-tangent of side slope ($K = 0$ for rectangular channel sections)
- y = depth of flow in straight portion of channel (m)

In the case of subcritical flow ($Fr < 1$), the additional freeboard would be required at the outside of the curve only, but for supercritical flow ($Fr > 1$) it is necessary on both the inside and the outside.

Where stormwater canals rarely flow at full capacity, it has become practice in South Africa to design these canals without freeboard, provided that barriers are provided alongside the canals to prevent erosion. These barriers are placed perpendicular to the edges of the canal preventing erosion when intermittent spillage occurs resulting from wave action.

5.4.3 Permissible slopes of drains

The slopes of unpaved median drains may not be less than 0,5%, and those of paved drains not less than 0,25% ^(5.8). On very small longitudinal slopes the local slope of the median drain may be made greater than that of the road, using a longitudinal saw-tooth pattern and allowing the draining away of water at the low points.

Acceptable maximum side slopes for unlined channels are reflected in **Table 5.5**.

Table 5.5: Acceptable maximum side slopes for unlined channels

Material type	Maximum side slope (Vertical : Horizontal)
Rock	Almost vertical
Stiff clay, soil with concrete lining	1 : 1 up to 1 : 2
Soil with stone pitching, large earth channels	1 : 1
Firm clay or small earth channels	1 : 1,5
Loose, sandy soil	1 : 2,5
Sandy clay, porous clay	1 : 3
Grassed channels*	1 : 3 to 1 : 4
Lined channels	**

Notes:

- * For maintenance purposes the side slopes of grassed channels should not be steeper than 1 (vert.) : 4 (hor.), and they should never be steeper than 1:3.
- ** Side slopes for lined channels should not be much steeper than the above values.

5.4.4 Calculation of hydraulic capacity of channels

The maximum discharge capacity of a channel under **uniform flow conditions** could be calculated by means of formulae such as those of Manning or Chézy (**Chapter 4**).

Uniform flow conditions apply only if:

- the depth of flow is not forced to deviate from the normal depth by a secondary control; and
- the channel drops at each transition by the energy head loss for the transition as was discussed in **Chapter 4**.

5.4.5 Permissible velocities: soils and grass covers

At velocities that are too low, sediment may be deposited, and at velocities that are too high erosion and structural damage to channels may occur.

Figure 5.15 indicates the minimum recommended average velocities at different depths to prevent the deposition of fine sandy material. The figure also contains graphs of the maximum permissible velocities for different types of soil. These graphs were developed based on data from the *Highway design – Manual of instructions* ^(5.8). The figures should be conservatively applied where gullies may form.

Grass covers could provide extra protection against soil erosion, and recommended design values are given in **Table 5.6**. The effectiveness of grass covers depends on the type of grass, the type of soil, as well as the annual rainfall. First of all, one should determine how well the grass would establish itself, and then a design velocity may be decided upon by the combined use of **Figure 5.15** and **Table 5.6**. The permissible velocity for soil with grass cover must be limited to a maximum of 1,3 times the allowable velocity for unprotected soil. ^(5.20).

Table 5.6: Permissible maximum velocities (m/s) for grass covers ^(5.9)

Mean annual rainfall (mm)	< 600			600 – 700			> 700		
Type of grass	% Clay content in the soil								
	> 15	6 - 15	< 6	> 15	6 - 15	< 6	> 15	6 - 15	< 6
Kikuyu	No data			1,8	1,5	0,8	2,5	2,0	1,2
NK 37				2,0	1,5	0,8	2,0	1,5	1,0
K11				1,5	0,8	0,6	2,0	1,5	1,0
Rhodes				1,2	0,8	0,6	1,5	1,0	0,8
*E Curvula	1,0	0,8	0,8	1,2	0,8	0,6	1,5	1,0	0,8
Blue Buffalo	1,0	0,8	0,8	1,2	0,8	0,6	No data		
Paspalum didatum	No data			1,2	0,8	0,6	2,0	1,5	1,0

Note:

These values are valid for a depth of flow of 0,3 m and on slopes of less than 3%. For other depths the permissible velocities may be adjusted proportionally to the curves in **Figure 5.15**.

5.4.6 Channel linings: Solid materials

A channel may be directly or indirectly protected against erosion. For direct protection, the bottom and sides of the channel are covered with a lining that is less erodible than the *in-situ* material. For indirect protection, introducing obstructions that cause damming reduces the flow velocity or erosive capacity.

Construction materials generally used for channel linings are:

- concrete;
- rip-rap and stone pitching;
- prefabricated paving blocks; and
- gabions.




Figure 5.15: Permissible velocities for different natural ground types

5.4.6.1 Concrete linings

The minimum channel lining thicknesses given in **Table 5.7** are based on past experience. Water velocities over linings with joints or cracks should not be higher than about 2,5 m/s^(5.10) for a liner thickness of 60 mm, because pulsating pressure changes at joints may cause pieces to break away. Where heavily reinforced sections are constructed, velocities of up to 8 m/s may be allowed and occasionally higher velocities can be accommodated. In these circumstances overlapping joints should be used. The safe velocity over shale is 3 m/s; over dolomite, sandstone or limestone 3 to 7 m/s; and over hard rock such as granite, up to 15 m/s or even higher^(5.11).

Table 5.7: Thicknesses of channel linings ^(5.10)

Total channel depth	Thickness of concrete lining
0 - 0,5 m	60 mm
0,5 - 1,5 m	75 mm
> 1,5 m	100 mm

Unbalanced hydraulic forces acting on concrete linings could cause serious damage in the form of cracking and displacement, which is very difficult and costly to repair. The following conditions may be **particularly harmful**:

- When a canal **empties rapidly**, whilst the water table below the concrete lining drops at a lower rate, the lining may pop up and suffer serious damage, especially during re-filling of the canal. To prevent this from occurring the pressure difference could be relieved by providing drainage below the lining or by installing valves in the lining. Measures to prevent concrete canals from emptying rapidly (long-weirs) should also be considered during the design.
- Where **active soils** occur below concrete linings and they shrink during dry periods, gaps tend to form between the linings and the soils as the soils shrink. When surface run-off from alongside the canal fills these gaps whilst the flow depth within the canal is low, serious cracking may occur ^(5.11). For this reason, seals should be provided to prevent the entry of water along the canal lining edge.
- Serious cracking could also occur when canals are **filled rapidly** and gaps are present between the lining and the supporting soil. Cracking problems could be particularly severe where the *in-situ* soils are active as well as dispersive.

To overcome the problem with active soils, it is often prescribed that canals should be over-excavated by 600 mm and backfilled with selected compacted material. Flexible linings such as pre-cast concrete panels on top of plastic linings are however preferred where active soils are encountered.

5.4.6.2 Riprap and stone pitching

Protective stone layers are often used as an economical means of combating erosion. A major advantage of stone layers is their ability to deform and remain effective with subsidence and limited undermining.

The Shields parameters cited in Henderson ^(5.12) is the best-known criteria for determining whether non-cohesive particles would be lifted off the bed by a given flow. When ordinary stones (relative density 2,65) with diameters > 6 mm are used, the **required diameters of stone d₁ that would just resist lifting from the bed and d₂, the required diameter to resist lifting from the sides**, may be calculated via the following equations:

$$d_1 > 11 Ds \qquad \dots(5.7)$$

(50% of the mass of the stone used for protection should be $\geq d_1$. The general form of **Equation 5.7** is:

$$d_1 > 11 Rs$$

where:

- D = depth of flow in channel (m)
- s = slope in longitudinal direction of channel (m/m)
- R = the hydraulic radius (m)

By using a relationship deduced by Lane ^(5.12) the **diameter of stone required to protect the sides of trapezoidal channels, shown in Figure 5.16, can be calculated with the following relationship:**

$$d_2 \geq \frac{8,3Ds}{\cos \theta \left[1 - \frac{\tan^2 \theta}{\tan^2 \emptyset} \right]^{\frac{1}{2}}} \quad \dots(5.8)$$

where:

θ = angle of slope of sides of the channel (°)
 \emptyset = natural angle of slope of stone material (°)




Figure 5.16: Required sizes of the stone for erosion protection of loose bed channels

(The side slope, θ , should always be smaller than the angle of repose, \emptyset , to ensure stability.)

Values of \emptyset (the natural friction slope) for different stone sizes and particle forms are given in **Figure 5.17** ^(5.12). These relationships were extended based on the conclusions by Shen ^(5.13).

Because flow around bends has increased erosive capability on the outside of the bend, the stone sizes calculated according to the above formulae (**Equations 5.7 and 5.8**) should be increased where the protective layers are placed around curves ^(5.14), as reflected in **Table 5.8**.

Table 5.8: Multiplication factor to increase the required particle size to prevent scour in curved channels

Channel curvature	Factor
Gentle	1,3
Sharp	1,6

Flowing water tends to lift fine material out from underneath the coarse material, and therefore care should be taken that the protective layer is not undermined. This can be achieved by providing filter material to prevent the migration of the fine materials.

In cases where only stone is used as protection, successive layers of adequate thickness and appropriate material sizes based on the following criteria should be considered ^(5.14):

- The thickness of the protection layers should be two to three times the diameter of the stones;
- If the stones are hand-packed, the layer should at least be 1½ times the stone diameter, but always at least 200 mm thick; and
- The ratio of stone sizes (diameters) in successive layers should be between 1:5 and 1:10, depending on the size-distribution curves of the material.
 An adequate number of layers should be placed between the natural material and the final protective layer to ensure stable protection.




Figure 5.17: Natural slope angles (ϕ) for different sizes of stone

5.4.6.3 Prefabricated paving blocks

Where any loose units, regardless of shape, are used for bed protection, the settling velocity, V_s , in water of individual units should be greater than ^(5.15):

$$V_s \geq \frac{\sqrt{gDs}}{0,12} \quad \dots(5.9)$$

where:

- V_s = settling velocity (m/s)
- D = depth of flow (m)
- s = energy gradient (m/m)

If the effectiveness of the units depends on interaction between different blocks or anchoring by grass, precautions should be taken against the large-scale failure of the protective layer resulting from a local failure, or before the grass becomes established.

Filters should be provided, where necessary, so that underlying material cannot be washed out from underneath the protective units.

5.4.6.4 Gabions

The use of gabions for direct protection may be advantageous, especially where available or manageable stone sizes are not adequate for the stones to function as separate units. It is very important to use the correct stone sizes in relation to the mesh sizes, so that it will not be possible for stones to be washed out. The wire boxes should be tightly packed with stones according to the manufacturer's guidelines.

Design consists of calculating the required size for single stones and based on that determine the equivalent size of gabions. The mass of gabions per unit area covered should be at least 1,5 to 2 times that of the stone calculated in accordance with **Equations 5.7** and **5.8**.

Cut-off walls, suitable filter material (as per the manufacturer's prescription) or linings should be provided where necessary. The life of the wire cages should be guaranteed and plastic coverings should not be used where there is a high probability of veld fires.

The corrosion potential of the wire boxes should be taken into consideration, especially in industrial and mining areas.

Photographs 5.5 and **5.6** provide details of mattresses whilst **Photographs 5.7** and **5.8** show gabions that can be used for erosion protection.



Photograph 5.5: Flexible concrete mattress for erosion protection in channels



Photograph 5.6: Flexible concrete mattress failure due to weak supporting soils



Photograph 5.7: Gabions used for bank stabilisation (Courtesy: Land Rehabilitation Systems)



Photograph 5.8: Gabions used for erosion protection (Courtesy: Land Rehabilitation Systems)

5.4.7 Indirect protection and stepped energy dissipation

Where considerations of safety permit, it is often more economical to protect a channel indirectly, rather than directly. This is done by the concentrated dissipation of energy at successive structures; the erosive capacity of the flow between the structures is thus decreased, so that continuous direct protection is not required here. Due to problems experienced with the calculations for indirect protection, methods of calculation and design data are treated in a fair amount of detail here.

Three of the variations for indirect protection of channels that could be used are shown schematically in **Figure 5.18**. These variations of stepped energy dissipators will be referred to as **Layouts I, II and III**.





Figure 5.18: Layouts I, II and III for stepped energy dissipators

Layout I sometimes present an economical solution, especially where the watercourse is not deep and a large area has to be protected against erosion. Construction is quite simple, because no formwork and little reinforcement are required. **Table 5.7** gives the required concrete thickness. **Layout II** offers an effective but expensive solution, and is rarely more economical than **Layout I**. **Layout II** could however be used to good effect, for example between the culverts under the carriageways of a freeway.

In cases where deep existing watercourses are to be protected from scour, **Layout III** often provides the best solution. The dams may be masonry, gabions or concrete.

When energy has to be dissipated at the bottom of a long slope, a conventional stilling basin may be used (**Chapter 7**). However, it is often more economical to use stepped energy dissipation for the layouts shown in **Figure 5.18**, especially on steep slopes for which the design calculations are done as described below.

Photographs 5.9 and 5.10 depict examples of stepped energy dissipators.



Photograph 5.9: Stepped energy dissipator (Hout Bay River, Cape Town)



Photograph 5.10: Stepped energy dissipator along the N3

Design procedures for energy dissipation as an indirect way to protect channels

Layout I – Hydraulic analysis

In each case the starting point is to determine the design discharge, Q (obtained from hydrological calculations). Then calculate a flow depth (y_3) and a flow velocity (v_3) at which unprotected soil would not be eroded under the design discharge. (**Figure 5.15** and **Table 5.6**) A detailed analysis is given below.




Figure 5.19: Longitudinal section through Layout I dissipator

Calculate both the required step height Δz and damming height, H_1 , taking into account whether broad-crested or sharp-crested conditions apply (**Chapter 4**). The depth $y_3 = \Delta z + H_1$. Then calculate y_{2w} , the depth just downstream of the step, in accordance with the y_3 value at the following step (**Chapter 4**), (If the floor slope as well as the distance is small, $y_{2w} \approx y_3$ – based on the conservation of energy principle).

By assuming that $y_2 = \frac{y_{2w}}{1,3}$

where:

y_2 = equivalent sequent jump depth with a horizontal bed ^(5.16) (m)

The depth y_1 can be calculated. For a “wide” stream, in accordance with the momentum principle:

$$\frac{y_1}{y_2} = \frac{1}{2} \left[\sqrt{1 + \frac{8v_2^2}{gy_2}} - 1 \right] \quad \dots(5.10)$$

Select the slope of the step, α , on the basis of considerations of soil mechanics, e.g. 20° .

L_2 and z_2 could now be calculated ^(5.16) from the following relationships:

$$L_2 = 0,82y_2 (\tan \alpha)^{-0,78} \quad \dots(5.11)$$

$$z_2 = L_2 \tan \alpha \quad \dots(5.12)$$

If the value of y_{2w} is increased to more than the minimum value of $1,3 y_2$, the front of the jump would advance up the slope by the same vertical distance. It is not normally practical, however, to make the value of y_{2w} greater than $1,3 y_2$.

The value of z_1 is now calculated (**Chapter 4**):

$$z_1 + y_3 + \frac{v_3^2}{2g} \approx \frac{v_1^2}{2g} + y_1 \cos \alpha \quad (\text{energy principle}) \quad \dots(5.13)$$

and $v_3 y_3 = v_1 y_1$ (continuity)

Calculate the damming level H (**Chapter 4**), as well as the dam height z to find the required depth y_3 at the most critical section. In cases where flow through the dam (gabions) occurs, allowance can be made for the through-flow.




Figure 5.21: Section through Layout III energy dissipator

In the spacing of the weirs, the water downstream of each weir should be as deep as possible. Under sharp-crest conditions, however, the surface downstream may not be higher than the crest of the dam; i.e. no submergence is allowed. Under broad-crested conditions σ , the submergence ratio may not be greater than 0,8 (the modular limit), otherwise additional damming could take place.

The length of channel protection that is required downstream may be estimated from the design procedure for Layout II structures (**Figure 5.20**).

5.5 DISCHARGE CHUTES

5.5.1 Introduction

Discharge chutes (**Figure 5.22**) are often used to discharge water down very steep slopes. Metal chutes cannot be used on slopes steeper than **4 Vertical : 1 Horizontal** ^(5.8), and separate concrete chute sections that fit into one another should not be used on slopes steeper than **1 Vert. : 1,5 Hor.**

The most important consideration in chute design is that the flow cannot easily change direction downstream of the point of release; i.e. where supercritical flow occurs. Consequently the flow upstream of the point of release should be subcritical. Where the flow across the shoulder is supercritical, subcritical flow can be ensured by the use of a collector channel. The channel should be long enough to intercept the oncoming flow. Its depth should be more than $1,5 y_c$ so that it will not become submerged. In calculating the approximate velocity at the bottom of the chute, energy losses may be ignored.

Then it follows (**Figure 5.22**): $\frac{3}{2} y_c + z = y_2 + \frac{v_2^2}{2g}$

and if $y_2 \ll z$ it follows $v_2 = \sqrt{\left(\frac{3}{2} y_c + z\right) 2g}$

$$v_2 = \left[\frac{3}{2} \left(\frac{q^2}{g} \right)^{\frac{1}{3}} + z \right]^{\frac{1}{2}} \sqrt{2g}$$

The same basic erosion protection measures as for culverts may be used at the outlet of a discharge chute.

Photograph 5.11 depicts an example of a discharge chute.



Photograph 5.11: Discharge chute, prefabricated blocks




Figure 5.22: Collector channel and discharge chute

5.5.2 Stepped energy dissipation in very steep channels or chutes

The energy in a very steep channel or chute can also be dissipated stepwise as shown in **Figure 5.23**. For slopes of up to about 40° and with rectangular cross section (width B), the system is designed as described below ^(5.17).

This system was earlier described as a solution for very steep culverts, but has not found wide application mainly because of **debris being trapped**. The principle has been applied in small chutes down the sides of embankments.




Figure 5.23: Section through stepped energy dissipator

For a given discharge, Q , the following equation applies:

$$Q = K_L \sqrt{2g} B H^{\frac{3}{2}} \quad \dots(5.19)$$

where:

K_L = discharge coefficient
 H = head (m)

In addition,

x = distance between obstructions (m)
 z = height of obstructions (m)

In design, an estimated value for H/B is used and the appropriate z/B value is read off from **Figure 5.24** for the slope angle α . For these values of H/B and α , a value for K_L may be read off from **Figure 5.25**. Test whether the above equation for discharge is satisfied. If not, select a new value for H/B and repeat the procedure. If the slope becomes steeper than 40° , simple obstructions are no longer effective ^(5.17), and obstructions with openings placed alternately left and right in the channel are to be used.




Figure 5.24: Energy dissipators in very steep channels: Optimum dimensions




Figure 5.25: Discharge coefficients for energy dissipators in very steep channels

In this case for the dimensional ratios shown below, the discharge equation reads as follows:

$$Q = K_L \sqrt{g} B^{\frac{5}{2}} \quad \dots(5.20)$$

and the ratios below were standardised at approximate optimum values:

$$\frac{X}{B} = 0,5 \quad \frac{Z}{B} = 0,3$$

$$\frac{b}{B} = 0,4$$

For a given value of α , the value of K_L could be read off from **Figure 5.26**, and the required value of B and other dimensions may be calculated directly. A similar system was developed for trapezoidal channels with slopes of up to 45° shown in **Figure 5.27**.




Figure 5.26: Discharge coefficients for energy dissipators in very steep channels




Figure 5.27: Definition sketch – Stepped energy dissipation in trapezoidal channels

The discharge equation for trapezoidal channels with side slopes standardised at 1:1,5 and X, the distance between the dissipator walls, at $3B$, is as follows:

$$Q = K_L \sqrt{2g} (B + 3z) H^{\frac{3}{2}} \quad \dots(5.21)$$

With Q known, values are estimated for B and H/B .

From **Figure 5.28** values for K_L and z/B can now be read off. The value of z/B is 0,5 below the dashed line and 0,75 above it.

Now test whether the values for K_L , B , z and H satisfy the equation above and select improved values for H and B until the equation is satisfied.




Figure 5.28: Discharge coefficients for obstructions in trapezoidal channels

5.6 DISCHARGE PIPES

5.6.1 Introduction

Discharge pipes are normally laid underground and serve:

- as connector pipes from draw-off structures, such as grid inlets to storm water mains, culverts, etc.; and
- to discharge water down erodible slopes.

5.6.2 Underground connector pipes

The following criteria should be applied when underground connector pipes are used:

- Pipes running in the same direction as the road should not be placed under the travelled way and the minimum allowable diameter for such pipes is 450 mm;
- Manholes should be provided at least every 200 - 350 m for diameters $\geq 1\ 200$ mm and at least every 100 - 200 m for diameters $< 1\ 200$ mm;
- Manholes should also be provided at:
 - all changes in direction $> 10^\circ$;
 - changes in size of the pipes;
 - at all junctions; as well as;
 - all slope reductions (slope reductions should however be avoided if at all possible); and
- Where it is impractical or dangerous to deal with supercritical flow in median and side drains, the water may be drained off or discharged at regular intervals into underground storm water mains.

5.6.3 Discharge pipes down side slopes

As in the case of discharge chutes (**Section 5.5**), the greatest problem here is to transfer supercritical flows into the down-pipes. This may be achieved by using a collector channel in which the flow depth is greater than the critical flow depth (subcritical flow). Fitting a cone inlet, which would improve the inlet conditions, could increase the capacity of a steep discharge pipe. The sectional area at the release point will control the capacity. Test the available specific energy value at different sections to determine where the minimum value occurs; i.e. where the control is formed.

The following criteria should be incorporated in the design of down pipes:

- Diameters < 200 mm should not be used, and where necessary a grid should be provided (on top of the collector channel) to prevent blockage. When used on steep slopes, lengths greater than 20 m should be well anchored.
- Where the danger of erosion is not great, a T-piece could be fitted at the lower end of a steep downpipe to dissipate energy. In other cases the same measures as for culverts may be adopted.

5.7 COMBATING EROSION ON STEEP SLOPES

5.7.1 Introduction

The erosion potential on embankments increases rapidly down slopes, due to the following factors:

- Rates of flow increase as rainwater accumulates;
- Flow velocities tend to increase.

With large-scale work, it is possible to determine beforehand, using the different methods ^(5.18) on what combinations of slopes and heights of embankments and cuts, serious erosion would take place. With high embankments the water could be diverted by a stepped system of berm channels if necessary, and the areas in between protected from erosion as described below.

5.7.2 Stepped energy dissipation on steep slopes

For erosion protection on steep slopes of typical cuts and embankments, vegetative protection along the contours is generally the best solution, especially if the flow velocity of the water could be repeatedly reduced by the vegetation. Where streams of water become too large, the indirect protection options given in **Section 5.4.7** may be employed, or the water may be discharged through berm channels.

Hedges are established by a combination of vegetative and structural materials. They may sometimes be used on slopes steeper than 1 Vert.: 1,5 Hor., but are more effective on flatter slopes such as 1 Vert. : 2 Hor. Their effectiveness is based on the fact that the speed of the water is repeatedly reduced, attenuated and absorbed to some extent. A good vegetative cover enhanced by the use of the hedges could be aesthetically pleasing.

The most important aspects ^(5.19) of energy dissipation on steep sections are:

- The slope should be given a stable finish; the maximum slope is often 1:1,5 but a slope of 1:2 is preferable. Water should be diverted at the top, as far as possible;
- Underground drainage should be provided at potential wet spots; and
- Toe protection should be constructed, as reflected below:
 - o If there is little space (**Figure 5.29**); or
 - o where more space is available (**Figure 5.30**); and
 - o form erosion hedges along contours **Figure 5.31**.




Figure 5.29: Toe protection options in limited space




Figure 5.30: Toe protection option where secondary fill can be accommodated




Figure 5.31: Slope protection option and spacing of hedges

If the water is dammed effectively at each hedge, the spacing may be determined approximately as follows: Determine the permissible flow velocity (V_c) for the given soil from **Figure 5.15** (assume the depth of flow ≈ 0).

Calculate:

$$v_c = \sqrt{2gH} \quad \text{or} \quad \dots(5.22)$$

$$H = \frac{v_c^2}{2g}$$

The spacing may now be determined in terms of the slope.

$$\ell = \frac{H}{\sin \alpha} \quad \dots(5.23)$$

It is often possible to determine the value of H by observing the vertical distance down existing nearby slopes where serious erosion has developed.

If plant bundles are used to restrict erosion on steep slopes, the procedure for installation is as follows:

Step 1

Begin at the bottom of the slope and knock in wooden pegs along the contour line.

Step 2

Dig a furrow above the pegs, with a sectional area of half that of the bundles to be used (diameter of bundles e.g. 200 mm). The bundles should preferably contain shoots that may take root, reeds or grass and should preferably be indigenous.

Step 3

Place the bundles in the furrows.

Step 4

Knock in more pegs through and next to the bundles. If necessary, cover the bundles with soil tamped down so as to stimulate the growth of the shoots.

Planks may be used instead of bundles. (Tree trunks have also been successfully used in a staggered pattern.)

Step 5

Suitable vegetation has now been established. To keep subsequent maintenance to a minimum, vegetation from the surrounding environment should preferably be used and should be chosen, established and cared for in consultation with botanists.

Step 6

Maintenance is carried out where necessary, especially during the early stages.

5.7.3 Direct protection

Direct protection is used mainly where vegetation protection will not be successful; for example, where too little sunlight penetrates (such as under bridge decks) or in very dry areas. Continuous paving, such as paving blocks or grouted stone, often provide the best solution for these scenarios. Erosion caused by people, where the public has access, should also be taken into account or be prevented by providing proper access in the form of well-proportioned steps.

5.8 REFERENCES

- 5.1 Martinez, J.E. et al. (1972). *A study of variables associated with wheel spin-down and hydroplaning*. Higher Res. Rec. 396. Highway Research Board, Washington DC.
- 5.2 Nomogram of the FHA, USA
- 5.3 Grobler, P. (1994). *Verification of the inlet capacities of modified stormwater kerb inlets and the development of new design kerbs*. MEng thesis. University of Stellenbosch.
- 5.4 Zwamborn, JA (1966). *Stormwater inlet design*. Proc. Annual Municipal Conf. Johannesburg.
- 5.5 Forbes, H.J.C. (1976). *Capacity of lateral stormwater inlets*. The Civil Eng in South Africa.
- 5.6 Rooseboom, A., Van Schalkwyk, A. and Kroon, C. (1988). *Modified kerb inlet design for improved hydraulic performance*. The Civil Eng in South Africa.
- 5.7 US Department of Agriculture SCS. (1966). *Engineering Design Standards*.
- 5.8 State of California. (1979). *Highway design – Manual of instructions*. Department of Transportation.
- 5.9 Crosby, C. (1981). *Grassed channels*. RSA Department of Agriculture and Fisheries, Division of Agricultural Engineering, Pretoria. (In Afrikaans).
- 5.10 Directorate of Water Affairs. (1980). *Guidelines for the design of canals*. Chief Engineer, Design Division, RSA Directorate of Water Affairs.
- 5.11 Kovács, Z.P. (1974). *Scour and protective measures at drainage works*. Van Niekerk, Kleyn and Edwards Consulting Engineers. Pretoria.
- 5.12 Henderson, F.M. (1966). *Open Channel Flow*. MacMillan Series in Civil Engineering.
- 5.13 Shen, H.W. (1971). *River Mechanics*. Colorado State University, Fort Collins.
- 5.14 Van Bendegom, L. and Zanen, A (1968). *Lecture notes on revetments*. ICHED, Delft.
- 5.15 Rooseboom, A. and Le Grange, A. du P. (2000). *The Hydraulic Resistance of Sand Streambed under Steady Flow Conditions*. Journal of the Int. Ass. for Hydraulics Research. Vol 38 No 1.
- 5.16 Bradley, J.N. and Peterka, A.J. (1957). *The hydraulic design of stilling basins*. Proc. Am. Soc. Civ. Engrs. Vol. 83, No. H Y 5.
- 5.17 Van der Vyver, I.C. and Van der Walt, A.K.H. (1978). *Guidelines for the design and use of energy dissipators in steep drainage channels*. Undergraduate thesis, University of Pretoria. (In Afrikaans).
- 5.18 Mulke, F.J. (1981). *Erosion prevention and prediction*. Symposium on road, rail and airport drainage, CSIR, Pretoria. (In Afrikaans).
- 5.19 Gray, D.H., Leiser, A.T. and White, C.A. (1980). *Combined vegetative–structural slope stabilization*. Civ. Eng Jl. ASCE.
- 5.20 US Department of Commerce. (1965). *Design of roadside drainage channels*. Bureau of Public Roads.

- 5.21 Chesterton, J., Nancekivelle, N. and Tunncliffe, N. (2006). *The use of the Gallaway Formula for Aquaplaning Evaluation in New Zealand*. NZIHT & Transit NZ8th Annual Conference.

Notes:

Blank lined area for notes or calculations.

CHAPTER 6 - LOW-LEVEL RIVER CROSSINGS

PA Pienaar and EJ Kruger

6.1 INTRODUCTION

6.1.1 Intended use of these guidelines

The objective of this chapter is to provide guidance for the design of low-level river crossings (LLRC). The applicability of recommendations in this chapter should be evaluated in terms of the specific conditions and circumstances being designed for. **Table 6.1, Road Map 6**, reflects aspects that are covered in this chapter.

6.1.2 Definition of low-level river crossings

A low-level river crossing (LLRC) is road structure which could be submerged under flood conditions. The LLRC is designed in such a way as to experience no or limited damage when overtopped. This type of structure is appropriate when the inundation of a road for short periods, is acceptable. The different aspects that need to be considered and references to sections in this chapter are reflected in **Table 6.1(Road Map 6)**.

Table 6.1: Road Map 6 – Low-level Crossings

ROAD MAP 6			
Typical topics			
Description	Par	Input information	Example problem
Low-level river crossings	6.1.2	Foundation conditions and traffic loads.	Implementation of a LLRC for a river section on a tertiary road linking rural settlements on both banks of a river. The route is inaccessible for vehicles, which use an alternative route via the main road with a length of 45 km. Current traffic volume is 50 vehicles per day and it is expected to increase to 300 vehicles per day, should a proper river crossing structure be provided. The expected traffic growth rate for the next 20 years is 2 percent per year. <u>The problem is included in the <i>Application Guide</i> which is included on the accompanying flash drive/DVD.</u>
Application of LLRCs	6.1.5	Cost benefit analysis including the cost of capital, discount rate, economic life and yearly costs.	
Selection of the structure type	6.4	Road usage and user cost relationships.	
Hydraulic considerations	6.5	Flood peaks and recurrence interval.	
Structural design considerations	6.6	Road usage, flows, foundation conditions, available shapes and erosion protection.	

6.1.3 Terminology

A number of terms are used to describe these structures, such as:

- low-level river crossing;
- low-level bridge;

- low-level structure;
- low-water structure;
- submersible structure;
- low-water stream crossing;
- causeway;
- vented causeway; and
- small bridge.

In this chapter, the term *low-level river crossing*, abbreviated as LLRC, is preferred.

6.1.4 Classification of LLRCs

LLRCs are either drifts or causeways which are defined as follows:

- **Drift** - A drift is defined as a specially prepared surface for vehicles to drive over when crossing a river. A drift does not contain any openings underneath the surface for allowing passing water through. The surface layer may consist of gravel, concrete, grouted stone or commercial products such as Armorflex (concrete blocks held together longitudinally with polyester, galvanised steel or stainless steel cables) and Hyson Cells. These are mats comprising square, hollow geocells - fabricated from thin plastic film – and filled *in-situ* with grout to form a layer of interlocking concrete blocks. Drifts are also referred to in the literature as *fords*.

Figure 6.1 to Figure 6.3 depicts examples of drifts.

- **Causeway** - A vented causeway (referred to as a causeway) in essence also consists of a suitable surface layer over which vehicles may drive, but contains openings underneath allowing water to pass through the structure.

These openings may be of circular or rectangular shape and could be formed by means of pre-cast pipes or portal culverts, corrugated iron void formers, short span decks (less than 2 m), etc. Vented causeways are also referred to in the literature as *vented fords*.

Figure 6.4 depicts an example of causeways.




Figure 6.1: Drift constructed with selected gravel (cross-sections through drifts)




Figure 6.2: Drift constructed with a concrete slab and cut-off walls (cross-sections through drifts)




Figure 6.3: Drift constructed with a concrete slab and cut-off walls (cross-sections through drifts)




Figure 6.4: Examples of causeways

- **Low-level bridge** - A low-level bridge is defined as a structure consisting of a short-span deck (typically between 4 and 7,5 m) supported by a sub-structure consisting of two abutments and any number of piers. The height of the deck above the riverbed is typically less than 2 m.

Figure 6.5 depicts a typical low-level bridge.





Figure 6.5: Example of a low-level bridge

Photographs 6.1 and 6.2 show examples of low-level structures.



Photograph 6.1: A low-level river crossing provides safe access across the wide river



Photograph 6.2: A low-level crossing constructed with stone

6.1.5 The application of LLRCs

6.1.5.1 Basic characteristics of LLRCs

Two distinctive characteristics of LLRCs are that the:

- structure will be inundated from time to time and hence not available for use. It is necessary for the users of these structures to be aware of this limitation, and to accept and respect it; and
- that the cost of construction is generally considerably lower than that of a conventional bridge.

LLRCs are appropriate under the following circumstances:

- when the inundation of the structure, and the associated disruption in traffic flow, is acceptable for short periods of time;
- where alternative routes that can be used during flooding are available;
- where traffic volumes are low, typically on the tertiary road network;
- where high-level bridges are not economically justified; and
- where funding available for construction is limited.

The use of LLRCs might be influenced by:

- their non-availability for use from time to time;
- the risk associated for road users who might use them during periods of inundation, and be washed away; and
- the required maintenance after floods to repair and remove debris.

6.1.5.2 Road network aspects to be reviewed when LLRCs are considered

The road network aspects to be considered when LLRCs are evaluated, are:

- If a particular community or land use has one access road only and the access road crosses a river without a structure, the decision whether to construct a LLRC or a high-level bridge depends on the acceptability of short periods of inaccessibility, the construction cost and the economic justification of the options. Under low traffic volume conditions, say less than 500 vehicles per day, the return on investment of a LLRC is generally better than that of a high-level bridge. The reason is the considerably lower construction cost, while disruption in traffic is generally of a limited nature.
- If an alternative access route to a community or land use is available during periods of flooding, the impact of using the alternative route in terms of travel cost and travel time should be assessed in relation to the possible savings in construction cost associated with a LLRC.

With larger rivers, attention should be paid to the total road network in the area, the number and locations of river-crossing structures, as well as the levels of these structures in terms of design return periods. Rather than designing all river-crossing structures for the same return period, variation in the return periods used for design could be considered. In this way the number of accessible structures during flooding will be reduced, whilst alternatives will remain available. In contrast with the first option, a situation may occur where all the structures under consideration are overtopped at the same time. Generally, one would prefer structures on the primary road network not to be inundated during floods, while inundation of structures on the tertiary network is acceptable.

6.1.6 Key focus areas of the design of LLRCs

During the analyses, design and construction of any river-crossing structure a number of aspects need to be considered. These include:

- site selection;
- determining the appropriate design discharge (hydrology);
- reviewing the hydraulic capacity of the structure;
- assessment of the geometric alignment and width of the structure;
- how to accommodate the different road users (vehicles and pedestrians);
- review of the foundation conditions;
- assessment of the structure itself, i.e.;
 - sub-structure (abutments, piers and foundations);
 - super-structure (deck, guide blocks, etc.);
 - approach fills; and
 - erosion protection measures.

This manual is, in essence, a drainage guide. Although reference will be made to the above aspects in the following paragraphs, the emphasis will only be on those that relate to drainage: i.e. location, hydrology, hydraulics and some structural design considerations. Detailed guidelines on foundation investigations, material characteristics, structural design of culverts and bridges, erosion protection and energy dissipation are not included in this document.

6.2 SITE SELECTION

6.2.1 Straight river section

A LLRC should be located within a straight section of a river where the river flow is as uniform as possible. Riverbanks on the outsides of bends tend to erode which might lead to the floodwater by-passing the structure during flooding. Refer to **Figure 6.6** in this regard.




Figure 6.6: Preferred location of LLRC in river

6.2.2 River channel cross-section

Where the width of a river channel varies, the advantages of locating the structure in a narrower section should be compared to those associated with location in a wider section. Benefits of a narrower section are shorter length and, therefore, lower construction cost. Benefits also cover the possibility that the narrower section is associated with less weathered *in-situ* material, which may offer better founding conditions. Benefits of a wider section in the river are that the flow velocity is relatively low with shallower depth. These two benefits reduce the risk that the structure may be damaged and increases the safety of vehicles crossing the structure. This is shown in **Figure 6.7**.




Figure 6.7: Wide versus narrow section in river

Generally speaking, a LLRC should be as low as possible to minimise the impact on water flow by the obstruction placed in the river channel. The depth of the natural river channel, compared to the width, should be considered. With narrow, deep sections the depth-to-width ratio may not allow the structure to be placed at a low-level due to the geometric alignment limitations of the road. LLRCs are generally more suitable for river cross-sections with low depth-to-width ratios as is depicted in **Figure 6.8**.




Figure 6.8: Effect of cross-section shape

Where the river cross-section consists of a channel located within a wider flood plain, it may be appropriate to place the structure at that height where overtopping of the structure occurs at the same time when river flow exceeds the channel capacity and extends onto the flood plain. The benefit of this approach is that the flow velocity over the structure is relatively low. In such cases the access road should be vertically aligned to be as close to natural ground level as possible, to minimise the obstruction to water flow. Under such conditions erosion protection should be reviewed. **Figure 6.9** reflects a typical side view of a LLRC where a floodplain is present.




Figure 6.9: Effect of flood plain

6.2.3 The angle at which a road crosses a river

Crossing of a river at an angle should be avoided. A skew approach, coupled with the possible blocking of openings with debris, tends to direct the full force of the river towards one of the riverbanks, which increases the possibility of the approach being washed away.

The structure should also be straight. A horizontally curved structure will be subject to similar problems of undesirable concentration of flow and it is extremely dangerous for road users to cross such a structure when inundated. **Figure 6.10** reflects schematically the preferred layout of LLRCs.

PREFERABLE	UNDESIRABLE
<p>Low level river crossing perpendicular to flow</p>	<p>Crossing river at a skew angle</p>
<p>Low level river crossing straight</p>	<p>Low level river crossing curved</p>

Figure 6.10: Schematic presentation the preferred layouts of LLRCs

6.3 HYDROLOGY

6.3.1 Methods to calculate run-off

Chapter 3 deals with a number of hydrological calculation methods that may be applied to determine the discharge at LLRCs. With LLRCs a high level of accuracy in the determination of the design floods for LLRCs are not essential because the structure will be overtopped from time to time.

Very often, therefore, only the rational method will be used, which is one of the most commonly used methods in South-Africa, especially if the catchment area does not exceed 500 km². If there is a need to determine the expected period of inundation, more sophisticated methods should be used, for example statistical analysis of the runoff data from a nearby flow gauging station.

6.3.2 The appropriate design return period for LLRCs

As discussed in **Chapter 3** of this manual, the return period is the average period over a large number of years during which an event (flood) repeats or exceeds itself. A flood is considered to be a mass wave that progresses along a watercourse and changes the water level, discharge, flow velocity and water surface slope over time at any specific location along the watercourse.

The selection of the flood return period used in the design of a LLRC is influenced by:

- the runoff hydrograph (flow rate-time relationship) which is characterized by the catchment's parameters and the storm event;
- the seasonal variation of the river flow (perennial rivers are less suitable for low-level structures);
- the road classification;
- the availability of alternative routes;
- the cost of the structure; and
- the anticipated maintenance and repair costs after flooding was experienced.

6.3.3 Determination of design flow rate

The basic principle of a LLRC is that it should be provided at as low a level as is possible, in order to limit the impact of water flow on the structure under flooded conditions. However, there is also a limit as to how low the structure can be placed, depending on:

- geometric design parameters of the road crossing the LLRC; and
- the discharge that needs to be accommodated underneath the structure, or within acceptable depth over the structure, to provide a certain level of service and access.

The design approach for LLRCs is based on the definition of design levels, which provide an indication of the level of service to be provided by the structure. Three design levels, with the associated frequency and duration, are defined as indicated in **Table 6.2**. If, for example, design level 1 is selected the design flow could be expected to be exceeded 1,3 times per year on average, with the average flood duration (period during which the design flow is exceeded) being 9 hours. The range of these values as observed in practice is also shown (minimum and maximum values). **Table 6.2** is based on an analysis of river flow data over 20 years at 41 hydrological gauging stations located in the northern provinces of South Africa ^(6.5).

Table 6.2: Levels of design for low-level structures
(based on observed data from the Northern Province)

Design level	Dimensionless factor, f_i	Average no of times flow can be expected to be exceeded per year			Average length of period flow is exceeded (hours)		
		Min value	Max value	Average value	Min value	Max value	Average value
1	0,25	0,0	4,2	1,3	0,0	30	9,0
2	0,50	0,0	2,4	0,8	0,0	13	5,5
3	1,00	0,0	1,4	0,5	0,0	6	3,4

The **suggested approach** for the determination of the design level is as follows:

- **Design level 1** is taken as the initial choice.
- **Design level 2** is applicable if:
 - o traffic volume passing over the structure exceeds 250 vehicles per day; or
 - o the additional travel distance along an alternative route exceeds 20 km.
- **Design level 3** is applicable if:
 - o traffic volume passing over the structure exceeds 500 vehicles per day; or
 - o the additional travel distance along an alternative route exceeds 50 km; or
 - o there is no alternative route available.

The designer must use his judgement in applying this approach, and should clarify the selected design level with the owner of the structure.

Once the design level has been determined, the design discharge is calculated as follows:

$$Q_{\text{design}} = f_i Q_2$$

...(6.1)

- where:
- Q_{design} = design discharge (m^3/s)
 - f_i = a dimensionless factor related to the design level chosen as shown in **Table 6.2**
 - Q_2 = discharge with a 2 year return period (m^3/s)

The structure should be designed in such a way that:

$$Q_{\text{over}} + Q_{\text{under}} \geq Q_{\text{design}}$$

...(6.2)

- where:
- Q_{over} = discharge that can be accommodated over the structure within the acceptable flow depth as defined below (m^3/s)
 - Q_{under} = discharge capacity of the openings through the structure (m^3/s), if any

With regard to flow depth, it is accepted that a vehicle should not pass over a LLRC if the depth of flow over the structure exceeds the under-body ground clearance height of the vehicle. The flow velocity, however, also needs to be taken into account. Design depth values are as follows:

- Supercritical flow: Maximum depth 100 mm
- Subcritical flow: Maximum depth 150 mm

6.4 HYDRAULIC CONSIDERATIONS

6.4.1 Introduction

The capacity of a structure is determined as the sum of the discharge that could be accommodated over the structure within acceptable depth, and the discharge to be accommodated underneath the structure. The sum is then compared to the design discharge, Q_{design} , in order to evaluate the adequacy of the structure, as discussed in Section 6.3.3.

6.4.2 Calculation of the discharge over the structure

The determination of the flow across the structure can be determined as follows:

- Decide on the maximum flow depth over the structure through which a vehicle will still be able to pass safely (100 mm for supercritical flow due to the high momentum transfer associated with the velocities, and 150 mm for subcritical flow over the structure).
- Calculate the discharge that could be accommodated over the structure. As a first assumption, especially if the slope in the direction of flow is 2 to 3% as recommended elsewhere, assume this flow to be supercritical. For supercritical channel flow over the structure:

$$Q_{\text{over}} = \frac{A_{\text{over}}^{5/3} S_0^{1/2}}{n P_{\text{over}}^{2/3}} \quad \dots(6.3)$$

where:

Q_{over}	=	the discharge that could be accommodated over the structure within the selected flow depth (m^3/s)
A_{over}	=	area of flow over structure at the selected flow depth (m^2)
S_0	=	slope in direction of flow, for example 0,02 or 0,03 m/m
n	=	Manning n-value. For a concrete deck n_{concrete} can be taken as $0,016 \text{ s/m}^{1/3}$
P_{over}	=	wetted perimeter at the flow depth selected (m)

A_{over} and P_{over} are calculated as follows (Refer to **Figure 6.11**):

$$A_{\text{over}} = A_1 + A_2 + A_3, \text{ or } A_{\text{over}} = \frac{1}{3} d \sqrt{800 K_1 d} + d L_2 + \frac{1}{3} d \sqrt{800 K_3 d} \quad \dots(6.4)$$

and

$$P_{\text{over}} = P_1 + P_2 + P_3, \text{ or } P_{\text{over}} = \frac{1}{2} \sqrt{800 K_1 d} + L_2 + \frac{1}{2} \sqrt{800 K_3 d} \quad \dots(6.5)$$

where:

A_1, A_2, A_3	=	the areas defined in Figure 6.11 (m^2)
d	=	depth of flow over the structure (m)
K_1	=	the geometric K value for vertical curve 1
K_3	=	the geometric K value for vertical curve 3

With K being a geometric vertical road alignment parameter, defined as the horizontal length of road required for a 1% change in the gradient of the road.

The vertical road alignment, K (K_1 and K_3) should not be confused with K_{in1} and K_{out} on the following page. The symbol K is used because it is the symbol used in vertical road design methodology. Vertical design aspects are also addressed in Section 6.6.2.1 with values suggested for K.

Figure 6.11 also defines the symbols P_1 , P_3 and L_2 .

Establish whether the flow is indeed supercritical by calculating the Froude number, Fr:

$$Fr = \sqrt{\frac{Q_{\text{over}}^2 B}{g A_{\text{over}}^3}} \quad \dots(6.6)$$

where:

$B = L_1 + L_2 + L_3$ (m), the width of the channel (or the length of the structure)

$g = 9,81 \text{ m/s}^2$, the gravity constant

$$L_1 = \frac{1}{2} \sqrt{800 K_1 d} \quad \text{and} \quad L_3 = \frac{1}{2} \sqrt{800 K_3 d}$$

Refer to the definition sketch (**Figure 6.11**) for L_1 , L_2 and L_3 .




Figure 6.11: Definition of symbols for the flow over the structure




Figure 6.12: Definition of symbols

If $Fr \geq 1,0$ it indicates that flow over the structure is supercritical at the selected flow depth, and that the methodology described here is applicable.

If $Fr < 1,0$ it indicates that flow over the structure is subcritical, and the analysis must be done as described elsewhere in this manual.

Note that in the calculation of the flow over the structure the effect of guide-blocks are for simplicity reasons ignored.

6.4.3 Flow passing through the structure

Assume outlet control (Refer to **Figure 6.12** for a definition of the symbols):

The flow passing through the structure is defined as Q_{under} , where:

$$Q_{\text{under}} = \bar{v}_{\text{under}} A_{\text{eff}} \quad \dots(6.7)$$

and where:

$$\bar{v}_{\text{under}} = \sqrt{\frac{H_1 - H_2}{\frac{C}{2g} + \frac{n_{\text{eff}}^2 L_B}{R^{4/3}}}} \quad \dots(6.8)$$

where:

- A_{eff} = the effective inlet area through the structure (m^2) = ΣA_{cell} (the effective inlet area through the structure)
- L_B = the total width of the deck of the structure (m)
- \bar{v}_{under} = the velocity of flow through the structure (m/s)
- C = factor that reflects the transition losses (Equation 6.13)

Determine the total energy height (H_1) upstream of the structure and the water level at the outlet of the structure:

Assumption: Since the water is dammed by the structure, the velocity $\bar{v}_1 \approx 0 \text{ m/s}$

$$H_1 = h + x + D \quad \dots(6.9)$$

where:

- x = the thickness of the deck (depending on the structural design outcome) (m)
- D = the height of the soffit of the deck above the river invert level (m)

By applying the conservation of energy principle, determine the depth upstream of the structure, h , that is required to pass the flow rate, Q_{over} :

$$h = \frac{\bar{v}_2^2}{2g} + d \quad \dots(6.10)$$

with:

$$\bar{v}_2 = \frac{Q_{\text{over}}}{A_{\text{over}}} \quad \dots(6.11)$$

$$H_2 = D - L_B S_0 \quad \dots(6.12)$$

where:

L_B	=	the total width of the deck of the structure (m)
S_0	=	slope of the conduit underneath the structure (m/m)

C is a factor representing the local or transition losses due to flow convergence/divergence at the inlet/outlet:

$$C = \sum (K_{inl} + K_{out})_{\text{each cell}} \quad \dots(6.13)$$

K_{inl} and K_{out} are determined as follows for rectangular sections:

K_{inl} at outlet control:	Sudden transition:	$K_{inl} = 0,5$
	Gradual transition:	$K_{inl} = 0,25$
K_{out} at outlet control:	Sudden transition:	$K_{out} = 1,0$
	Gradual transition:	$K_{out} = 1,0$ for $45^\circ < \theta < 80^\circ$
		$0,7$ for $\theta = 30^\circ$
		$0,2$ for $\theta = 15^\circ$

where:

θ is the diversion angle.

Also refer to Section 4.3.4 where the energy principle is discussed.

n_{eff} is the effective Manning n-value for flow through the structure:

$$n_{eff} = \frac{\sum (n_{cell} P_{cell})}{P_{eff}} \quad \dots(6.14)$$

and

$$n_{cell} = \frac{P_{concrete} n_{concrete}}{P_{cell}} + \frac{P_{river} n_{river}}{P_{cell}} \quad \dots(6.15)$$

where:	$P_{concrete}$	=	the part of the wetted perimeter that has a concrete surface per cell (m)
	P_{river}	=	the part of the wetted perimeter that is made up by the riverbed per cell (m)
	P_{cell}	=	the total wetted perimeter of each cell (m)
	P_{eff}	=	$\sum P_{cell}$ (effective wetted perimeter for the flow passing through the structure) (m)
	$n_{concrete}$	=	the Manning roughness coefficient of concrete ($s/m^{1/3}$) (typically $0,016 s/m^{1/3}$ - refer to Section 4.2.6 for more detail)
	n_{river}	=	the Manning roughness coefficient of the river bed ($s/m^{1/3}$) (typically $0,03 s/m^{1/3}$ - refer to Section 4.2.6 for more detail)
	R	=	A_{eff} / P_{eff} (hydraulic radius (m))

6.4.4 Total flow

The total discharge capacity needs to exceed the design discharge:

Determine if $Q_{over} + Q_{under} > Q_{design}$

If so, the capacity of the structure meets the design capacity. If not, the design height and/or length of the structure would have to be increased, and the flow capacity be checked again.

6.5 SELECTION OF STRUCTURE TYPE

6.5.1 Introduction

In applicable circumstances it might be required to compare the implementation of a LLRC with a culvert or a bridge. In the following paragraphs some characteristics of LLRCs are compared with that of culverts or bridges.

6.5.2 Comparing LLRCs and culverts

A decision needs to be made whether a culvert or a LLRC is more appropriate. The following guidelines are provided in this regard:

- The cost of a culvert should be compared to the cost of a LLRC. For small catchment areas (typically smaller than 10 km²) culverts tend to cost less. In the case of larger catchment areas, LLRCs generally offer the lowest cost solutions. Culverts or high level bridges will, however, be used in larger catchment areas where it is not possible to construct LLRCs, for example due to geometric road alignment limitations, the unacceptability of inundation during flooding or very poor founding conditions.
- As far as topography is concerned, culverts tend to be more appropriate in mountainous terrain where fills are required at low points in the road alignment. In rolling and flat terrain LLRCs are generally more appropriate.
- Culverts are designed for higher return periods than LLRCs. They will, therefore, be preferred on roads where occasional disruption of traffic flow due to flooding is not acceptable.

6.5.3 Comparing LLRCs and high-level bridges

The cost of bridge structures may form a significant portion of the cost of a road construction project. The construction costs of LLRCs are generally considerably lower than those of high-level bridges. In view of the rainfall characteristics and the tendency of short, high intensity rainfalls encountered in smaller catchments in South Africa, there is considerable room for cost savings by using LLRCs. The following guidelines are provided with regard to the choice between a high-level bridge and a LLRC:

- On high order roads (Road Classes 1 to 3)* high-level bridges are generally required because of the unacceptability of disruptions due to flooding.
- On lower order roads (Road Classes 4 to 6)* the cost of the LLRC option should be compared to the cost of the high-level bridge option. If there is a significant difference, a LLRC could be opted for, except in cases where it is not practical to construct a LLRC, for example due to geometric alignment constraints, or where inundation is unacceptable. Especially in the case of Class 4* roads, the comparative advantage needs to be discussed and agreed upon with the authority concerned.
- Where the additional cost of providing a high-level bridge is marginal, for example where the cost of the sub-structure is relatively high due to poor founding conditions, a high-level bridge may be warranted.

** For a description of the various classes of roads see Chapter 8.*

6.5.4 Application of LLRCs for different road types

Any type of LLRC may be used with either paved or unpaved roads. In both cases it is important to ensure that the approaching road user is informed about the presence of such a structure, either by means of road signage, road layout (curved alignment) and/or good visibility of the structure.

6.6 STRUCTURAL DESIGN CONSIDERATIONS

6.6.1 Structural dimensions

6.6.1.1 *Number of lanes*

LLRCs are particularly appropriate on tertiary roads, characterised by low traffic volumes. As tertiary roads under most conditions have two lanes (one per direction) LLRCs will generally also be provided with two lanes. In certain instances, however, the provision of a single-lane structure may be justified. A single-lane structure may be considered where:

- The approach gradients are moderate and there is no significant curvature on the immediate approach roads.
- The LLRC is long and considerable savings associated with a single-lane structure are likely.
- There is good visibility on approaches to the structure, and LLRCs are infrequent on an otherwise good section of road.
- Traffic volume is not expected to exceed 500 vehicles per day during the life of the structure.
- Pedestrian volume is low, less than 100 pedestrians in the peak hour. For longer bridges provision can be made for a dedicated walkway with or without handrails. Details are provided in Section 6.6.1.6.

6.6.1.2 *Width of structure*

The following widths are recommended (**Figure 6.13**):

- Two-lane structure: 7,5 m between the guide-blocks
- Single-lane structure: 4,0 m between guide-blocks.

Widths of between 4,0 and 7,0 m should be avoided, as these widths create the impression that it is a two-lane structure, although vehicles cannot pass each other safely within this space.




Figure 6.13: Proposed width for LLRC

6.6.1.3 Cross-sectional and longitudinal slope of surface

A cross-fall of 2 to 3% in the direction of flow is recommended to prevent sediment being deposited on the driving surface (Refer to **Figure 6.15**).

In the travel direction it is imperative that the structure is level (with the exception of short vertical curves at both ends of the structure), see **Figure 6.14**. From the road user’s perspective a variation in water depth when the structure is overtopped, is undesirable. From a hydraulic point of view concentration of water flowing over a LLRC is undesirable, especially if one end of the structure is lower than the other end (Refer to **Figure 6.15**).

RECOMMENDED	NOT ALLOWED

Figure 6.14: Level crossing




Figure 6.15: Cross-sectional and longitudinal slopes

6.6.1.4 Length of structure

It is imperative that the length of the structure equals the total width of the river. If the structure protrudes significantly above the river bed, the total length of the structure should be provided with openings underneath, so as not to create a dam wall across the river (refer to **Figure 6.16**).




Figure 6.16: Cross-sectional area

6.6.1.5 Size of openings

The size of the openings through the structure depends on the design discharge. However, in the design of openings it is desirable to provide as much waterway area as possible within the river channel, so that the structure minimises obstruction of the river flow (refer to **Figure 6.16**).

As a general guideline openings should be as large as possible to allow as much debris as possible to pass through the structure.


6.6.1.6 Guide-blocks and provision for pedestrians

Guide-blocks are to be provided on all LLRCs. Guide-blocks are placed along the edges of the deck with the objective of guiding the road user, and of assisting him in gauging the depth of flow over the structure. Guide-blocks should be designed to withstand debris blockages. Although a wide range of guide-block sizes and spacing are encountered in practice, the following are recommended: 250 mm blocks (cubical) at 2,0 m spacing. **Photograph 6.3** reflects the use of guide blocks.



Photograph 6.3: A low-level crossing near Steytlerville, showing the guide blocks

Where significant numbers of pedestrians are expected, especially on longer single-lane bridges, then separate provision should be made for the pedestrians by means of a dedicated walkway on the upstream side of the bridge deck. In addition, handrails that can collapse under larger floods should be provided where structures are higher than 3 m measured from top of deck level to river invert (also refer to Section 8.3 of **Chapter 8**). Such a bridge showing guide blocks, pedestrian walkway and collapsible handrail is reflected in **Photograph 6.4**.



Photograph 6.4: A low-level crossing on Tsitsa River with provision for pedestrians

6.6.1.7 Apron slabs, approach slabs and wing-walls

The use of apron slabs on both the upstream and downstream sides of a LLRC is recommended to absorb the energy of water flowing over the structure, and to protect the foundations of the structure.

These slabs also contribute towards increased stability of water flows in the immediate vicinity of the structure. Apron slabs should have toe walls (cut-off walls) to prevent scouring and undermining of the slabs.

Approach slabs should preferably be built high enough to accommodate the 1:5 to 1:10 year flow. In remote areas where regular maintenance is not possible, consideration could be given to increase the return period that is used in designing the approach slab to prevent undermining and failure of the bridge approach.

Apron and approach slabs would normally be constructed using concrete. Reno mattresses could be considered under certain circumstances for apron slabs.

Wing-walls assist in directing water flow, and in protecting the abutments and road approach fill embankment of the structure.




Figure 6.17: Approach slab on approach roads

6.6.1.8 Inclined buttresses on upstream side

It is considered good practice to provide LLRCs with inclined buttresses on the upstream side of each pier, to assist in lifting floating debris over the structure – not that this is always effective. It also provides additional stability in the case of debris loads. **Figure 6.18** shows an example of inclined buttresses.




Figure 6.18: Inclined buttresses on upstream side

6.6.2 Road geometry

6.6.2.1 Vertical alignment

Generally, it is acceptable to use reduced geometric road design standards on the approaches to, and over LLRCs, provided that road users are warned; e.g. by means of speed reduction road signage, and provided that the environment changes sufficiently for them to realise that they are approaching a river. The maximum gradients suggested are shown in **Table 6.3**.

Table 6.3: Suggested maximum gradients for LLRC approach roads

Road type	Desirable maximum grade (%)	Absolute maximum grade (%)
Paved roads	10	12
Unpaved roads	8	10

Vertical curves in the alignment of the approach road are parabolic, as is normal for vertical road design. The **K-value** is defined as the horizontal length of road required for a 1% change in gradient. Minimum K-values are functions of design speed. Where practical, the design speed over a LLRC should be the same as for the associated road section. This is, however, often not possible. Where not possible, consideration may be given to lower the design speed over the LLRC, preferably by not more than 20 km/h, and in extreme cases up to an absolute maximum of 40 km/h. The necessary traffic signage must be provided. Typical values for sag vertical curves (as opposed to crest vertical curves which are not applicable to low level structures) are shown in **Table 6.4**.

Table 6.4: Suggested minimum K values for sag vertical curves

Design speed (km/hr)	K value
40	7
60	17
80	32
100	50
120	73

6.6.2.2 Horizontal alignment

The horizontal alignment of the approach roads should be designed according to the same standards as the road passing over the structure. The designer should specifically pay attention to the sight distance towards a LLRC, to ensure that the road user observes the structure in good time. Sharp horizontal curves in close proximity of a LLRC should be avoided for this reason.

6.6.3 Foundations

Ideally LLRCs should be founded on solid rock. Stiff clay may also offer suitable founding conditions, subject to the structure being designed to accommodate relative movement. Founding of LLRCs on unstable or sandy material is undesirable because of the tendency for riverbed material to become liquid under conditions of flooding. As a rule of thumb, one may assume that the depth of this instability may be as much as the depth of water flowing in the river channel at that point. The general scour equations, given in **Chapter 8** (Section 8.4.3), may also be applied.

Where rock is not available, raft foundations are recommended. The raft should consist of a slab (the floor slab of the LLRC) and toe walls on all sides of the slab to form a closed cell, as shown in **Figure 6.19**. The horizontal dimensions of the raft should generally not exceed 6 to 8 m. Toe walls should extend to non-erodable material, or in extreme cases anchorage could be used. The design engineer should check for buoyancy and release the built up pressure. Between the toe walls the raft should be filled with properly graded and compacted material which can withstand seepage water.

With longer structures multiple rafts are to be provided, which should then be secured to one another by means of dowels, for example. Refer to **Figure 6.19** in this regard.




Figure 6.19: Raft foundation

Table 6.4 provides guidelines with regard to the effect of founding conditions on the selection of the LLRC structure type. Where more expensive foundations are required, for example piling, longer spans may be justified (8 to 15 m, versus the 6 m typically used in the case of good founding conditions).

Table 6.4: The selection of LLRC type according to founding conditions

Foundation condition	LLRC type		
	Drift	Causeway	Low-level bridge
Uneven rock	Unsuitable	Unsuitable	Very suitable
Even rock	Very suitable	Very suitable	Very suitable
Stiff clay	Suitable – use raft foundation	Suitable – use raft foundation	Spread footings, or piling/caissons may be required. Consider longer spans.
Sand	Consider a raft foundation	Consider a raft foundation	Piling/caissons required. Consider longer spans.

6.6.4 Structural design

6.6.4.1 Structural design approach

In the case of drifts and causeways it is advisable to limit the dimensions of units of construction to between 6 and 8 metres, to allow for thermal and other movement. These units should then be properly linked together by using dowels or keying them into each other.

In the case of low-level bridges (pier and deck construction) either a continuous beam approach or a simple supported slab approach may be used. It is important, however, to properly tie down the deck slab(s) to the piers by using dowels.

The use of I-beam slabs or slabs with voids that can trap air and induce buoyancy forces should be avoided.

Figure 6.20 shows various shapes, which could be considered for causeway openings. The use of arch shaped openings could be considered for the labour intensive construction option, as it generally only requires relatively simple steel reinforcement (**Figure 6.20**). The benefit of the arch type shown, compared to circular or semi-circular openings, is that it allows a higher percentage of openings underneath the deck, which reduces the extent of the obstruction to water flow.




Figure 6.20: Various shapes of openings for causeways

With regard to the impact of the structure on water flow, it is recommended that the impact be kept as low as possible. Specifically, the ends of piers should be properly finished off to minimise obstruction to river flow.

6.6.4.2 Construction materials

The most commonly used material for LLRCs are concrete and stone masonry. The advantage of concrete is its durability and ability to withstand abrasion forces. The advantage of stone masonry construction is its suitability for labour-intensive construction.

In causeways pre-fabricated pipe and box-culverts are often used as void-formers. These elements have structural strength in themselves, but are relatively expensive. Where void-formers are totally encased in concrete or stone masonry work, consideration should be given to lower-cost options, such as corrugated iron void-formers. Armco-type elements should preferably not be used, based on cost considerations.

6.6.4.3 Structural loading

TMH 7 Parts 1 and 2: Code of practice for the design of highway bridges and culverts in South Africa (1981 as revised 1988) distinguishes between the following types of traffic loading on road bridges:

- normal loads (NA)
- abnormal loads (NB)
- super loads (NC).

The Code stipulates that while NC loading may be omitted on certain routes, all road bridges should be designed for both the NA and at least the NB24 load. These values are recommended for LLRCs, provided that the design engineer ascertains the applicability in each case. Obtaining the prior approval of the owner or responsible authority is considered essential.

6.6.5 Approach fills

The abutments of LLRCs should be keyed into the river banks where possible. In the case of flat river cross-sections the approach road should be constructed as close to natural ground level as possible, to avoid embankments being breached when overtopped by floods. Where the overtopping of embankments is likely, provision should be made for erosion protection by suitably cladding the upstream and downstream faces and the road formation. Flow depth and velocity for the 1:5 or 1:10 year flood should be determined, and provision should be made to accommodate their impact on the approach roads and structures.

In certain circumstances it may be necessary to protect banks downstream of the structure to a level calculated on the basis of a chosen design flood, preferably the 1:5 year flood.

6.6.6 Erosion protection

Because they are designed to be overtopped, erosion protection is particularly important with LLRCs. Attention should be given to:

- The downstream apron slab area;
- Approach roads to the structure; and
- The banks downstream of the LLRC.

Chapters 7 and 8 of this manual deal with this topic.

6.6.7 Safety

6.6.7.1 General

Driver safety and convenience should be addressed in the design of LLRCs. Human life may not be endangered. On the structure itself this can be accomplished by providing an adequate warning system in the form of guide-blocks. Guide-blocks indicate both the limits of the structure and the depth of water flow over the structure. Guide-blocks are also spaced in such a way as to prevent a motor vehicle from sliding down the structure.

On the approach roads the necessary road signage should be erected, specifically some or all of these reflected in paragraphs 6.6.7.1 and 6.6.7.2 ^(6.6).

6.6.7.2 Warning signs

The following warning signs should be considered for LLC's:

- W350: Drift
- W326: Narrow bridge
- W327: One vehicle width structure
- W328: Road narrows both sides
- W202 and W203: Gentle curve
- W204 and W205: Sharp curve
- W348: Jetty edge or river bank
- W401 and W402: Danger plate

6.6.7.3 Regulatory Signs

The following regulatory signs could be applicable near LLC's:

- R1: Stop
- R6: Yield to oncoming traffic
- R201: Speed limit

6.7 OTHER CONSIDERATIONS

6.7.1 Community considerations

The perceptions of rural communities regarding LLRCs are sometimes not positive; the reasons being both the safety risks in the event of flooding and the lack of all-weather access. These concerns can only be addressed through proper communication and information being made available. Road users should be made aware of the safety risks and the need to use alternative routes during periods of flooding.

LLRCs offer more job creation potential during construction than most other elements of a roads project. This will benefit the local community in cases where workers are employed locally.

6.7.2 Labour-intensive construction

The suitability of LLRCs for labour-intensive construction methods is well known and is referred to in the text.

The use of local materials, specifically sand and stone for stone masonry construction, is encouraged, subject to it being environmentally and functionally acceptable.

6.7.3 Environmental considerations

Aspects to be addressed include:

- The environmental impacts of a LLRC, such as accelerated flow velocity, possible impact on the river banks and visual appearance.
- The need for regular maintenance, especially after periods of flooding, to remove debris, sand, and to repair minor damage.

6.7.4 Legal aspects

The legal aspects pertaining to drainage in general are covered in **Chapter 2**. With regard to the design of LLRCs it is required that appropriate guidelines; such as the material covered in this document should be consulted. The acceptance of lower design standards than those indicated in the guidelines needs to be justified in terms of the risk involved and the financial and legal position of the “owner” of the structure.

6.7.5 Economic justification

Generally the level of economic justification of LLRCs is high when compared to high-level structures. The main reason for this is the relatively low construction cost of these structures, while the negative impact on road users is restricted to a maximum of a few days per year.

Costs to be considered in the economic evaluation of alternatives are amongst other the:

- cost of construction;
- the useful life and cost of replacement or extension of the components;
- the cost and inconvenience to road users resulting from delays in the case flooded and inaccessible crossings (in severe cases there might not be any alternative route available);
- the cost to road users associated with the use of alternative routes in the case of the crossing not being accessible (where available); and
- maintenance cost, especially maintenance and/or repairs after flooding.

The delays (length of period during which the design flow is exceeded) to be expected may be determined from **Table 6.2**. By considering the time cost of road users, the cost of delays can be quantified. The cost of using alternative routes may include direct travel cost, as well as time cost of road users. Maintenance costs would need to be estimated from experience, while road construction costs may be estimated quite accurately.

6.8 REFERENCES

- 6.1 Van Zyl, G.D. *et al.* (1993). *Towards appropriate standards for rural roads: discussion document*. Report RR 92/466/1 (ISBN: 1-874844-89-5), Department of Transport, Pretoria.
- 6.1 Rossmiller, R.L. *et al.* (1983). *Design manual for low water stream crossings*. Iowa DOT Project HR-247, ERI Project 1599, ISU-ERI-Ames 84029, College of Engineering, Iowa State University, Ames, Iowa, USA.
- 6.2 Parry, J.D. (1992). *Overseas Road Note 9: A design manual for small bridges*. Transportation and Research Laboratory, Crowthorne, Berkshire, UK.
- 6.3 Pienaar, P.A. (1993). *The management of tertiary road networks in the rural areas*. PhD dissertation, University of Pretoria, Pretoria.
- 6.4 Jordaan & Joubert (1993). *Guidelines on project evaluation for tertiary roads*. Report PR91/232, SA Roads Board, Pretoria.
- 6.6 Road Traffic Signs Manual, 3rd Edition, Volume 1: *Uniform Traffic Control Devices, Part 1, of the Southern African Development Community*.

Notes:

Lined area for notes.

CHAPTER 7 - LESSER CULVERTS (AND STORMWATER CONDUITS)

A Rooseboom and SJ van Vuuren

7.1 INTRODUCTION

This chapter covers the practical design of lesser culverts

The reference to lesser- (**Chapter 7**) and major culverts (**Chapter 8**) is based on the distinction whether positive freeboard is present. In the case of lesser culverts the optimal sizing of the culvert, operating as inlet controlled, limits the total upstream energy (H) to 1,2 times the vertical dimension (D). This normative approach, conceptualize parameters such as:

- Limiting the total time of inundation to limit the potential of failure of the structure due to piping;
- Limiting the deceleration of the approaching flow to minimize upstream siltation;
- Limiting the potential of downstream erosion which is a function of the velocity at the outlet of the culvert and which is related to the square root of the upstream energy (\sqrt{H}); and
- Limiting the size of the culvert to obtain an economical solution for the structure.

The term “lesser culverts” are practically entrenched and is therefore maintained in this manual.

Major culverts are discussed in **Chapter 8**.

Low-level crossings, lesser culverts and storm water pipes, as well as bridges and major culverts have a great deal in common in terms of hydrological assessment and hydraulic design calculations. The different hydrological assessment procedures being applied depend more on the catchment size than on structure type. In hydraulic design calculations for all hydraulic structures a distinction is drawn between upstream (inlet) and downstream (outlet) control.

The term “lesser culverts” refers to culverts that are small enough to be designed by means of simplified hydraulic and hydrological analyses. More sophisticated procedures used in the hydraulic design of bridges are applicable in the design of major culverts and are covered in **Chapter 8**.

Table 7.1 (Road Map 7) reflects typical problems related to lesser culverts and which are discussed in this chapter.

Table 7.1: Road Map of lesser culverts (and storm water conduits)

ROAD MAP 7						
Typical theme		Input information	Worked examples #		Supporting software	Other topics
Topic	Par.		Problem	In <i>Application Guide</i>		
Practical considerations	7.2	n/a				
Determination of the required culvert size	7.4	Design flow rate, maximum water level, control characteristics and available culvert sizes	Determine the required culvert size for a given flow rate	7.1	Utility Programs for Drainage, HEC-RAS & HY-8	Flood calculations - Chapter 3
Flood attenuation at culverts	7.5	Inflow hydrograph, discharge characteristics and the storage height relationship	Level pool flood routing	10.1		
Erosion protection downstream of culverts	7.7	Flow velocities at the exit, geometric data and downstream normal flow depth	Selection of erosion protection measures downstream of a culvert	7.3		

Note:

The worked examples are included in the Application Guide of which an electronic copy is included on the flash drive/DVD at the back of this document.


7.2 PRACTICAL CONSIDERATIONS TO BE CONSIDERED FOR LESSER CULVERTS

7.2.1 Typical problems experienced at lesser culverts

Most of the serious cases of water-related damage to culverts and endangerment of traffic in the past could be attributed to one or more of the following conditions:

- Scour on the downstream side of a culvert because of inadequate erosion protection and inadequate energy dissipation, which could ultimately lead to failure;
- Overtopping and scour on the downstream side resulting from supercritical flow approaching the culvert entrance at an angle, forming a hydraulic jump at the entrance and then overtopping the structure;
- Overtopping and scour of the embankment and surface layers, because of the blockage of culvert inlets by debris;
- Scour around inlets, often due to flow alongside the road towards the culvert inlet in wide flood plain rivers;
- Piping resulting from the saturation of the backfill around the structure initiating a flow path to develop between the culvert structure and fill, especially where the fill material is dispersive. **Photograph 7.1** reflects a flow path through a culvert joint; and
- Popping up of a light-weight (metal) culvert inlet section as a result of a high water table in the fill around the culvert.

- Failures have occurred in large embankments with small culverts. Where severe debris is anticipated and increase in culvert size is warranted to give free flowing conditions or provide debris catchers/collectors.



Photograph 7.1: Piping (flow path through culvert joint eroding dispersive material)
(Courtesy of: MVD Consulting Engineers)

In the following paragraphs practical measures related to lesser culverts are discussed with the objective to limit risk of road users and minimizing the potential flood damage.

7.2.2 Practical measures to be considered for lesser culverts

7.2.2.1 Introduction

A culvert serves to convey water from the upstream to the downstream side of a road. In flat areas where embankments are constructed mainly to provide vertical space for culverts, the optimum balance between fill costs and drainage costs should be sought.

Every natural watercourse reflects the prevailing pattern of quasi-equilibrium between flow and erosion processes. In an optimal hydraulic design the disturbance of the balance should be minimised.

7.2.2.2 Hydraulic design aspects applicable to lesser culverts

The implementation of an optimal hydraulic design for lesser culverts requires that:

- Flow is concentrated as little as possible. Culverts should preferably not be further apart than 100 m.
- The direction of flow should be changed as little as possible. Oncoming flow approaching at an angle to the inlet reduces the capacity of a culvert. On the downstream side the flow should be released in the original direction of flow to prevent alteration of the downstream erosion pattern.

- Water velocities should be altered as little as possible. Retardation of flow may cause the deposition of sediment, and acceleration may cause downstream scour. Upstream material deposits should be prevented where it may lead to a reduction in the hydraulic capacity of a culvert. Silt deposits inside culverts with flat gradients should be prevented. To achieve this, the flow velocities through culverts should, not be less than 1 m/s, and the slope of a culvert should accordingly not be less than about 1%. Where the stream returns to a natural watercourse, its erosive capacity should not be significantly higher than under the original conditions. If necessary, the velocity of flow should be reduced by means of energy dissipaters.

7.2.2.3 *Supercritical approach velocities at lesser culverts*

It should always be borne in mind that supercritical oncoming flow must be allowed to pass virtually undisturbed, otherwise considerable damming and erosion may take place. Supercritical flow can only change direction very gradually unless it switches to subcritical flow.

If the oncoming flow is supercritical and it is uncertain whether or not damming may occur, the case should be treated as an inlet-controlled case or should be analysed by an expert. A culvert should be placed at the lowest point of each embankment. Since long-lasting damming may lead to the saturation of fill and foundation material, all low points need to be properly drained.

7.2.2.4 *Optimum vertical dimension of lesser culverts*

For a given head and inlet control, an H/D ratio of 1,2 approximately yields the optimum hydraulic section (maximum Q for a given head). This is also a good practical value from the point of view of preventing siltation, inlet erosion and minimising the height of an embankment over a culvert. It must be noted that for a flood with double the design return period (Q_{2T}) the road, for Road Classes 1 to 3, should not be overtopped under these flooding conditions.

7.2.2.5 *Minimum sizes for lesser culverts*

The minimum acceptable recommended practical size for a culvert up to 30 m long is 600 mm in diameter or a rectangular section of 750 mm (wide) x 450 mm (high), and for a culvert longer than 30 m a minimum diameter of 900 mm or a rectangular section of 900 mm (wide) x 450 mm (high) should be considered with the aim of being able to conduct maintenance.

7.2.2.6 *Handling of debris at lesser culverts*

In cases where excessive debris is dumped in the upstream natural channels and where it may be transported, the culvert should be large enough to allow it to pass, or otherwise a debris grid needs to be provided upstream of the culvert.

The available flow area through the grid should be at least four times that of the culvert. The loss of energy or extra head resulting from the presence of the grid may be put at $\frac{\bar{v}^2}{2g}$, with \bar{v} = average water velocity through the grid with allowance being made for blockage.

7.2.2.7 *Alignment of lesser culverts*

Provision should be made to prevent culvert misalignment when differential settlement can occur, by way of upward cambers and or steeper culvert slopes. Differential settlement can be minimized when the culvert is installed after sufficient fill has been placed.

7.2.2.8 *Hydrostatic forces on lesser culverts*

The large hydrostatic buoyant forces that may arise at culvert inlets should be taken into account in structural design. These arise when a culvert empties rapidly, but the surrounding soil remains saturated with water.

Where piping in soils may pose a problem, all culvert joints should be watertight, and collars, enclosed in impervious material, should be provided. In this case the H/D ratio for metal pipes should not be greater than 1.

7.2.2.9 *Limiting the upstream water level for lesser culverts*

In culvert design the water level at the design discharge may not rise higher than the shoulder, especially where the culvert inlet is on the outside of a curve with super elevation. The possibility of soil mechanical failure should be taken into account in the determination of maximum heads, especially in the case where non-cohesive materials have been used for fill. A flood of two times the design return period should be accommodated below the shoulder break point. This is a freeboard requirement as described in Section 8.3 of **Chapter 8**.



Photograph 7.2: Typical culvert with wing walls

7.3 CULVERT HYDRAULICS

7.3.1 Hydraulic controls experienced in culverts

A distinction should be made between UPSTREAM (INLET) CONTROL and DOWNSTREAM (OUTLET) CONTROL. The former occurs most often and is preferred, due to the following:

- It yields the smallest culvert cross-section for a given upstream head; and
- The higher flow velocities through the culvert prevent the deposition of sediment inside.

7.3.2 Basic hydraulic theory applicable to lesser culvert design

The theory of culvert flow is relatively simple, but its strict application is difficult. Therefore, aids have been developed to simplify design calculations.

The basis of culvert design is that the energy equation is satisfied, together with the continuity equation.




Figure 7.1: Energy components of flow through a culvert

Regardless of flow conditions through the culvert, the following equation must be satisfied:

$$z_1 + y_1 + \frac{\bar{v}_1^2}{2g} = z_2 + y_2 + \frac{\bar{v}_2^2}{2g} + h_{f1-2} + \sum h_{L1-2} \quad \dots(7.1)$$

where:

h_{f1-2} = friction losses between cross-sections 1 and 2 (m)

z_1 and z_2 are the upstream and downstream bed elevations (m)

y_1 and y_2 are the upstream and downstream water depths (m), and

\bar{v}_1 and \bar{v}_2 are the upstream and downstream average flow velocities (m/s)

and

$\sum h_{L1-2}$ = transition losses between cross-section 1 and 2 (m)

It is convenient to set the energy reference line at the level of the downstream invert level, $z_2 = 0$, and then:

$$H_1 = H_2 + h_{f1-2} + h_{L1-2} - z_1 \quad \dots(7.2)$$

Where:

H_1 and H_2 are the upstream and downstream energy levels, measured relative to the inlet invert level.

Because flow past a section is not possible with less specific energy than the critical value in open channel flow, this restriction often applies at the inlet.

In simplified culvert capacity determinations, for a given discharge Q :

- H_1 is calculated for full-flow conditions through the culvert (Outlet Control/Downstream Control).
- The minimum H_1 required at the inlet is calculated (Inlet Control/Upstream Control).
- The greater of these values of H_1 is accepted as representing the controlling flow level for the flow rate, Q .

Conversely, for a fixed value of H_1 , the lower value of Q obtained by the two methods would apply.

7.3.2.1 Downstream (Outlet) control of lesser culverts

In practice, the culvert should be full-flowing for at least part of its length for outlet or downstream control to apply.




Figure 7.2: Section of a culvert partially flowing full

As before:

$$H_1 \text{ must be } = H_2 + h_{f1-2} + \sum h_{L1-2} - S_0 L \quad \dots(7.3)$$

H_2 must be determined beforehand according to downstream conditions.

By substitution in equation 7.3 for friction losses and transition losses, the following equations are obtained:

$$H_1 - H_2 = \frac{K_{in} \bar{v}_1^2}{2g} + \frac{K_{out} \bar{v}_2^2}{2g} + \frac{\bar{v}^2 n^2 L}{R^{\frac{4}{3}}} \quad (\text{Manning}) \quad \dots(7.4)$$

or

$$H_1 - H_2 = \frac{K_{in} \bar{v}_1^2}{2g} + \frac{K_{out} \bar{v}_2^2}{2g} + \frac{\bar{v}^2 L}{C^2 R} \quad (\text{Chezy}) \quad \dots(7.5)$$

Where K_{in} and K_{out} = inlet and outlet secondary loss coefficients.

The required roughness coefficients may be obtained from **Chapter 4**.

If H_2 is known, as well as the dimensions and roughness of a culvert, the value of H_1 for a given discharge (Q) can be determined through step-by-step calculation.

These calculations have been performed with a value of $n = 0,016 \text{ s/m}^{1/3}$, which is a realistic design value for concrete culverts, and the results are given in **Figure 7.4** (It has conservatively been assumed that the culvert is flowing full over its entire length.)

7.3.2.2 Upstream (Inlet) control of lesser culverts

With upstream (inlet) control, flow passes from sub- to supercritical at the inlet and theoretically the Froude number is equal to 1, as depicted below.

$$\frac{Q^2 B}{g A^3} = 1 \quad \dots(7.6)$$

In order to determine H_1 , allowance should be made for contraction effects and energy losses at the entry as shown in **Figure 7.3**. **Table 7.2** provides a summary of the equations for inlet control in round and rectangular culverts ^(7.2).




Figure 7.3: Flow through a culvert with upstream control

Table 7.2: Relationships for the flow rate under inlet control ^(7.2)

ROUND CULVERTS	RECTANGULAR CULVERTS
$D = \text{inside diameter (m)}$	$D = \text{height (inside) (m)}$ $B = \text{width (inside) (m)}$
For : $0 < H_1/D < 0,8$ $\frac{Q}{D^2 \sqrt{gD}} = 0,48 \left[\frac{S_0}{0,4} \right]^{0,05} \left[\frac{H_1}{D} \right]^{1,9}$	For: $0 < H_1/D \leq 1,2$ $Q = \frac{2}{3} C_B B H_1 \sqrt{\frac{2}{3} g H_1}$ Where: $C_B = 1,0$ for rounded inlets ($r > 0,1B$) $C_B = 0,9$ for square inlets
And for: $0,8 < H_1/D \leq 1,2$ * $\frac{Q}{D^2 \sqrt{gD}} = 0,44 \left[\frac{S_0}{0,4} \right]^{0,05} \left[\frac{H_1}{D} \right]^{1,5}$ ($S_0 = \text{slope of culvert bed with slight effect on capacity}$) Note: * For $H_1/D > 1,2$, the orifice formulae applies $Q = C_D A \sqrt{2g \left(H_1 - \frac{D}{2} \right)}$ with $C_D \approx 0,6$	And for: $H_1/D > 1,2$ $Q = C_h B D \sqrt{2g (H_1 - C_h D)}$ Where: $C_h = 0,8$ for rounded inlets $C_h = 0,6$ for square inlets

For a H/D ratio of 1,2 and with inlet control, the equations in **Table 7.2** are represented graphically in **Figure 7.3** (Inlet control procedure).

7.4 DETERMINATION OF CULVERT SIZE

7.4.1 Distinction between inlet and outlet control

In the typical design problem, Q is known from hydrological calculations (**Chapter 3**), the maximum value for H_1 is known on the basis of the vertical road alignment and considerations of soil mechanics, and a suitable culvert has to be provided. The design return period for different road classes is determined based on the reference 20 year recurrence interval flood (Q_{20}) as described in **Chapter 8**.

First of all, the maximum probable value of the downstream energy level, H_2 (normal flow depth, y_{2n}), should be determined in accordance with downstream conditions (**Chapter 4**).

The sizes of culverts with adequate capacity may then be determined directly from **Figure 7.4**. **The size required for inlet control is determined first, and then the required size for outlet control. The larger calculated upstream required energy H_1 value, to maintain the discharge through the culvert, reflects the applicable hydraulic control (inlet- or outlet control). It reflects the energy needed to get the flow into the culvert (inlet control) or the energy needed to maintain the flow through the culvert overcoming all the energy losses (outlet control).**

Especially in the case of very long culverts where inlet control applies, it is often possible to affect considerable savings by using a transitional tapered inlet layout to get the flow into the culvert together with a smaller culvert section, placed at a steeper grade.

In the following sections where the velocity at the culvert outlet and erosion protection is discussed, the following notation is used:

A	=	cross sectional flow area (m^2)
v	=	average flow velocity (m/s)
Q	=	discharge rate (m^3/s)
y_n	=	normal flow depth (m)
y_c	=	critical flow depth (m)
S_0	=	natural slope (m/m) and
S_c	=	critical slope (m/m), where $Fr = 1$

7.4.2 Improving the inlet capacity and determining the discharge velocities of lesser culverts

Rounding-off of inlet corners normally only gives a small (5 to 10%) increase in culvert capacity. However, by adapting the inlet section, as shown in **Figure 7.5**, the capacity of long culverts with inlet control can often be increased. Additional reference material is provided on the flash drive/DVD such as the Federal Highway Administration report on the *Effects of Inlet Geometry on Hydraulic Performance of Box Culverts* ^(7.6 & 7.7).




Figure 7.5: Steep culvert with dimensional and slope variations to increase the capacity (Changes at the entrance)




Figure 7.6: Diagram for the determination of outlet velocities for steep culverts and storm water pipes (Only $H_1/D = 1,2$, $S_0 > S_c$)
(A copy of this diagram has been included on the flash drive/DVD at the back of this document)

The slope downstream of B (control at the inlet), has to be hydraulically steep ($y_n < y_c$ or $S_0 > S_c$) and it should be ensured that the **specific energy values at all sections upstream of B are higher than those for critical conditions**. To achieve this it is necessary to increase the sectional area along the inlet portion.

The procedure for the determination of the layout for steep culverts is as follows:

As indicated in **Figure 7.5**, A and C are the natural levels at the culvert's inlet and outlet.

Step 1 – Selecting the culvert size:

For the given design discharge, Q and available upstream energy head H_1 , the required culvert section for inlet control is determined (**Table 7.2** or **Figure 7.4**). Select a smaller culvert section and determine the minimum required slope for the flow to be sufficiently supercritical ($\frac{Q^2 B}{gA^3} \approx 1.2$) and for the culvert to be almost full-flowing using the relationships of Manning or Chézy.

Step 2 – Applying the selected culvert size on the downstream side:

Apply the selected culvert section between B and C at the minimum required slope which was calculated in step 1.

Step 3 – Determining the culvert side of the first section of the culvert:

Now draw in the energy grade line UVW (V and W are at a distance $y_n + \frac{\bar{v}_n^2}{2g}$ above the culvert bed,

and U corresponds with the total upstream energy level at the inlet), see **Figure 7.5**. Gradually increase the culvert section upstream of B (make it wider and/or deeper) so that the distance (vertical) between the culvert invert and the energy line everywhere is:

$$\geq y_c + \frac{\bar{v}_c^2}{2g} \quad \text{and} \quad \frac{Q^2 B_c}{gA_c^3} = 1$$

Step 4 – Review the continuity of energy through the culvert:

Ensure that the specific energy at the entrance where contraction occurs is sufficient to accommodate the discharge without resulting in an increase of the energy level at the inlet. If this cannot be achieved with the selected culvert size, the inlet dimensions should be further increased.

If the invert level at the entrance is lowered beyond the natural ground level at the inlet, care must be taken that the overflow edge at A will be long enough for the specific energy above A to be sufficient

($H_1 \geq y_c + \frac{\bar{v}_c^2}{2g}$) to accommodate the discharge.

7.5 FLOOD ATTENUATION AT CULVERTS

Any requirement of additional energy to maintain the discharge through a hydraulic structure will result in a temporal storage of water and hence a reduction in the discharge flow rate downstream from the hydraulic structure. All the discussions on the sizing of lesser culverts were conducted on the premise that no storage and therefore attenuation will occur and that the maximum upstream energy, H , will be limited to $1.2 D$ (the vertical dimension of the culvert).

If temporal storage upstream from an inlet controlled culvert is allowed, the capacity of the culvert could be reduced. This will however result in a longer period of inundation upstream from the culvert, increase the potential of piping, and increase the potential of upstream siltation and increasing the downstream potential erosion.

In the hydraulic assessment of new culverts the influence of storage is not reviewed but in the case where existing culverts need to be reviewed it is proposed that temporal storage will be considered. In **Chapter 10** flood attenuation and the review of existing hydraulic structures are discussed.

7.6 EROSION PREVENTION UPSTREAM OF CULVERTS

Erosion is generally found where:

- water velocities are high, and
- the direction of flow changes rapidly.

When conventional inlets with wing-walls (standard design) are used, scour upstream of culverts is rarely a problem. The provision of pitching over a distance of twice the vertical dimension upstream of the culvert inlet (or upstream of the concrete slab between the wing walls), with stones 200 mm in size is usually sufficient^(7.1) to prevent local scour.

Where problems are expected, additional protective measures may be required as discussed in **Chapter 8**.

7.7 EROSION PREVENTION DOWNSTREAM OF CULVERTS

7.7.1 Determination of the outlet velocity

Before erosion protection at a culvert outlet can be designed, the water velocity at the outlet needs to be determined.

In the case of **outlet control**, the downstream flow depth determines the sectional area at the outlet and the corresponding average velocity can be calculated for a given value of Q and A $\left(v = \frac{Q}{A} \right)$.

More important is the case in which inlet control applies and the flow is supercritical at the outlet (upstream control).




Figure 7.7: Definition sketch of the energy components through a culvert

The energy at section 2 (just inside or outside the culvert) can be compared with the available energy at section 1. The following equation applies in the case of non-submerged conditions at section 2 (free outflow):

$$H_1 + z_1 = y_2 + \frac{\bar{v}_2^2}{2g} + h_{f\ 1-2} + h_{1-2} \quad \dots(7.7)$$

Once again, h_f can be calculated according to the Manning or Chézy roughness coefficients, and h_1 equals the entry loss at section 1.

Outlet velocities just inside or outside the culvert outlet may be read off from **Figure 7.6** when inlet control applies. **Figure 7.6** is based on a conservatively low value for n of $0,014 \text{ s/m}^{1/3}$ which will result in unfavourable downstream conditions (high velocities). The outlet velocity cannot be higher than that given by the Manning equation for uniform flow through the culvert, and in the case of steep slopes is limited by the difference in height between the inlet and the outlet, while the equilibrium uniform velocity has not yet been reached).

7.7.2 Protective downstream measures

The primary aim of downstream erosion protection is to release water into the natural channel at a velocity no greater than the original velocity and in the same direction.

Energy dissipation normally takes place downstream of the culvert, but may also take place in steps inside the culvert.

For effective energy dissipation and erosion protection downstream of the culvert, the following alternatives are available for consideration:

- Grass covers (**Chapter 5**) (**Figure 7.9**).
- Types II, III, IV of stone pitching as developed by the US Waterways Experiment Station^(7.3) (**Figure 7.9**, **Figure 7.10** and **Figure 7.11**).
- Type V stilling basin with baffle wall was at the University of Pretoria based on alterations to the stilling basin for dam outlets proposed by the US Bureau of Reclamation's^(7.4) (**Figure 7.12**).

Taking into account different aspects, such as maximum permissible water velocities, maximum stone sizes that can be handled by labourers, and relative costs, **Figure 7.8** approximately indicates the optimum selection of the energy dissipation solutions for different flow conditions.

The following procedure is used when applying **Figure 7.8** to obtain the optimum erosion protection option for the culvert outlets:

- Determine the outlet velocity at the entrance to the stilling basin in accordance with **Figure 7.6**.
- Calculate the depth of flow from the continuity equation.
- Calculate the Froude number, Fr , as well as $\frac{y}{D}$ where D is the height or diameter of the culvert and y is the outlet flow depth.
- Read off **Figure 7.8** the most appropriate type of energy dissipation and obtain the required dimensions from the detailed data.

If another type of protection is preferred, it has to be checked to see whether it may be used under the prevailing conditions.

Where a grass cover is used, the outlet should be above ground level and if necessary, the area around the outlet should be paved to prevent grass and/or deposits of sediment from blocking the outlet.






Figure 7.8: Limiting values for different methods of erosion protection at culvert outlets
(A copy of this diagram has been included on the flash drive/DVD which is included at the back of this document)






Figure 7.11: US Army waterways stone stilling basins – Type III




Figure 7.12: Type V Stilling Basin

7.8 REFERENCES

7.1 Edgeron, R.C. (1961). *Culvert inlet failures – a case history*. Bulletin 286 Highway Research Board. Washington DC.

7.2 Henderson, F.M. (1966). *Open Channel Flow*, MacMillan Series in Civil Engineering.

- Notes:

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins or other markings on the paper.

CHAPTER 8 - BRIDGES AND MAJOR CULVERTS

AM Jansen van Vuuren, A Rooseboom and EJ Kruger

8.1 INTRODUCTION

The hydraulic design of bridges and major culverts, as well as the practical aspects of bridge site location and of scour protection are covered in this chapter. **Table 8.1** reflects the typical problems associated with this chapter.

Definitions applicable in this chapter are as follows:

- **Bridge**
A structure shall be classified as a bridge if one or more of the following criteria are satisfied:
 - o Any single span (as measured horizontally at the soffit along the road or rail centre line between faces of supports) is greater or equal to 6 m; or
 - o The individual clear spans (as measured horizontally at the soffit along the road or rail centre line between the faces of its supports) exceed 1,5 m **and** the overall length measured between abutment faces exceeds 20 m; or
 - o The opening height, which is the maximum vertical distance from the streambed or structure floor at the inlet or the top of any base, to the soffit of the superstructure, is equal to or greater than 6 m; or
 - o Where the total cross-sectional opening is equal or larger than 36 m²; or
 - o The structure is a road-over-rail, or rail-over-rail structure, even if the span is less than 6 m.
- **Major culvert**
A cellular structure with dimensions less than those defining a bridge but with clear span length (as measured horizontally at the soffit perpendicular to the faces of its supports) equal to or larger than 2,1 m, or diameter equal to or larger than 2,1 m, or a culvert with a total cross-sectional opening equal to or larger than 5 m².
- **Lesser culvert**
All culverts smaller than that defined as a Major Culvert (See **Chapter 7**).
- **Backwater h^* (or damming; afflux)**
The rise in water level upstream of the waterway constriction, as shown in **Figure 8.1**.
- **Freeboard (F_D)**
Freeboard is the height difference between the design high flood level (that includes the backwater) and the lowest level along the soffit of the bridge deck or culvert as defined in **Figure 8.1**.
- **Maximum design afflux**
The maximum allowable afflux for the flood having a return period of twice the return period of the design flood (Q_{2T}).
- **Shoulder breakpoint** – Defined in **Figure 8.1**.

Important note pertaining to bridge and culvert classification: It must be noted by the reader that the definitions for bridges and culverts are purely for categorisation purposes for *structures management* from a risk viewpoint and do not refer to the form of the structure. Thus a bridge may take the structural form of a culvert and a culvert may have the structural form of a bridge. It will be noted that in this chapter no distinction is made between bridges and culverts for freeboard or other requirements. Distinction is made between free flow type structures and inlet control type structures as depicted in **Figure 8.1**. This is a major departure from previous editions (Editions 1 to 4) of this manual where anomalies existed (different flood return periods were used depending on whether one regarded a structure as a culvert or a bridge). Lesser culverts should also follow the freeboard requirement as outlined in this chapter.

Table 8.1: Road Map for bridges and major culverts

ROAD MAP 8						
Typical problems		Input information	Worked examples	Supporting software	Other topics	
Topic	Par .				Topic	Reference
Determination of the required freeboard at bridges and major culverts	8.2	Road Class, Q_{20} and Q_T (design peak discharge), Q_{2T} (maximum allowable damming), associated social, environmental and structural impact associated with overtopping.	-	-	Risk of overtopping and failure (LCC) Flood calculations	Chapter 2 and 3
Calculation of the backwater	8.3	Flow rate, cross-sectional parameters, representative roughness, eccentricity and orientation of the opening, flows in the left, right and centre channels (where applicable).	Worked examples have been included in the "Drainage Manual – Application Guide" which is available on the memory stick included at the back of this document.	HEC-RAS	Sub- or supercritical flow conditions in the bridge	8.5
Scour estimation at bridges	8.4	Flow rate, cross-sectional parameters, representative particle characteristics, longitudinal channel characteristics and sediment loads. Physical properties of clay.			Long and short term general scour	8.8
		Pier dimensions and shape, orientation, form of the pier nose.			Local scour	
		Dimensions of narrowed section.			Contraction scour	
		Influenced by all the above factors.			Total scour	
		Summary of all the steps required.			Procedures for estimation of scour	8.11
Scour counter-measures at bridges	8.5	Erodibility, topography and alignment of the road.	-		Counter-measures at bridges	8.12




Figure 8.1: Illustration of the hydraulic definitions

Freeboard requirements are discussed in Section 8.3 and the selected design flood frequency depends on the classification of the road which is described in Section 8.2.

8.2 ROAD CLASSIFICATION

Roads in South Africa are classified into six general classes. These definitions correspond to the document TRH 26: “South African Road Classification and Access Management Manual”. R classes are rural roads and U classes are urban roads. For more in depth descriptions refer to TRH26 (Section 4.5) ^(8.33).

- **Class 1 (R1 Rural principal arterial, U1 Urban principal arterial)**

Strategic function: High mobility roads with limited access for rapid movement of large volumes of traffic.

Typical descriptions:

Class R1 Rural principal arterials carry countrywide traffic between:

- Metropolitan areas and large cities (population typically greater than about 500 000);
- Large border posts;
- Other Class 1 arterials; and
- Smaller centres than above when travel distances are very long (longer than 500km)

Typically average annual daily traffic (AADT) would in most cases exceed 1 000 vehicles per day on long distance routes, 5 000 vehicles per day on medium distance routes and can reach 100 000 vehicles per day or more on shorter routes.

Class U1 Urban principal arterials serve traffic for:

- Metropolitan areas and large cities (population typically greater than about 500 000);
- They are generally also connectors to rural Class R1 Routes;
- They generally stretch from boundary to boundary and connect to other metropolitan or rural principal arterial routes; and are
- Normally 20km or more in length

Typically the AADT would be 40 000 or more vehicles per day and the roads are typically freeways.

- **Class 2 (R2 Rural major arterial, U2 Urban major arterial)**

Strategic function: Relative high mobility roads with lower levels of access for movement of large volume traffic.

Typical descriptions:

Class R2 Rural major arterials carry interregional traffic between:

- Smaller and medium to large towns cities (population typically greater than about 25 000);
- Smaller border posts;
- Class 1 and other Class 2 routes;
- Important regions, transport nodes and commercial areas that generate large volumes of freight and other traffic such as seaports and international airports;
- Smaller centres than above when travel distances are relatively long (longer than 200km)

Typically average annual daily traffic (AADT) would exceed 500 vehicles per day on long distance routes, 2 000 vehicles per day on medium distance routes but on shorter routes the volumes could exceed 25 000 vehicles per day.

Class U2 Urban major arterials serve traffic for:

- Metropolitan areas, cities and medium to large towns (population typically greater than about 25 000);
- They connect larger regions of a city;
- They may connect to rural Class R2 routes;
- They generally stretch from boundary to boundary and connect to other metropolitan or rural principal arterial routes; and
- They are normally 10km or more in length

Typically the AADT would be about 20 000 to 60 000 vehicles per day.

- **Class 3 (R3 Rural minor arterial, U3 Urban minor arterial)**

Strategic function: Moderate mobility roads with controlled higher levels of access for movement of traffic in rural and urban areas of regional importance.

Typical descriptions:

Class R3 Rural minor arterials carry inter-district traffic between:

- Small towns, villages and larger rural settlements (population typically less than 25 000);
- Smaller commercial areas and transport nodes of local importance, i.e. terminals, railway sidings, small seaports and landing strips;
- Very small or minor border posts;
- Other Class 1,2 or 3 routes;
- Tourist destinations
- Smaller centres than the above when travel distances are relatively long (longer than 50 to 100km)

Typically the length of routes would vary between 10 and 100km and are not always continuous. Roads are not busy with typical AADT of between 100 and possibly 2 000 vehicles per day.

Class U3 Urban minor arterials serve traffic for:

- Most urban areas and small towns;
- They connect districts of a city or town;
- They may connect to rural Class R3 routes;
- They generally are through routes on a district scale and serve shorter distance trips.

Generally these roads are only 2km or less in length.

- **Class 4 (R4 Rural collector road, U4 Urban collector street)**

Strategic function: Lower mobility roads with high levels of access for lower traffic volumes in urban and rural areas of local importance.

Typical descriptions:

Class R4 Rural collector roads form the link to local destinations. Typically they give access to smaller rural settlements, tourist areas, mines, game and nature parks and heritage sites and large farms. The length of these roads would be shorter than 10km and the AADT should not exceed 1 000 vehicles per day.

Class U4 Urban collector streets penetrate local neighbourhoods or commercial developments with very little or no through traffic.

- **Class 5 (R5 Rural local road, U5 Urban local street)**

Strategic function: Very low mobility roads with high levels of access for low traffic volumes in urban and rural areas.

Typical descriptions:

Class R5 Rural local roads provide access to smaller individual properties such as small to medium sized farms or settlements.

Class U5 Urban local streets provide access to individual properties.

- **Class 6 (R6 Rural walkway, U6 Urban walkway)**

Strategic function: Public rights of way for non-motorised transport.

Typical descriptions:

R6 Rural walkways provide access and mobility for pedestrians and non-motorised transport to access the road network or other point of gathering or interest. Very rarely specifically constructed but generally start as informal pathways that in due time may be formalised.

U6 Urban walkways are where pedestrians are given priority without need for signs or road markings. On certain walkways limited provision for delivery vehicles may be made.

Guidance on how to apply the above classifications:

It is required that, **before** any detail design work is undertaken, the designer shall obtain in writing the classification of the specific road from the applicable road or municipal authority. This is particularly relevant for upgrading projects on existing roads where the road may have changed to a higher class than when the road was originally designed. Normally in these cases all the existing structures should be checked for the required design floods for the class concerned.

As a guide, structures that have hydraulic capacities that satisfy the requirements of a class of road one below the specified class of the road could be considered acceptable. Those structures that are totally hydraulically inadequate should be replaced with structures that can accommodate the correct floods for the current class of road. Care must be taken in making recommendations to an authority after due consideration of the site specific risks involved to the travelling public. Where rapid increases in water depth flowing over a road may occur without warning, great care must be exercised. The theoretical time of inundation of a road should also be considered since long inundation periods that isolate whole communities for extended periods of time should be avoided, even for lower classes of road.

Chapter 10 provides a detailed description and procedure to be followed in the application of the road classification, to assess the hydraulic criteria for existing structures that require upgrading.

8.3 DESIGN FLOOD FREQUENCY AND FREEBOARD REQUIREMENTS

8.3.1 The Design Flood

The design flood, Q_T , is the flow rate (m^3/s) with a return period of T years for which the hydraulic structure will be designed for freeboard requirements to the deck soffit. The 20-year flood is used as the “indicator” flood and it in essence reflects the hydrological risk classification of the road river-crossing at the bridge site. The selection of the return period for design is normally determined using the classification of the road, but may also be influenced in certain cases by the cost of the structure and if the risk of failure can be managed, and other factors. The applicable design floods are determined according to the methodology described in **Chapter 3** and the determination of the natural or “normal” flow depths is set out in **Chapter 4**. The design flood frequency, T , can be obtained from **Figure 8.2**. For roads crossing major rivers where high flood flows are maintained for several days, it may be advisable to build the bridge to the standard required for a higher class than the given road classification if alternative access is not available to a community. If alternative access is available then one can possibly consider structures that may be overtopped for road Classes 4 to 6 (see **Chapter 6**).




Figure 8.2: Design flood frequency estimate (Revised in 6th edition)

8.3.2 Freeboard

Distinction can be made between two hydraulic types of conveyance structures where two requirements need to be met:

- **Free flow structures** - structures with freeboard at the design flood and the friction loss in the flow conduit is relatively small so that the water surface does not touch the soffit of the structures.
 - A prescribed freeboard, F_D , which is the distance that the level of the design flood, Q_T , below a deck soffit (underside of deck) should be maintained. F_D is shown in **Figure 8.3** and is dependent on the magnitude of the design flood, Q_T , whose return period is determined from **Figure 8.2** for the applicable road class; and
 - The level of afflux caused by a flood having **twice** the recurrence interval (**2T**) of the design flood shall be below the shoulder breakpoint F_{SBP} of the road (see also **Figure 8.1**). Please note this is **not** $2Q_T$ but a flood with magnitude of Q_{2T} . The maximum afflux requirement to shoulder breakpoint, F_{SBP} , shall generally only apply to Road Classes 1, 2 and 3.
- **Inlet and outlet control type structures** - structures where the upstream water level of the design flood is above the soffit of the structure.
 - The submergence of the inlet is usually limited to a ratio of $H_1/D = 1.2$ for the design flow rate of Q_T , where D is the internal height of the structure and H_1 is the water depth at the inlet measured from the invert of the structure; and
 - For the flow rate of Q_{2T} the maximum allowable submergence level is limited to the smallest of $2D$ or the SBP.

The design flood, Q_T , and the freeboard/submergence requirements above should be regarded as minimum standards. As discussed in Section 8.4, the engineer should investigate the impacts of debris, standing wave action and super-elevation of the flow on the freeboard to be provided. Additional freeboard shall be provided where sediment build-up is likely, e.g. if the structure is positioned upstream of an existing or a planned dam. Such build-up often extends above the full supply level of the dam.

In certain marginal cases sensitivity analysis as to assumed roughness and slope should be considered as changing these parameters may significantly affect flood levels. In addition where flow is verging on supercritical flow (Froude Number $Fr > 0,8$) where flow conditions are unstable, care must be exercised. For bridges where approach flows are supercritical one should aim to minimise the obstructions in the main stream flow. For this reason it is often ill-advised to place a pier in the main channel of the river or stream. It is always advisable to span the main channel. Generally one would consider the natural stream flow without the road or bridge as a guide on how to proceed and physical or numerical modelling of the flow patterns may be required.




Figure 8.3: Required freeboard from the calculated backwater to the deck’s soffit of bridges and culverts (revised in 6th Edition)

8.4 OTHER DESIGN CONSIDERATIONS

8.4.1 Debris build-up

This aspect needs careful evaluation considering the risks involved and the economy of the structure. The backwater effect due to accumulation of debris should be taken into account where appropriate without being overly conservative. Where large debris is likely, the recommended minimum span lengths should be at least 7,5 m for all roads but preferably 15 m for Class 1 to Class 3 roads. In addition placing piers central on the main channel of flow should be avoided if possible. A typical failure partly due to the build-up of debris is shown in **Photograph 8.1** below. A minimum freeboard of 0,3 m for **all** bridges and culverts should be provided where significant debris is anticipated. Local conditions should be studied when freeboard is determined and local maintenance teams should be consulted.



Photograph 8.1: Failure partly due to debris build-up

8.4.2 Wave action

Standing waves are normally associated with high flow velocities (and particularly when flow is supercritical), large variation in roughness and abrupt changes in the cross-sectional flow area. At bridge crossings over large impoundments or in coastal areas, wind generated wave heights and run-up as well as the tidal influence need to be considered. Section 7 of Volume II of TRH 25 (CSRA, 1994) ^(8.7) contains detailed design guidelines on this topic.

8.4.3 Super elevation of flow

Directional changes at bends will result in a centrifugal acceleration that will manifest in the conveyance channel as an increase in the water depth on the outside of the bend. **Table 5.4** reflects the requirements in channels. Although it is not ideal to locate a bridge at a bend in the river, this aspect will have to be considered where bridges are to be located on a river bend. The three-dimensional nature of the problem might require a physical modelling of the layout.

8.4.4 Overtopping of the structure

There is always a probability that the design flood might be exceeded, resulting in the overtopping of the structure and the approaches. The impact of overtopping, including the influence of **buoyancy forces** on the deck should be reviewed and the potential alleviating options should be considered.

Class 3 to Class 6 roads and all structures built below the 50-year return period flood line, should be designed to be stable when overtopped. Due cognisance should be taken of embankment scour and careful consideration must be given as to the type of pedestrian and traffic barriers that are used. Collapsible pedestrian barriers or guide blocks shall be used where appropriate. The designer is referred to **Chapter 6** dealing with submersible structures. However guide blocks can only be considered for bridges that are less than 3 m high, from top of deck level. For higher bridges a combination of guide blocks and collapsible railings could be used. Basic economic considerations could however, for return periods less than 20 years, require the bridge to be designed for a higher return period to prevent the maintenance problems associated with the hand rails if overtopping occurs frequently, as well as problems that arise if periods of inundation are very long (several days). This aspect must be discussed with the authority concerned.

The volume of pedestrians using a bridge is a critical consideration. Solid traffic barriers should, if possible, be avoided on bridges that will be overtopped.

It is professionally irresponsible to place bridges or culverts below the 50-year flood level and to ignore the fact that these structures will be overtopped at some stage during their structural design life. The design flood return period may have to be increased to that required of the next higher Class of road. Refer such cases to the roads authority for a decision.

8.5 BACKWATER DETERMINATION

8.5.1 Introduction

A bridge often reduces the available cross-sectional flow area of a stream. This leads to additional energy losses and causes upstream damming of subcritical flow. The flow patterns through a normal (subcritical) crossing are shown in **Figure 8.4**^(8.4). Where supercritical flow is maintained, the depth of flow increases where the stream section narrows. Because urban or agricultural development often limits permissible backwater levels, land use plays a part in the determination of bridge openings. The sizing of a bridge opening is also affected by the scour or sediment build-up that may take place. Scour at bridges is dealt with in Section 8.6.

Once the backwater, h^* (or afflux) has been determined, the freeboard of the proposed bridge or culvert openings should conform to the minimum requirements in Section 8.3.2, adjusted for factors such as a high debris load.

The following design limit criteria should be implemented^(8.26):

- Backwater generally not more than 0,6 m.
- The design flow velocity through the constriction should generally be less than 4 m/s.
- In addition to the above, the ratio of the design flow velocity through the structure to the natural flow velocity should not exceed 1,67 due to scour considerations.

Detailed backwater calculations are described by Bradley in the publication *Hydraulics of Bridge Waterways*^(8.4). A copy of the design guideline is included on the memory stick at the back of this Manual. Full details of the methodologies to be applied to the four types of flow through a constriction are also contained in Volume I of TRH25^(8.7). In this manual, only the more common cases of slight backwater (Type I flow) and more severe backwater (Type II flow) are dealt with to illustrate the concepts and to assist in hand calculations. Both the aforementioned types are associated with subcritical upstream flow conditions. Software to determine the bridge backwater is available. HEC-RAS, for example, incorporates this methodology (referred to as the WSPRO method), as well as solves the standard step energy equation, or the momentum balance, or the empirical Yarnell equations, and is widely used. The software is included on the memory stick at the back of this Manual.

In the analysis of backwater the following procedures should be followed:

Determine the Froude number:

$$Fr = \left(\frac{Q^2 B_n}{g A_n^3} \right)^{\frac{1}{2}} \quad \dots(8.1)$$

for normal flow in the river, where:

Fr	=	Froude number
Q	=	design discharge (m ³ /s)
B _n	=	total flow width for the normal stage (m)
A _n	=	total flow area for normal stage (m ²)
g	=	gravitational acceleration (m/s ²)

If the normal flow is subcritical, Type I or Type II flow may occur at the structure (**Figure 8.5** and **Figure 8.8** illustrate the flow patterns through the structure). Determine the backwater for both cases, and adopt the greater value.

8.5.2 Backwater height, h_1^* for Type I flow through bridge

Figure 8.5 serves as a definition sketch. The backwater height is given by:

$$h_1^* = K^* \alpha_2 \frac{\bar{v}_{n2}^2}{2g} + \alpha_1 \left\{ \left(\frac{A_{n2}}{A_4} \right)^2 - \left(\frac{A_{n2}}{A_1} \right)^2 \right\} \frac{\bar{v}_{n2}^2}{2g} \quad \dots(8.2)$$

where:

K^*	=	secondary energy loss coefficient
α_1, α_2	=	velocity coefficients (see Figure 8.6 and the description below)
\bar{v}_{n2}	=	$\frac{Q}{A_{n2}}$ (m/s) where Q = design discharge (m ³ /s)
A_{n2}	=	projected flow area at constricted section 2 below normal water level of the river section (m ²)
A_1	=	flow area at section 1, including the influence of the backwater on the flow depth (m ²)
A_4	=	flow area at section 4 (m ²)




Figure 8.4: Water levels and flow distribution at normal crossings ^(8.4)

The loss coefficient K^* can be determined from the chart in **Figure 8.7** ^(8.22), which summarises the graphs in *Hydraulics of Bridge Waterways* ^(8.4). The designer may consult the reference for more detailed charts. The graphs were compiled from the results of laboratory tests where a straight channel with uniform section and a constant bed slope was used. The slope of the bed was adjusted until uniform flow was obtained. Although bridges are usually built in rivers with non-uniform flow depths and velocities, Equation 8.2 and **Figure 8.7** can still be used as a good estimate for these conditions.

In complex cases, such as double bridges, consult TRH 25 ^(8.7). Note, however, that there is often more uncertainty about the undisturbed (normal) flow depth than about the increase in the flow depth that would be caused by a bridge.

The calculation procedure for Type II flow (**Figure 8.8**) is illustrated below:

8.5.3 Backwater height, h_1^* for Type II bridge flow

Figure 8.8 serves as a definition sketch. The backwater height is given by:

$$h_1^* = \alpha_2 \frac{\bar{v}_{2c}^2}{2g} (C_b + 1) - \alpha_1 \frac{\bar{v}_1^2}{2g} + y_{2c} - \bar{y} \quad \dots(8.4)$$

where:

- \bar{y} = projected normal flow depth in the constriction = $\frac{A_{n2}}{b}$ (m)
- y_{2c} = critical depth in constriction = $\frac{A_{2c}}{b}$ (m)
- \bar{v}_1 = average velocity through section 1 = $\frac{Q_1}{A_1}$ (m/s)
- \bar{v}_{2c} = critical velocity in constriction = $\frac{Q}{A_{2c}}$ (m/s)
- α_2 = velocity head coefficient for the constriction (**Figure 8.6**)

The backwater coefficient C_b , can be obtained from **Figure 8.9**, whilst the other terms are as previously defined for Equation 8.2.

If the normal flow is supercritical, the flow section should preferably not be constricted. Also ensure that the freeboard is adequate, so that the superstructure will not affect the flow and cause a hydraulic jump to occur. If the section is constricted, treat as Type II flow or obtain expert opinion.




Figure 8.7: Chart to determine the backwater coefficient, K^* (8.4; 8.22)




Figure 8.8: Type II flow with substantial damming and critical flow through the bridge




Figure 8.9: Estimation of the Backwater Coefficient, C_b ^(8.4, 8.22)

Note that where abnormal stage conditions are caused by downstream hydraulic controls, the unconstricted flood water level at the bridge should be determined by computing the flow profile as described in Section 4.2 of this Manual. The backwater is then calculated using a contracted version of the original Equation 8.2:

$$h_{1A}^* = K^* \alpha_2 \frac{v_{2A}^2}{2g} \quad \dots(8.5)$$

where the subscript A refers to abnormal stage conditions.

8.5.4 Additional considerations

In order to compute the flow profile, sufficient information in the form of river cross-sections of the downstream river reach (for subcritical flow conditions) should be available.

Other points also to be borne in mind in the analysis of backwater are as follows:

- To determine the undisturbed (normal) flow depths, the prevailing controls should be properly identified.
- The presence of sand-spits at river mouths has to be considered carefully, because spits often block river mouths.

A spit may wash away only after severe damming has taken place. This impact tends to become more serious as more water is extracted from a river and the spit is broken through less frequently.

- River channels are often in a state of change. Changes in the position of the main channel and flood plains may have an effect on backwater, especially if the angle of approaching flow is increased. The morphological changes of a river channel may be traced by studying aerial photographs taken over a period of time, if available.
- Man-made influences affecting backwater at a bridge site may include additional damming resulting from the sediment delta at the upper end of a dam basin well above the full supply level. On the other hand, when a dam far upstream attenuates flood peaks through storage, the river channel far downstream tends to become shallower and narrower, which could lead to increased flood levels.
- Excavation of material under a bridge to reduce damming is not recommended because sediment build-up and bed forms rapidly reduce the extra capacity. The effect of scour whereby a greater opening is created is to be ignored when determining the required waterway opening, because the most reliable damming formulae have been calibrated in the field and they automatically allow for scour under flood conditions.

The methodology ^(8.4) described above is based on a number of assumptions, such as normal flow in relatively straight reaches of streams with subcritical flow conditions prevailing. In view of the limitations and assumptions inherent in the method, a list of references to other methods is given in CSRA ^(8.7). It was found ^(8.1) that the Bradley equations provided realistic answers in cases where the bridge opening ratio (M) was less than 0,85. However, the equations lead to underestimation of backwater where $M > 0,85$. It was recommended that the d'Aubuisson equation should be used in these cases. This equation is described in the literature ^(8.6, 8.30).

8.6 SCOUR AT BRIDGES AND CULVERTS

8.6.1 General remarks

Scour is a major mechanism responsible for the failure or partial failure of bridges during flood events. This section provides practising engineers with simple process descriptions and selected equations that could be applied to assess the potential effect of scour on bridge structures.

Scour is a complex process. Some of the factors contributing to the complexity are:

- non-homogenous mixtures of water and sediment;
- three-dimensional flow patterns at bridges during floods;
- difficulties in establishing the actual geometrical properties of rivers under extreme flood conditions;
- difficulties in observing actual scour depths and processes in rivers during floods; and
- highly variable properties of *in-situ* bed materials around bridge foundations.

Various researchers have attempted to address the complexity by assuming dominant variables and then deducing simplified relationships to describe scour. The result has been a multitude of divergent approaches for determining scour. Generally, more weight should be attached to relationships that are fundamentally sound, i.e. that are based on a sound understanding of the underlying mechanisms involved in scour and which have been calibrated against actual prototype data for rivers, rather than laboratory data.

Total scour is often described in terms of the components of long-term and short-term general scour, contraction scour and local scour. This approach is used in this section.

Local scour is dealt with for both piers and abutments. As is common practice, distinction is drawn between scour in alluvial materials and scour in cohesive materials.

Whereas the scour resistance in alluvial materials is linked to grain size, particle shape and armouring effects, the scour resistance in cohesive materials such as clay, is linked to the physiochemical properties of the material. Scour in cohesive materials consequently only takes place when the physiochemical bonds are broken ^(8.20).

Many equations for scour estimation in the literature have been derived as envelope curves from experimental data. Practical experience has been that due to scale effects laboratory conditions rarely provide proper simulation of sediment transport and scour processes in actual rivers under flood conditions. This implies that such equations have to be treated with circumspection. The focus in this section is on equations that have been either deduced from studies on actual rivers or have been calibrated against available prototype data.

8.6.2 Concepts and definitions

Incipient motion

Various relationships exist that define the boundary conditions under which a stream will begin to erode material along its bed and banks. The best known of these is probably the Shields relationship, which is currently still in use and is based on a representative particle size for a specific material density.

However, it has been argued ^(8.22) that particle size is neither a representative, nor a unique measure of transportability of sediments. Rooseboom ^(8.22) instead recommends the **use of settling velocity of particles in alluvial streams and critical tractive strength of clay in cohesive materials as representative of the transportability of sediments.**

Analysis of incipient movement in terms of stream power considerations has led to the representation of incipient motion of cohesionless materials as shown in **Figure 8.10** (Modified Liu Diagram), which expresses the boundary between sediment movement and no sediment movement in terms of a plot of a 'shear Reynolds number' against the ratio between shear velocity and settling velocity. For turbulent boundary conditions, the ratio between shear velocity and settling velocity (which represents the ratio of applied power over power required to suspend particles) is constant, as given by equation 8.6.

$$\frac{V_{*c}}{V_{ss}} = 0,12 \quad \dots(8.6)$$

with

$$V_* = \sqrt{gDS} \quad \dots(8.7)$$

where:

- V_* = 'shear velocity' (m/s)
- V_{*c} = 'critical shear velocity' (m/s)
- g = gravitational acceleration (9,81 m/s²)
- D = flow depth (m)
- S = energy slope (m/m)
- V_{ss} = particle settling velocity (m/s) (**Figure 8.11**)




Figure 8.10: Modified Lui Diagram showing the relationships for incipient sediment movement

For laminar boundary conditions, the critical condition between sediment movement and no movement is given by:

$$\frac{V_{*c}}{V_{*ss}} = \frac{1,6}{\frac{V_* d_{50}}{\nu}} \quad \dots(8.8)$$

where:

$$\begin{aligned} d_{50} &= \text{average particle diameter (m)} \\ \nu &= \text{kinematic fluid viscosity (m}^2/\text{s)} \end{aligned}$$

The boundary between turbulent and laminar conditions is defined by:

$$\frac{V_* d_{50}}{\nu} = 13 \quad \dots(8.9)$$

For values less than 13, the boundary flow condition is laminar and for values more than 13, boundary flow is turbulent. This boundary coincides with a particle size in the order of 5 mm.

The relationship between settling velocity and particle diameter is shown in **Figure 8.11**.




Figure 8.11: Settling velocity as a function of the sediment size (Shape factor not taken into consideration) ^(8.13)

Sediment loads

South African rivers generally carry a significant amount of fine sediments in suspension. There is no singular relationship between discharge and suspended sediment load. Instead, the limiting factor tends to be the availability of transportable materials in upstream catchments. The amount of transportable material may be related to various factors such as rainfall, soil erodibility, slope and land-use ^(8.25). These factors vary both in space and time. This means that the same discharge may be associated with sediment concentrations that vary by a factor of a thousand or more ^(8.7).

Total scour

Most approaches to scour determination, consider total scour as the sum of separate components that have been referred to before. These are long-term general scour, short-term general scour, contraction scour and local scour ^(8.7).

- **Long-term general scour** results in permanent deformation of the riverbed. The mechanisms that trigger long-term general scour may be natural (geomorphological changes due to events such as floods) or man-made (directly downstream of major dams). Determination of these long-term effects needs to be done by specialists as part of the feasibility studies for dams and other major projects.
- **Short-term general scour** often makes the most significant contribution to the total scour at a bridge ^(8.7). An estimation of the effects of short-term general scour could be made by using relationships for determining equilibrium flow depths and widths. Some of these relationships based on regime considerations and applied stream power considerations are provided in further sections of this manual.
- **Contraction scour** takes place because of a decrease in channel width at a bridge site, which increases the unit width discharge (see **Photograph 8.4**). The effect of contraction scour is automatically discounted in the short-term general scour relationships, provided that the width of flow at the bridge is carefully determined ^(8.7).

- **Local scour** results from the obstruction caused by piers, piles and abutments on the stream flow (see **Photograph 8.3**). This has proven to be a fertile research area for many years, with numerous relationships in existence that describe the local scour depth at piers of different configurations. The resulting scour depths calculated by means of the different relationships tend to vary greatly. There are many reasons for this, the main being that calibrations tend to be based on laboratory tests, which are subject to serious scale effects. An additional complicating factor is that actual river flow patterns differ significantly from laboratory conditions, with the result that some directives on scour strongly discourage the use of local scour formulae that are solely based on laboratory results ^(8.10).

In terms of Equation 8.9, physical models for studying bed scour should not contain particles smaller than about 5 mm. For hydraulic similarity, the plotted values of the functions on the vertical and horizontal axes in **Figure 8.10** for a prototype and a model should coincide.

Some areas of local scour are under-researched. These include scour in cohesive materials and scour at abutments. More prototype calibrations of scour formulae are needed in general.



Photograph 8.2: General scour



Photograph 8.3: Local scour at pier



Photograph 8.4: Constriction scour (Courtesy of: Free State Department of Transport)

8.8 SCOUR ESTIMATION

8.8.1 General remarks

The equations presented for the purpose of scour estimation have been selected to represent prototype conditions as far as possible. For short-term general scour, the regime equations^(8.2,8.9) are recommended. A method based on applied stream power and calibrated on a limited number of South African prototype data is presented as a check method for total scour in alluvial rivers. For scour at piers and abutments, the regime equations of Blench and the HEC-18 equations (Colorado State University, or 'CSU' equations) are recommended. Although the CSU equation was derived on the basis of model studies, it has also been calibrated with limited prototype data.

Scour at abutments is problematic, with limited information being available. Regime equations and some rough factors presented by Faraday and Charlton (1983)^(8.9) are presented for an initial estimate of the scour depth at abutments.

It is recommended that, where possible, scour depths should be calculated by more than one method and the answers compared. Judicious selection of the most representative scour depths should then be made, using other available data such as the results of Penetration Tests and engineering judgement.

8.8.2 Long-term general scour

Long-term general scour should be considered as part of the domain of specialists. Specialists will typically use procedures developed in the field of large dam engineering to determine the influence of major structures and make use of fairly sophisticated modelling tools in order to quantify long-term river aggradation or degradation effects. In addition, a multi-disciplinary team should do some long-term scour predictions, as knowledge of hydraulics, geomorphology, geology, etc. is required.

8.8.3 Short-term general scour

8.8.3.1 Short-term general scour in alluvial channels

Faraday and Charlton^(8.9) recommend the following relationships for the equilibrium dimensions for a channel, based on the work of Blench^(8.2):

$$y = 0,38q^{0,67} D_{50}^{-0,17} \quad \dots(8.10)$$

And

$$B = 14Q^{0,5} D_{50}^{0,25} F_s^{-0,5} \quad \dots(8.11)$$

where:

- B = mean channel width (m)
- y = mean depth of flow (m)
- Q = equivalent steady discharge which would generate the channel geometry (m³/s)
- q = discharge per unit width (Q/B) (m³/s.m) (Note: To estimate channel geometry conditions under flood conditions the design flood flow may be used.)^(8.9)
- D₅₀ = median size of bed material (m)
- F_s = side factor to describe bank resistance to scour (**Table 8.2**)

The following side factors may be applied in the channel width equation (Equation 8.11):

Table 8.2: Side factors

Bank type	Value of F_s
Sandy loam	0,1
Silty clay loam	0,2
Cohesive banks	0,3

It is necessary to calculate the equilibrium width before the equilibrium depth can be calculated. The maximum channel depth, y_{\max} can be determined by multiplying the calculated equilibrium depth with the factor from **Table 8.4**. Now the short term general scour depth, d_s , can be determined as the difference between y_{\max} and the normal flow depth (y_n).

8.8.3.2 Short-term general scour in cohesive bed channels

For cohesive bed channels, the equilibrium depth equation becomes:

$$y = 51,4n^{0,86}q^{0,86}\tau_c^{-0,43} \quad \dots(8.12)$$

where:

- y = mean depth of flow (m)
- n = Manning's coefficient of roughness ($s/m^{1/3}$)
- q = discharge per unit width ($m^3/s.m$)
- τ_c = critical tractive stress for scour to occur (N/m^2) –Refer to **Table 8.3**

Table 8.3: A guide to assessing the physical properties of clay ^(8.9)

Voids ratio	2,0-1,2	1,2-0,6	0,6-0,3	0,3-0,2
Dry bulk density (kg/m^3)	880-1200	1200-1650	1650-2030	2030-2210
Saturated bulk density (kg/m^3)	1550-1740	1740-2030	2030-2270	2270-2370
Type of soil	τ_c - Critical tractive stress (N/m^2)			
Sandy clay	1,9	7,5	15,7	30,2
Heavy Clay	1,5	6,7	14,6	27,0
Clay	1,2	5,9	13,5	25,4
Lean clay	1,0	4,6	10,2	16,8

The bulk densities in this table assume a specific particle density = 2,64 and the relationship with the voids ratio reads as follows:

$$\rho_d = \frac{\rho_s}{e + 1} \quad \dots(8.13)$$

And

$$\rho_s = \frac{\rho(s + e)}{e + 1} \quad \dots(8.14)$$

where:

- ρ = density of water (kg/m^3)
- ρ_d = dry bulk density (kg/m^3)
- ρ_s = saturated bulk density (kg/m^3)
- s = specific gravity of soil particles
- e = voids ratio of soil mass

Detailed descriptions of the type of soil (e.g. clay, lean clay, etc.) have not been provided ^(8.9). It is proposed that the Casagrande classification be followed where 'lean clay' is clayey silts (CL), 'clay' is clay of medium plasticity (CI), 'heavy clay' is taken as clays of high plasticity (CH) and 'sandy clay' is well graded sands with small clay content (SC).

8.8.3.3 General

The mean flow depth (y) calculated by means of the Equations 8.10 and 8.12, needs to be adjusted in order to calculate maximum flow depths that might result from short term general scour. The recommended factors are provided in **Table 8.4**.

Table 8.4: Factors to convert mean flow depth (y) to maximum channel depth

Description	Multiplying factor
Straight reach of channel	1,25 ^(*)
Moderate bend	1,50
Severe bend	1,75
Right-angled abrupt turn	2,00

*Note: * Neill^(8.20) recommends that this factor be increased to 1,50 in cases where dune movement takes place on the riverbed.*

The basic assumptions for which the Blench equations are valid include:

- steady flow;
- negligible bed transport;
- sediment transport through turbulent suspension that is sufficiently limited not to influence the calculations;
- channel sections and slopes that are uniform;
- viscosity that does not vary significantly;
- conditions under which the equations are applied that are similar to conditions for which the equations had been deduced. These conditions represent the ideal situation, which is not often found in rivers under extreme flood conditions^(8.2). Nevertheless, the equations are approximately valid as long as discharge and bed transport of sediment do not vary too quickly; and
- flow is in the rough turbulent phase.

8.8.4 Contraction Scour

Rooseboom in TRH 25^(8.7) indicated that the formulae for short-term general scour may take contraction scour into account. The flow width that is used is set to the contraction width and by applying Equations 8.10 or 8.12 the contraction scour based on regime theory is calculated.

Where an existing bridge is evaluated which has a width less than the equilibrium flow width of the channel, or where fixed banks occur, the contraction scour depth has to be determined. In the following relationships a distinction is made between sediment-laden and clear water flow.

To test whether sediment-laden flow occurs, determine the average particle size, d_{50} , of the sediment in the river upstream of the bridge area. Use **Figure 8.11**^(8.13) to determine its settling velocity V_{ss} . Calculate the value of Equation 8.9 to determine if the flow is in the laminar or turbulent region. To calculate the critical shear velocity, apply Equation 8.8 for laminar flow or Equation 8.6 for turbulent flow. The velocity at the boundary between sediment movement and no sediment movement (the 'critical' velocity), V_c , is determined from the logarithmic relationship:

$$V_c = 5,75V_{*c} \log \frac{12R}{k_s} \quad \dots(8.15)$$

where:

R and k_s represent the hydraulic radius and the absolute roughness value just upstream of the bridge.

If the approach velocity $V > V_c$, sediment-laden flow takes place, else clear water flow occurs. The latter tends to occur at bridge openings on flood plains (relief bridges) where the velocity is lower and the resistance to scour greater. Velocity and sediment size become important in clear water scour estimates and therefore a different set of equations is used to estimate constriction scour for clear water flow conditions.

8.8.4.1 Sediment-laden flow

For definition of terms see **Figure 8.12**. The equation below is applicable to a constriction of the river and was adapted from HEC 18 ^(8.10), based on the assumption that in southern African conditions the mode of bed material transport is mostly suspended bed material discharge:

$$\frac{y_2}{y_1} = \left(\frac{Q_t}{Q_c} \right)^{6/7} \left(\frac{B_1}{B_2} \right)^{2/3} \left(\frac{n_2}{n_1} \right)^{1/3} \quad \dots(8.16)$$




Figure 8.12: Long constriction in sediment-laden flow: definition of terms

The depth of scour is given by:

$$d_s = (y_2 - y_1) + (1 + K) \left(\frac{\bar{v}_2^2 - \bar{v}_1^2}{2g} \right) \quad \dots(8.17)$$

Where:

K is the secondary energy loss coefficient for the constriction (refer to Section 4.2.7).

If the degree of constriction is slight, it will be found that the last term in Equation 8.17 is negligible, and can be neglected.

The equations above apply to subcritical flow, with uniform flow upstream and downstream of the transition. The bed material is non-cohesive and is identical in both the wide and the constricted parts. The effect of varying sediment characteristics has been investigated^(8.32) and found to play only a significant part in the case of severe constrictions.

8.8.4.2 Clear water flow

For a definition of terms see **Figure 8.13**. The equation below was taken from HEC 18^(8.10).

$$y_2 = \left[\frac{Q^2}{40D_m^{2/3} B_2^2} \right]^{3/7} \quad \dots(8.18)$$

and d_s is calculated from Equation 8.17.




Figure 8.13: Long constriction in clear water flow: definition of terms

Note that Equation 8.18 is based on a Shields parameter of 0,039 and an assumption of homogeneous bed material. The term D_m is the effective mean bed material size and is equal to $1,25D_{50}$.

The equations above for scour in constrictions should be regarded as the first level of analysis and experts using sediment transport models can perform a more detailed analysis.

8.8.5 Local Scour

Local scour is difficult to quantify. However, its contribution to total scour in southern Africa is mostly not as critical as the contributions of short-term general and contraction scour.

The mechanism causing local scour is complex and is characterised by a downward flow at the upstream face of the pier (caused by stagnation pressure), a horse-shoe vortex at the base of the pier (which removes sediments) and oscillating slipstream vortices at the back of the pier that further remove sediments ^(8.18).

The Blench equation for local scour showed reasonable agreement when calculated values and a limited number of measured South African prototype values were compared ^(8.17).

The regime family of equations, of which this equation is a member, has the advantage of having been calibrated against actual observations of stream behaviour (mainly irrigation canals in India, of which the behaviour corresponds largely with that of prototype rivers). This equation is recommended for use under South African conditions.

The second set of equations is the CSU equations, which is the most frequently used formula in the USA (HEC 18) ^(8.10), and is provided for comparative purposes. The formula was derived from laboratory data and compared with limited prototype data.

A comparison was made between most of the existing formulae with published sets of prototype data by Johnson ^(8.15). Unfortunately the regime formulae were not included in this study. In addition, the prototype data used contained no information on bed forms, sediment grading and flow direction and consequently a number of assumptions had to be made. The findings tentatively indicated that some of the formulae should not be used as they potentially under-predict local scour. These include the equations of Shen et al. (1969) ^(8.27) and Hancu, as quoted ^(8.3). The equations by Melville and Sutherland ^(8.19) were found to over-predict scour significantly. The CSU equations ^(8.10) are conservative, although it predicted local scour reasonably well under most conditions.

8.8.5.1 Local scour at piers in alluvial channels (cohesionless material)

Blench ^(8.3) presented the following equation for calculating local scour in cohesionless material at bridge piers:

$$d_s = 1,8y_0^{0,75} b^{0,25} - y_0 \quad \dots(8.19)$$

where:

$$\begin{aligned} d_s &= \text{local scour depth at pier (m)} \\ y_0 &= \text{depth upstream of pier (m) (calculated by means of regime Equation 8.10)} \\ b &= \text{pier width (m)} \end{aligned}$$

This depth is recommended for local scour at cylindrical piers. Corrections for other pier shapes should be done by multiplying the value obtained from Equation 8.19 with the correction factors in **Table 8.5**. To take the angle of attack into account, the correction factors in **Table 8.6** have to be used.

The conditions under which the Blench formula is valid were discussed under the section on general short-term scour.

The CSU equation ^(8.10) is recommended for comparative purposes:

$$\frac{y_s}{b} = 2,0K_1K_2K_3K_4 \left(\frac{y_1}{b} \right)^{0,35} Fr_1^{0,43} \quad \dots(8.20)$$

where:

$$\begin{aligned} y_s &= \text{scour depth (m)} \\ y_1 &= \text{flow depth directly upstream of pier (m)} \\ K_1 &= \text{correction for pier nose shape} \\ K_2 &= \text{correction factor for angle of attack of flow} \end{aligned}$$

- K_3 = correction factor for bed condition
 K_4 = correction factor for armouring due to bed material size
 b = pier width (m)
 L = pier length (m)
 Fr_1 = Froude number directly upstream of the pier

$$Fr_1 = \frac{\bar{v}_1}{\sqrt{gy_1}} \quad \dots(8.21)$$

where:

- \bar{v}_1 = mean velocity upstream of the pier (m/s)
 g = gravitational acceleration (9,81 m/s²)

The correction factors are given in **Table 8.5** to **Table 8.7**.

Table 8.5: Correction factor K_1 , for pier nose shape

Shape of pier in plan [#]	Length/Width ratio (L/b)	K_1
Circular	1,0	1,0
Lenticular	2,0	0,91
	3,0	0,76
	4,0	0,67-0,73
	7,0	0,41
Parabolic nose		0,8
Triangular 60°		0,75
Triangular 90°		1,25
Elliptic	2,0	0,91
	3,0	0,83
Oval	4,0	0,86-0,92
Rectangular	2,0	1,11
	4,0	1,11 (Hec 18) - 1,40 (F&C)
	6,0	1,11

Note: [#] **Table 8.5** is based on the list by Faraday and Charlton (1983)^(8.9), which is more complete than the list in HEC 18 documentation^(8.10)

Table 8.6: Correction factor K_2 , for angle of attack of the flow

Angle (skew angle of flow)	L/b = 4	L/b = 8	L/b = 12
0	1,0	1,0	1,0
15	1,5	2,0	2,5
30	2,0	2,75	3,5
45	2,3	3,3	4,3
90	2,5	3,9	5,0

Note: In the case of L/b larger than 12, the ratio's for L/b = 12 should be used.

Table 8.7: Correction factor K_3 , for bed conditions

Bed condition	Dune Height (m)	K_3
Clear-water scour	Not applicable	1,1
Plane bed and anti-dune flow	Not applicable	1,1
Small dunes	0,6 m – 3 m	1,1
Medium dunes	3 m – 9 m	1,1 – 1,2
Large dunes	≥ 9 m	1,3

The value of the correction factor for armouring, K_4 , could be determined from the following sets of equations:

$$K_4 = [1 - 0,89(1 - v_R)^2]^{0,5} \quad \dots(8.22)$$

where:

$$v_R = \left[\frac{v_1 - v_i}{v_{c90} - v_i} \right] \quad \dots(8.23)$$

and

$$v_i = 0,645 \left[\frac{D_{50}}{b} \right]^{0,053} v_{c50} \quad \dots(8.24)$$

with:

v_R	=	velocity ratio
v_1	=	approach velocity (m/s)
v_i	=	approach velocity when particles at pier begin to move (m/s)
v_{c90}	=	critical velocity for D_{90} bed material size (m/s)
v_{c50}	=	critical velocity for D_{50} bed material size (m/s)
b	=	pier width (m)

and

$$v_c = 6,19y^{1/6} D_c^{1/3} \quad \dots(8.25)$$

where:

D_c	=	critical particle size for the critical velocity v_c (m)
-------	---	--

8.8.5.2 Local scour at piers in cohesive bed channels

The limited data were used to compile a rough guide on the expected scour depths at piers in cohesive material. **Table 8.8** reflects the findings ^(8.20).

Table 8.8: Local scour depths at piers in cohesive materials ^(8.20)

Pier shape (plan)	Inclination of pier faces	Depth of local scour (b=pier width)
Circular	Vertical	1,5b
Rectangular		2,0b
Lenticular		1,2b
Rectangle with semi-circular noses	Vertical	1,5b
	Inclined inwards towards top. (Angle more than 20° to vertical)	1,0b
	Inclined outwards towards top (Angle more than 20° to vertical)	2,0b

8.8.5.3 Local scour at abutments in alluvial channels (cohesionless material)

Local scour at abutments is difficult to quantify. Approximate estimates of scour may be made by applying an appropriate factor selected from the following table (**Table 8.9**) to the general (short term) average scour depth in order to obtain a maximum depth.

Table 8.9: Factors for estimating scour depth at abutments and training works ^(8.9)

Description	Factor
Nose of groynes or guidebanks	2,0 to 2,75
Flow impinging at right angles on bank	2,25
Flow parallel to bank	1,5 to 2,0

In cases where the abutments protrude into the river channel, a conservative approach is recommended in which the local scour level is taken as the lower value of the maximum scour at piers and the general scour level multiplied by a factor of 2,0 ^(8.9).

8.8.5.4 *Local scour at abutments in cohesive bed channel*

In cases of cohesive scour at abutments, Faraday and Charlton ^(8.9) recommended the use of the appropriate Blench normal depth equation for cohesive beds, with the correction factors for maximum depth given in **Table 8.9**. Although these factors were derived for alluvial materials, they provide a first estimate of the scour in cohesive soils.

8.9 TOTAL ESTIMATION USING APPLIED STREAM POWER PRINCIPLES

The equation presented in this section was derived from applied stream power principles.

The assumptions for which the equation is valid are the following:

- Flow is one-dimensional. There is increasing evidence that general and contraction scour are dominant in sand-bedded rivers ^(8.21, 8.23, 8.31), which means that this assumption is approximately valid for extreme flood conditions.
- Flow is uniform and steady. Flow changes during floods, but under the assumption that these changes take place relatively slowly, flow may be considered uniform and steady at any specific moment in time.
- Flow is in the rough turbulent flow zone. Plotting the design flow data used in **Figure 8.10** and confirming whether the design flow conditions are rough turbulent may check this assumption.
- Equilibrium conditions prevail. This is not the case, but the use of the instantaneous flood peak value for calculations is thus conservative.

The total scour values calculated by means of this equation were compared with limited observed prototype data for five South African rivers. For this limited data set, the results were consistent. The equation is recommended as a check to be used in conjunction with the other equations for alluvial rivers provided in previous sections.

The form of the equation recommended for the calculation of scour in rivers is ^(8.17):

$$\frac{C(Y_t)(v_{ss} k_s)^{1/3}}{q\sqrt{g}} = F \tag{8.26}$$

where:

C = Chézy coefficient

$$Y_t = Y_0 + Y_s \tag{8.27}$$

where:

Y_t = total maximum scour depth (m)
Y₀ = maximum general scour depth (m)
Y_s = local scour depth (m)

v_{ss}	=	particle settling velocity (m/s)
k_s	=	absolute roughness of river bed (m)
q	=	discharge per unit width (m ³ /s.m)
g	=	gravitational acceleration (9,81 m/s ²)
F	=	constant obtained from measured data

The value of the constant, F , as calibrated on limited South African prototype data, is recommended at 0,8 as an envelope value. The depth of scour was assumed to be equal to the depth of piers, which failed, whilst their neighbours remained intact.

Estimation of the bed roughness in rivers under extreme flood conditions is obviously important in the case of this equation. In this regard, it is interesting to note the size of bed forms that were calculated ^(8.16, 8.29) based on observations of eyewitnesses, as well as evidence on video recordings of both the Domoina and 1987 KwaZulu-Natal floods. Typical bed form sizes varied between 1m and 3 m, while at a number of bridges (notably the John Ross Bridge), waves of up to 5 m were observed. It was stated ^(8.20) that bed forms might be as high as half the depth of flow. The size of bed forms and associated absolute roughness could, however, be determined ^(8.24) and the results may be used to calculate the depths to which piers become exposed as bed forms move past. A number of piers, which went down 10 m in sand beds of rivers in South Africa, have failed due to scour. A depth of scour of 10 m is thus not unprecedented.

8.10 SPECIAL CASES OF SCOUR

8.10.1 Scour at bridges in tidal areas

The **mechanisms** that cause scour at bridges in tidal zones are similar to those at bridges across non-tidal rivers. The implication is that the same relationships are valid to describe these scour mechanisms in tidal rivers ^(8.10). The challenge lies in describing tidal flow conditions, which differ from non-tidal conditions. For a more detailed discussion of tidal effects at bridges, references that deal with tidal effects at bridges should be consulted ^(8.7, 8.10).

Where tidal processes are found to be complex, it is recommended that a specialist should quantify the flow conditions and recommend input variables to determine the effects of scour.

8.10.2 Pressure scour

One of the fundamental assumptions underlying most scour equations is the assumption of free-surface flow conditions. However, some bridges are designed to be overtopped. It has been argued ^(8.14) that, while it **may be economically feasible for bridges to overtop at these intervals, a bridge foundation failure at these recurrence intervals would probably not often be found to be economically acceptable.**

At the stage when a bridge starts to be overtopped, the flow pattern at the bridge starts to resemble culvert flow, i.e. the flow becomes pressurised. In limited laboratory experiments conducted on pressure scour, it was found that scour increases relative to the depth under free-surface flow conditions. This could be ascribed mainly to the influence of the submerged bridge deck. The correction factors for this ^(8.14) are unfortunately based on a limited number of clear-water scour laboratory tests and are consequently not necessarily representative of the actual flood conditions in South African rivers. It is suggested that the assistance of a specialist should be enlisted in cases where pressure scour is considered to be problematic. The scour protection measures as described for lesser culverts can also be considered for smaller bridges.

8.10.3 Lateral movement of rivers

Lateral movement of the main channel of a river within a floodplain may have serious impacts on scour and bridge stability.

These may include increased scour depths at piers and abutments, erosion of approaches to the bridge structure and changed angles of flow relative to piers and abutments. Lateral movement is influenced by factors such as the geomorphologic properties of the stream, bridge location, flow characteristics and characteristics of the bed and bank materials ^(8.10). Inspection of the river is crucial in understanding the potential for lateral movement at the bridge site.

The common-sense understanding of these processes underlying the regime theory may be used as a framework to consider the potential impact of lateral stream movement at a bridge site.

In this regard, the following points may be useful ^(8.20):

- The equilibrium geometry of rivers is established under high, but not extreme, flow conditions;
- A constriction in channel width would lead to increased scour of the river bed;
- Straightening of the river (e.g. in the case of river training) may result in large-scale local erosion if care is not taken; and
- Fixing the channel geometry at one point in an alluvial channel (e.g. at a bridge site) would probably lead to increased channel movement at another location.

The typical scour related problems that could be encountered as part of the dynamic processes in rivers were summarised and are shown in **Table 8.10**.

Table 8.10: Typical scour related problems that may be encountered in rivers ^(8.20)

River type	Stream type	Materials typically exposed	Dominant geomorphologic processes	Potential scour-related problems
Steep mountainous rivers	Boulder torrent	Bedrock/boulders	'Downcutting' and waterfalls	Erosion of river banks
	Braided gravel river	Sand, gravel, cobbles	Movement of coarse alluvium	Scour, choice of length of openings
	Alluvial fan	Sand, gravel, cobbles	Deposition of coarse alluvium; sudden channel shifts	Control of approach channel geometry; scour
Streams with moderate slopes	Entrenched river channel	Bedrock, shale	Thin layer of material is transported	Few
	Laterally meandering river	Sand, gravel, cobbles	Widening of river valley, sediment transport	Bank erosion and outflanking of bridge openings; scour; erosion of bridge approaches
Plains and streams with flat slopes	Meandering alluvial river	Sand and silt	Migration of meanders; erosion of river banks	Erosion of river banks and outflanking of bridge openings
		Clay, silt, cobbles	Degradation, erosion of river banks	Erosion of river banks
	Low velocity stream with multiple windings	Silt, sand	Relatively inactive	n.a.
	Lake crossings	Silt, clay, organics	n.a.	Soft foundations
Tidal areas	Deltas	Silt, sand	Deposition and frequent movement of meanders	Location of bridge openings, soft foundations
	Tidal estuaries	Silt, sand	Sediment deposition and multi-directional flow conditions	Soft foundations, scour
	Tidal basins	Sand, pebbles, clay, rock	Sediment transport, multi-directional flow	Abutment scour due to wave action

8.11 PROCEDURES FOR INITIAL ESTIMATION OF SCOUR AT BRIDGES

To conduct an initial estimation of scour at bridges, seven steps are proposed as discussed in the following paragraphs.

Step 1: Data acquisition phase

The following information may be relevant in estimating the effects of scour at bridges and should thus be gathered ^(8,10):

- Borehole logs define the geology of the bridge site (obtain advice from a geotechnical expert in defining the spacing and depth of drilling required). In addition to valuable information on the properties of the bed material and strata, the logs may potentially yield clues as to previous scour depths at the site ^(8,20).
- Bed material size, gradation and distribution in the vicinity of the bridge.
- Existing stream and floodplain cross-sectional survey information from upstream to downstream of the bridge, including all channel geometry details needed *inter alia* to perform backwater calculations for the site.
The normal principles for defining geometries and calculating backwater profiles are valid and cross-sections should be selected with these in mind.
- Catchment characteristics - include a catchment inspection as part of the site inspection.
- Any available scour data at structures in the vicinity of the site.
- Energy slope of the river for design flows. This is derived from backwater calculations for the bridge design.
- Historical flooding information. In the case of South Africa, valuable information may often be gleaned for the major rivers from reports compiled by the Department of Water Affairs (DWA) after major flood events.
- Location of the bridge site relative to other bridges, river features such as tributaries, confluences, etc. and human-made controls such as dams, training work, etc.
- Character of the river and its flows. Is it a stable perennial stream, or is it subject to flash floods, etc.?
- Geomorphology of the site.
- Erosion history of the stream where available.
- Development history of the stream, and the catchment.
- Other relevant factors.
- Aerial photographs of the area may yield valuable insights. Also useful may be a comparison of older photographs with more recent ones, where these are available.

From the above information an initial qualitative assessment of the potential scour impact on the bridge should be made.

Step 2: Analyse long-term change

Preferably consult an expert, especially if there are any major dams constructed or being planned in the vicinity of a bridge. The expert may use techniques, such as extrapolation of existing trends, worst-case scenarios or sophisticated computer modelling and good engineering judgement to make recommendations on potential long-term effects.

Step 3: Determine short-term general and contraction scour effects

The following parameters feed into the scour equations and need to be determined:

- Estimate the design flood for the site and use this value for further calculations (as described in **Chapter 3**).

- Estimate the contracted flow width at the bridge site for the purpose of determining short-term general and contraction scour effects. The unit width discharge could be calculated by dividing the design flood by the flow width.
- Make estimates of the bed roughness under flood conditions and representative sediment material sizes to be used in calculations.

For alluvial material:

- Use Equation 8.10 to determine mean flow depth and Equation 8.11 to determine mean channel width (if width is required), with side factor values from **Table 8.2**.
- Convert mean flow depth to maximum flow depth using the factors in **Table 8.4**.
- Calculate the scour depth as the difference between the maximum flow depth and the normal flow depth.

For cohesive material:

- Estimate cohesive material properties using **Table 8.3** and Equations 8.13 and 8.14.
- Use Equation 8.12 for mean flow depth.
- Convert to maximum flow depth using **Table 8.4**.
- Calculate the scour depth as the difference between the maximum flow depth and the normal flow depth.

Contraction scour is factored into Step 3 through the judicious choice of flow width at the bridge site. If an existing bridge or a channel with fixed banks is considered, apply the set of constriction scour Equations 8.15 to 8.18. The maximum scour depth from the different analyses should be used.

Step 4: Determine local scour effects

For piers in alluvial cohesionless materials:

- Use Equations 8.19 and 8.20 to compute local scour in two different ways. Obtain the factors needed for Equation 8.19 from **Table 8.5** and **Table 8.6**. Obtain the factors needed for Equation 8.20 from **Table 8.5**, **Table 8.6** and **Table 8.7** and Equations 8.22, 8.23, 8.24 and 8.25. Compare answers obtained from Equations 8.19 and 8.20 and select a conservative answer using good engineering judgement.

For piers in cohesive materials:

- Use **Table 8.8** as a rough guide to estimate local scour at the piers.

For abutments in alluvial cohesionless materials:

- Apply factors in **Table 8.9** to the general short-term average scour depth obtained from Equation 8.10.

For abutments in cohesive materials:

- Apply the factors in **Table 8.9** to the short-term average scour depth obtained from Equation 8.10. This is a preliminary indication only.

Step 5: Determine total scour

Total scour is the sum of long-term general scour (where applicable), short-term general scour, (contraction scour) and local scour.

For total scour at piers in alluvial rivers, check the answer against values obtained by means of Equations 8.26 and 8.27. Select design values on the basis of good engineering judgement. Try and corroborate calculations with available published and on-site evidence.

Step 6: Plot design values

Plot the design scour depth values using the design water level (e.g. 1:50 year return period water level, as determined by the methods described in **Chapter 4** for a fixed-bed configuration).

Step 7: Assess the results obtained

Assess the results, taking into account all available qualitative and quantitative information available. In cases of significant complexity, or cases where significant financial and other risks exist, consider consulting an expert or doing a physical hydraulic model study of the bridge site.

The equations presented in this section provide bridge designers with simple methods in which an **initial estimate** of the potential effects of scour at bridges may be made. If serious problems are foreseen, expert advice should be acquired.

8.12 SCOUR COUNTERMEASURES AT BRIDGES

8.12.1 Introduction

Scour countermeasures at bridges are aimed at reducing the negative impact:

- of shear stresses and turbulence and velocity variations near the boundary of the structure-water interface and
- of macro turbulent flow processes, such as eddies and helicoidal flows around bends ^(8.20).

This section does not attempt to provide a comprehensive coverage of all available scour countermeasures. Instead, it provides information on some of the frequently considered options that are available and potentially useful under local conditions.

The scour countermeasures are described below. These countermeasures broadly follow the categories into which these countermeasures have been divided previously ^(8.12).

Hydraulic countermeasures (mainly *river training structures* and *revetments*) are designed to either modify erosive flow characteristics or to provide resistance against hydraulic and turbulence effects.

- **River training structures** may have to be put into place to counter the effects of bank erosion, migrating meanders and other dynamic river processes at bridge sites ^(8.9). They are divided into transverse, longitudinal and areal types, depending on their orientation relative to the flow direction. The structures that are broadly discussed in following sections are **spurs** (transverse) and **dykes** and **berms** (or **guide banks**) (longitudinal), see groynes structures in **Photograph 8.5**.
- **Revetments and bed armouring** protect channel beds and banks against the erosive effects of river flow through the provision of a protective layer, covering a specified area of the channel. Revetments are *flexible* or *rigid* scour counter measures which do not significantly constrict flow channels. Appropriate revetment types may include riprap, gabions, precast concrete blocks, *in-situ* concrete and steel sheet piling. Considerations that need to be taken into account when making a selection include the extent of protection needed, cost, ease of construction and maintenance and environmental issues ^(8.9). A fairly comprehensive subsection on **riprap protection** has been included. Some of the issues related to the use of **gabions** are also discussed.

Local scour armouring uses similar protective layers to revetments, but has to take into account local flow patterns around structural elements, such as **piers** and **abutments**. Riprap protection of local elements is dealt with fairly comprehensively in the following sections.

Structural countermeasures involve the design of structural elements and foundations of bridges to minimise scour effects. These are broadly discussed.

Countermeasures during the maintenance phase include monitoring and implementation of further scour countermeasures when scour problems are identified.

Table 8.11, which was adapted from available information ^(8.12) provides a broad overview of the applicability of various scour countermeasures and is shown on separate pages.



Photograph 8.5: River training (courtesy of Mr Hans King)

8.12.2 General considerations in respect of scour countermeasures

Scour countermeasures at bridges should be seen as an integrated approach aiming to reduce the risk of scour damages to vulnerable structures. The approach should be a considered one in which design and construction of scour countermeasures are complemented with actions, such as continuous monitoring and where necessary, on-going maintenance and expansion of scour protection measures ^(8.12).

The effective design and implementation of scour countermeasures should be an interdisciplinary effort, with inputs from hydraulic, geotechnical and bridge engineers ^(8.12).

Selection of scour protection measures should be undertaken with environmental impact, construction and maintenance implications kept in mind ^(8.12).

Most importantly, the benefits of scour protection should be measured against the cost of provision of these countermeasures ^(8.12, 8.20). For new bridges, the **most economical options tend to be the lowering of foundation depths to levels well below estimated scour depths and ensuring that abutments are placed back from eroding river banks** ^(8.12).

It is important to keep in mind that countermeasures themselves are often damaged and that erosion processes may take place in locations where this may not have been envisaged. This means that a large component of scour protection measures may often be implemented during the maintenance phase, as an economical option ^(8.12).

The FHWA ^(8.10, 8.11, 8.12) recommends the following principles in the design of bridge scour countermeasures:

- Comparison of costs against benefits is of prime importance except in certain cases where routes are of strategic importance.
- Designs should be based on 'channel trends' and experience of similar field situations is extremely valuable.
- The environmental impacts of scour countermeasures have to be assessed.
- The designer should personally undertake a field inspection trip of the site and the river and catchment upstream and downstream of the bridge site.
- Any previous evidence of dynamic changes in the vicinity of the site (such as early photographs) is useful.
- Geotechnical and soil characteristics that may impact on the design of countermeasures should be determined and taken into account.
- Many of the countermeasures induce complex interaction with the river and its environment. This means that a physical hydraulic model study may often be justified to study the impact of these complex interactions and to determine potential unforeseen effects.
- Often the dynamic nature of scour processes implies that not all effects may be foreseen at the stage that the bridge is initially designed and constructed. This means that an inspection and maintenance plan is usually essential in order to affect on-going countermeasures as and when required.

In the following paragraphs some of the scour countermeasures are discussed in more detail.

Table 8.11: Overview of the applicability of various scour countermeasures ^(8.12)

Type	Local scour		Contraction scour	Instability		River Type	Stream size	Bend radius	Velocity	Bed material	Debris load	Bank condition	Flood plain	Resource allocation
	Abutments	Piers		Vertical	Lateral	B=Braided M=Meander S=Straight	W=Wide M=Med S=Small	L=long M=Med S=Short	F=Fast M=Med S=Slow	C=Coarse S=Sand F=Fine	H=high M=Med L=Low	V=Vertical S=Steep F=Flat	W=Wide M=Med N=Narrow/ None	H=High M=Med L=Low
Transverse structures														
Impermeable spurs	□	□	x	x	■	B,M	W,M	L,M	•	•	•	•	•	M-L
Permeable spurs	□	□	x	x	■	B,M	W,M	L,M	M,S	S,F	L	•	•	H-M
Drop structures	□	□	□	■	x	•	•	•	•	•	•	•	•	M
Longitudinal structures														
Guide banks	■	□	□	x	□	•	W,M	•	•	•	•	•	W,M	M-L
Areal structures														
Canalisation	□	□	x	x	■	B,M	•	•	•	•	•	•	•	M
Sediment detention basin	x	x	x	■	□	•	•	•	•	C,S	•	•	•	H-M
Revetments and bed armour														
Rigid														
Soil cement	■	□	□	□	■	•	•	•	•	S,F	•	S,F	•	L
Concrete pavement	■	□	■	□	■	•	•	•	•	•	•	S,F	•	M
Rigid grout filled mattress/ concrete mat	■	□	□	□	■	•	•	•	•	•	•	S,F	•	M
Flexible														
Riprap	■	□	□	□	■	•	•	•	•	•	•	S,F	•	M
Gabion mattresses	■	□	□	□	■	•	•	•	•	S,F	M,L	•	•	M

Table 8.11: Overview of the applicability of various scour countermeasures ^(8.12) (continued)

Type	Local scour		Contraction scour	Instability		River type	Stream size	Bend radius	Velocity	Bed material	Debris load	Bank condition	Flood plain	Resource allocation
	Abutments	Piers		Vertical	Lateral	B=Braided M=Meander S=Straight	W=Wide M=Med S=Small	L=long M=Med S=Short	F=Fast M=Med S=Slow	C=Coarse S=Sand F=Fine	H=high M=Med L=Low	V=Vertical S=Steep F=Flat	W=Wide M=Med N=Narrow/ None	H= High M=Med L=Low
Local scour armouring														
Riprap	■	□	N/A	N/A	N/A	●	●	●	●	●	●	S,F	●	H-M
Gabions	■	□	N/A	N/A	N/A	●	●	●	●	●	●	S,F	●	H-M
Foundation strengthening														
Continuous spans	x	■	■	■	x	●	●	●	●	●	●	●	●	L
Pumped concrete/grout	■	■	□	□	□	●	●	●	●	●	●	●	●	M
Lowering foundations	■	■	■	■	■	●	●	●	●	●	●	●	●	L
Pier geometry modification														
Extended footings	N/A	■	N/A	N/A	N/A	●	●	●	●	●	●	●	●	L
Pier shape modifications	N/A	■	N/A	N/A	N/A	●	●	●	●	●	●	●	●	M

Legend for the notation used in Table 8.11.

- primary use/well suited
- x not suitable/ seldom used
- suitable for the full range of the characteristic
- secondary use/potential application
- N/A not applicable

8.12.3 Spurs, Berms and Dykes

8.12.3.1 Spurs

Spurs (groynes) are intended to control the movement of river meanders and erosion of river banks^(8.9). These may be placed either upstream or downstream of the area to be protected. Spurs should preferably be used in groups to either 'repel' or 'attract' flow. Spurs usually require some scour protection themselves. Examples of spur lay-outs are given in **Figure 8.14** to **Figure 8.16**.

It is recommended that the following formula for spacing groups of spurs should be used^(8.9):

$$L_s < \frac{Cy^{1,33}}{2gn^2} \quad \dots(8.28)$$

where:

- L_s = spacing between spurs (m), see **Figure 8.16**
- C = a constant (approximately 0,6)
- y = mean depth of flow (m)
- n = Manning's roughness coefficient ($s/m^{1/3}$)
- g = gravity acceleration (m/s^2)
- P_s = length of spur (m), with $P_s = (0,22 \text{ to } 0,25)$ of L_s




Figure 8.14: Plan view of repelling flow spur layout^(8.9)

On smaller narrow rivers it should be carefully considered whether spurs offer the most appropriate form of erosion protection, as the use of these on one bank may result in erosion on the opposite bank.

The interaction of factors influencing the layout and spacing of spurs is complex and a model study is recommended for most cases. An expert should preferably be involved in the design of spurs.

Economic considerations should feature strongly in the final layout decision.




Figure 8.15: Plan view of attracting spur layout ^(8.9)




Figure 8.16: Plan view of groups of spur for repelling flow ^(8.9)

Note that fairly detailed design guidelines for spurs are also given in HEC 20^(8.11).

8.12.3.2 Berms (Guide banks)

Berms may have various uses, including:

- protecting the bridge and approaches from erosion through elimination of lateral stream movement patterns;
- improving flow distribution through the bridge opening and in the process also reducing the effects of contraction scour; and
- changing the angle of the approach flow.

The main design issues are orientation relative to the bridge opening, shape, length upstream and downstream of the bridge and crest levels ^(8.12).

The plan layout of berms should conform to good hydraulic principles, in addition to providing adequate protection against lateral stream movement. Their height should normally allow for the design water level plus freeboard ^(8.20). Guide banks normally need some protection against undermining. An expert should preferably undertake or review the design of guide banks.

8.12.3.3 Dykes

Dykes are linear structures that prevent or control overbank flow. These may typically be used to prevent flood flow in braided rivers from bypassing the bridge opening. Hydraulic model studies to optimise the layout of dykes are usually justified for major bridges ^(8.9).

8.12.4 Revetments: Riprap protection

8.12.4.1 General comments

Riprap is defined as follows ^(8.5):

"A flexible channel or bank lining or facing consisting of a well graded mixture of rock, broken concrete, or other material, usually dumped or hand-placed, which provides protection from erosion."


Riprap protection serves its main purpose in reducing the effects of local scour ^(8.12). It has been fairly popular because of the availability of materials, ease of construction and low costs ^(8.12).

Riprap layers may fail in various ways, which should be considered during the design process. Some of these failure modes may even cause riprap protection to fail where the stone sizes are adequate ^(8.12).

The failures that might be encountered with riprap layers, are summarised below:

- **Riprap particle erosion.** Various factors may contribute to this type of failure. These include inadequate stone sizing, removal of particles through various causes and steep slopes where the angle of repose of the material could be easily overcome ^(8.5). This failure mode is limited by sizing of particles to withstand hydraulic and turbulent forces, but factors such as slope, waves and vandalism may not be addressed in this way.
- **Mass failure.** This failure mode happens when a large mass of the riprap slides or slumps because of the effect of gravity. This may happen because of pore water pressure, steep slopes or loss of support (such as undermining of toe support at abutments) that may be ascribed to erosive processes. Undermining and failure of toe support is considered to be a primary reason for revetment failure ^(8.5) and significant attention should be paid to this aspect during design and construction.
- **Substrate particle erosion or base material failure.** In this case, the underlying materials are displaced through erosion or fails and slumps ^(8.5). This may be countered through the use of filters. However, care has to be exercised in the design of the filters to ensure that water pressure does not build up due to filter blockages.

Special care should be taken with the edges of revetments, such as the head, toe and flanks, to ensure that undermining does not occur ^(8.12).



Photograph 8.6: River training and protection with gabions and mattresses

8.12.4.2 Riprap stone sizing for revetments

Much of the understanding of riprap design is based on laboratory experiments, with limited field data to verify this understanding. This should be kept in mind when using the design formulae presented for use.

A relationship for the required particle size that was derived from tractive force theory has been recommended for the determination of the riprap size ^(8.5). The formula was derived for straight channels with uniform flow conditions, but a coefficient in the formula allows for flow conditions that deviate from these ideal conditions. The formula is:

$$D_{50} = \frac{K_u C \bar{V}_a^3}{d_{avg}^{0.5} K_1^{1.5}} \quad \dots(8.29)$$

where:

D_{50}	=	median riprap size (m)
K_u	=	0,0059 (SI units)
C	=	coefficient for specific gravity and stability factors
\bar{V}_a	=	average velocity in the main channel (m/s)
d_{avg}	=	average depth in the main channel (m)
K_1	=	a factor defined by Equation 8.30

$$K_1 = \left[1 - \left(\frac{\sin^2 \theta}{\sin^2 \phi} \right) \right]^{0.5} \quad \dots(8.30)$$

where:

θ	=	bank angle with the horizontal (°)
ϕ	=	riprap angle of repose (°)

The angle of repose for various riprap types may be read from **Figure 5.17**.

The coefficient for specific gravity and stability factors may be obtained from the following equation:

$$C = \frac{1,61(SF)^{1,5}}{(S_s - 1)^{1,5}} \quad \dots(8.31)$$

Here the following values for the variables are used:

S_s = specific gravity of riprap (usually approximately 2,65)
 SF = required stability factor to be applied (typically varies between 1,2 and 2,0)

The recommended values for the stability factor, SF , are shown in **Table 8.12**.

Table 8.12: Recommended values for stability factor, SF ^(8.5)

Flow description	Stability Factor
Uniform flow, no significant bends, little uncertainty regarding parameters involved.	1,0 – 1,2
Gradually varied flow, moderate bend curvature, moderate debris impact	1,3 – 1,6
Rapidly varied flow; significant bends; high turbulence (e.g. at abutments); high parametric uncertainty	1,7 – 2,0

8.12.4.3 Grading of riprap and stone characteristics

Riprap should in general be well graded in order to ensure maximal interlocking of particles. Individual stones should have a length to width ratio of not more than 1:3 ^(8.5). Also materials should not weather easily or be prone to chemical wear.

Table 8.13 shows the recommended grading for riprap.

Table 8.13: Recommended grading of riprap ^(8.12)

Diameter	Weight	Percentage passing
1,5 D_{50} to 1,7 D_{50}	3,0 W_{50} - 5,0 W_{50}	100
1,2 D_{50} to 1,4 D_{50}	2,0 W_{50} - 2,75 W_{50}	85
1,0 D_{50} to 1,15 D_{50}	1,0 W_{50} - 1,5 W_{50}	50
0,4 D_{50} to 0,6 D_{50}	0,1 W_{50} - 0,2 W_{50}	15

It is recommended ^(8.12) that the 85% requirement be dropped in the case where the above specification would overburden certain smaller quarries.

8.12.4.4 Riprap layer thickness

Guidelines ^(8.5) stipulate that riprap layer thickness should generally not be less than the greater of the D_{100} stone diameter or 1,5 times the D_{50} stone diameter. The layer should have a minimum thickness of 300 mm for practical purposes. In cases where the riprap is placed under water, layer thickness should be increased by 50% because of uncertainties involved in the placement process ^(8.5).

8.12.4.5 Design of filters and filter materials

Filters have a dual purpose to fulfil as part of a scour protection system. Firstly the filters have to prevent fine materials from leaching out underneath riprap layers or other protection layers. Secondly, the filter material has to provide for drainage to prevent build-up of pore pressure ^(8.12).

A geotechnical specialist should preferably undertake the design or be consulted on the design results. **As a broad guideline, the following formula may be used for the design of filter material** ^(8.12):

$$D_{15(\text{Coarser Layer})}/D_{85(\text{Finer Layer})} < 5 < D_{15(\text{Coarser Layer})}/D_{15(\text{Finer Layer})} < 40$$

The left side of the inequality provides for erosion prevention and the right side for sufficient permeability.

8.12.5 Revetments: Gabions and stone mattresses

Gabions and stone mattresses may be an option where available rock is of too small size and of lesser quality than would be required for riprap. The manufacture of gabions and rock mattresses is labour intensive, which may be considered an advantage in instances where local job creation is considered an important component of projects.

However, the disadvantages of gabions and stone mattresses have to be carefully considered prior to use ^(8.5). These include the higher costs of installation and maintenance relative to riprap and the decrease in flexibility of the system that is created. Whereas riprap particles may move individually to adapt to geometrical deformations, gabions and stone mattress systems are more rigid. More rigid systems generally have a higher potential for catastrophic failure.

The failure mechanisms that need to be considered in the case of gabions and stone mattresses are:

- failure of the wire mesh of the baskets; and
- movement of stones within the baskets that exposes base materials, with the potential of subsequent base material erosion and system failure.

For these reasons, gabions and stone mattresses are only recommended for small streams, preferably having no vertical stability problems ^(8.12).

8.12.6 Local scour armouring

8.12.6.1 Sizing of riprap at piers

The standard Isbash formula, recommended by FHWA in HEC-11 ^(8.5) is:

$$D_{50} = \frac{0,692(K_v)^2}{2g(S_s - 1)} \quad \dots(8.32)$$

where:

D_{50}	=	riprap size (m)
v	=	velocity along the pier (m/s)
S_s	=	specific gravity of riprap (approximately 2,65)
K	=	pier shape coefficient (1,5 for round-nosed and 1,7 for rectangular piers)

The velocity along the pier may be calculated by multiplying the average channel velocity by a coefficient that varies between 0,9 for a pier near the bank of a uniform reach to 1,7 for a pier in the main current at a bend in the river.

8.12.6.2 Riprap mat dimensions at piers

The following may be considered as guidelines to the dimensions of riprap protection that are required (**Table 8.14**):

Table 8.14: Recommended riprap protection dimensions

Dimension	Recommended
Horizontal	Twice pier width on both sides
Thickness	At least three stone diameters (D_{50})
Maximum rock size	Not more than twice D_{50} of riprap

The following should be considered when deciding on the level at which the riprap should be placed:

FHWA ^(8.5, 8.12) considers it to be disadvantageous to place riprap at such a depth that the top of the riprap is buried below stream level, as this creates problems during inspections to determine the extent to which riprap has been damaged or removed. The top level of the riprap layer should, therefore, be at the invert level of the streambed. This is in contrast with the view of other references ^(8.9) that the top of the riprap should be below the expected general scour levels.

Riprap should, however, **never be placed at levels higher than the streambed invert** ^(8.12).

8.12.6.3 *Sizing of riprap at abutments*

Two equations are recommended, HEC-11 ^(8.5), for the sizing of riprap at abutments:

For **Froude numbers less or equal to 0,80** - the Isbash relationship is recommended:

$$\frac{D_{50}}{y} = \frac{K}{S_s - 1} \left[\frac{\bar{v}^2}{gy} \right] \qquad \dots(8.33)$$

where:

- D_{50} = median stone diameter (m)
- \bar{v} = characteristic average velocity in the contracted section (m/s)
- S_s = specific gravity of riprap
- g = gravitational acceleration (m/s^2)
- y = depth of flow in the contracted bridge opening (m)
- K = 0,89 for a spill-through abutment
- = 1,02 for a vertical wall abutment

For **Froude numbers in excess of 0,80** - the recommended equation reads:

$$\frac{D_{50}}{y} = \frac{K}{(S_s - 1)} \left[\frac{\bar{v}^2}{gy} \right]^{0,14} \qquad \dots(8.34)$$

with the symbols having similar meanings as in the previous equation, and

- K = 0,61 for spill-through abutments or
- K = 0,69 for vertical wall abutments

The characteristic average velocity in the contracted section method of calculation is as follows:

A **setback ratio (SBR)** is calculated for each abutment. (This is the ratio of the distance from the near edge of the main channel to the toe of the abutment to the channel flow depth).

If the SBR is less than five for both abutments, the characteristic velocity is based on the entire contracted area through the bridge opening.

If SBR is greater than five for one abutment, the characteristic velocity could be based on the overbank flow only. It should be assumed that the entire overbank flow passes through the bridge section in the overbank section only.

In cases where the SBR on one side is less than 5 and on the other side more than 5, the characteristic velocity for the side less than 5 should be based on a flow area bounded by the abutment and an imaginary boundary along the opposite main channel bank.

It is recommended that the HEC-11 equations described in the previous sections be used as well as a control method before an engineering judgement is made. In this case, the velocity in the vicinity of the abutment should be used, instead of the main channel velocity, with a stability factor of between 1,7 and 2,0 to allow for high turbulence. It should be remembered that all these equations are mainly based on laboratory data and should be treated as such.

In complex cases or where damage may be costly, scale model studies may be an attractive option. It should be remembered that riprap is not generally the preferred method of scour protection for new structures and alternative protection measures should be considered.

8.12.6.4 *Dimensions of riprap protection at abutments*

The extent to which riprap should be placed is as follows ^(8.12):

- The apron at the toe of the abutment should extend along the entire abutment toe around curved portions to the tangent point with the embankment slopes.
- The horizontal dimension of the riprap into the overbank area of the river should be twice the flow depth on the overbank area in the vicinity of the abutment, but not less than 1,5 m ^(8.22) or more than 7,5 m ^(8.12).
- For spill-through abutments, riprap layers should be placed to a height of at least 0,6 m above the high water level for the design flood. Downstream placements should extend back from the abutment for twice the flow depths, or 7,5 m (to 15 m), whichever are greater.
- Riprap layer thickness should not be less than the larger of 1,5 times D_{50} or D_{100} . If the riprap is placed under water, this thickness should be increased 1,5 times. The minimum thickness should be 300 mm.

Abutments should be inspected after every major flood event for scour damage.

8.12.7 **Structural countermeasures**

Adherence to certain general principles during the design of the bridge may reduce the effects of scour ^(8.20). These may include:

- Locating the invert levels of pier footings well below the maximum estimated scour levels and preferably on rock, where possible ^(8.22);
- Placing piers on piles or columns that extend to a great depth below scour levels;
- Designing slender structural elements that do not provide a significant flow obstruction and orienting piers and abutments to ensure good hydraulic flow patterns;
- Reduction of number of piers and widening of bridge opening to reduce contraction scour ^(8.12);
- Designing the bridge superstructure to be above water (and debris) level at design flood levels will reduce the risk of pressure scour, which could have severe effects.

8.12.8 Maintenance measures

It is important to note that maintenance measures include not only the continuous monitoring of scour patterns at bridges, but also knowing which actions need to be taken once a problem has been identified ^(8.12). Maintenance measures include continuous inspection of scour prone bridges after flood events, the removal of debris caught on piers and the repair of any scour damage observed after major flood events ^(8.20).

8.13 OTHER DESIGN ASPECTS

A number of design aspects are described below (TRH 25: Volume 1, Chapter 5) ^(8.7).

8.13.1 Piers and pier spacing

The number of piers and alignment of piers should be chosen to minimise contraction effects at the bridge site ^(8.11). Lateral scour has been identified as the major cause of serious hydraulic problems at bridges in the USA ^(8.7). Ideally, the total opening width should not be less than the equilibrium channel width corresponding to the design discharge. Alignment should be in the flow direction at the flood stage, which may differ from the flow direction at low flows. Local scour depths are determined by the projected pier widths at the levels where scour occurs.

Pier footings should be located **below the maximum estimated scour depth** and should preferably be placed on piles or caissons that extend to a significant depth below the expected scour depth. Piers should be designed to be stable when partially exposed due to scour. Piers on flood plains should be protected against bank scour and meandering (by ensuring sufficient foundation depths). Foundation depths may well be similar to those of the piers in the main river channel ^(8.11).

Piers should not encroach on the main channel of small rivers, where possible ^(8.11).

Piers and abutments should be designed to minimise the entrapment of debris, as this may impact on both contraction and local scour. Pier footings may reduce local scour should they remain below the general scour levels for the bridge and if their horizontal dimensions are sufficient to cover the area over which the local vortex action takes place ^(8.20). Should the pier footing be above general scour levels, the effect would be similar to that of a larger pier, with resulting increases in local scour depths.

8.13.2 Provision of additional capacity

In areas with significant bank stability problems, consideration should be given to the provision of extra bridge spans as an alternative to extensive bank and channel stabilisation measures ^(8.10), but not on the inside of bends, due to sediment build-up.

8.13.3 Monitoring

The complex nature of scour processes may lead to unforeseen scour effects becoming visible after design and construction of a bridge. Monitoring of structures after construction is thus important in order to detect any developing scour problems.

8.13.4 Scour at multiple bridges

Where bridges are constructed close to each other, the effect of scour induced by one bridge at another should be carefully considered ^(8.20). Scour depths determined by means of the equations presented in this section should always be compared to the depths at which scour-resistant strata are situated, as these may impose limits on the scour depths ^(8.20). Good geotechnical knowledge is required to interpret the resistance to scour of different types of bed materials.

In cases where scour impact is deemed significant, but is difficult to predict and in cases where structures are expensive or of strategic importance, it may be useful to build a scale model of the structure and to do laboratory tests to determine scour patterns ^(8.20).

8.13.5 Drainage of bridge decks

Adequate discharge capacity should be provided to meet the requirements of Section 5.2. Refer to applicable design procedural codes. Water discharged from bridge decks should not be released directly onto railway lines, roads, streets, etc.

8.13.6 Forces acting on bridge structures

Besides provision for the normal hydrostatic and hydrodynamic forces acting on a bridge, provision should be made for forces as a result of debris and impact forces which result from debris colliding with the piers and overtopping forces (if appropriate). The effects of buoyancy should also be considered.

8.14 REFERENCES

- 8.1 Basson, G.R. (1991). *Opdamming by brûe en hidrouliese kragte op brugstrukture*. University of Stellenbosch. M-thesis. Unpublished.
- 8.2 Blench, T. (1969). *Mobile-bed fluviology*. Edmonton: University of Alberta Press.
- 8.3 Breusers, H.N.C., G. Nicollet and H.W. Shen. (1977). *Local scour around cylindrical piers*. International Journal of Hydraulic Research, No 3, Vol 15, pp 211-252.
- 8.4 Bradley, J.N. (1973). *Hydraulics of bridge waterways*. Hydraulic Design Series No 1. Second edition. FHWA. Washington DC.
- 8.5 Brown, S.A. and Clyde, E.S. (1989). *Design of riprap revetment*. Report No FHWA-IP-89-016. HEC 11. Georgetown: Federal Highway Administration.
- 8.6 Chow, V.T. (1959). *Open channel hydraulics*. New York. McGraw Hill.
- 8.7 CSRA. (1994). *Guidelines for the hydraulic design and maintenance of river crossings. (TRH 25 : 1994) Volume I*. South Africa: Committee of State Road Authorities.
- 8.8 CSRA. (1994). *Guidelines for the hydraulic design and maintenance of river crossings. (TRH 25 : 1994) Volume III*. South Africa: Committee of State Road Authorities.
- 8.9 Farraday, R.V. and Charlton, F.G. (1983). *Hydraulic factors in bridge design*. Wallingford: Hydraulics Research Station Limited.
- 8.10 FHWA. (1995a). *Evaluating Scour at Bridges*. HEC 18. Third Edition.
- 8.11 FHWA. (1995b). *Stream stability at highway structures*. HEC 20. Second edition.
- 8.12 FHWA. (2001). *Bridge Scour and Stream Instability Countermeasures: Experience, Selection and Design guidance*. Second edition. Publication No. FHWA NHI 01-003. Washington DC: FHWA.
- 8.13 Graf, W.H. (1977). *Hydraulics of sediment transport*. New York, McGraw-Hill.
- 8.14 Jones, J.S., Bertoldi, D.A. and Umbrell, E.R. (1995). *Interim procedure for pressure flow scour*. FHWA. *Evaluating Scour at Bridges*. HEC 18, Third Edition.

- 8.15 Johnson, P.A. (1995). *Comparison of pier-scour equations using field data*. International Journal of Hydraulic Engineering, Vol 121, No 8, pp. 626-629.
- 8.16 Kovács, Z.P et al. (1985). *Documentation of the 1984 Domoina floods*. Pretoria. Department of Water Affairs Technical Report TR122.
- 8.17 Lotriet, H.H. (1991). *Uitskuring by brûe - 'n Vergelykende studie van berekende en waargenome dieptes*. University of Stellenbosch. M-thesis. Unpublished.
- 8.18 Melville, B.W. (1988). *Scour at bridge sites*. Civil engineering practice 2 – Hydraulics/Mechanics. Lancaster. Technomic Publishing Co Inc.
- 8.19 Melville, B.W. and J. Sutherland. (1988). *Design method for local scour at bridge piers*. International Journal of Hydraulic Engineering, Vol 114, No 10, pp 1210-1226.
- 8.20 Neill, C.R. (ed.) (1973). *Guide to bridge hydraulics*. Toronto. Toronto Press.
- 8.21 Nouh, M. (1985). *Flood damages to structures - A case study in Saudi Arabia*. Proceedings of the 2nd International Conference on the hydraulics of flood and flood control. Cambridge.
- 8.22 Rooseboom, A. et al. (1983). *National Transport Commission road drainage manual*. Second edition. Pretoria: Director-General: Transport. Chief Directorate: National Roads.
- 8.23 Rooseboom, A. and Basson, G.R. (1990). *Report on the hydraulic model investigation of the proposed Tugela River Bridge B351 on National Route 2 Section 27*. Pretoria: Director General: Transport. Chief Directorate: National Roads.
- 8.24 Rooseboom, A and Le Grange, A. (2000). *The hydraulic resistance of sand streambeds under steady flow conditions*. International Journal of Hydraulic Research, Vol 38, 2000, No 1.
- 8.25 Rooseboom, A. Verster, E., Zietsman, H.L. and Lotriet, H.H. (1992). *The development of the new sediment yield map of southern Africa*. Pretoria: Water Research Commission. Report No WRC 297/2/92.
- 8.26 SANRAL. (2002). *Code of procedure for the planning and design of highway and road structures in South Africa*. Pretoria, South Africa.
- 8.27 Shen, H.W. V.R. Schneider and S. Karaki. (1969). *Local scour around bridge piers*. International Journal Hydraulics Div, ASCE, Nov 1969, p1919-1940.
- 8.29 Van Bladeren, D. en Burger, C.E. (1989). *Documentation of the September 1987 Natal floods*. Pretoria: Department of Water Affairs Technical Report TR139.
- 8.30 Webber, N.B. (1971). *Fluid mechanics for civil engineers*. London. Chapman and Hall.
- 8.31 Hopkins, G.R., Vana, R. W. and Kasraie, B. (1980). *Scour around bridge piers*. Springfield. National Technical Information Service.
- 8.32 Komura, S. (1966). *Equilibrium depth of scour in long constrictions*. International Journal Hydraulics Div, ASCE, Sep 1966, pp 17-37.
- 8.33 Committee of Transport Officials (COTO). (2012) *TRH 26: South African Road Classification and Access Management Manual Version 1.0*. August 2012.

CHAPTER 9 - STORMWATER SYSTEM ANALYSIS AND DESIGN

M van Dijk, SJ van Vuuren and AM Jansen van Vuuren

9.1 OVERVIEW OF THIS CHAPTER

This chapter covers the procedures that could be used to analyse complex road stormwater drainage systems. To be able to use these procedures a theoretical introduction is given which is then reinforced by worked examples in the *Application Guide*. The focus of this chapter is on the design and analysis of more complex stormwater drainage systems, typically found in urban areas. The design standards and other requirements of the relevant authorities need to be considered where the road drainage system impacts on existing or planned urban drainage systems.

Table 9.1 provides a Road Map for this chapter.

Table 9.1: Road Map for stormwater system analysis and design

ROAD MAP 9						
Typical problems		Input information	Worked examples in <i>Application Guide</i>	Supporting software	Other topics	
Topic	Par.				Topic	Chapter
Calculate energy losses in stormwater system	4.2.6, 4.2.7, 4.3.3, 9.2.6 & 9.2.7	Catchment area, slopes, run-off characteristics, mean annual rainfall	9.1	Utility Programs for Drainage, EPASWMM	Flood peak calculation	3
					Hydraulic calculations	4
Design of detention pond	9.5	Inflow hydrograph, storage/depth relationship, outlet characteristics	9.2	EPASWMM	Discharge characteristics of outlet components	3
					Flood routing	10

The components of storm drainage systems can be categorized by its function: it collects stormwater runoff from the roadway surface and servitude, it conveys it along and through the servitude, and it discharges it to an adequate receiving body without causing adverse environmental impacts.

Stormwater collection

Roadside and median drains are used to intercept runoff and carry it to an adequate storm drain. Gutters/side drains are used to intercept pavement runoff and carry it along the roadway shoulder to an adequate storm drain inlet. Kerbs are typically installed in combination with gutters/side drains where runoff from the pavement surface would erode fill slopes and/or where topographic conditions will not permit the development of roadside drains. Drainage inlets are the receptors for surface water collected in drains and gutters, and serve as the mechanism whereby surface water enters storm drains. When located along the shoulder of the roadway, storm drain inlets are sized and located to limit the spread of surface water onto travel lanes. The term "inlets," as used here, refers to all types of inlets such as grid inlets, kerb inlets, slotted inlets, etc. This was primarily dealt with in **Chapter 5**.

Stormwater conveyance

Upon reaching the main storm drainage system, stormwater is conveyed along and through the right-of-way to its discharge point via storm drains. Storm drains are defined as that portion of the storm drainage system that receives runoff from inlets and conveys the runoff to some point where it is discharged into a channel, waterbody, or other piped system. Storm drains can be closed conduits or open channels; they consist of one or more pipes or conveyance channels connecting two or more inlets.

Manholes, junction boxes, and inlets serve as access structures and alignment control points in storm drainage systems. This **Chapter 9** deals predominantly with this component of the stormwater drainage system.

Stormwater discharge controls

Stormwater discharge controls are often required to off-set potential runoff quantity and/or quality impacts. Water quantity controls include detention/retention facilities. The routing procedures are discussed in **Chapter 10**. Water quality controls include extended detention facilities as well as other water quality management practices. A reduction in runoff quantity can be achieved by the storage of runoff in detention/retention basins, storm drainage pipes, swales and channels, or other storage facilities. Outlet controls on these facilities are used to reduce the rate of stormwater discharge. Water quality controls are used to control the quality of storm water discharges from highway storm drainage systems.

9.2 HYDRAULICS OF STORM DRAINAGE SYSTEMS

Hydraulic design of storm drainage systems requires an understanding of basic hydrologic and hydraulic concepts and principles. Hydrologic concepts were discussed in **Chapter 3**. Important hydraulic principles include flow classification, conservation of mass, conservation of momentum, and conservation of energy was introduced in **Chapters 4 and 5**.

9.2.1 Flow types

The flow of stormwater in conduits may be open-channel or pressure flow. When flow fills the conduit and the hydraulic grade line (HGL) rises above the stormwater conduit crown, the flow is classified as pressure flow (see **Photograph 9.1**). When the conduit is partially full and a free-water surface develops in the conduit, i.e. the HGL is below the crown, the flow is classified as an open-channel flow.



Photograph 9.1: Pressurized flow in conduits (Courtesy of: MVD Consulting Engineers Southern Cape)

The following types of open-channel flow may be found in stormwater conduits:

- *Steady flow* occurs when the depth of flow is constant with respect to time
- *Unsteady flow* occurs when the depth of flow is not constant with respect to time
- *Uniform flow* occurs when the depth of flow does not change with respect to location
- *Non-uniform flow* occurs when the depth of flow changes with respect to location

The various combinations of these types are listed in **Table 9.1**.

Table 9.2: Types of open-channel flow

Type of flow	Steady	Unsteady
Uniform	This flow occurs when in a given stretch of a stormwater conduit, having a constant shape, size, slope and interior roughness, a constant rate of flow enters the upstream end of the conduit and the same exits at the downstream end of the conduit. In this flow regime, the depth of flow is constant with respect to time and location and the HGL is parallel to the conduit invert slope.	This flow occurs when the HGL remains parallel to the conduit invert and fluctuates up and down as the rate of flow fluctuates. This type of flow is not very common in conduit design. It may occur approximately in wide flow channels (e.g. wetlands) with slow rate of change of the inflow.
Non-uniform	This flow shall occur when different constant rates of flow enter a stormwater conduit along its length at various locations. However, a simplification of this case is used in the design of such conduits. Accordingly, the sum of all the flows for a given stretch of the stormwater drain is assumed to enter the pipe at its upstream end, thereby reducing the flow regime to a steady uniform case.	Design of stormwater drains based on this flow regime is seldom performed by hand calculation, as it involves extensive calculations for flow routing, wave and water surface profiles. Numerical modelling is usually required.

The simplified design procedures usually assume that flow within each storm drain segment is steady and uniform. This means that the discharge and flow depth in each segment are assumed to be constant with respect to time and distance. In actual storm drainage systems, the flow at each inlet is variable, and flow conditions are not truly steady or uniform.

However, since the usual hydrologic methods employed in storm drain design are based on computed peak discharges at the beginning of each run, it is a conservative practice to design using the steady uniform flow assumption. When setting up a numerical stormwater model it will allow the analysis, of more complex systems with unsteady non-uniform type flow, as discussed in paragraph 9.6.

9.2.2 Open channel or pressurised flow

Two design philosophies exist for sizing storm drains under the steady uniform flow assumption. The first is referred to as open channel or gravity flow design. To maintain open channel flow, the segment must be sized so that the water surface within the conduit remains open to atmospheric pressure. For open channel flow, flow energy is derived from the flow velocity (kinetic energy), depth (pressure), and elevation (potential energy). If the water surface throughout the conduit is to be maintained at atmospheric pressure, the flow depth must be less than the height of the conduit. Pressure flow design implies that the flow in the conduit is at a pressure greater than atmospheric. Under this condition, there is no exposed flow surface within the conduit. In pressure flow, flow energy is again derived from the flow velocity, depth, and elevation. The significant difference here is that the pressure head will be above the top of the conduit, and will not equal the depth of flow in the conduit. In this case, the pressure head rises to a level represented by the hydraulic grade line (see paragraph 9.2.4 for a discussion of the hydraulic grade line).

The question of whether a system should be designed for open channel or pressure flow control depends on the site conditions and risk assessment: for a given flow rate, designs based on open channel flow require larger conduit sizes than those systems based on pressure flow design. While it may be more expensive to construct storm drainage systems designed based on open channel flow, this design procedure provides an additional margin of safety by providing headroom in the conduit where an increase in flow above the design discharge can be accommodated. The pressure flow design approach would lead to higher flow velocities and thus require more substantial energy dissipating structures. On the other hand, higher flow velocities may minimise sediment deposition which reduces maintenance.

Since the methods of runoff estimation are not exact and existing storm drains are difficult and expensive to replace, a factor of safety may be desirable. However, there may be situations where pressure flow design is advantageous. For example on some projects there may be adequate headroom between the conduit and inlet/manhole elevations to tolerate pressure flow. In this case, significant cost savings may be realized over the cost of a system designed to maintain open channel flow. In instances where existing systems have to be upgraded to accommodate higher flow rates, this can be achieved by allowing pressure flow to develop, providing the EGL remain below ground level over the length of the system. Under most ordinary conditions, it is recommended that piped storm drains be sized based on a gravity flow criteria typically H/D ratios of 0,6 to 0,7. However, the designer should maintain awareness that pressure flow design may be justified in certain instances. When pressure flow is allowed, special emphasis should be placed on the proper design of the joints so that they are able to withstand the pressure flow. Adequate venting should be provided to limit transient pressures due to trapped air pockets.

9.2.3 **Hydraulic capacity**

A storm drain's size, shape, slope, and friction resistance controls its hydraulic capacity. Several flow friction formulas have been advanced which define the relationship between flow capacity and these parameters. The most widely used formula for designing storm drains is either the Chezy Equation or the Manning Equation (see **Chapter 4**).

The shape of a storm drain conduit also influences its capacity. Although most storm drain conduits are circular, a significant increase in capacity can be realized by using an alternate shape. **Table 9.3** provides a tabular listing of the increase in capacity which can be achieved using alternate conduit shapes that have the same height as the original circular shape, but have a different cross sectional area.

Table 9.3: Increase in capacity of alternate conduit shapes compared to a circular shape

Shape	Area (percentage increase)	Conveyance (percentage increase)
Oval	63	87
Arch	57	78
Box (B = D)	27	27

9.2.4 **Energy and Hydraulic Grade Line**

The energy grade line (EGL) represents the total energy level above a selected datum along a channel or conduit carrying water. Total energy includes elevation (potential) head, velocity head and pressure head. The calculation of the EGL for the full length of the system is critical to the evaluation of a storm drain. In order to develop the EGL it is necessary to calculate all of the losses through the system. The energy equation states that the energy head at any cross section must equal that in any other downstream section plus the intervening losses.

The intervening losses are typically classified as either friction losses or form losses. Knowledge of the location of the EGL is critical to the understanding and estimating the location of the hydraulic grade line (HGL).

The hydraulic grade line (HGL) is a line coinciding with the level of flowing water at any point along an open channel. In closed conduits flowing under pressure, the hydraulic grade line is the level to which water would rise in a vertical tube at any point along the pipe. The hydraulic grade line is used to aid the designer in determining the acceptability of a proposed storm drainage system by establishing the elevation to which water will rise when the system is operating under design conditions.

HGL, a measure of flow energy, is determined by subtracting the velocity head ($V^2/2g$) from the EGL. Energy concepts, introduced in **Chapter 4**, can be applied to pipe flow as well as open channel flow. **Figure 4.2** illustrates the energy and hydraulic grade lines for open channel and pressure flow in pipes.

When water is flowing through the pipe and there is a space of air between the top of the water and the inside of the pipe, the flow is considered as *open channel flow* and the HGL is at the water surface. When the pipe is flowing full under *pressure flow*, the HGL will be above the crown of the pipe. When the flow in the pipe just reaches the stage where the pipe is flowing full, this condition is described as *gravity full flow* because the flow is influenced by the resistance of the total pipe circumference. Under gravity full flow, the HGL coincides with the crown of the pipe.

Inlet surcharging and possible access hole lid displacement can occur if the hydraulic grade line rises above the ground surface as shown in **Photograph 9.2**. A design based on open channel conditions must be carefully planned, including evaluation of the potential of excessive flooding occurring when a storm event larger than the design storm pressurizes the system. Storm drainage systems can often alternate between pressure and open channel flow conditions from one section to another. Methods for determining energy losses in a storm drain are presented in Section 9.2.6.



Photograph 9.2: Surcharging manhole

For most storm drainage systems, computer methods are the most efficient means of evaluating the EGL and the HGL, such as EPASWMM. However, it is important that the designer understands the analysis process to allow better interpretation of the output from computer generated storm drain designs and be able to calculate the various losses along flow path of the stormwater system. **Figure 9.1** provides a sketch illustrating use of the two grade lines in developing a storm drainage system.




Figure 9.1: Energy and hydraulic grade line illustration

9.2.5 Storm drain outfalls

Storm drains discharge to receiving water bodies through outlets, or outfall structures. The receiving water body can be a natural river or stream, an existing storm drainage system, or a channel that is either existing or proposed for the purpose of conveying the storm water away from the road. The procedure for calculating the energy grade line through a storm drainage system begins at the outfall. Therefore, consideration of outfall conditions is an important part of storm drain design.

Several aspects of outfall design must be given serious consideration. These include the flowline or invert (inside bottom) elevation of the proposed storm drain outlet, tailwater elevations, the need for energy dissipation, and the orientation of the outlet structure.

Evaluation of the hydraulic grade line for a storm drainage system begins at the system outfall with the tailwater elevation. For most design applications, the tailwater will either be above the crown of the outlet (i.e. outlet is submerged at the design flood) or can be considered to be between the crown and critical depth of the outlet. The tailwater may also occur between the critical depth and the invert of the outlet (i.e. supercritical outflow velocities will occur). Note that the vertical drop between the invert of the proposed outlet and the invert of the system outfall (be it a natural stream or a channel) should be carefully selected to minimise potential erosion problems, at a range of flow rates.

However, the starting point for the hydraulic grade line determination should be either the design tailwater elevation or the average of critical depth and the height of the storm drain conduit, $(y_c + D)/2$, whichever is greater.

If the outfall channel is a river or stream, it may be necessary to consider the joint or coincidental probability of two hydrologic events occurring at the same time to adequately determine the elevation of the tailwater in the receiving stream. The relative independence of the discharge from the storm drainage system can be qualitatively evaluated by a comparison of the drainage area of the receiving stream to the area of the storm drainage system. For example, if the storm drainage system has a drainage area much smaller than that of the receiving stream, the peak discharge from the storm drainage system may be out of phase with the peak discharge from the receiving watershed.

There may be instances in which an excessive tailwater causes flow to back up the storm drainage system and thus discharge out of inlets and access holes, creating unexpected and perhaps hazardous flooding conditions. The potential for this should be considered.

Energy dissipation may be required to protect the storm drain outlet. Protection is usually required at the outlet to prevent erosion of the outfall bed and banks. Riprap aprons or energy dissipators should be provided if high velocities are expected, refer to Chapters 5 and 8 of this Manual and "Hydraulic Design of Energy Dissipators for Culverts and Channels"^(9.1) for more detailed guidance with designing an appropriate dissipator. The orientation of the outfall is another important design consideration. Where practical, the outlet of the storm drain should be positioned in the outfall channel so that it discharges in a downstream direction. This will reduce turbulence and the potential for excessive erosion, such as along the opposite bank of the outfall channel or stream.

9.2.6 Energy losses

Prior to computing the hydraulic grade line, all energy losses in pipe runs, junctions and access manholes (see **Photograph 9.3**) must be estimated. In addition to the principal energy involved in overcoming the friction in each conduit reach, energy (or head) is required to overcome changes in momentum or turbulence at outlets, inlets, bends, transitions, junctions, and access holes. The following paragraphs present relationships for estimating typical energy losses in storm drainage systems^(9.2) which should be read in conjunction with the material on the general cases discussed in **Chapter 4**.



Photograph 9.3: Construction of stormwater access manhole
(Courtesy of: MVD Consulting Engineers Southern Cape)

9.2.6.1 Theoretical description of calculating the energy losses: Energy-Loss Method

This method as described below is extracted from the Haestead Method document entitled *Stormwater Conveyance Modeling and Design*^(9.2). The incoming pipe(s) to an inlet, manhole, or junction structure in a storm water conveyance system can occur in a number of different configurations with respect to their invert elevations. The various configurations that can occur are:

- All incoming pipe invert elevations lie below the elevation of the predicted depth of water in the structure.
- All incoming pipe invert elevations lie above the elevation of the predicted depth of water in the structure.
- One or more of the incoming pipe invert elevations lie above the elevation of the predicted depth of water in the structure, and one or more incoming pipe invert elevations lie below the elevation of the predicted depth of water in the structure.

$$h_L = K \frac{V_o^2}{2g} \quad \dots(9.1)$$

Where	h_L	=	minor loss (m)
	V_o	=	velocity in the outlet pipe (m/s)
	K	=	adjusted minor loss coefficient
	g	=	gravitational acceleration (9,81 m ² /s)

Laboratory research has shown that K can be expressed as:

$$K = K_O C_{D1} C_{D2} C_Q C_P C_B \quad \dots(9.2)$$

Where	K_O	=	initial head loss coefficient based on relative size of structure
	C_{D1}	=	correction factor for pipe diameter
	C_{D2}	=	correction factor for flow depth
	C_Q	=	correction factor for relative flow
	C_P	=	correction factor for plunging flow
	C_B	=	correction factor for benching

Equation 9.1 and Equation 9.2 can be applied to each of several incoming pipes at a structure, provided their invert elevations lie below the predicted water surface elevation within the structure. The initial head loss coefficient, K_o , depends on the size of the structure relative to the outlet pipe diameter, and on the angle θ between the inlet and outlet pipes (see **Figure 9.2**).

$$K_o = 0,1 \left(\frac{B}{D_o} \right) (1 - \sin\theta) + 1,4 \left(\frac{B}{D_o} \right)^{0,15} \sin\theta \quad \dots(9.3)$$

Where	B	=	structure diameter (m)
	D_o	=	outlet pipe diameter (m)
	θ	=	angle between inlet and outlet pipes

If the structure is not circular, an *equivalent structure diameter* should be used. The equivalent diameter is defined as the diameter of a circular structure having the same area as the actual non-circular one.




Figure 9.2: Plan view of junction structure

Computing C_{D1} (Correction for Relative Pipe Diameter)

The correction factor for pipe diameter, C_{D1} , needs to be considered only in cases where the predicted water depth d in the structure is at least 3,2 times as great as the outlet pipe diameter. When applying this and other correction factors, the depth of water d should be taken as the difference between the hydraulic grade line elevation at the upstream end of the outlet pipe and the invert elevation of the outlet pipe. In such cases, C_{D1} is determined as

$$C_{D1} = \left(\frac{D_o}{D_i} \right)^3 \quad \dots(9.4)$$

Where D_i = inlet pipe diameter (m)

When the predicted depth in the structure is not at least 3,2 times the outlet pipe diameter, $C_{D1} = 1$.

Computing C_{D2} (Correction for Flow Depth)

The correction factor for flow depth, C_{D2} , needs to be considered only in cases where the predicted depth in the structure is less than 3,2 times the outlet pipe diameter; otherwise, $C_{D2} = 1$. The correction factor is determined as:

$$C_{D2} = 0,5 \left(\frac{d}{D_o} \right)^{0,6} \quad \dots(9.5)$$

Where d = water depth in the structure computed as the difference in HGL and invert at the upstream end of the outlet pipe (m)

Computing C_Q (Correction for Relative Flow)

The correction factor for relative flow, C_Q , is required in applications where there are two or more incoming pipes at a structure. When there is only one incoming pipe, $C_Q = 1$. The correction factor depends on the angle θ between the outlet pipe and the incoming pipe of interest, and on the ratio of the discharge in the incoming pipe of interest to the outlet pipe:

$$C_Q = 1 + (1 - 2\sin\theta) \left(1 - \frac{Q_i}{Q_o} \right)^{0,75} \quad \dots(9.6)$$

Where Q_i = discharge in the incoming pipe of interest (m^3/s)
 Q_o = discharge in the outflow pipe (m^3/s)

Computing C_p (Correction for Plunging)

When one or more of the incoming pipes to a structure have invert elevations higher than the elevation of the free water surface in the structure d , they are said to have free outfalls, and the water plunges into the structure. Plunging flow can also enter a structure from the inlet opening. The resulting turbulence and energy dissipation within the structure has an effect on the head loss for other incoming pipes whose flow is not plunging (that is, their invert elevations lie below the free water surface). The coefficient C_p is computed and applied in the head loss calculations only for the pipe(s) whose flow is not plunging. The coefficient is determined as:

$$C_p=1+0,2\left(\frac{h}{D_o}\right)\left(\frac{h-d}{D_o}\right) \qquad \dots(9.7)$$

Where h = difference in elevation between the highest incoming pipe invert and the centreline of the outlet pipe (m)

For cases in which no plunging incoming pipes are present, or in which $h \leq d$, the value of the coefficient is $C_p = 1$.

Selecting C_B (Correction for Benching of Structure Invert)

Benching of the invert of a structure (see **Figure 9.3**) can reduce head losses by effectively directing the path of the flow through the structure. In practice, the base of a manhole can be benched by pouring a cast-in-place base that is shaped to the pipes connecting to the structure. Benching can also be achieved by pouring fresh concrete into the inside base of a precast manhole section and shaping it to the required form. The correction factor for benching, C_B , is presented in **Table 9.4** and depends on the depth of water in the structure relative to the outlet pipe diameter. For the use of that table, submerged flow is considered to occur if $d/D_o \geq 3,2$, and unsubmerged flow is considered to occur if $d/D_o \leq 1,0$. For values of d/D_o between 1,0 and 3,2, linear interpolation between the tabulated values may be performed.

Table 9.4: Correction factors for benching

Bench Type	Submerged	Unsubmerged
Flat a depressed floor	1,00	1,00
Half bench	0,95	0,15
Full bench	0,75	0,07




Figure 9.3: Benching the invert of a structure

9.2.6.2 Theoretical description of calculating the energy losses: Composite Energy-loss Method

This method as described below is extracted from the Haestad Method ^(9.2) document. The composite energy-loss method can be used in situations similar to those for which the energy-loss method, discussed in the previous section, applies. However, **the composite method is better suited to analysing losses in structures with many inflow pipes**. It is only applicable to *subcritical flows* in pipes. The method is used to compute a unique head loss through the junction structure for each of the incoming pipes. This head loss is then added to the energy grade at the upstream end of the outlet pipe (EGL_o) to obtain the EGL at the downstream end of the incoming pipe (EGL_i). The velocity head for the incoming pipe can then be subtracted from EGL_i to obtain the hydraulic grade, HGL_i . The head loss through the structure for a particular inflow pipe is again given by Equation 9.1, repeated here as Equation 9.8:

$$h_L = K \frac{V_o^2}{2g} \quad \dots(9.8)$$

Where K = the adjusted minor loss coefficient for the composite energy-loss method

The adjusted minor loss coefficient K is defined as:

$$K = (C_1 C_2 C_3 + C_4) C_B \quad \dots(9.9)$$

Where	C_1	=	coefficient for the relative access hole diameter
	C_2	=	coefficient for the water depth in the access hole
	C_3	=	coefficient for lateral flow, the lateral angle, and plunging flow
	C_4	=	coefficient for the relative pipe diameters
	C_B	=	coefficient for benching (given in Table 9.4)

Empirical equations describing these coefficients were developed from laboratory studies and analyses. These equations are presented in the subsections that follow.

Computing C_1 (Relative access-hole diameter coefficient)

The energy-loss coefficient relative to the access-hole diameter is related to the ratio of the access-hole diameter, B , to the outlet pipe diameter, D_o , and is given by Equation 9.10.

$$C_1 = \begin{cases} \frac{0,9 \left(\frac{B}{D_o} \right)}{6 + \frac{B}{D_o}} & \frac{B}{D_o} < 4 \\ 0,36 & \frac{B}{D_o} \geq 4 \end{cases} \quad \dots(9.10)$$

Thus, the value of this coefficient increases with the ratio B/D_o until that ratio is equal to 4. For $B/D_o \geq 4$, C_1 has the constant value $C_1 = 0,36$. Note that the value of C_1 is the same for all incoming pipes.

Computing C_2 (Water depth in access hole coefficient) and C_3 (Lateral flow, lateral angle, and plunging flow coefficient)

The coefficients C_2 and C_3 represent the composite effect of all the inflow pipes, the outflow pipe, and the access hole. Their calculation is affected by and also affects the calculation of the access-hole water depth, d . Because of this interdependence, an iterative method is used to calculate these coefficients. The first step is to compute an initial estimate of d with the Equation 9.11:

$$d = HGL_o + C_1 C_2 \frac{V_o^2}{2g} - Z_o \quad \dots(9.11)$$

Where	HGL_o	=	hydraulic grade elevation at the upstream end of the outlet pipe (m)
	Z_o	=	elevation of the outlet pipe invert (m)

This value is used to calculate an estimate of C_2 as

$$C_2 = \begin{cases} 0,24 \left(\frac{d}{D_o} \right)^2 - 0,05 \left(\frac{d}{D_o} \right)^3 & \frac{d}{D_o} \leq 3 \\ 0,82 \frac{d}{D_o} & > 3 \end{cases} \quad \dots(9.12)$$

The analysis of the factors affecting energy losses for lateral flows resulted in an equation for C_3 that is the most complex of any of the coefficients. For a simple, two pipe system with no plunging flow, $C_3 = 1,0$. (A pipe has plunging flow if the critical flow depth elevation in the pipe, $y_c + Z_i$, is higher than the access-hole depth elevation, $d + Z_o$.)

Otherwise, C_3 is expressed in the form:

$$C_3 = 1 + C_{3A} + C_{3B} + C_{3C} + C_{3D} \quad \dots(9.13)$$

Where the individual terms in Equation 9.13 are given by Equations 9.14 to 9.18.

The calculations for C_3 consider the angle θ_i between the inlet and outlet pipes. As this angle deviates from 180 (straight line flow), the energy loss increases because the flow cannot smoothly transition to the outlet pipe. All inflow pipe angles are measured clockwise from the outlet pipe. The calculation of C_3 accounts for inlet-flow plunging by considering the inlet as a fourth, synthetic inflow pipe with the corresponding angle set to 0.

C_3 can have a value ranging from 1 for no lateral flow to potentially very high values for greater plunge heights. Because empirical studies do not support this result, a value of 10 is set as a realistic upper limit on C_3 .

The term C_{3A} represents the energy loss from plunging flows and is valid for three inlet pipes plus the plunging flow from the inlet:

$$C_{3A} = \sum_{i=1}^4 \left(\frac{Q_i}{Q_0} \right)^{0,75} \left[1 + 2 \left(\frac{Z_i}{D_0} - \frac{d}{D_0} \right)^{0,3} \left(\frac{Z_i}{D_0} \right)^{0,3} \right] \quad \dots(9.14)$$

Where Q_1, Q_2, Q_3 = discharge from inflow pipes 1, 2, and 3 (m^3/s)
 Q_4 = discharge into the access hole from the inlet (m^3/s)
 Z_1, Z_2, Z_3 = invert elevations of the inflow pipes relative to the outlet pipe invert (m)

The term C_{3B} represents the energy loss due to change in direction between the inlet and outlet pipes. If the horizontal momentum check HMC_i as computed using Equation 9.15 is less than 0, then the flow is assumed to be falling from such a height that horizontal momentum can be neglected and $C_{3B} = 0$. Otherwise, HMC_i is given by Equation 9.15. Note that the inlet flow is not considered in this calculation.

$$\text{HMC}_i = 0,85 - \left(\frac{Z_i}{D_0} \right) \left(\frac{Q_i}{D_0} \right)^{0,75} \quad \dots(9.15)$$

If $\text{HMC}_i \geq 0$, C_{3B} is computed as

$$C_{3C} = 4 \sum_{i=1}^3 \frac{\cos \theta_i \cdot \text{HMC}_i}{\left(\frac{d}{D_0} \right)^{0,3}} \quad \dots(9.16)$$

Where Z_A, Z_B = angle between the outlet main and inflow pipes 1, 2, and 3, degrees
 HMC_i = horizontal momentum check for pipe i computed using Equation 9.15

If there is more than one inflow pipe, C_{3C} is calculated for all combinations of inflow pipes with $\text{HMC}_i > 0$. The pair that produces the highest value is then used for the calculations of C_{3C} and C_{3D} :

$$C_{3C} = 0,8 \left(\frac{Z_A}{D_0} - \frac{Z_B}{D_0} \right) \quad \dots(9.17)$$

Where Z_A, Z_B = invert elevation, relative to the outlet pipe invert, for the inflow pipes that produce the largest value of C_{3D}

$$C_{3D} = \left| \left(\frac{Q_A}{Q_0} \right)^{0.75} \sin \theta_A + \left(\frac{Q_B}{Q_0} \right)^{0.75} \sin \theta_B \right| \quad \dots(9.18)$$

Where Q_A, Q_B = discharges for the pair of inflow pipes producing the largest value of C_{3D} (m^3/s)
 θ_A, θ_B = angle between the outlet main and inflow pipes for the pair of inflow pipes producing the largest value of C_{3D}

With the initial estimates of C_2 and C_3 , the access-hole depth is recalculated with:

$$d = HGL_0 + \frac{V_0^2}{2g} + C_1 C_2 C_3 C_B \frac{V_0^2}{2g} - Z_0 \quad \dots(9.19)$$

Where HGL_0 = hydraulic grade line at the upstream end of the inlet pipe (m)
 Z_0 = invert elevation of the outlet pipe at the upstream end (m)

This new value of d is compared to the previous estimate, and the entire procedure for calculating C_2 , C_3 , and d continues until the method converges on the value of d .

Computing C_4 (Relative Pipe Diameter Coefficient)

The last coefficient to be determined in Equation 9.9, the coefficient related to relative pipe diameters, C_4 , is computed for each inflow pipe using:

$$C_{4i} = 1 + \left(\frac{Q_i}{Q_0} + 2 \frac{A_i}{A_0} \cos \theta_i \right) \frac{V_i^2}{V_0^2} \quad \dots(9.20)$$

Where A_i, A_0 = cross-sectional areas of the inlet and outflow pipes (m^2)
 θ_i = angle between the outlet pipe and inflow pipe i
 V_i, V_0 = velocity of flow in the inlet pipe and outflow pipes (m/s)

9.2.7 Pipe friction losses

The major loss in a storm drainage system is the friction or boundary shear loss. At any position along the pipeline where there is a transition an additional energy loss will occur which reduces the available energy to overcome friction. In this case the friction slope will not be the same as the conduit gradient.

Flow in storm drainage systems can be calculated using either the Manning or Kutter formula with ' n - roughness parameter' or the Colebrook-White Darcy Weisbach or, the *preferred method* the Chezy equation with ' k_s - roughness parameter', see **Table 9.5. Chapter 4** provides details in **Figures 4.8, 4.9 and 4.10** on typical roughness parameters applicable to storm drainage systems.

Table 9.5: Friction formulae

Formulae		Parameter and units
Manning Eq (9.21)	$Q = \frac{1}{n} \frac{A^{\frac{5}{3}}}{P^{\frac{2}{3}}} S^{\frac{1}{2}}$	<div>Q = flow rate (m³/s)</div> <div>n = coefficient of roughness (s/m^{1/3})</div> <div>A = flow area (m²)</div> <div>P = wetted perimeter (m)</div> <div>R = hydraulic radius (m) – A/P</div> <div>S = slope of the energy grade line (m/m)</div> <div>v = kinematic viscosity (m²/s)</div> <div>k_s = absolute roughness of conduit (m)</div> <div>g = gravitational acceleration (m/s²)</div>
Kutter Eq (9.22)	$Q = \left[\frac{\frac{1,81}{n} + 41,67 + \frac{0,0028}{S}}{1 + \frac{n}{\sqrt{R}} \left(41,67 + \frac{0,0028}{S} \right)} \right] A \sqrt{RS}$	
Colebrook-White Darcy-Weisbach Eq (9.23)	$Q = -2A \sqrt{2gDS} \log \left(\frac{k_s}{3,7D} + \frac{2,51v}{D \sqrt{2gDS}} \right)$	
Chezy Eq (9.24)	$Q = 18 \log \left(\frac{12R}{k_s} \right) A \sqrt{RS}$	

9.2.8 Properties of circular sections

The flows in stormwater pipes are usually open-channel type flow, which means that there is always some free space above the flow of stormwater in the conduit. The hydraulic design of stormwater conduits requires knowledge of the area of flow and the hydraulic radius. Both these parameters vary with the depth of flow, as shown in **Figure 9.4** for a circular conduit and trigonometric relationships can be derived for the area of flow, wetted perimeter, hydraulic radius and breadth of flow.




Figure 9.4: Definition of parameters for open-channel flow in circular stormwater pipes

The ratio d/D is termed the proportional depth of flow (which is dimensionless). The equations are provided in **Table 9.6**.

Table 9.6: Formulae for partially full flowing pipes

Description	Equation	Eq. No.	Parameter and units
Angle of flow	$\theta = 2\cos^{-1}\left(1 - 2\frac{d}{D}\right)$	(9.25)	D = pipe inner diameter (m) d = depth of flow (m) n = coefficient of roughness (s/m ^{1/3})
Area of flow	$a = D^2\left(\frac{(\theta - \sin\theta)}{8}\right)$	(9.26)	A = full-flow area (m ²) P = wetted perimeter for full flow (m)
Wetted perimeter	$p = \theta\frac{D}{2}$	(9.27)	R = hydraulic radius full flowing (m) – A/P a = area of partially full flowing pipe (m ²) p = wetted perimeter of partially full flowing pipe (m)
Hydraulic radius	$r = \left(\frac{D}{4}\right)\left(1 - \frac{\sin\theta}{\theta}\right)$	(9.28)	r = hydraulic radius of partially full flowing pipe (m)
Width of flow	$b = D\sin\left(\frac{\theta}{2}\right)$	(9.29)	b = breadth of flow (m) θ = angle of flow (radians)

For circular pipes, the following formulae (Equations 9.30 and 9.31) can be used to compute critical depth. Critical depth can then be compared to the design depth to determine if flows will be subcritical or supercritical and whether or not a hydraulic jump may occur. Critical depth occurs when energy is at a minimum with respect to depth, $dE/dY=0$. A numerical solution method is followed to

solve for θ_c and then for y_c . (Alternatively, the Froude number = $\left(\frac{Q^2B}{gA^3}\right)^{\frac{1}{2}}$ at the design depth may be calculated to determine the nature of the flow, i.e. sub- or super-critical.)

$$16Q\left[2g\sin\left(\frac{\theta_c}{2}\right)\right]^{\frac{1}{2}} = D^{\frac{5}{2}}[\theta_c - \sin(\theta_c)]^{\frac{3}{2}} \quad \dots(9.30)$$

$$y_c = \frac{D}{2}\left[1 - \cos\left(\frac{\theta_c}{2}\right)\right] \quad \dots(9.31)$$

Where:

D	=	inside diameter of pipe (m)
g	=	gravitational acceleration (m/s ²)
Q	=	flow rate (m ³ /s)
y_c	=	critical depth (m)
θ_c	=	angle at critical depth (radians)

The critical velocity for circular conduits can be calculated using Equation 9.32.

$$V_c = \left(\frac{gA}{B}\right)^{\frac{1}{2}} \quad \dots(9.32)$$

Where:

V_c	=	critical velocity (m/s)
A	=	flow area (m ²)
B	=	width of water surface (m)
g	=	gravitational acceleration (m/s ²)

9.3 DESIGN GUIDELINES AND CONSIDERATIONS

9.3.1 Time of concentration and discharge

The Rational Method (**Chapter 3**) is the most common means of determining design discharges for storm drain design. The time of concentration is very influential in the design discharge obtained using the Rational Method. The time of concentration is defined as the period required for water to travel from the most hydraulically distant point of the watershed to the point of interest. The time of concentration for inlet spacing is the time required for water to flow from the hydraulically most distant point of the unique drainage area contributing only to that inlet. Typically, this is the sum of the times required for water to travel overland to the pavement side drain and along the length of the gutter between inlets. The time of concentration for each successive inlet should be determined independently in the same manner as was used for the first inlet.

The time of concentration for pipe sizing is defined as the time required for water to travel from the most hydraulically distant point in the total contributing watershed to the design point. Typically, this time consists of two components ^(9.8):

- (1) the time for overland and side drain flow to reach the first inlet, and
- (2) the time to flow through the storm drainage system to the point of interest.

The flow path having the longest time of concentration to the point of interest in the storm drainage system will usually define the duration used in selecting the intensity value in the Rational Method. Exceptions to the general application of the Rational Equation exist. For example, a small relatively impervious area within a larger drainage area may have an independent discharge higher than that of the total area. This anomaly may occur because of the high runoff coefficient (*C* value) and high intensity resulting from a short time of concentration. Two exception scenarios can usually be defined:

The first exception occurs when there is a highly impervious section at the most downstream area of a catchment area and the total upstream area flow through the lower impervious area resulting in two separate calculations which should be made:

- First, calculate the runoff from the total drainage area with its weighted *C* value and the intensity associated with the longest time of concentration.
- Secondly, calculate the runoff using only the smaller less pervious area. The typical procedure would be followed using the *C* value for the small less pervious area and the intensity associated with the shorter time of concentration.

Compare these two calculations and use the largest value of discharge for design purposes.

The second exception could be when a smaller less pervious area is tributary to the larger primary catchment area and in this case two sets of calculations should also be made:

- First, calculate the runoff from the total drainage area with its weighted *C* value and the intensity associated with the longest time of concentration.
- Secondly, calculate the runoff to consider how much discharge from the larger primary area is contributing at the same time the peak from the smaller less pervious tributary area is occurring. When the small area is discharging, some discharge from the larger primary area is also contributing to the total discharge. In this calculation, the intensity associated with the time of concentration from the small less pervious area is used. The portion of the larger primary area to be considered is determined by the following equation:

$$A_C = A \left(\frac{T_{C1}}{T_{C2}} \right) \quad \dots(9.33)$$

Where:

- A_C = most downstream part of the larger primary area that will contribute to the discharge during the time of concentration associated with the smaller, less pervious area (km²).
- A = area of the larger primary area (km²)
- T_{C1} = time of concentration of the smaller, less pervious, tributary area (h),
- T_{C2} = time of concentration associated with the larger primary area as is used in the first calculation (h)

The C value to be used in this computation should be the weighted C value that results from combining C values of the smaller less pervious tributary area and the area A_C . The area to be used in the Rational Method would be the area of the less pervious area plus A_C . This second calculation should only be considered when the less pervious area is tributary to the area with the longer time of concentration and is at or near the downstream end of the total drainage area.

Compare these results and the largest value of discharge should be used for design purposes.

9.3.2 Maximum high water

Maximum high water is the maximum allowable elevation of the water surface (hydraulic grade line) at any given point along a storm drain. These points include inlets, access holes, or any place where there is access from the storm drain to the ground surface. The maximum high water at any point should not interfere with the intended functioning of an inlet opening, or reach an access hole cover. Maximum allowable high water levels should be established along the storm drainage system prior to initiating hydraulic evaluations.

9.3.3 Minimum velocity and grades

It is desirable to maintain a self-cleaning velocity in the storm drain to prevent deposition of sediments and subsequent loss of capacity. For this reason, storm drains should be designed to maintain full-flow pipe velocities of 0,7 m/s or greater, a minimum flow velocity of 0,6 m/s at a flow depth equal to 25% of the pipe diameter. Minimum slopes required for a velocity of 0,7 m/s can be computed using any of the formulae as shown in **Table 9.5**.

9.3.4 Cover depth

The cover depth should be sufficient to prevent crushing of pipes due to external loading (live and dead loads), typically traffic loads. Both minimum and maximum cover limits must be considered in the design of storm drainage systems. Minimum cover limits are established to ensure the conduits structural stability under live and impact loads. With increasing fill heights, dead load becomes the controlling factor. For highway applications, a minimum cover depth of 0,9 m should be maintained where possible. In cases where this criterion cannot be met, the storm drains should be evaluated to determine if they are structurally capable of supporting imposed loads.

Procedures for analysing loads on buried structures are outlined in the Handbook of Steel Drainage and Highway Construction Products ^(9.5), and the Concrete Pipe Design Manual ^(9.6) as well as the Design Manual for Concrete Pipe Outfall Sewers ^(9.7).

9.3.5 Access holes / Manholes

9.3.5.1 Introduction

The primary function of an access hole is to provide convenient access to the storm drainage system for inspection and maintenance. As secondary functions, access holes also serve as flow junctions, and can provide ventilation and pressure relief for storm drainage systems. It is noted that inlet structures can also serve as access holes, and should be used in lieu of access holes where possible so that the benefit of extra stormwater interception is achieved at minimal additional cost.

Like storm drain inlets, the materials most commonly used for access-hole construction are pre-cast concrete, cast-in-place concrete and brick work.

9.3.5.2 Chamber and access shaft

Most access holes are circular with the inside dimension of the bottom chamber being sufficient to perform inspection and cleaning operations without difficulty. A minimum inside diameter of 1,2 m has been adopted widely with 1,5 m diameter access hole being used for larger diameter storm drains.

9.3.5.3 Frame and cover

Access hole frames and covers are designed to provide adequate strength to support superimposed loads, provide a good fit between cover and frame, and maintain provisions for opening while providing resistance to unauthorized opening (primarily from children). In addition, to differentiate storm drain access holes from those on sanitary sewers, communication conduits, or other underground utilities, it is good practice to have the words "STORM DRAIN" or equivalent cast into the top surface of the covers. Most agencies maintain frame and cover standards for their systems.

If the hydraulic grade line could rise above the ground surface at an access-hole site, special consideration must be given to the design of the access-hole frame and cover. The cover must be secured so that it remains in place during peak flooding periods, avoiding an access hole "blowout." A "blowout" is caused when the hydraulic grade line rises in elevation higher than the access-hole cover and forces the lid to explode off. Access-hole covers should be bolted or secured in place with a locking mechanism if "blowout" conditions are possible. **Photograph 9.4** depicts a stormwater access-hole surcharging.



Photograph 9.4: Surcharging stormwater system

9.3.5.4 Channel and bench

Flow channels and benches are illustrated in **Figure 9.5**. The purpose of the flow channel is to provide a smooth, continuous conduit for the flow and to eliminate unnecessary turbulence in the access hole by reducing energy losses. The elevated bottom of the access hole on either side of the flow channel is called the bench. The purpose of a bench is to increase hydraulic efficiency of the access hole. Benching is only used when the hydraulic grade line is relatively flat and there is no appreciable head available. Typically, the slopes of storm drain systems do not require the use of benches to maintain the hydraulic grade line below ground level (in case of free flowing pipes).

The inflow and outflow pipe invert elevations are to be aligned as follows: the top of the outlet pipe is below the top of the inlet pipe by the amount of loss in the access hole. This practice is often referred to as "hanging the pipe on the hydraulic grade line."




Figure 9.5: Efficient channel and bench configurations

9.3.5.5 Access-hole depth

The depth required for an access hole will be dictated by the storm drain profile and surface topography. Common access hole depths range from 1,5 to 4,0 m. Access holes which are shallower or deeper than this may require special consideration. Deep access holes must be carefully designed to withstand soil pressure loads. If the access hole is to extend very far below the water table, it must also be designed to withstand the associated hydrostatic pressure or excessive seepage may occur.

9.3.5.6 Location and spacing

Access-hole location and spacing criteria have been developed in response to storm drain maintenance requirements. Spacing criteria are typically established based on the local authorities past experience and maintenance equipment limitations. At a minimum, access holes should be located at the following points:

- Where two or more storm drains converge.
- Where pipe sizes change.
- Where a change in alignment occurs.
- Where a change in grade occurs.

In addition, access holes may be located at intermediate points along straight runs of storm drain in accordance with the criteria outlined in **Table 9.7**; however, individual transportation agencies may have limitations on spacing of access holes due to maintenance constraints.

Table 9.7: Access hole spacing criteria

Pipe size (mm)	Suggested maximum spacing (m)
300 – 600	100
700 – 900	125
1000 - 1400	150
1500 and up	300

9.3.6 Junction chambers

A junction chamber is a specially designed underground chamber used to join two or more large storm drain conduits. This type of structure is usually required where storm drains are larger than the size that can be accommodated by standard access holes. For smaller diameter storm drains, access holes are typically used instead of junction chambers. Junction chambers by definition do not need to extend to the ground surface and can be completely buried. For maintenance, the buried roof of the chamber should be a removable precast element.

However, for deeper chambers it is recommended that riser structures be installed to provide for surface access and/or to intercept surface runoff.

Materials commonly used for junction chamber construction include pre-cast concrete, cast-in-place concrete and brick work. To minimize flow turbulence in junction boxes, flow channels and benches are typically built into the bottom of the chambers. **Figure 9.5** illustrates several efficient junction channel and bench geometries.

9.3.7 Alignment of the storm water drains

Where possible, storm drains should be straight between access holes. However, curved storm drains are permitted where necessary to conform to street layout or avoid obstructions. Pipe sizes smaller than 1200 mm should not be designed with curves. For larger diameter storm drains deflecting the joints to obtain the necessary curvature is not desirable except in very minor curvatures. Long radius bends are available from many suppliers and are the preferable means of changing direction in pipes 1200 mm in diameter and larger. The radius of curvature specified should coincide with standard curves available for the type of material being used.

9.4 MAINTENANCE CONSIDERATIONS

Design, construction and maintenance are very closely related. It is essential that storm drain maintenance be considered during both design and construction. Common maintenance problems associated with storm drains include debris accumulation, sedimentation, erosion, scour, piping, roadway and embankment settlement, and conduit structural damage - also see the Routine Maintenance section in **Chapter 10**. The accumulation of debris and sediment in storm drains is a possibility. This problem is particularly prevalent during construction.

Designs for a minimum full flow velocity of 0.7 m/s give some assurance that sedimentation will not occur. It is also important that access hole spacing be maintained to ensure adequate access for cleaning. Scour at storm drain outlets is another frequently reported source of storm drain maintenance needs. Prudent design of riprap aprons or energy dissipators at storm drain outlets can minimize scour. Piping, roadway and embankment settlement, and conduit structural failure can also be avoided through proper design and installation specifications. These problems, when they occur, are usually related to poor construction. Correct specifications along with good construction supervision can help reduce these problems. Even in a properly designed and constructed storm drainage system, a comprehensive program for storm drain maintenance is essential to the proper functioning of the storm drainage system. A regular in-pipe inspection will detail long term changes and will point out required maintenance necessary to insure safe and continued operation of the system. The program should include periodic inspections with supplemental inspections following storm events. Since storm drains are virtually entirely underground, inspection of the system is more difficult than surface facilities. Remote-controlled cameras can be used to inspect small diameter conduits. A document which may provide guidance for inspecting storm drains or culverts is the FHWA's Culvert Inspection Manual ^(9.3) (included on supporting flash drive/DVD).

9.5 DETENTION AND RETENTION FACILITIES

9.5.1.1 Introduction

Land development activities, including the construction of roads, convert natural pervious areas to impervious and otherwise altered surfaces. These activities can in some cases cause an increased volume of runoff because infiltration is reduced, the surface is usually smoother thereby allowing more rapid drainage, and depression storage is usually reduced although slopes may be altered. In addition, natural drainage systems are often replaced by lined channels and storm drains systems. These man-made systems produce an increase in runoff volume and peak discharge, as well as a reduction in the time to peak of the runoff hydrograph. This result of this is illustrated by the hydrographs in **Figure 9.6** ^(9.8).

The temporary storage or detention/retention of excess storm water runoff as a means of controlling the quantity and quality of storm water releases is a fundamental principle in storm water management and a necessary element of a growing number of highway storm drainage systems.

The storage of storm water can reduce the frequency and extent of downstream flooding, soil erosion, sedimentation, and water pollution. Detention /retention facilities have also been used to reduce the costs of large storm drainage systems by reducing the required size for downstream storm drain conveyance systems. The use of detention/retention facilities can reduce the peak discharge from a given watershed, as shown in **Figure 9.6**. The reduced post-development runoff hydrograph is typically designed so that the peak flow is equal to or less than the pre-developed runoff peak flow rate.

Stormwater quantity control facilities can be classified by function as either detention or retention facilities. The main function of detention is to store and gradually release or attenuate stormwater runoff by way of a control structure or other release mechanism.

Retention facilities however provide for storage of stormwater runoff, and release via evaporation and infiltration only.




Figure 9.6: Hydrograph schematic ^(9.8)

9.5.2 Detention facilities

The detention concept is most often employed in highway and municipal stormwater management plans to limit the peak outflow rate to that which existed from the same catchment area before development for a specific range of flood frequencies. Detention storage may be provided at one or more locations and may be either above or below ground. These locations may exist as impoundments, collection and conveyance facilities, underground tanks, and on-site facilities such as parking lots, pavements, and basins. The facility may have a permanent pool, known as a wet pond. Wet ponds are typically used where pollutant control is important. Detention ponds are the most common type of storage facility used for controlling stormwater runoff peak discharges. The majority are designed as dry ponds which release all the runoff temporarily detained during a storm.

Detention facilities should be provided only where they are shown to be beneficial by hydrologic, hydraulic, and cost analysis. Additionally, some detention facilities may be required by ordinances and should be constructed as deemed appropriate by the governing agency. **Chapter 3** can be used to perform the hydrological analyses of the catchment area and **Chapter 10** provides details of routing procedures and a utility program to calculate the influence of the detention volume on the discharge flow rate. Details of the outlet characteristics used in the calculation of the outlet hydrographs are described in **Chapter 4**.

9.5.3 Retention facilities

Retention facilities can be used for stormwater storage, water supply, recreation, pollutant removal, aesthetics, and/or groundwater recharge. Infiltration facilities provide significant water quality benefits, and although groundwater recharge is not a primary goal of highway stormwater management, the use of infiltration basins and/or swales can provide this secondary benefit. Retention facilities are typically designed to provide the dual functions of stormwater quantity and quality control. These facilities may be provided at one or more locations and may be either above or below ground.

These locations may exist as impoundments, collection and conveyance facilities (swales or perforated conduits), and on-site facilities such as parking lots and roadways using pervious pavements.

9.6 STORMWATER MODELLING

The EPA Storm Water Management Model (SWMM) is a dynamic rainfall-runoff simulation model used for single event or long-term (continuous) simulation of runoff quantity and quality from primarily urban areas. The runoff component of SWMM operates on a collection of subcatchment areas that receive precipitation and generate runoff and pollutant loads. The routing portion of SWMM transports this runoff through a system of pipes, channels, storage/treatment devices, pumps, and regulators. SWMM tracks the quantity and quality of runoff generated within each subcatchment, and the flow rate, flow depth, and quality of water in each pipe and channel during a simulation period comprised of multiple time steps.

SWMM continues to be widely used throughout the world for planning, analysis and design related to stormwater runoff, combined sewers, sanitary sewers, and other drainage systems in urban areas, with many applications in non-urban areas as well. It provides an integrated environment for editing study area input data, running hydrologic, hydraulic and water quality simulations, and viewing the results in a variety of formats.

SWMM accounts for various hydrologic processes that produce runoff from urban areas. These include:

- time-varying rainfall
- evaporation of standing surface water
- snow accumulation and melting
- rainfall interception from depression storage
- infiltration of rainfall into unsaturated soil layers
- percolation of infiltrated water into groundwater layers
- interflow between groundwater and the drainage system
- nonlinear reservoir routing of overland flow

Spatial variability in all of these processes is achieved by dividing a study area into a collection of smaller, homogeneous subcatchment areas, each containing its own fraction of pervious and impervious sub-areas. Overland flow can be routed between sub-areas, between subcatchments, or between entry points of a drainage system.

SWMM also contains a flexible set of hydraulic modelling capabilities used to route runoff and external inflows through the drainage system. These include the ability to:

- handle networks of unlimited size;
- use a wide variety of standard closed/open conduit shapes as well as natural channels (**Figure 9.7**);
- model special elements such as storage/treatment units, flow dividers, pumps, weirs, and orifices;
- apply external flows and water quality inputs from surface runoff, groundwater interflow, rainfall-dependent infiltration/inflow, dry weather sanitary flow, and user-defined inflows;
- utilize either kinematic wave or full dynamic wave routing methods;
- model various flow regimes, such as backwater, surcharging, reverse flow, and surface ponding; and
- apply user-defined dynamic control rules to simulate the operation of pumps, orifice openings, and weir crest levels.

In addition to modelling the generation and transport of runoff flows, SWMM can also estimate the production of pollutant loads associated with this runoff. The following processes can be modelled for any number of user-defined water quality constituents:

- dry-weather pollutant build-up over different land uses;
- pollutant wash-off from specific land uses during storm events;
- direct contribution of rainfall deposition;
- reduction in dry-weather build-up due to street cleaning;
- reduction in wash-off load due to BMPs;
- entry of dry weather sanitary flows and user-specified external inflows at any point in the drainage system;
- routing of water quality constituents through the drainage system; and
- reduction in constituent concentration through treatment in storage units or by natural processes in pipes and channels.




Figure 9.7: Stormwater modeling (dual)

Typical applications of SWMM include:

- design and sizing of drainage system components for flood control;
- sizing of detention facilities and their appurtenances for flood control and water quality protection;
- flood plain mapping of natural channel systems;
- designing control strategies for minimizing combined sewer overflows;
- evaluating the impact of inflow and infiltration on sanitary sewer overflows;
- generating non-point source pollutant loadings for waste load allocation studies; and
- evaluating the effectiveness of BMPs for reducing wet weather pollutant loadings.

9.7 REFERENCES

- 9.1 FHWA. (2006). *Hydraulic Design of Energy Dissipators for Culverts and Channels*. Hydraulic Engineering Circular No. 14, Third Edition. U.S. Department of Transportation. Federal Highway Administration. Publication No. FHWA-NHI-06-086.
- 9.2 Haestad Methods. (2003). *Stormwater Conveyance Modeling and Design*. First Edition. Haestad Press, Waterbury, USA.
- 9.3 FHWA. (1986). *Culvert Inspection Manual*. U.S. Department of Transportation. Federal Highway Administration. Publication No. IP-86-2.
- 9.4 Wallingford, H.R. and Barr, D.I.H. (2006). *Tables for the Hydraulic Design of Pipes, Sewers and Channels* (8th edn.). (Volume 2). Thomas Telford, London, UK.
- 9.5 American Iron and Steel Institute. (1983). *Handbook of Steel Drainage and Highway Construction Products*. Washington, D.C.
- 9.6 American Concrete Pipe Association. (1978). *Concrete Pipe Design Manual*. ACPA, Washington, D.C.
- 9.7 PIPES. (2009). *Design Manual for Concrete Pipe Outfall Sewers*. Pipes, Infrastructural Products and Engineering Solutions Division. Concrete Manufacturers Association. South Africa.
- 9.8 FHWA. (2009). *Urban Drainage Design Manual*. Hydraulic Engineering Circular No. 22, Third Edition. U.S. Department of Transportation. Federal Highway Administration. Publication No. FHWA-NHI-10-009.

Notes:

[illegible]

CHAPTER 10 - ASSESSMENT OF THE HYDRAULIC CAPACITY OF EXISTING DRAINAGE STRUCTURES, APPLICATION OF FLOOD ROUTING AND THE VALUE OF MAINTENANCE

SJ van Vuuren and N Gomes

10.1 INTRODUCTION

SANRAL's mandate to provide and maintain the national road infrastructure has been extended to include existing provincial roads which have been designed and constructed to hydraulic design standards and criteria which may differ from those of SANRAL. Furthermore, upstream developments and changes in land use may alter the catchment's response to rainfall, resulting in changing characteristics of flood peaks and flood volumes for a given return period, T .

The hydraulic capacity of drainage structures of existing roads, which do not comply with the SANRAL requirements as reflected in **Section 8.3**, will have to be assessed in a structured manner to maintain road-user safety within the constraints of limited capital expenditure for the required upgrades of these structures. This has necessitated the redefinition of the design return floods, freeboard requirements, optimum design criteria and the inclusion of the influence of the upstream temporal storage volume (flood routing) on the required capacity of existing drainage structures.

In the following paragraphs the classification of the design return period for existing structures is reviewed, followed by the assessment of the hydraulic capacity of existing hydraulic structures and a description of flood routing. Finally, an example of the use of the software utility software developed for level-pool routing is discussed. The software which has been developed to assist in the hydraulic assessment of existing drainage structures is included on the supporting flash drive/DVD.

It should be emphasised that in this chapter the energy H refers to the energy upstream of the culvert with the reference level at the inlet of the culvert, i.e. the positional energy component, Z , is zero (This differs from the definition given in Chapter 7, Section 7.3, on culvert hydraulics).

Table 10.1: Road Map for assessment of the hydraulic capacity of existing drainage structures, application of flood routing and the value of maintenance

ROAD MAP 10						
Typical problems		Input information	Worked examples	Supporting software	Other topics	
Topic	Par.				Topic	Reference
Design return period for existing structures	10.2	Capacity of existing culverts and road classification	Worked examples have been included in the "Drainage Manual – Application Guide"	Utility Program for Level pool Routing, EPASWMM	Risk of overtopping and failure (LCC) and Flood calculations	Chapter 2 and 3
Flood routing	10.4	Inflow hydrograph, discharge characteristics and storage height relationship		EPASWMM, HEC-RAS	Discharge characteristics of culverts	Chapter 7
Increasing the hydraulic capacity of existing hydraulic structures	10.7	Up- and downstream conditions. Utilising of energy through the system and its impacts.		HEC-RAS	-	Chapter 7 and 11
Routine maintenance	10.8	Identification of problems such as silting, debris, scouring, development issues and vandalism		-	-	

10.2 DESIGN RETURN PERIOD REVIEW FOR EXISTING HYDRAULIC STRUCTURES

In the design of drainage structures for new projects ('Greenfield' projects), the design flood frequency is determined based on the road classification (RC) (**Section 8.2**) and the reference flood peak for a return period of 20 years, Q_{20} . The selected design return period, T is then used to determine the design flood, Q_T which is used to determine the required size of the culvert with a maximum upstream energy head, H , less than $1,2 D$ (D is the vertical dimension of the selected culvert). Furthermore, the flood with twice the design return period, Q_{2T} , is determined and tested for the selected culvert, ensuring that the selected culvert's upstream energy level is below the shoulder break point (SBP), with a maximum level of $2D$.

In cases of hydraulic structures on existing road sections where design criteria differs from those of SANRAL, the hydraulic assessment is conducted differently to that described in **Chapter 8**. This procedure for the assessment of the hydraulic capacity of existing hydraulic structures is discussed below.

10.3 HYDRAULIC REVIEW OF EXISTING ROAD-DRAINAGE STRUCTURES

10.3.1 Introduction

Based on the road classification and the suggested design return period, T obtained in accordance with **Chapter 8**, the existing culvert's hydraulic capacity will be reviewed for inlet and outlet control as discussed in **Chapter 7**. The freeboard for culverts and bridge structures will be assessed in accordance with **Sections 8.1** and **8.3**.

In the following paragraphs the assessment of existing culverts (**paragraph 10.3.2**) and existing bridges (**paragraph 10.3.3**) is discussed separately.

10.3.2 Procedure for the hydraulic assessment of existing culverts operating under inlet control

10.3.2.1 Hydraulic control at the culvert

The sizing of culverts operating at inlet controlled structures is based on the notion of the most economical size which is related to an upstream energy head, H in relation to the vertical dimension of the culvert, D . The economical size on which the hydraulic design of culverts is based, is associated with a ratio of $H/D = 1,2$ for inlet- and outlet-controlled conditions. In the cases where freeboard is required, the contents in the following paragraph do not necessarily apply.

Although most culverts operate under inlet-control conditions, it is important that the hydraulic capacity under outlet (or downstream) conditions should also be verified in accordance with the procedures described in **Chapter 7**.

The review of the current capacity of existing culverts, operating under inlet control, is discussed below. Prior to the implementation of the following procedure, the hydraulic control of the culvert should be established for the design flow rate, Q_T .

10.3.2.2 Determination of the current capacity of the culvert

When it has been established that the existing culvert operates under inlet control conditions, the hydraulic capacity should first be calculated for the condition associated with $H/D = 1,2$. This is referred to as the **current hydraulic capacity of the culvert**, Q_{C1} . At an energy head of $H = 1,2 D$, the energy level, in this discussion, is (normally) assumed to be below the shoulder break point (SBP).

Setting the upstream energy level to the SBP or to 2D (whichever is the lowest), **the associated existing hydraulic capacity, Q_{C2}** , can be determined which in the case of a new project (a Greenfield project), should be sufficient to handle the design discharge of Q_{2T} .

10.3.2.3 Reducing the road class for existing hydraulic structures

The design criteria, without any relaxation as applicable to new projects (Greenfield projects), require that $Q_{C1} \geq Q_T$ and $Q_{C2} \geq Q_{2T}$. Should either of these criteria not be met, the road class may be reduced to RC_{-1} ($RC_{-1} = RC_0 - 1$), the next lower road class, for which the required design return period can be determined as indicated before. The lower design flood, Q_{T1} associated with the lower road classification, RC_{-1} , should then be compared with the current hydraulic capacity, Q_{C1} . It is important to validate that the control of the system, at a discharge of Q_{T1} and Q_{2T1} is the inlet control before proceeding with the hydraulic analysis of the culvert.

If the total upstream energy head, H , to maintain the reduced discharge, Q_{T1} , associated with the lower road class, RC_{-1} , is less than $1,2 D$, it is assumed that the hydraulic capacity of the culvert is sufficient.

Should the upstream energy head, H for the discharge of Q_{2T1} be above the SBP or more than $2D$, the capacity of the culvert is insufficient and consideration should be given to improve the capacity by altering the inlet or changing the vertical alignment of the road and increase the size of the hydraulic structure. The revised level of the SBP should be reassessed for the flow rate of Q_{2T1} ensuring that the criteria related to the storage volume and time during which the level will be in excess of $1,2 D$ are adhered to, as is indicated in **paragraph 10.3.2.4**.

10.3.2.4 Reviewing the influence of temporal storage on the required hydraulic capacity for existing structures with insufficient hydraulic capacity

If the total upstream energy head, H , to maintain the reduced discharge, Q_{T1} , associated with the lower road class, RC_{-1} , is more than $1,2 D$, and the total energy head H for the discharge of Q_{2T1} is below the SBP, the hydraulic capacity of the culvert is deemed insufficient. In this event, before deciding on replacement of the culvert, a check should be carried out on the potential influence of storage against the road embankment on the energy head H associated with the flow of Q_{2T1} .

Before proceeding with a full flood routing it is recommended that a preliminary manual check from a contour survey plan be conducted to obtain an indication of the storage available for a depth of $1,2 D$, which should be at least 25% of the volume of the triangular hydrograph depicted in **Figure 10.1**.




Figure 10.1: Typical triangular and flat topped hydrographs

When flood routing is implemented there are two additional criteria which need to be evaluated. One being the maximum storage volume V_{T1} in relation to the volume of the runoff hydrograph (V_{storm}) for a triangular-shaped hydrograph; and secondly the duration during which the energy head exceeded the value of $1,2 D$ for an alternative flat-topped hydrograph. The suggested approach is that in the case of the flat-topped hydrograph, sensitivity analyses should be conducted with the flat top of the hydrograph between 1 and 2 times the time of concentration.

No upgrade of the culvert is required if the following two criteria are met:

- Firstly, the maximum temporal storage should be less than 0.5 times the volume of the storm resulting from a triangular-shaped hydrograph (V_{storm}) with a peak discharge equal to Q_{2T1} .
- Secondly, the duration for the energy level to exceed the value of $1,2 D$ for a flat-topped hydrograph should be less than 0.5 times the time of concentration, T_c .

It should be noted that these criteria might change based on further analyses and it is recommended that in special circumstances the matter be referred to SANRAL.

10.3.2.5 Alternatives to be considered to improve the hydraulic capacity of existing culverts

The procedure and the possible outcomes of the assessment which were discussed above are shown in **Table 10.2**.

Table 10.2: Summary of the possible outcomes from the assessment of the hydraulic capacity of existing drainage structures for a road classification, RC_{-1} , one less than the required classification

Assessment of the upstream total energy head, H in relation to the vertical dimension of the existing culvert, D for the design discharge associated with a road class RC_{-1}		Action to be considered	Comment
Q_{T1}	Q_{2T1}		
$H/D \leq 1,2$	$H \leq SBP$	None	Capacity of existing culvert is sufficient.
	$H > SBP$	Improve the inlet conditions or change the vertical alignment [#]	Prevent inundation of the road by changing the vertical alignment (and if required extend the culvert).
$H/D > 1,2$	$H \leq SBP$	Routing of the flood	Routing of the different hydrographs to evaluate if whether the time of the storage could not potentially endanger the safe use of the road section. Use the flow rates associated with a road class, RC_{-1} .
	$H > SBP$	Increase the size of the culvert	Determine the required culvert size for the road class RC_0 and the design discharge Q_T and Q_{2T} .

Note: # Check the time of inundation for the time when H is above $1,2 D$ for different flat-topped hydrographs.

A flow diagram in two parts is given in **Figure 10.2** and **Figure 10.3** which demonstrates the procedure that was introduced and discussed above. The notation used in **Figure 10.2** is explained in **Table 10.3**.

Table 10.3: Clarification of the notation used in flow diagram

Symbol	Units	Definition
T_c	h	Time of concentration. This reflects the duration of a storm event for the whole catchment to contribute to the discharge (associated with the rational flood calculation procedures).
Q_{20}	m ³ /s	The index flood for the contributing catchment with a return period of 20 years.
RC_0	none	The original road classification based on the criteria in Section 8.2 .
Q_{T0}	m ³ /s	The design flood for the design return period which was obtained from the review of the road classification, RC_0 and the index flood, Q_{20} . Figure 8.2 refers.
Q_{2T0}	m ³ /s	This is the flow rate related to a return period twice that which was obtained for the design flood, Q_{T0} .
Q_{C1}	m ³ /s	The maximum calculated existing inlet capacity of the culvert by limiting the total energy head to be equal to $1,2 D$. D reflects the vertical dimension of the existing culvert.
Q_{C2}	m ³ /s	The maximum calculated current existing hydraulic capacity of the culvert by limiting the total energy head to be equal to the shoulder brake point (SBP).
RC_{-1}	none	This reflects the selection of a road classification which is one class less than that determined for the road in accordance with Section 8.2 .
Q_{T1}	m ³ /s	The design flood for the design return period which was obtained from the review of the road classification, RC_{-1} and the index flood, Q_{20} . Figure 8.2 refers.
Q_{2T1}	m ³ /s	The flood rate related to a return period twice that which was obtained for the design flood, Q_{T1} .
V_{T1}	m ³	The maximum storage volume upstream of the culvert assuming level-pool routing conditions and an inflow hydrograph with a peak flow rate of Q_{T1} and a triangular distribution with a base width of $3 T_c$ and the peak discharge occurring at T_c .
V_{storm}	m ³	The calculated storm volume based on the assumption of an inflow hydrograph with a peak flow rate of Q_{T1} and a triangular distribution with a base width of $3 T_c$ and the peak discharge occurring at T_c .
T_s	h	The total time during the routing of the flood when the upstream energy head is more than $1,2 D$.

The above notation is used in the flow diagrams shown in **Figure 10.2** to **Figure 10.5** which set out the procedures for the review of the hydraulic capacity of existing drainage structures operating under inlet control.




Figure 10.2: Flow diagram for the assessment of the hydraulic capacity of existing drainage structures operating under inlet control (Overview)




Figure 10.3: Flow diagram for the assessment of the hydraulic capacity of existing drainage structures operating under inlet control (Reviewing the current capacity for road class, R_{C0})




Figure 10.4: Flow diagram for the assessment of the hydraulic capacity of existing drainage structures operating under inlet control (Reviewing the current capacity for road class, R_{C1})




Figure 10.5: Flow diagram for the assessment of the hydraulic capacity of existing drainage structures operating under inlet control (Flood routing)

Table 10.4: Description of the actions to be undertaken when existing hydraulic structures are reviewed

Step number from Figure 10.2 to Figure 10.5	Short description of the actions to be taken
1	The index flood, Q_{20} is determined in accordance with the methods discussed in Chapter 3 .
2	The road classification, RC_0 , is a function of the road function and number of vehicles using the road in accordance with Section 8.1 .
3	The capacity of a hydraulic structure will be determined by considering inlet and outlet control. Chapters 4 and 7 should be reviewed.
4	The hydraulic capacity, Q_{C2} , with the water level at the SBP, can be determined by considering inlet and outlet control as illustrated in Chapters 4 and 7 .
5	Based on the definition of the road class in Section 8.1 with insufficient hydraulic capacity, the road classification is lowered with one. This lower road classification is defined as RC_{-1} .
6	Based on the RC_{-1} the design floods Q_{T1} and Q_{2T1} can be determined for return periods T_1 and $2T_1$.
7	The hydraulic capacity is sufficient for the reduced road classification RC_{-1} and no alterations to the existing culvert capacity are required.
8	With insufficient capacity at a reduced road classification, RC_{-1} , flood routing (influence of temporal storage) should be considered.
9	Obtain sufficient surveyed upstream cross sections to be able to determine the upstream storage characteristics.
10	Derive a relationship of the upstream storage volume and the inlet discharge characteristics as a function of the upstream energy head, H .
11	Determine the temporal maximum storage volume, V_{T1} and compare it with a portion of the volume of the runoff hydrograph (V_{storm}).
12	The culvert size should be increased. The design flow rate to be used in the determination of the required culvert size is associated with the road's original class, RC_0 and the associated design flow rates, Q_T and Q_{2T} .
13	Determine the time duration, T_s during the routing of the appropriate inflow hydrograph, where the upstream energy level was in excess of $1,2 D$ and compare it with the time of concentration, T_c .
14	The culvert size should be increased. The design flow rate to be used in the determination of the required culvert size is associated with the road's original class, RC_0 and the associated design flow rates, Q_T and Q_{2T} .
15	The existing culvert capacity is sufficient and no redesign is required.
16	The drop in the approaching velocity upstream from the culvert is due to the reduction in the cross-sectional flow area of the culvert. This could potentially result in sedimentation upstream of the culvert and erosion downstream of the culvert. Sedimentation remains a complex problem but the aspect needs to be reviewed in accordance with the procedures reflected in Chapter 5 and Chapter 7 .
17	The final culvert size will be determined by considering the life-cycle cost of the different alternatives.

10.3.3 Procedure for the hydraulic assessment of existing bridges

The determination of the design flood frequency, T , the required freeboard F_D , and the calculation of the backwater or afflux, has been discussed in **Chapter 8**. The hydraulic review of the capacity of any existing bridge will be done based on the road classification, RC_0 , and the available freeboard for the two flow regimes through the bridge, i.e. sub- and critical flow conditions as discussed in **Chapter 8**.

If the freeboard requirement is not met for the road class, RC_0 , one lower road class RC_{-1} could be assumed similar to the procedure described in paragraph 10.3.2. If the calculated freeboard is less than the required freeboard or the upstream Froude number is more than 0,8, the bridge opening is insufficient for the reduced road classification RC_{-1} and needs to be upgraded or augmented in accordance with the procedures and hydraulic capacities discussed in Chapter 8.

Flood routing is discussed in paragraph 10.4.

10.4 FLOOD ROUTING

10.4.1 Basic theory of flood routing

Flood routing can be defined as the influence of the storage characteristics, between two spatial boundaries, on the discharge characteristics between the inlet and outlet flow rates when a specific hydrograph is assessed.

Two distinct differences between the inflow and outflow hydrographs can be determined by flood routing. The differences resulting from flood routing are shown by the reduction in the maximum discharge between the inflow and the outflow from the culvert (attenuation) and the point in time when the peak discharge will occur, referred to as the translation (time lag between the occurrence of the peak inflow and outflow hydrographs).

Figure 10.6 reflects a typical inflow and outflow hydrograph for a hydraulic structure where the maximum rate of outflow is less than the maximum rate of inflow resulting from the discharge characteristics and the available temporal storage.




Figure 10.6: Typical inflow and outflow hydrographs when flood attenuation occurs

Based on the above differences in the hydrographs it is possible to determine the change in the storage volume for a time step, dt , is reflected in Figure 10.7.




Figure 10.7: Change in the storage volume for a time step dt

By plotting the change in the storage volume and the total required temporal storage volume as is shown in **Figure 10.8**, the following deductions can be made:

- The maximum outflow will occur at the point in time when the inflow and outflow hydrographs intersect.
- The maximum change in the storage volume occurs when the inflow hydrograph peak is reached.
- The maximum storage volume is reached when the inflow and outflow rates are equal.




Figure 10.8: Change in the storage volume and the total storage volume

Limited recorded flow-stage data are available to determine the form of the inflow hydrograph which is normally simplified by assuming a triangular or trapezoidal shape. In the following paragraphs reference is made to recent research findings related to the form of the hydrograph, governed by the shape of the catchment and the temporal and spatial distribution of the rainfall.

Two main categories of flood-routing procedures can be identified ^(10.3) based on the fundamentals used to derive the relationship between the inflow and outflow hydrographs. The first method uses the principle of the continuity of mass while the second procedure uses the theory of unsteady (gradually varied flow) flow. In the case of road drainage structures the preferred method is to apply the principle of mass continuity. Level-pool routing provides satisfactory results for flood routing at culverts and is the proposed procedure. In the case where the routing along an open channel needs to be reviewed, the river routing (Muskingum) procedure will be used. Both these procedures are briefly discussed below.

10.4.2 Level-pool routing

The temporal storage upstream of a road-drainage structure which influences the discharge through the culvert can be modelled by the 'level-pool' procedure. When the stage-storage relationship upstream of the reservoir is favourable for temporary storage, a smaller culvert section could be considered. The attenuation of the flow through the smaller culvert will reduce the peak discharge through the culvert. The effect of the temporary storage on the inflow hydrograph is not limited to the reduction of the peak-flow rate (attenuation), but would also cause the peak flow to occur at a later time.

The principle of the continuity of mass forms the basis of flood-attenuation calculations. This is applied for a given time step, Δt over which the average inflow, \bar{I} , minus the average outflow, \bar{O} , should be equal to the change in the storage volume, ΔS . This can be written as follows:

$$\bar{I}\Delta t - \bar{O}\Delta t = \Delta S \quad \dots(10.1)$$

where:

$$\begin{aligned} \bar{I} &= \text{average inflow (m}^3/\text{s)} \\ \bar{O} &= \text{average outflow (m}^3/\text{s)} \\ \Delta S &= \text{change in storage volume (m}^3\text{)} \\ \Delta t &= \text{time step that is used (s)} \end{aligned}$$

This relationship may be written as:

$$\frac{I_1 + I_2}{2} \Delta t - \frac{O_1 + O_2}{2} \Delta t = S_2 - S_1 \quad \dots(10.2)$$

where:

$$\begin{aligned} \frac{I_1 + I_2}{2} \Delta t &= \text{average volumetric inflow (m}^3\text{)} \\ \frac{O_1 + O_2}{2} \Delta t &= \text{average volumetric outflow (m}^3\text{)} \\ S_2 - S_1 &= \text{change in storage volume (m}^3\text{)} \end{aligned}$$

This relationship may also be written as follows:

$$S_2 - S_1 = \frac{I_1 + I_2}{2} \Delta t - \frac{O_1 + O_2}{2} \Delta t \quad \dots(10.3)$$

If the known terms are grouped together, it follows that:

$$\left(\frac{S_2}{\Delta t} + \frac{O_2}{2} \right) = \left(\frac{S_1}{\Delta t} + \frac{O_1}{2} \right) + \frac{I_1 + I_2}{2} - O_1 \quad \dots(10.4)$$

It is helpful to develop a graphical relationship between the function $\left(\frac{S_1}{\Delta t} + \frac{O_1}{2} \right)$ and the outflow O_1 for a selected time step Δt . This is referred to as the auxiliary function, N vs. O , which is used to simplify the solution of the outflow time relationship, as shown in **Figure 10.9**.

With $\left(\frac{S_2}{\Delta t} + \frac{O_2}{2} \right) = N_2$ and $\left(\frac{S_1}{\Delta t} + \frac{O_1}{2} \right) = N_1$, the solution could then be written as follows:

$$N_2 = N_1 + \frac{I_1 + I_2}{2} - O_1 \quad \dots(10.5)$$

where:

$$N = \text{auxiliary function (m}^3/\text{s)}$$

The inflow hydrograph is normally given or could be obtained from the methods given in **Chapter 3**. Furthermore, for a given stage at the culvert entrance the outflow rate, O , may be determined from the methods described in **Sections 7.3** and **7.4**. **Figure 10.9** reflects a typical example of an auxiliary curve.




Figure 10.9: Typical auxiliary curve

Beginning at time $T = 1$, with a known outflow, O_1 and known inflow relationship, $I_1, I_2, I_3, \dots, I_n$ and storage value, S_1 and the relationship for N_i determined from Equation (10.5), N_2 can be solved and from the auxiliary function (Equation 10.6 or **Figure 10.9**), O_2 can be determined.

In summary, the level-pool routing analysis is performed as follows:

- Use the hydrological calculations (**Chapter 3**) to obtain an inflow hydrograph (discharge - time curve) for the catchment contributing to the flow which has to be handled by the culvert for a selected design return period, T .
- Determine the storage volume (S) for different water levels at the site, and assume that the storage volume = 0 at the invert level of the culvert (assume that any storage volume below this invert will not result in any attenuation).
- Use the dimensions of the existing culvert or select a suitable size for the analysis by employing **Figure 7.4** (if temporal storage is considered, the required discharge will decrease as discussed in **paragraph 10.3.2**).
- Determine the head/discharge relationship for inlet-controlled conditions in accordance with the relationships reflected in **Table 7.2**.
- Draw a graph showing the relationship between outflow (O) and the auxiliary function, N .

$$N = \frac{S}{\Delta t} + \frac{O}{2} \quad \dots(10.6)$$

where:

- S = temporal storage or ponding volume (m^3)
- Δt = selected time increments (say, 0.1 of time from the start of the inflow to the peak inflow (time of concentration or the lag time)) (s)
- O = outflow through culvert (m^3/s)

- For each time increment Δt , calculate the change in the value of the auxiliary function, ΔN .

$$\frac{I_1 + I_2}{2} - O_1 = \Delta N \quad \dots(10.7)$$

where:

I_1 and I_2 = the inflows into the storage area upstream of the culvert at times t_1 and t_2 , respectively, with $(\Delta t = t_2 - t_1)$ and O_1 = the outflow rate at the previous time, t_1

- Calculate successive values of N by setting $N_2 = N_1 + \Delta N$. Corresponding values of the outflow, O , for known N -values, can be read off the graph which represents the relationship between N and the outflow rate, O (auxiliary graph).
- The maximum discharge coincides with the maximum energy head (energy head at the culvert inlet) which can thus be calculated.

If required, an alternative culvert with different dimensions could be assessed by repeating the above steps until a satisfactory solution is found.

10.4.3 River routing

10.4.3.1 Introduction

In the case of the assessment of temporal storage in a river or channel where the water level is not horizontal, the storage volume between any two sections in the river affected by the gradually varied flow becomes a function of the stage at both the upstream and downstream side of the river reach. The storage volume in a typical reach, **Figure 10.11**, consists of prismatic and wedge-shaped sections.

Based on the continuity principle:

$$\frac{dS}{dt} = I - O \quad \dots(10.8)$$

where:

$\frac{dS}{dt}$ = the change in storage over the time step of dt (m^3)

S = sum of the storage volume of the prism and the wedge (m^3)

$I - O$ = difference between the inflow (I) and the outflow (O) (m^3/s)

10.4.3.2 Principles of river routing

In the case of a natural (river) or artificial channel where the water depth, y for a certain reach cannot be assumed to be constant (dy/dx is not zero) due to the change in flow rate over a time step, dt , the storage volume in the river or channel reach becomes a function of the stages at both the upstream and downstream sections of the reach. Depending on the stage of the movement of the hydrograph from the upstream to the downstream side of the reach the relative upstream and downstream flow depths will differ. The possible flow profiles between the upstream (inflow to the reach, I) and the downstream side (outflow from the reach, O) of the reach is reflected in **Figure 10.10**.




Figure 10.10: Different water profiles during unsteady flow conditions

In the case where the upstream section experiences the increase in discharge, the storage volumes in the reach may be defined as graphically shown in **Figure 10.11**.




Figure 10.11: Storage components in a river reach

10.4.3.3 Hydraulic relationships applicable to river routing

Based on the continuity of mass, it can be postulated that the change in storage volume in a river reach over a time step, dt , is equal to the difference between the average inflow minus the average outflow over the time step. The storage volume, S under unsteady flow conditions will comprise of a prismatic storage volume and a wedge-shaped storage volume, refer to **Figure 10.11**.

Ignoring the change in the water profile between the upstream and downstream sections of the reach it can be assumed that the prismatic storage volume is related to the flow depth on the downstream side of the reach (O). Furthermore the wedge-shaped volume is the result of the difference between the flow rate on the upstream - (I) and downstream side (O) of the reach.

The assumption can therefore be made that the wedge-shaped storage volume should be a function of the difference between the inflow and the outflow ($I-O$). In **Figure 10.10**, the following conditions are illustrated:

- Inflow (I) is larger than the outflow (O) – reflecting the rising limb of the hydrograph at the upstream end of the reach. This constitutes an additional volume and should be added to the prismatic volume to obtain the total storage in the reach (S).
- Inflow (I) is less than the outflow (O) – reflecting that the falling limb of the hydrograph has reached the upstream section of the reach. This will result in a negative wedge volume which should be subtracted from the prismatic storage volume to determine the total storage volume for the reach (S).
- Inflow (I) is equal to the outflow (O) – this reflects a steady-state condition where the wedge shaped storage volume is zero.

The total storage volume of the reach, S can be represented by the following relationship:

$$S = f_1(O) + f_2(I - O) \quad \dots(10.9)$$

This relationship is more complex than the relationship which was previously used for level-pool routing because the storage volume is a function of the inflow (I) and the outflow (O). By using a finite-difference method similar to that in Equation (10.2), it is possible to determine the unknown storage volume after a time step, dt .

In the Muskingum method ^(10.2) it is assumed that the function f_1 and f_2 can be approached by straight-line functions as shown below:

$$f_1(O) = KO \quad \text{and} \quad f_2(I - O) = b(I - O)$$

From these assumptions it follows that:

$$S = bI + (K - b)O \quad \dots(10.10)$$

$$S = K\left[\frac{b}{K}I + \left(1 - \frac{b}{K}\right)O\right]$$

If $\frac{b}{K} = x$ then it follows that:

$$S = K[xI + (1 - X)O] \quad \dots(10.11)$$

In this simplification, x is a dimensionless weighting factor indicating the relative importance of the inflow (I) and the outflow (O) in determining the storage (S) in the reach. The value of x has limits between zero and 0.5 with typical values in the range 0.2 to 0.4. Furthermore K has the dimensions of time.

Based on the continuity of mass and by substituting the above relationships the storage can be determined as follows:

$$\frac{1}{2}(I_1 + I_2)\Delta T - \frac{1}{2}(O_1 + O_2)\Delta T = K[xI_2 + (1 - X)O_2] - K[xI_1 + (1 - X)O_1] \quad \dots(10.12)$$

and by rearranging the terms it follows:

$$O_2(-0,5\Delta T - K + Kx) = I_1(-Kx - 0,5\Delta T) + I_2(Kx - 0,5\Delta T) + O_1(-K + Kx + 0,5\Delta T) \quad \dots(10.13)$$

Then it follows that:

$$O_2 = c_1 I_1 + c_2 I_2 + c_3 O_1$$

where:

$$c_1 = \frac{\Delta T + 2Kx}{\Delta T + 2K - 2Kx}$$

$$c_2 = \frac{\Delta T - 2Kx}{\Delta T + 2K - 2Kx}$$

$$c_3 = \frac{-\Delta T + 2K - 2Kx}{\Delta T + 2K - 2Kx}$$

and:

$$c_1 + c_2 + c_3 = 1$$

The application of the Muskingum method requires that the values of K and x are known. This makes it possible to calculate the c coefficients.

Recorded inflow and outflow hydrographs for the river reach are used for which a trial value of x is taken and the weighted flow in the reach $[xI + (1 - X)O]$ is plotted against the storage volume (S) in the reach as shown in **Figure 10.12**.




Figure 10.12: Plots of the weighted flow in the reach against the storage volume in the reach for different trial values of x

The correct value for x (**Figure 10.12 (c)**), will provide an approximated straight-line plot, confirming the relationship:

$$S = K \left[\frac{b}{K} I + \left(1 - \frac{b}{K} \right) O \right] \quad \dots(10.14)$$

As shown in **Figure 10.12**, the slope of the plot represents the value of K . With K known, the values of c_1 , c_2 and c_3 can be determined.

Other river/channel routings are also available ^(10.3). Alternatively the routing can be conducted using a numerical model such as HEC-RAS, which has been included on the flash drive/DVD at the back of this Manual. Worked examples can be reviewed in the *Drainage Manual - Application Guide* ^(10.4).

10.5 DIFFERENT FORMS OF INFLOW HYDROGRAPHS

A recent study (Görgens, 2007) reviewed the recorded peak-flow events for 43 catchments in South Africa and derived 'typical hydrographs' for regional areas in South Africa ^(10.1). The information obtained from the study reflected that, for large catchments, different hydrograph forms are possible and that there is no correlation between the return periods for the flood peak and the flood volume. **Figure 10.13** reflects the typical hydrographs for the 'high' K region.




Figure 10.13: Typical flood hydrographs for the 'high' Kovacs region ^(10.1)

These variant forms of the inflow hydrographs could change the hydraulic performance and risk of potential failure of the structure. This aspect needs to be considered by the designer, especially when the contributing catchment area is more than 50 km².

10.6 UTILITY PROGRAM FOR LEVEL-POOL ROUTING

The purpose of the utility software named '**Assessment of existing drainage structures**' is to calculate the upstream water level, the outflow hydrograph and the time for which the upstream water level will exceed 1,2D for inlet-controlled conditions and level-pool routing. The information required to conduct the analysis is reflected in **Table 10.5**.

Table 10.5: Information required to conduct an assessment of the level-pool routing through an inlet-controlled culvert

Information	Relationship / Units
Inflow hydrograph	Flow rate against time, m ³ /s
Upstream storage volume	Storage volume as a function of the flow depth, m ³
Inlet capacity of the culvert	Inlet capacity as a function of the upstream energy head, m ³ /s
Time step	The time step required for the analyses, seconds

Figure 10.14 shows the graphical output of the utility software '**Assessment of existing drainage structures**'.

The level-pool routing utility is included on the flash drive/DVD which is attached to the document.




Figure 10.14: Graphical representation of the inflow and outflow hydrographs and the duration when the ratio of $H/D=1,2$ is exceeded

10.7 REMEDIAL ACTIONS TO BE CONSIDERED TO INCREASE THE HYDRAULIC CAPACITY OF EXISTING HYDRAULIC STRUCTURES

Based on the procedure to evaluate the capacity of existing culverts in **paragraph 10.3.2**, it is also possible to increase the capacity of existing inlet-controlled culverts by the addition of a steep enlarged upstream section (**Section 7.4**) or by improving the inlet conditions of the culvert. A major problem associated with insufficient hydraulic capacity is the sedimentation and blockage of culverts (see **Photograph 10.1**).



Photograph 10.1: An example of a culvert blocked by sedimentation on the N1 (Photo courtesy of Nuno Gomes)

Alternative culvert inlet layouts to minimise the problem of siltation is currently reviewed. **Photograph 10.2** shows an example of a culvert inlet where limited siltation is experienced.



Photograph 10.2: Alteration to the culvert inlet to prevent siltation (Photo courtesy of Nuno Gomes)

The expected research findings now undertaken for SANRAL, will reflect the effectiveness and cost of these alternative layouts and provide typical dimension for these culvert inlets.

Another complication of excessive energy heads upstream of the culvert is the high velocities which are created downstream of the structure which could lead to excessive erosion as is shown in **Photograph 10.3**. **Chapter 7 and 8** provides some guidance on scour protection, including references to readily available design sources.



Photograph 10.3: Example of excessive erosion which occurred downstream from the culvert

10.8 ROUTINE MAINTENANCE

10.8.1 Introduction

Regular maintenance of hydraulics structures is absolutely critical. Most of the premature road prism and verge failures can be attributed to the inability of surface and subsurface water to be drained from the road reserve as soon as possible.

The maintenance team must regularly conduct visual inspections to assess the drainage structures and determine the maintenance requirements. In the following paragraphs some guidance on aspects to consider during a routine inspection are highlighted.

10.8.2 Aspects to consider during routine inspections

Vegetation, mostly grass, will not allow access to the hydraulic structures for proper inspections. While vegetation is extremely important for the prevention of erosion in the road reserve, it needs to be maintained and kept short as is shown in **Photograph 10.4**. Long grass will retard water movement and cause deposition of sediments which could ultimately lead to costly maintenance.



Photograph 10.4: Well-maintained lateral drainage channel

Trees and bushes should not be allowed to grow in the vicinity of drainage structures, such as bridge abutments and culvert inlets or outlets. The roots of small trees and bushes can cause drainage structures to eventually crack. It is not uncommon to find abutment walls and wing walls damaged by the roots of trees in the close proximity of hydraulic structures.

Sometimes it will be necessary to work outside the road reserve, especially downstream of culvert outlets. Under these circumstances it is important to ensure that water does not pond near the outlet of culverts, by opening an adequate length channel outside the road reserve until the water drains away freely. The maintenance team must ensure that permission from the owner of the adjacent property is obtained before any work outside the road reserve is carried out.

10.8.3 Influence of development close to road infrastructure


Freeways in major cities are being encroached upon by developments. There is a tendency to develop adjacent to freeways because of the exposure, especially for businesses, and also to obtain access to the freeway.

New developments change the pre-development drainage parameters and tend to increase the peak flows, especially when attenuation structures are not provided and the time of concentration is reduced within the development. Increased peak flows are then discharged into the road reserve at specific outlet points with higher velocities. It is critical that the outlet points link into the existing drainage system, preferably below the surface, without causing any additional maintenance effort. When the existing system does not have enough additional capacity to accommodate the increased peak flow, jacking of an additional structure under the highway may be the only solution. When attenuation facilities within developments are provided, it is critical that they be maintained because there will be no attenuation when the pond is totally silted up.

10.8.4 Alternative materials to reduce theft and damage to hydraulic structures

An additional problem, mostly in urban areas, is the theft of steel drop inlet grids. Grid designs, which use alternate materials with no scrap value, are a necessity.

Successfully implemented designs include a fibre reinforced high strength concrete drop inlet grid (**Photograph 10.5**), an externally reinforced fibre glass quartz epoxy (**Photograph 10.6**) drop inlet grid and a reinforced concrete median drop inlet grid; all are in current use, having passed the required load tests.



Photograph 10.5: Fibre reinforced concrete grid inlet

More informal developments are being constructed adjacent to predominantly rural roads, without any proper drainage designs or town planning. The buildings often impede the flow of water from and to the road reserve. Illegal accesses can also cause problems because side drains are simply filled in resulting in storm water not being able to flow free past the intersections.



Photograph 10.6: Glass fibre drop inlet

10.8.5 General problems

Maintenance staff often finds that subsurface drainage structures were omitted in the initial design of some rural roads. It is false economy to have designs that exclude subsurface drainage, especially in road cuttings. Lack of subsurface drainage causes the road layers to be permanently wet; this in turn leads to the failure of the pavement and the formation of potholes. The result is costly pavement maintenance.

Scour of un-grassed side channels remains a problem (**Photograph 10.7**), especially when water velocities are excessive and the soils have very little or no clay fraction. The use of stepped channels, using gabions is a relatively low cost solution. Concrete stepped channels are preferable because of the reduced maintenance costs over the long term, even though they are initially more expensive.



Photograph 10.7: Un-grassed side channels leads to erosion

Silting of culvert inlets is a problem especially in rural areas (**Photograph 10.8**). This is mainly due to the number of earth side drains in use and the low water velocities at some of the culvert inlets. A possible solution is to introduce drop structures as was shown in **Photograph 10.2**.



Photograph 10.8: Siltation of culvert inlets

Scour at bridges is always a problem (**Photograph 10.9**) which can lead to the failure of abutment walls, piers/columns and caissons. Frequent inspections are essential to identify the problems before the infrastructure is seriously damaged. Early remedial actions, which include the use of rip rap, gabions and “Reno mattresses” as shown in **Photograph 10.10** are far less costly than partial or total reconstruction of the bridge.



Photograph 10.9: Scour at a bridge pier



Photograph 10.10: Repair of scour damage which occurred at bridge shown in Photograph 10.9

Scour at the outlet of culverts remains a problem due to excessive water velocities and the lack of energy dissipation structures (**Photograph 10.3**). The most common solution is the use of a wide “Reno Mattresses”, or rip rap, downstream of the outlet apron slab as is shown in **Photograph 10.11**.



Photograph 10.11: Repair to the erosion damages reflected in Photograph 10.3

The maintenance of cut-off drains and fills is extremely important because the lack thereof could result in slope failures and slips at road cuttings and embankment failure as is depicted in **Photograph 10.12**.



Photograph 10.12: Embankment failure

Fencing across culvert inlets remains a problem (**Photograph 10.13**) because vegetation, including tree branches, can form a barrier which impedes the natural flow of water into the culvert, causing water to back up and eventually flow over the road. Damage to the road and the culvert can create serious safety problems and alternative fencing layouts should be implemented.



Photograph 10.13: Fences across the inlet of culverts will lead to undesirable blockages

In areas where dolomite occurs special care must be taken with all drainage structures. Under no circumstances may standing water occur, especially in the road reserve. Culverts must be watertight to prevent leakage.

Lack of, or improper maintenance of drainage structures in areas where dolomite is present may result in the formation of sinkholes with possible catastrophic consequences (**Photograph 10.14**). Remedial repairs to sinkholes are extremely costly and special care should be taken to prevent it.



Photograph 10.14: Sinkhole formed on the median of the N14

In conclusion it must be emphasised that failures to drainage structures can be prevented by timely maintenance, reacting on the priorities obtained from the inspection of these drainage structures on a regular basis. Potential failures can only be prevented if they are identified in time and when the required preventative maintenance has been undertaken.

10.9 REFERENCES

- 10.1 Görgens, A. (2007) *Joint Peak-Volume (JPV) Design Flood Hydrographs for South Africa*. WRC Report No. 1420/3/07. Water Research Commission, Pretoria, South Africa.
- 10.2 McCarthy, G.T. (1938) *The unit hydrograph and flood routing*. Unpublished conference of the US Army Corps of Engineers. Sited in Shaw, E.M.
- 10.3 Shaw, E. M. (1994) *Hydrology in Practice* (Third edition). Chapter 16. Chapman and Hall. ISBN 0-412-48290-8. pp 408 – 413.
- 10.4 Kruger, E.J. (Editor), Rooseboom, A. Van Vuuren, S.J., Van Dijk, M., Jansen van Vuuren, A.M., Pienaar, W.J., Pienaar, P.A., James, G.M., Maastrecht, J. and Stipp, D.W. (2013). *Drainage Manual – Application Guide*. 6th ed Fully Revised. The South African National Roads Agency SOC Ltd.
- 10.5 B Durow. (2012). *Personal communication providing valuable practical input*.

Notes:

Lined area for notes.

CHAPTER 11 – MODELLING OF FREE SURFACE FLOW AND FLOOD LINE CALCULATIONS

M van Dijk and SJ van Vuuren

11.1 INTRODUCTION

The purpose of this chapter is to lay the groundwork for application of the concepts of free surface flow and river mechanics to the design, maintenance, and environmental problems associated with road crossings and encroachments.

Roads are artificial barriers for the natural flow of storm water. Based on certain design criteria the drainage structures are designed to hydraulically accommodate a specific recurrence interval storm event. The drainage structures almost always cause damming and its impact upstream thereof needs to be determined.

The necessity to determine the influence of road structures on the pre-developed flood lines needs to be determined to meet legislative requirements. The National Water Act Section 144 requires that a flood line needs to be determined prior to the development.

Increasing demands for residential, industrial and recreational areas within our towns and cities require the maximum beneficial utilization of all available land within their boundaries. This includes areas prone to flooding. However, encroachment of the flood zone not only involves a measure of risk to occupiers and owners of property within the flood zone, but may also result in raising the water levels during floods to the extent that other development at higher levels may be endangered.

Some development within flood zones cannot be avoided. This includes roads, railways, and the provision of services. Road and rail embankments may raise upstream water levels and concentrate flood flows. Bridge openings are often restricted by debris during major floods causing upstream water levels to rise still further. The magnitude of floods could be increased by urban development within the catchment area of a stream unless special measures are included in the layout and storm water drainage design of the upstream development.

The consequences of flooding are often more serious than the mere inundation and damage to the contents of buildings. There are many recorded floods in South Africa where lives were lost when residents were trapped in their homes. Buildings and other structures in the direct path of the enlarged river channel have been totally destroyed. Other buildings further from the main channel have collapsed due to scour or in the case of older buildings, due to poor construction methods. Severe structural damage has been caused by floating debris.

There have been instances where development within the flood zone has obstructed the path of flood water, raised the water levels, and concentrated the flows along roadways to the extent that these have become obstacles to evacuation rather than escape routes.

These are all factors which should be taken into account when making decisions relating to the decision of drainage structure (low level crossing, culvert or bridge).

This section will provide background and describe the methodology to determine the influence of these structures on flood lines.

11.2 UNCERTAINTY IN CONVEYANCE CALCULATION

There are different practitioner groups in flood management all with a need to establish river capacity for one of the following reasons:

- Planning and development control
- Flood forecasting

- River maintenance
- Design of new works
- Hydrometric data analysis

There are a number of difficulties that practitioners experiences when estimating flood lines of which the most significant are as follows:

1. Issues in uncertainty
 - The number of modeling methods and the variation in their results
 - The confidence of choice of Manning's n-value
 - Seasonal variability affecting vegetation
 - Lack of adequate calibration data / errors in data
 - Variation of parameters along a river reach
2. Gaps in knowledge
 - Effect of vegetation / hedges / banks / bushes on flow levels and extent of flooding
 - Interaction between the main channel and flood plain
 - Comparative benefit of different conveyance methods – validity of methods
3. Barriers to uptake of knowledge
 - Lack of understanding and consensus on the best approach arising from lack of confidence in knowledge
 - Tradition, risk from using the unfamiliar and inertia
 - The time to do project work coupled to the cost of the project (i.e. budget constraints)

There are differences between accuracy, error and uncertainty. Accuracy deals with the precision to which measurement or calculation is carried out; potentially, accuracy can be improved by better technology. Errors are mistaken calculations or measurements with quantifiable differences. Finally, uncertainty arises principally from lack of knowledge or of ability to measure or to calculate which gives rise to potential differences between assessment of some factor and its real value.

There are several contributions to uncertainty in the estimation of conveyance, the main ones being:

1. Process uncertainty which arises from the selection and approximation of physical processes and from parameterisation made to define conveyance.
2. Representation uncertainty from the density of the discrete survey points and interpolation rules, i.e. the difference between the shape of the river and the physical features on the flood plain as represented in the calculations and in “real” life
3. Data uncertainty from the limitations of the survey methods used
4. Uncertainties arising from parameter estimation – particularly the experience and expertise of the modelers who set up and calibrate computational models of river flows
5. Uncertainties from the model calculation methods, approximations and rules; and
6. Uncertainty from seasonal variations in vegetation, temperature etc.

The potential consequences of uncertainty and typical current methods of mitigation for the uncertainty are listed in **Table 11.1**.

Table 11.1: Potential consequences of uncertainty ^(11.2)

Management function	Consequence of uncertainty	Current mitigation strategy
Flood defence design	Under capacity of defences leading to potential failure below the design standard or over capacity potentially leading to morphological problems or lower economic return than planned. Over estimation of capacity of defences leading to lack of implementation of schemes due to excessive cost.	Undertake sensitivity analyses and add a freeboard to allow for under capacity
Real time forecasting	Under- (over-) estimation of lead times, inexact inundation extent, and incorrect retention times of floods.	Implement real-time updating procedures
Hydrometry and rating curve extension	Incorrect discharges with potentially large errors, influences flood forecasting and statistical estimation of flood flows for design, impacts upon cost-benefit assessment and decisions to promote flood defence schemes.	Undertake sensitivity analyses
Maintenance	Inadequate or excessive maintenance activities, possibly unnecessary disruption to aquatic and riparian habitats or insufficient capacity of the watercourse leading to increased flood risk.	Maintenance according to a defined programme
Flood risk mapping	Indicative Flood Mapping (IFM) in error – inadequate tool for planning and information on possible flood risk, inadequate (or over necessary) development control, loss of professional and public confidence in the Agency's technical abilities.	Give "health warnings" on use of IFM

11.3 STATUTORY REQUIREMENTS ^(11.3)

Developers are sometimes willing to take the risk of developing within the 1:50 and 1:100 year flood zones without taking into account the impact on upstream and/or downstream users which could lead to increased flooding or scouring of the watercourse. Municipalities are often left with the management of higher flood peaks and damage to properties; infrastructure and the resource.

In addition, Developers have interpreted Section 144 of the National Water Act (Act No 36 of 1998) as merely notifying affected parties of the flood line and not as an activity under Section 21 (i) of the said Act.

Since the Department of Water Affairs is the custodian of the water it is requisite for them to provide guidance to other organs of state such as municipalities to ensure the sustainable use of the resource and to reduce the potential harm to the public and damage to property and the resource. It is a well-accepted fact that the prevention and/or control of development within the floodplain of a watercourse is important to ensure the following:

- Protection of the natural floodplain;
- Reduction or Mitigation of adverse impacts on the natural watercourse;
- Enhance the social, ecological and amenity value of the watercourse and its floodplain;
- Prevention of wasteful public expenditure on remedial works due to damage caused during flood conditions;
- Minimise disaster management associated with floods; and
- Prevent the potential loss of life.

There are a number of Acts and policies which legislates development along flood lines.

11.3.1 EIA Regulations (2007)

According to Regulation 386 Section a basic assessment report must be completed for Section 1 (m) and Section 4 activities. Where Section 1 (m) refers to the construction of facilities or infrastructure, including associated structures or infrastructure, for any purpose in the one in ten year flood line of a river or stream or within 32 meters from the bank of a river or stream where the flood line is unknown, excluding purposes associated with existing residential use but including:

- canals;
- channels;
- bridges;
- dams; and
- weirs.

Section (4) refers to the dredging, excavation, infilling removal or moving of soil, sand or rock exceeding 5 cubic metres from a river, tidal lagoon, tidal river, lake, in- stream dam, floodplain or wetland.

The EIA Regulation introduces the requirement to acknowledge development in the 1:10 year flood line which is not considered in any other legislation.

11.3.2 National Water Act (Act No 36 of 1998)

Section 144 of the Act states the following,

"for the purpose of ensuring that all persons who might be affected have access to information regarding potential flood hazards, no person may establish a township unless the layout plan shows, in a form acceptable to the local authority concerned, lines indicating the maximum level likely to be reached by floodwaters on average once in every 100 years".

This only relates to the establishment of a township and requires the developer to make information regarding the location of the flood line available. It does not require the developer to consider how downstream or upstream users will be affected by the development. The determination of the impact of the development on the environmental and social environment is captured in Section 21 (i) of the Act.

11.3.2.1 Section 21 (c) and (i) Activities of the National Water Act (Act No 36 of 1998)

Section 21 of the Act identifies the types of water uses that need to be licensed. One of the main segments regarding flood lines is in Section 21 (i) which is,

"altering the bed, banks or characteristics of a water course".

The following guiding principles were extracted from the *Policy and Guidelines for Developments within Floodlines* document compiled by the Department of Water Affairs ^(11.3).

Although the characteristics of a watercourse are not defined in the Act the Department of Water Affairs defines it as the original features of the watercourse including the bed, banks and floodplain of the watercourse ^(11.3). Any development that affects the 1:100 year flood or even 1:50 year flood must be licensed by DWA. According to the Act a water course means a river or spring; a natural channel in which water flows regularly or intermittently; a wetland, lake or dam into which, or from which water flows.

The policy of the Department of Water Affairs with regard to development within flood lines is as follows: Development within flood lines is strictly controlled as section 21(c) and (i) water uses.

In all cases where developments are proposed inside the flood lines, the developer is responsible for a thorough investigation of all effect the development may have on the natural, social or economic environment.

No developments of any type shall be authorised within the original floodplain below the RMF line if it results in rising of water levels sufficient to have an adverse impact on adjacent properties. Buffer zones of 20 m should be provided between the 1:100 year flood line area and any proposed development, to ensure that no development has a direct impact on the natural flow of rivers and streams. No earthworks are allowed within the buffer zone or any development.

Where the 1:100 year flood line and the buffer strip is not sufficient to cover areas frequently inundated by stream flow, additional land should be excluded from development to ensure that the stream and its natural processes are not directly impacted upon by a single development, to the detriment of all other developments upstream or downstream.

Types of developments that will be considered within the different zones of the original flood lines are as follow (the restrictions at any level apply to all levels below):

- **100 year to Regional Maximum Flood**
 - a) Any structure provided:
 - the risk is pointed out to occupants; and
 - adequate escape routes exist.
- **50 year to 100 year flood lines**
 - a) No structure that results in a loss of flood storage from the system
 - b) No fill, dykes, levees or berms intended to restrict the area of floodplain inundated
 - c) No structure that has not been designed by a structural engineer to withstand the floodwater load
 - d) No ground floor in which people sleep at night
 - e) No sewer lines
- **20 year to 50 year flood line**
 - a) No permanent structures except bridges (this includes swimming pools, tennis courts, brickwork gazebos)
 - b) Temporary structures that do not interfere with the function of the floodplain as an ecological corridor.
- **10 year to 20 year flood line**
 - a) Only ground level modifications that do not reduce the permeability of the floodplain soils.
- **Below the 10 year flood line**
 - a) approved water abstraction facilities
 - b) landscaping with very minor earthworks and planting with locally indigenous riparian vegetation only

11.4 GUIDELINES FOR DEVELOPMENT WITHIN THE FLOOD LINE

The following guiding principles were extracted from the *Policy and Guidelines for Developments within Floodlines* document compiled by the Department of Water Affairs ^(11.3).

11.4.1 Information requirements

Any proposal for development in the proximity of a watercourse shall contain an accurate flood line plan and technical report reflecting:

- The boundaries of all wetlands and the edges of all watercourses.
 - The edge of the existing and original flood lines for the following recurrence intervals, 5, 10, 20, 100 years and Regional Maximum Flood (RMF).
Drawings showing flood lines for proposed developments shall be accompanied by a technical report containing the following information:
 - i) the name and technical competency of the certifying Engineer
 - ii) details of the hydrological calculations including the methods used, the peak flood discharges as calculated by each method with a comparative plot on Gumbel paper and the final design discharges used to determine the flood lines. Proportions of the RMF and where applicable the Standard Design Flood shall be included in the methods used to compute the design discharges.
 - iii) Details of the hydraulic calculations including a description of the method and software used, the locations of the cross sections used to compute the profile and the control levels and the hydraulic roughness at each section
 - iv) The calculations results shall show for each section and each design discharge:
 - a. the computed water surface elevation;
 - b. the computed energy line elevation
 - c. the distribution of discharges between the overbanks and the main channel
 - d. the average channel and overbank flow velocities
 - e. the energy slope
 - f. the Froude Number
 - v) if supercritical flow is expected to occur and to prevail during flood conditions the position of all hydraulic jumps shall be shown, and the flood lines for conjugate depths shall be indicated for the super critical reaches
 - The stormwater management plan, containing the following:
 - i) A description of the calculation methods used.
- Pre-development**
- ii) A description of the topography, vegetation, soils and anything else that may influence stormwater runoff.
 - iii) Calculation of the critical storm duration using at least 2 methods one of which shall be the kinematic equation.
 - iv) Stormwater runoff peak discharges and hydrographs for the critical storm duration for the 2, 5, 10, 20, 50 and 100 year recurrence interval events
- Post-development**
- v) A description of the stormwater management techniques to be implemented on the site, including information on the maintenance requirements, probability and consequences of failure.
 - vi) Effective stormwater management dissipates the energy of stormwater discharges and reduces potential for scouring and erosion.
 - vii) Stormwater runoff peak discharges and hydrographs for the range of storm durations for the 2, 5, 10, 20, 50 and 100 year recurrence interval events. These calculations shall identify the critical duration storm for each recurrence interval and indicate the change from the predevelopment condition.
- The incremental effect of the development on a rare event such as the Regional Maximum Flood must be quantified.
 - The developer is responsible to communicate all possible effects to all likely stakeholders, to seek their approval and co-operation.

11.4.2 Development guidelines

Land adjacent to streams is usually sought after by developers for high-density developments or business developments. In order to gain more valuable land for development it is common practice to modify the 1:100 year floodplain by filling it up, thereby creating artificially steep stream banks of highly erodible material. The cumulative impact of these practices and the total disregard for geomorphologic and hydrological processes has disastrous effects during flooding. Further engineering efforts to reduce flooding - such as levees, concrete channels, damming and piping further destroy stream beds and habitats like ponds and wetlands. Consecutive backfilling and 1:100 year flood line modifications usually result in very narrow, steep artificial storm water sewer replacing urban streams and their associated pending areas such as wetlands, which cater for storm events and bank overtopping. This type of modification is especially evident on commercial and business sites with stream frontage and it is usually required that more land for development must be provided and that parking requirements are adhered to.

Therefore no backfilling will be allowed in the 1:100-year flood line. Modification to the flood line on one side of the stream will have a direct effect on the position of the flood line on the opposite side of the stream and therefore no levees, berms or fills will be allowed.

11.5 FLOOD PEAK AND FLOOD HYDROGRAPH DETERMINATION

The first assessment that must be made is the magnitude of floods and their associated frequency of occurrence. Methods for estimating the flood peaks for various frequencies of occurrence are described in **Chapter 3**.

The next step is to calculate the corresponding water level in the area of interest. Here the assumption is made that it is the water level reached by a constant flow equal to that of the flood peak.

The flood peak and flood profile calculations are relatively straightforward, and the calculations for a series of different frequencies of occurrence do not require much additional effort.

It is most important that the present and possible future development within the catchment be taken into account when determining the flood peaks, and that existing and possible future structures within the flood zone or which may influence water levels within this zone be taken into account when determining the flood profiles.

11.6 RISK OF INUNDATION

Provided the influence of present and possible future development within the flood zone is taken into account, the flood profile associated with the Maximum Flood will indicate the level above which flooding is extremely unlikely, and for all practical purposes development above this level can be considered as being beyond the influence of future floods.

Obviously, the risk of flooding will be greatest on the river banks and will decrease to near zero at the Maximum Flood level. The flood levels associated with 20, 50, 100 and 200-year floods will be located between the river bank and the Maximum Flood level. The water level will be equal to or higher than the 20-year level once in 20-years on average, i.e. there is a 5% risk of this occurring in anyone year. Similarly, there is a 1% risk of the water level reaching or exceeding the 100-year level in anyone year, etc.

11.7 CONSEQUENCES OF FLOODING

The risk of inundation based on the calculated flood peak, flood profile and recurrence interval calculations are not the only risk that has to be faced^(11.5).

11.7.1 Loss of life

This is the most serious consequence of flooding, and is directly related to the rate of increase in water level rather than the ultimate depth of inundation. Coupled with this is the length of prior warning and access to escape routes.

For example, residents within the flood zone of the Orange River near Upington usually have more than 24-hours advance warning of floods, and can easily make their way to higher ground.

Residents in an urban area alongside a stream downstream of a catchment which is fully developed can expect high flash floods characterised by short response times (tens of minutes). Floods could arrive during the night without warning. In these small catchments high ground is usually near at hand, but the streams are steep and high velocities are common even near the edge of the flooded area, making escape hazardous.

Even moderately sized catchments in the drier and therefore more sparsely vegetated parts of South Africa or even in steep coastal areas can develop flash floods which rise to a peak in less than 10 hours. Many of these rivers have wide, almost level flood plains. Water levels rising two or three metres in as many hours have caused many deaths within developed areas located on flood plains in South Africa. Possibly the main reason has been that by the time that occupants have appreciated the seriousness of the situation (water entering the house), the depths and velocities of water along escape routes are already too high to be negotiated in safety.

A moderately sized person begins to lose stability in a metre of water flowing at 0,6 m/s per second. Children, the aged, and the infirm would have difficulty in negotiating lower water depths and velocities. As a general rule, it can be stated that water depths greater than one metre cannot be negotiated by non-swimmers or conventional vehicles with safety.

Assuming that families evacuate their houses when the water level reaches the lowest floor level in the house, then the water depth/velocity relationship along their evacuation route should not exceed the following (Table 11.2):

Table 11.2: Acceptable water depth/velocity relationship

Velocity (m/s)	Depth (m)
0,5	1,0 (maximum)
1,0	0,7
1,5	0,5
2,0 (maximum)	0,4

11.7.2 Structural damage

Most newly constructed buildings will be able to withstand the effects of inundation alone. However, the risk of structural damage increases rapidly with increase in the velocity of the water. Damage can be from scour, battering by floating debris, or failure due to pressure differences on either side of doors, windows, walls, or the building itself.

11.7.3 Damage to the contents of buildings

Potential damage to the contents of buildings will depend on the likely advance warning time and the portability of the items. In areas susceptible to flash floods it is unlikely that more than the few items that can be transported in the family car will be saved from inundation.

11.7.4 Damage due to the deposition of sediment

Most floods carry a lot of sediment. In the more arid areas heavy deposition of sediment can be expected in areas where rapid decreases in velocity occur. This is usually in the immediate vicinity of buildings as well as inside the buildings themselves.

11.7.5 Insurance

Another important risk is the possibility that properties subject to inundation may have difficulty in obtaining insurance cover, particularly after the first occasion when damage is caused. Properties subject to damage from the 20-year flood have a 64% risk of being damaged at least once in a 20-year period. This is significantly greater than the normal risks covered by standard insurance cover.

11.8 OPEN CHANNEL FLOW

11.8.1 Gradually varied flow

Whilst considering rapidly varied flow the bed slope and channel friction was ignored, for flow only occurred over short distances. For gradually varied flow conditions the channel friction and bed slope are the telling factors in determining whether the flow is sub- or supercritical.

For any given channel and discharge, the normal depth (y_n) of flow may be found using Manning's or Chezy's equation (**Chapter 4**) and the critical depth (y_c) using Equation 11.1. These values can then be used to determine whether sub- or supercritical flow is present:

- if $y_n < y_c$, then supercritical flow;
- if $y_n > y_c$, then subcritical flow.

For any given channel shape and roughness, only one value of slope will produce the critical depth, this is known as the critical slope (S_c).

- if $S > S_c$, then supercritical flow, (S is termed as a steep slope);
- if $S < S_c$, then subcritical flow, (S is termed as a mild slope).

$$\frac{\alpha Q^2 B}{g A^3} = 1 \quad \dots(11.1)$$

where:

- Q = flow rate (m^3/s)
- B = top width (m)
- g = gravitational acceleration (m/s^2)
- A = cross sectional flow area (m^2)
- α = velocity coefficient

11.8.2 Flow transitions

For a specific Q the following is true (**Figure 11.1**):




Figure 11.1: Subcritical to supercritical

In **Figure 11.1**, the upstream slope is mild and downstream slope steep, the critical depth is constant because of the constant Q . Upstream is the flow subcritical ($Fr < 1$), for the downstream section the opposite is true, flow is supercritical ($Fr > 1$). The transition occurs in the vicinity of the intersection of the slopes; at the transition flow is critical. A smooth transition occurs because of the fact that the downstream flow is supercritical, disturbances only have an effect downstream.




Figure 11.2: Supercritical to subcritical

In **Figure 11.2**, the slopes have been reversed and the resulting flow is more complex. Upstream is the flow supercritical ($Fr > 1$) and its disturbances propagate only downstream. Downstream subcritical flow ($Fr < 1$) is present and the disturbances propagate both up- and downstream. The net result is that the disturbances are concentrated into a small area, which is the hydraulic jump.

11.8.3 The general equation of gradually varied flow

To determine the flow profile through a region of gradually varied flow, due to changes in bed slope and cross-sectional area, the general equation of gradually varied flow is needed. For gradually varied flow the assumption is made that the change in energy with distance is equal to the frictional losses. Hence:

$$\frac{dy}{dx} = \frac{S_o - S_f}{1 - Fr^2} \quad \dots(11.2)$$

S_o = bed slope (m/m)

Fr = Froude number

S_f = represents the slope of the total energy line, it may be evaluated using the Manning, Chézy or Colebrook-White's equation, (**Chapter 4**).

dy = change in water depth (m)

dx = distance over which change occurs (m)

11.8.4 Classification of flow profiles

A deeper understanding of gradually varied flow may be gained by taking a general overview of Equation 11.2. For a given discharge are both S_f and Fr^2 functions of the depth (y), e.g.

$$S_f = \frac{n^2 Q^2 P^{4/3}}{A^{10/3}}$$

$$Fr^2 = \frac{Q^2 B}{g A^3}$$

both decrease with the increasing of A , hence increasing of y .

As $S_f = S_o$ when $y = y_n$ (uniform flow), then

- $S_f > S_o$ and $Fr^2 > 1$ when $y < y_n$
- $S_f < S_o$ and $Fr^2 < 1$ when $y > y_n$

These inequalities may now be used to find the sign of dy / dx in Equation 11.2 for any condition.




Figure 11.3: Profile types for a mild slope

Figure 11.3 shows a channel of mild slope with the critical and normal depths of flow marked. For a specific Q the following possibilities exist:

Region 1

$y > y_n > y_c$, $S_f < S_o$ and $Fr^2 < 1$, hence dy / dx is positive

Region 2

$y_n > y > y_c$, $S_f > S_o$ and $Fr^2 < 1$, hence dy / dx is negative

Region 3

$y_n > y_c > y$, $S_f > S_o$ and $Fr^2 > 1$, hence dy / dx is positive

The boundary conditions for each region may be determined similarly.

Region 1

As $y \rightarrow \infty$, S_f and $Fr \rightarrow 0$ and $dy / dx \rightarrow S_o$, hence the water surface is asymptotic to a horizontal line.

For $y \rightarrow y_n$, $S_f \rightarrow S_o$, and $dy / dx \rightarrow 0$, hence the water surface is asymptotic to the line $y = y_n$.

This water surface profile is termed an M1 profile. It is the type of profile which would form upstream of a bridge, weir or reservoir, and is known as a backwater curve as shown in **Photograph 11.1**.



Photograph 11.1: Backwater curve due to damming at bridge

The profiles for Regions 2 and 3 may be derived in a similar manner; they are also shown in **Figure 11.3**.

Region 2

For the M2 profile, $dy / dx \propto \infty$ as $y \rightarrow y_c$. This is physically impossible, and may be explained by the fact that as $y \rightarrow y_c$ the fluid enters a region of rapidly varied flow, and hence Equation 11.2 is no longer valid. The M2 profile is known as a drawdown curve, and would occur at a free overfall.

Region 3

For the M3 profile, $dy / dx \propto \infty$ as $y \rightarrow y_c$. Again this is impossible, and in practice a hydraulic jump will form before $y = y_c$.

The surface profiles of channels of critical, steep, horizontal and adverse slopes can all be derived by similar reasoning as for the mild slope profiles, these profiles are shown in **Figure 11.4**.




Figure 11.4: Classification of gradually varied flow profiles

11.8.5 Determining of surface profiles

Before particular types of flow profile can be determined for any given situation, a few things must be ascertained. Determine whether it is a mild (M), steep (S) or critical (C) slope by determining the critical and normal depth. The position of the control point or points must be established. A control point is defined as any point where there is a known relationship between the head and discharge.

Typical examples are weirs, flumes and gates. (In **Figure 11.5** that follows, \square illustrate a control point).

Determine now whether the profiles are controlled from downstream or upstream of the control point ($Fr < 1$, downstream control; $Fr > 1$, upstream control). In **Figure 11.5** the profiles at channel entry and exit are shown.




Figure 11.5: Profiles at channel entry and exit

11.8.6 Direct step method

Equation 11.2 can be rewritten in finite difference form as

$$\Delta x = \Delta y \left(\frac{1 - Fr^2}{S_o - S_f} \right)_{mean} \quad \dots(11.3)$$

where 'mean' refers to the mean value for the interval (Δx).

Accuracy

The normal depth (y_n) is approached asymptotically, so for depths approaching normal depth, $(S_o - S_f)$ is very small and must be calculated accurately.

Choice of step interval

Numerical solutions always involve approximations, and here the choice of step interval affects the solution. The smaller the step interval, the greater the accuracy.

Validity of solution

The equations may be solved between any two depths provided they are within the same region of flow.

11.8.7 Standard step method for regular channels

For gradually varied flow the assumption is made that the change in energy with distance is equal to the frictional losses (Equation 11.4).

$$\frac{dH}{dx} = \frac{d}{dx} \left(y + \frac{\alpha V^2}{2g} + z \right) = -S_f \quad \dots(11.4)$$

Rewriting:

$$\frac{d}{dx} \left(y + \frac{\alpha V^2}{2g} \right) = -\frac{dz}{dx} - S_f \quad \text{or} \quad \frac{dE_s}{dx} = S_o - S_f \quad \dots(11.5)$$

Equation 11.5 can be rewritten as

$$\Delta E_s = \Delta x (S_o - S_f)_{mean} \quad \dots(11.6)$$

where 'mean' refers to the mean values for the interval Δx . The depth can now be determined at a specific distance.

The solution method is an iterative procedure as follows:

- i) Assume a value for depth (y);
- ii) Calculate the corresponding specific energy (E_{sc});
- iii) Calculate the corresponding friction slope (S_f);
- iv) Calculate ΔE_s , over the interval Δx using Equation 11.6;
- v) Calculate $E_{sx + \Delta x} = E_{sx} + \Delta E_s$;
- vi) Compare $E_{sx + \Delta x}$ and E_{sxG} ;
- vii) If $E_{sx + \Delta x} \neq E_{sxG}$, then return to i).

11.8.8 Standard step method for natural channels

A few difficulties arise when viewing natural channels, those already mentioned are the discharge that is more variable and difficult to quantify and Manning's n that is less accurate. Other problems and possible solutions are listed below:

- a) A representative S_f should be obtained for the channel (river), for every section varies. The solution technique is to use Equation 11.4 in finite difference form as

$$\Delta H = \Delta x (-S_f)_{mean} \quad \dots(11.7)$$

Depth is replaced by stage, as depth is not a meaningful quantity for natural sections.

- b) When flood discharges are being considered, the flow will overtop the main channel and flow on the flood plain will occur. Under these conditions the energy coefficient (α) must be computed. An iterative solution method for two-stage natural sections can, therefore, be set up as follows:
- assume a value for stage (h_G) at $x + \Delta x$;
 - calculate the corresponding values of A_i , P_i and K_i at $x + \Delta x$ from the tabulated cross-sectional data and hence find α (using Equation 11.8) at $x + \Delta x$ for the assumed stage;
 - calculate the mean cross-sectional velocity ($\bar{V} = Q/A$) at $x + \Delta x$ and hence find the total energy at $x + \Delta x$ ($H_G = h_G + \alpha \bar{V}^2 / 2g$);
 - calculate the friction slope $S_{fG(x+\Delta x)}$ at $x + \Delta x$ using Equation 11.10 and hence find the mean friction slope $S_{f\text{mean}} = (S_{fG(x+\Delta x)} + S_{f(x)})/2$;
 - calculate ΔH over the interval Δx using Equation 11.7;
 - calculate $H_{x+\Delta x} = H_x + \Delta H$;
 - compare $H_{x+\Delta x}$ and H_G ;
 - if $H_{x+\Delta x} \neq H_G$ then repeat from (i) until suitable convergence is obtained.

$$\alpha = \frac{\left(\sum_{i=1}^N A_i \right)^2}{\left(\sum_{i=1}^N K_i \right)^3} \sum_{i=1}^N \left(\frac{K_i^3}{A_i^2} \right) \quad \dots(11.8)$$

Where:

- α = velocity coefficient
 A = cross sectional flow area (m^2)
 K = channel conveyance (m^3/s), Equation 11.9
 N = number of subsections in channel

$$K = \frac{A^{\frac{5}{4}}}{nP^{\frac{2}{3}}} \quad \dots(11.9)$$

Where:

- A = cross sectional flow area (m^2)
 n = Manning roughness parameter ($s/m^{1/3}$)
 P = wetted perimeter (m)

$$S_o = \frac{Q^2}{\left(\sum_{i=1}^N K_i \right)^2} \quad \dots(11.10)$$

Where:

- S_o = bed slope (m/m)
 Q = flow rate (m^3/s)
 K = channel conveyance (m^3/s)

Factors influencing conveyance

For flows apart from steady discharge in a straight uniform rigid bed channel, other factors influence the conveyance. These include (in no relative order of importance):

- detailed cross-section geometry;

- unsteadiness in time;
- plan form induced rotations (secondary currents);
- effects of section variation in the downstream direction;
- gross lateral variations in flow velocity in different section zones (lateral shear layers);
- resistance effects of vegetation;
- large-scale features on the river bed (boulders, debris, dunes, riffles); and
- force needed for sediment transport.

11.9 DETERMINING FLOODLINES

In general, flood plain mapping is a four step process involving the application of modern tools and analytical methods in computer-based topographic mapping and hydrology and open channel hydraulics.

Step 1 – preparation of accurate topographic mapping of the river and the adjacent lands including any drainage structures or other obstructions in the waters flow path.

Step 2 – calculation of the expected river flow (or discharge) for different return periods (or flood frequencies) by using statistical hydrology methods, if there are sufficient records of historical streamflow, or using mathematical hydrologic models, or both as detailed in **Chapter 3**.

Step 3 – calculation of expected water levels along the river for the expected discharges, using mathematical models that simulate the hydraulic characteristics of the river and its flood plain as shown in **Figure 11.6**. Included in the *Drainage Manual Application Guide* are examples of how to set-up a numerical model of a river system in HEC-RAS.



Figure 11.6: Numerical model set up for flood line determination

Step 4 – plotting flood lines on the mapping to illustrate the areas that are expected to be inundated as depicted in **Figure 11.7**.




Figure 11.7: Plotting flood lines (Courtesy of Newground Consulting)

11.10 REFERENCES

- 11.1 FHWA. (2006). *Hydraulic Design of Energy Dissipators for Culverts and Channels*. Hydraulic Engineering Circular No. 14, Third Edition. U.S. Department of Transportation. Federal Highway Administration. Publication No. FHWA-NHI-06-086.
- 11.2 Samuels, P.G., Bramley, M.E. and Evans, E.P. (2002). *Reducing Uncertainty in Conveyance Estimation*. River Flow 2002, Université Catholique Louvain, Belgium.
- 11.3 DWAF. (2007). *Policy and Guidelines for Developments within Floodlines*. The Chief Directorate: Water Use. Pretoria.
- 11.4 SRK Consulting. (2003). *City of Tshwane Metropolitan Municipality Guidelines and Specifications for Local Survey to Aid in Determining Floodlines*. Report No. 314327/SS.
- 11.5 Alexander, W.J.R. (1981). *Guidelines for development within areas susceptible to flooding*. Department of Water Affairs, Forestry and Environmental Conservation. Pretoria.
- 11.6 Chadwick, A., Morfett, J. and Borthwick, M. (2006). *Hydraulics in Civil and Environmental Engineering*. Fourth edition. SPON press, Taylor & Francis Group.

Notes:

CHAPTER 12 – SUB-SURFACE DRAINAGE

A Rooseboom, N Gomes, GM James, J Maastricht and DW Stipp

12.1 INTRODUCTION

12.1.1 General

Water in the structural layers of a pavement is the chief cause of road failures. This water causes the mechanical properties of the material to weaken, because excessively high pore pressures develop under traffic conditions. This weakening of mechanical properties and the washing out of underlying foundation materials is generally known as “pumping” (**Figure 12.1**). The purpose of sub-surface drainage is to remove from the road structure, as rapidly as possible, any infiltrated water occurring in damaging quantities.




Figure 12.1: Schematic visualisation of the pumping phenomenon under pavements

Table 12.1: Road Map for sub-surface drainage

ROAD MAP 12			
Typical problems		Input information	Worked examples
Topic	Paragraph		
Planning of sub-surface drainage	12.2	Road horizontal and vertical alignment, surface drainage and maintenance requirements	The design of a herringbone drainage system is shown in the <i>Application Guide</i> .
Design of intercept drains	12.3	Material size distribution, soil permeability	
Design of underground pipes	12.6	Gradient of pipes, pipe perforations and layout of the drainage system	
Design of layer drainage	12.8	Grade of the subbase	
Outlets for sub-surface drainage	12.9	Topography and erosion potential at the outlets	

Important sources of underground water are:

- the natural water table;
- irrigation, canals and dams; and
- rainfall infiltration.

Such water may enter the pavement layers by infiltration, either sideways or through the road surface.

The following types of underground drainage systems to remove water are generally used:

- interception drainage
- herringbone drainage
- layer drainage
- structural drainage

Photograph 12.1 reflects the typical problems associated with poor sub-surface drainage design, and **Photograph 12.2** shows the installation of sub-surface drainage to improve the situation.



Photograph 12.1: Typical conditions associated with poor sub-surface drainage design



Photograph 12.2: Installation of sub-surface drainage to improve the drainage

12.1.2 Sub-surface interception drainage (Trench drains)

This type of drain intercepts mainly groundwater moving horizontally, and lowers the water table. It is used in the following cases:

- at the toe of a cut where the side slope is stable;
- at the toe of a fill to prevent or limit groundwater inflow into the road prism; and
- across the road on the downhill side of a cut.

Trench drains could consist of conventional drains incorporating granular material. This material could act as a natural filter; as a permeable collector, or as a geocomposite incorporating a synthetic collector.

Permeable collector drains consist of single sized aggregates between 9,5 and 25 mm encapsulated within a geosynthetic filter material.

Geocomposite drains consist of a geospacer synthetic collector encapsulated within a geosynthetic filter material. The main advantages of geocomposite drains are:

- smaller dimensions (narrow trenches);
- speed and ease of construction; and
- pre-assembly before installation into the trench.

The total cost of geocomposite drains are usually lower than conventional drains of the same depth.

12.1.3 Herringbone sub-surface drainage

This type of sub-surface drainage reduces a generally high groundwater table to an acceptable level. It is used in the following cases:

- In areas, cuts or fills where there is a high groundwater table that is undesirable; or
- To stabilise areas where a high water table interferes with construction.

The herringbone sub-surface drainage may be installed below the road prism or within the pavement layers.

12.1.4 Layer sub-surface drainage

This type of sub-surface drainage removes, in particular, water that seeps in through the road surface. In many cases an attempt is made to make the road surface impermeable which, from the point of view of drainage, makes the construction of an open-graded layer unnecessary.

Blanket drains could consist of either natural filters or permeable collectors. A geosynthetic filter material is placed at the interface between the permeable collector (sand, gravel or aggregate) and the subgrade, and functions as a filter and a separator to prevent two dissimilar materials from intermixing. These drains may consist of a thick geosynthetic material where flow may occur both perpendicular to and transversely in the plane of the geotextile.

12.1.5 Structural sub-surface drainage

These drains are used for structures, such as bridge abutments and retaining walls. Geocomposite drains or thick non-woven geotextiles tied into a collector pipe are especially useful in these applications because of the speed and ease of installation, pre-assembly benefits and narrower dimensions.

12.2 PLANNING OF SUB-SURFACE DRAINAGE

In the planning of an underground drainage system, the first step is to undertake a groundwater investigation in the area. There are two basic groundwater conditions for which drainage systems are essential:

- Groundwater with a hydraulic gradient smaller than the slope of the ground. Typical warning signs here are wet patches and visible outflows on the side of a cut. Interception drains are installed in such cases.
- A groundwater table close to the surface. Signs of this are collapsing wet spots in flat areas. This condition arises where water infiltrates from higher areas or through a “leaking” surface layer. Herringbone or layer drainage is installed in such cases.

Observations should be carried out on:

- geology – fractured, fissured or jointed rock, impermeable dykes or alternating layers of permeable and impermeable material
- vegetation – variations in colour and vigorous growth, or hydrophilic vegetation
- topography – shape of the land, depressions, valley lines, catchments, etc
- road surface failures – crocodile cracking, pumping, rutting, tension cracks.

A design method should now be chosen to calculate the capacity of the drainage system. (Note: Storm water may not be discharged into a sub-surface drain.)

In the case of ground water intercepted from cuts, it is generally not practical to carry out a sophisticated calculation, probably because too wide a variety of material is found in a cut, and seasonal changes also have a strong influence on the groundwater discharge. In practice, the capacity of an intercept drain may be determined by *in-situ* flow measurement (during the wet season after the channel has been excavated!) or, if excessive quantities of groundwater have not been observed, or there is no groundwater in the dry season, nominal drainage may be provided. In calculating the capacity of herringbone drainage, **Table 12.3** may be used to determine the depth/spacing of the system. Layer drainage is designed with the aid of formulae such as those described in section 12.5. During the planning and design of a drainage system the following points should be borne in mind:

- A thorough investigation of the sub-surface drainage requirements is essential. Such an investigation should be performed during the rainy season, because the dry season may present a completely false picture of groundwater conditions.
- A sub-surface drainage system should ensure that the road structure is without free water for about 1 metre below the road surface most of the time.
- It is, therefore, advisable to provide sub-surface drainage in all cuts and underneath some low embankments.
- Intercept drains should be provided at the end of a cut.
- Water should be able to escape from an embankment that drains towards a solid bridge abutment.
- The capacity of the drainage network should be adequate.
- The drainage network should require minimum maintenance.
- The drainage network should not become blocked.
- Repairs and alterations are extremely expensive.
- The drainage network should be economical.

12.3 DESIGN OF AN INTERCEPT DRAIN

12.3.1 General

Intercept drains may be open (above ground) or covered (below ground). Open channels normally occupy greater space and require more maintenance than underground drains.

12.3.2 Introduction to sub-surface intercept drains

Sub-surface drains require less maintenance than surface drains, but blockages are difficult to rectify. Rodding eyes may be provided for long lengths of drains in problem soil areas.

The theory discussed below regarding sub-surface drains also applies in general to open intercept channels. The use of intercept drains is normally recommended where investigations have shown a definite inflow of water, and they are then placed across the direction of flow. The length of the flow-path should also be limited to approximately:

- 200 to 300 m for conventional subsoil drains ^(12.1); and
- 50 to 150 m for geocomposite drains ^(12.2).

Unusual formations or groundwater conditions may be responsible for a high water table in certain localities, and likewise sudden changes in the topography may cause a high water table in some areas. These conditions are difficult to describe, and no fixed rules can therefore be laid down.

Sub-surface intercept drains consist of a mechanism for interception, such as a filter and a discharge system, which is usually a system of pipes. **Figure 12.2** shows typical, sub-surface intercept drains.

12.3.3 Design capacity of intercept drains

The capacity of an intercept drain may be calculated by using the Darcy methods, but normally not all the accepted assumptions would apply in practice. If visible ground water is present, a guide ditch may be used to measure the yield accurately. When little or no ground water is present, nominal sizes are used (**Section 12.6.2**).




Figure 12.2: Typical sub-surface drain details

12.4 DESIGNING A GRANULAR FILTER LAYER

Groundwater moving along a hydraulic gradient is intercepted by a filter layer (coarser material). Water usually flows from the fine to the coarse material, and the following should be ensured:

- Fine material should not wash into the coarse material and so clog it.
- The grading of each layer should be uniform to ensure good quality.
- Adequate through-flow should take place.
- The minimum layer thickness for construction purposes should be 100 mm.

Table 12.2 reflects the requirements that should be satisfied when a filter material is selected.

Table 12.2: Criteria for filter material

Requirement	Criteria *	Objective
1	$\frac{D_{15} \text{ filter material}}{D_{85} \text{ protected soil}} \leq 5$	To ensure retention of fines in the soil by the filter
2	$\frac{D_{60} \text{ filter material}}{D_{10} \text{ filter material}} < 20$	To ensure that the filter is well graded and stable
3	$\frac{D_{15} \text{ filter material}}{D_{15} \text{ protected soil}} \geq 5$	To ensure a permeability differential between the filter and the soil
4	$\frac{D_{50} \text{ filter material}}{D_{50} \text{ protected soil}} < 25$	To ensure uniformity

Note: D_x = the sieve size through which x % of the material passes (mm)

The D_{15} value of a filter material may not be $< 0,1$ mm, and if $D_{15} > 0,4$ mm it would not be necessary to meet requirement 1, provided that 2 applies.

12.5 DESIGNING A GEOTEXTILE FILTER

12.5.1 Introduction

Designing with geotextiles for filtration is essentially the same as designing graded granular filters. A geotextile is similar to a soil in that it contains voids (pores) and particles (filaments and fibres). However, because of the shape and arrangement of the filaments and the compressibility of the structure of geotextiles, the geometric relationships between filaments and voids are more complex than in soils. In geotextiles, pore size is measured directly, rather than using particle size as an estimate of pore size, as is done with soils. Since pore size may be directly measured, relatively simple relationships could be developed between the pore sizes and particle sizes of the soil to be retained. The following three simple filtration concepts are used in the design process:

- If the size of the largest pore in the geotextile filter is smaller than the larger particles of soil, the soil will be retained by the filter. As with graded granular filters, the larger particles of soil will form a filter bridge over the hole which, in turn, filters smaller particles of soil which then retain the soil and prevent “piping”. **Photograph 12.3** indicates the failure of a road surface due to “piping” that occurred around the installed culvert.
- If the smaller openings in the geotextile are large enough to allow smaller particles of soil to pass through the filter, then the geotextile will not blind, block or clog.

- A large number of openings should be present in the geotextile so that proper flow could be maintained even if some of the openings later become blinded, blocked or clogged.



Photograph 12.3: Failure of a road surface due to “piping”, occurring around the culvert

These simple concepts, which are synonymous with soil filter design criteria, can also be summarised as follows:

- The geotextile should retain the soil (retention criteria), while
- allowing water to pass (permeability criterion), throughout
- the life of the structure (clogging resistance criterion).

To perform effectively, the geotextile should also survive the installation process (survivability criterion).

These design criteria ^(12.3) provide an excellent prediction of filter performance, particularly for granular soils (< 50% passing a 0,075 mm sieve).

There are six criteria that should be considered for the design and selection of geotextile filters. These criteria are:

- Retention criteria
- Dynamic (multidirectional) flow conditions
- Permeability/permittivity criteria
- Clogging resistance
- Survivability criteria, and
- Durability criteria.

These criteria are briefly discussed below.

12.5.2 Retention criteria

12.5.2.1 Steady state (unidirectional) flow conditions

$$\text{AOS or } O_{95(\text{geotextile})} \leq B D_{85(\text{soil})}$$

where:

AOS	=	apparent opening size (mm)
O_{95}	=	opening size in geotextile for which 95% of openings are smaller (mm)
AOS	\approx	O_{95}
B	=	a coefficient (dimensionless)
D_{85}	=	soil particle size for which 85% of openings are smaller (mm)

The coefficient B ranges from 0,5 to 2,0, and is a function of the type of soil to be filtered, its density, the uniformity coefficient C_u (if the soil is granular), the type of geotextile (woven or non-woven) and the flow conditions.

For sands, gravelly sands, silty sands and clayey sands (with less than 50% passing the 0,075 mm sieve per the United Soil Classification System), B is a function of the uniformity coefficient, C_u . Thus for:

$C_u \leq 2$ or ≥ 8	:	$B = 1$
$2 \leq C_u \leq 4$:	$B = 0,5 C_u$
$4 < C_u < 8$:	$B = 8 / C_u$

where:

$$C_u = D_{60} / D_{10} \quad (\text{coefficient of uniformity})$$

Sandy soils that are gap-graded or well graded tend to bridge across the openings; thus the larger pores may actually be up to twice as large ($B \leq 2$) as the larger soil particles because, quite simply, two particles cannot pass through the same hole at the same time. Consequently use of the criterion $B = 1$ would be quite conservative for retention, and such a criterion has been used by, for example, the US Corps of Engineers.

If the protected soil contains any fines, only the portion passing the 4,75 mm sieve for selecting the geotextile is used (i.e. scalp off the +4,75 mm material).

For silts and clays (with more than 50% passing the 0,075mm sieve) B is a function of the type of geotextile:

for wovens	$B = 1; O_{95} \leq D_{85}$
for non-wovens	$B = 1,8; O_{95} \leq 1,8 D_{85}$
for both	$\text{AOS or } O_{95} \geq 0,30 \text{ mm}$

Due to their random pore characteristics and, in some types, their felt-like nature, non-wovens would generally retain finer particles than a woven geotextile of the same AOS. Therefore, the use of $B = 1$ would be even more conservative for non-wovens.

In the absence of detailed design, the AASHTO M288 Standard Specification for Geotextiles (2000) ^(9.4) provides the following recommended maximum AOS values in relation to percent of *in-situ* soil passing the 0,075 mm sieve:

- 0,43 mm for less than 15% passing;
- 0,25 mm for 15 to 50% passing; and
- 0,22 mm for more than 50% passing.

In the case of cohesive soils, with a plasticity index greater than 7, the maximum AOS size is 0,30 mm. These default AOS values are based upon the predominant particle sizes of the *in-situ* soil. The engineer may require performance testing based on engineering design for drainage systems in problematic soil environments. Site-specific testing should be performed, especially if one or more of the following problematic soil environments are encountered:

- unstable or highly erodible soils such as non-cohesive silts;
- gap-graded soils;
- alternating sand/silt laminated soils;
- dispersive soils; and/or
- gold or coal-ash tailings.

12.5.2.2 *Dynamic (multidirectional) flow conditions*

Soil particles may move behind the geotextile, if it is not properly weighted down and intimate contact with the soil to be protected, or if dynamic, cyclic or pulsating loading conditions produce high, localised hydraulic gradients. Thus the use of $B = 1$ is not conservative because the bridging network would not develop and the geotextile would be required to retain even finer particles. When retention is the primary criterion, B , should be reduced to 0,5 or:

$$O_{50} \leq 0,5 D_{85}$$

Dynamic flow conditions may occur in pavement drainage applications, e.g. a road fill across the upper reaches of a dam. For reversing inflow-outflow or high-gradient situations it is best to maintain sufficient weight or load on the filter to prevent particle movement.

12.5.2.3 *Stable versus unstable soils*

The above retention criteria assume that the soil to be filtered is internally stable – it will not pipe internally. If unstable soil conditions are encountered, performance tests should be conducted to select suitable geotextiles. Broadly graded ($C_u > 20$) soils with concave upward grain size distributions, gap-graded soils and dispersive soils tend to be internally unstable.

12.5.3 Permeability/permittivity criteria and requirements

As long as the permeability of the geotextile ($k_{\text{geotextile}}$) is greater than the permeability of the soil (k_{soil}) the flow of water will not be impeded at the soil/geotextile interface. To provide for an additional level of conservatism apply the following formula to all critical applications and severe conditions:

$$k_{\text{geotextile}} > 10 k_{\text{soil}}$$

By applying a factor of safety of 10 to k_{soil} , allowance is made for the potential reduction in permeability of the geotextile through the pores becoming blinded, blocked or clogged by migrating soil particles.

Optional permittivity requirements

$$\begin{array}{lll} \psi & \geq & 0,5 \text{ sec}^{-1} \text{ for } < 15\% \text{ passing } 0,075 \text{ mm} \\ \psi & \geq & 0,2 \text{ sec}^{-1} \text{ for } 15 \text{ to } 50\% \text{ passing } 0,075 \text{ mm} \\ \psi & \geq & 0,1 \text{ sec}^{-1} \text{ for } > 50\% \text{ passing } 0,075 \text{ mm} \end{array}$$

In these equations:

$$\begin{aligned}
 k &= \text{Darcy coefficient of permeability (m/s)} \\
 \psi &= \text{geotextile permittivity which is equal to } k_{\text{geotextile}} / t_{\text{geotextile}} \text{ (s}^{-1}\text{) and is a function of} \\
 &\quad \text{the hydraulic head where } t_{\text{geotextile}} \text{ is the thickness of the geotextile}
 \end{aligned}$$

In very critical applications, to minimise the risk of the geotextile filter not being sufficiently permeable, performance testing should be conducted. For actual flow capacity the permeability criteria for non-critical applications are conservative, since an equal quantity of flow through a relatively thin geotextile takes significantly less time than through a thick, granular filter. Even so, some pores in the geotextile may become blocked, blinded or clogged with time.

The AASHTO M288 Standard Specification for Geotextiles (2000) presents recommended minimum permittivity values in relation to percent of situ soil passing the 0,075 mm sieve. The values are the same as presented in the equations above. The default permittivity values are based upon the predominant particle size of the *in-situ* soil. Again, the engineer may require performance testing based on engineering design for drainage systems in problematic soil environments.

The required flow rate, q , through the system should also be determined, and the geotextile and drainage aggregate selected to provide adequate capacity. As indicated above, flow capacities should not be a problem for most applications, provided the geotextile permeability is greater than the soil permeability. However, in certain situations, such as where geotextiles are used to span joints in rigid structures and where they are used as pipe wraps, portions of the geotextile may be blocked. For these applications the following criteria should be used together with the permeability criteria:

$$q_{\text{required}} = q_{\text{geotextile}} (A_g / A_t)$$

where:

$$\begin{aligned}
 A_g &= \text{geotextile area available for flow (m}^2\text{);} \\
 A_t &= \text{total geotextile area (m}^2\text{)}
 \end{aligned}$$

12.5.4 Clogging resistance

In the following sections a distinction is made between less critical and critical conditions which are discussed separately.

12.5.4.1 Less critical / less severe conditions

For less critical / less severe conditions:

$$O_{95}(\text{geotextile}) \geq 3 D_{15}(\text{soil})$$

This applies to soils with $C_u > 3$. For $C_u \leq 3$ select a geotextile with the maximum AOS value.

In situations where clogging is a possibility (e.g., gap-graded or silty soils) the additional criteria in **Table 12.3** should be considered.

Table 12.3: Additional criteria to be considered when there is a potential for clogging

Material	Additional criteria
Non-woven material	Porosity (void ratio) of the geotextile, $n \geq 30\%$
Woven monofilament and slit film wovens	Percent open area, $POA \geq 4\%$

Most common non-wovens have porosities much greater than 70%, while most woven monofilaments easily meet the criteria. **Tightly woven slit films do not, and are thus not recommended for sub-surface drainage applications.**

Performance type filtration tests provide another option for consideration, especially by inexperienced users.

12.5.4.2 Critical / severe conditions

For critical/severe conditions, select geotextiles that meet the retention and permeability criteria. Then conduct a performance filtration test using samples of on-site soils and hydraulic conditions. One type of performance filtration test is the Gradient ratio test that is well described in literature ^(12.2).

Although several empirical methods have been proposed to evaluate geotextile filtration characteristics (i.e. the clogging potential) the most realistic approach for all applications is to perform a laboratory test that simulates or models field conditions. This test utilises a rigid-wall soil permeameter (**Figure 12.3**) with piezometer taps that allow for simultaneous measurement of the head losses in the soil and the head loss across the soil/geotextile interface. The ratio of the head loss across this interface (nominally 25 mm) to the head loss across 50 mm of soil is termed the gradient ratio. As fine soil particles adjacent to the geotextile become trapped inside or blind the surface, the gradient ratio will increase. A gradient ratio of less than 3 is recommended.




Figure 12.3: Typical gradient ratio permeameter

These filtration tests are performance tests. They should be conducted on samples of project site soil by the specifying agency or its representative.

12.5.5 Survivability criteria

To ensure that the geotextile will survive the construction process, certain geotextile strength and endurance properties are required for filtration and drainage applications, see **Table 12.4**. Detailed description of the geotextile fabric specification falls outside the scope of this manual and as such is not dealt with. Suffice to say it is the duty of the engineer, after doing site-specific evaluation, testing and design, to ensure that an appropriate geotextile is selected for use in the actual construction.

Table 12.4: Survivability specifications (Kaytech, 2012)

Properties		Units	Standard grades							Test method
			A1	A2	A3	A4	A5	A6	A7	
Thickness	Under 2kPa	mm	1,3	1,6	1,8	2,3	2,9	3,2	4,2	SANS 10221
Permittivity	@ 100 mm head	s ⁻¹	3,0	2,9	2,5	2,3	2,0	1,7	1,1	Calculated
Porosity	Under 2 kPa	%	93	93	93	93	93	92	90	Geosynthetic laboratory
Throughflow	@ 100 mm head	l/s/m ²	300	285	250	235	200	180	110	SANS 10221
Permeability	1,0 x 10 ⁻³	m/s	3,9	4,3	4,5	4,9	5,4	5,9	4,8	Calculated
Pore size	Q _{95 W}	µm	181	170	154	138	132	130	114	EN 12956
	Q _{95 H}	µm	195	185	170	155	125	100	70	CGSB-148.1 10
Penetration load	CBR	kN	1,5	1,7	2,1	2,5	3,6	4,5	6,5	SANS 10221
	elongation	%	30-50							

12.5.6 Durability criteria

Geotextile endurance relates to its longevity. Geotextiles have been shown to be basically inert materials for most environments and applications. However, certain applications may expose the geotextile to chemical or biological activity that could drastically influence its filtration properties or durability. For example, in drains granular filters and geotextiles could become chemically clogged by iron or carbonate precipitates, and biologically clogged by algae, mosses, etc. Biological clogging is a potential problem when filters and drains are periodically inundated and then exposed to air. Excessive chemical and biological clogging may significantly influence filter and drain performance. These conditions are present, for example, in landfills.

Biological clogging potential could be determined with the ASTM D5322-92 Standard Test Method for biological clogging of geotextile or soil/geotextile filters (1991). If biological clogging is a concern, a higher porosity geotextile may be used, and/or the drain design and operation may include an inspection and maintenance programme to flush the drainage system.

12.6 DESIGN OF UNDERGROUND PIPES

12.6.1 Slope of pipes

The slope of a pipe is largely influenced by the road alignment or the final contours.

Changes in slope, especially a reduction in slope, should be avoided as far as possible. The following minimum slopes and flow velocities are recommended:

- A minimum slope of 0,5%, with an absolute minimum of 0,2% for laterals and 0,25% for mains.
- The design flow velocities should be between 0,5 and 3,0 m/s.
- The absolute minimum of the half-full velocity should not be less than 0,6 m/s ^(12.3).

For slopes steeper than 2%, pipes with couplings should be used to prevent erosion of the material around the joints caused by excessive eddying at the joints.

12.6.2 Pipe diameter and outlet spacing

Under normal to dry conditions the pipe diameters and maximum pipe lengths (without outlets) given below are used if no design data are available:

- Diameter 100 mm, lengths up to 200 m;
- Diameter 150 mm, lengths up to 300 m.

In freeway drainage systems 100 mm diameter pipes are mainly used, but where high inflows of water are encountered, 150 mm diameter pipes are more suitable.

In cases where the maximum discharge is known, the pipe diameter is calculated according to **Figure 12.4** . A sub-surface drainage pipe should preferably not flow more than 70% full under maximum discharge conditions, so that excessive pressure conditions do not develop.

The capacity of different pipes may also be calculated by means of the Manning formula, and typical design values of Manning-n for underground drainage pipes are given in **Table 12.5**.

Table 12.5: Roughness parameters of drain pipes

Pipe type	n-value (s/m ^{1/3})
PVC	0,010
Corrugated polyethylene	0,025
Smooth-bore polyethylene ^(12.6)	0,010
Open-lattice HDPE	0,010

12.6.3 Pipe perforations

The pipe perforations should satisfy the following requirements to prevent penetration of filter material:

- Diameter of openings, slots or perforations < D₈₅ filter;
- 1,2 x width of openings, slots or perforations < D₈₅ filter.

Simply put, the smaller sized particles of the filter material should be larger than the largest size openings, slots or perforations of the pipe.

12.6.4 Pipe material

Pipe materials generally used are HDPE and PVC. It is important that the pipes be installed in accordance with manufacturers’ instructions.




Figure 12.4: Nomogram for the discharge rate of drainage pipes




Figure 12.5: Infiltration index of drainage pipes

12.6.5 Pipe bedding

Figure 12.6 is a recommended way of laying of sub-surface drainage pipes.




Figure 12.6: Typical drainage pipe bedding details

The purpose of the bedding is to provide a working surface and to ensure that the drainage pipe does not come into contact with rocks or clay material. Drainage pipes are flexible, and consequently their load-bearing capacity depends less on the inherent strength of the pipe, and more on the quality of the backfill surrounding the pipes.

Where the *in-situ* material is reasonable, the bedding thickness should be 100 mm. In softer, saturated conditions the bedding layer should be between 150 and 200 mm thick (SABS 1200).

Proper compaction of the bedding will ensure that the grade (fall) of the drainage pipe is maintained. The side-fill and the compaction thereof are most important and require special care during placement in the haunch areas beneath the drainage pipe. If selected backfill material is not placed beneath the drainage pipe, voids will result and, when loaded, the drainage pipe will deform into these voids. The degree of compaction for bedding should be 90% Mod AASHTO.

Granular soils are normally graded. It gives uniform support to the drainage pipe, and readily accommodates the haunch support material, which is compacted adjacent to and above it, after the drainage pipe is placed.

Two classes of crushed aggregate or selected granular fill recommended for drainage pipe installation are described in **Figure 12.6**.

The drainage pipe being flexible, will deform slightly under vertical load (vertically downwards and horizontally outwards). This outward movement develops horizontal earth pressures against the wall of a pipe and enables the pipe to carry loads far in excess of its crushing strength.

If any trench is left open for too long it may cause local instability or sloughing failures, thereby negatively influencing the drainage pipe placement and/or backfilling. In the event of trench wall collapse or dynamic lateral loading (induced by compaction or other equipment) occurring before proper bedding has been provided, the drainage pipe could well deform (vertically upwards and horizontally outwards). These situations depend largely on the soil type and depth of trench. In some cases trench support systems may be required. Local conditions and safety considerations will govern each situation.

Correct selection and placement of bedding and padding will ensure that deformation is kept within acceptable limits. Also the backfilling should be done in a reasonably symmetric manner so the drainage pipe is not pushed laterally out of alignment. This should preferably be done in 100 mm layers.

Indiscriminate dumping of backfill soil adjacent to and above the drainage pipe will severely jeopardise the integrity of the drainage pipe. Rocks bearing against the drainage pipe will also result in high stress concentrations. **Such practices should not be permitted under any circumstances.**

A layer of selected granular material is placed above the drainage pipe again to protect the pipe from rocks, etc. and to provide support and load transfer to the top of the drainage pipe and support for the subsequent backfilling operations. The thickness of this layer should be at least equal to the diameter of the drainage pipe. It is recommended that hand compaction is carried out up to 300 mm above the drainage pipe; thereafter mechanical compaction may be used. A minimum overall compacted cover layer of 450 mm is recommended (**Figure 12.6**).

Bad compaction of this latter material would not adversely affect the performance of the drainage pipe, but it could lead to consolidation of these layers, settlement of the surface and some deformation of the drainage pipe if not adequately bedded.

Following the placement of this backfill material, natural soil or the soil being used to construct the structure or facility is brought up to final grade in lifts/layers as per the plans and specifications. This aspect follows standard earthworks procedures.

12.6.6 Selection of geotextiles

The South African Bureau of Standards has compiled a standard for the testing of geotextiles ^(12.7). The Standard contains details about the thickness, through flow capacity, and penetrating load.

Table 12.6 reflects some of the details to be considered when geotextiles are considered a part of the subsurface drainage.

Table 12.6: Specification sheet for the selection of geotextiles

Trench depth (m), description	Compaction	Proposed grade	Thickness (mm)	Through flow @ 100 mm head (l/s/m ²)	Penetrating load (kN)
< 2, with smooth sides and rounded drainage stones	Moderate	A1	1,3	300	1,5
< 2, with rough and sharp stones		A2	1,6	285	1,7
< 2, with rough and sharp stones	High	A3	1,8	250	2.1
> 2, with smooth sides and rounded drainage stones	Moderate	A4	2,3	235	2,5
> 2, with rough and sharp stones	High	A5	2,9	200	3,6

The suppliers could be contacted for further technical details and availability.

12.7 DESIGN OF A HERRINGBONE SYSTEM

12.7.1 Spacing of laterals

For the general case the spacing of laterals may be determined with the aid of **Table 12.7**, which is self-explanatory.

Table 12.7: Recommended depth and spacing of laterals for different types of soil

Soil classification	Soil composition			Spacing of laterals			
	% sand	% silt	% clay	0,9 m deep	1,2 m deep	1,5 m deep	1,8 m deep
Clean sand	80-100	0-20	0-20	33-45	45-60		
Sandy loam	50-80	0-50		15-30	30-45		
Loam	30-50	30-50		9-18	12-25	15-30	18-36
Clayey loam	20-50	20-50	20-30	6-12	8-15	9-18	12-25
Sandy clay	50-70	0-20	30-50	4-9	6-12	8-15	9-18
Silt/clay	0-20	50-70		3-8	4-9	6-12	8-16
Clay	0-50	0-50	30-100	4 max	6 max	8 max	12 max

In more complex cases, and if feasible, the spacing of the laterals may be designed according to the methods for steady or unsteady groundwater flow.

12.7.2 Design of laterals

The diameter of laterals may be read off **Figure 12.4**. However, if the drainage rate is known, the area that could be drained by a pipe of a certain diameter may be calculated by means of Equation 12.1 below.

$$A = \frac{(26,92 \times 10^6) d^{\frac{8}{3}} S_o^{\frac{1}{2}}}{nq} (0,7) \quad (\text{for } 70 \% \text{ of full capacity}) \quad \dots(12.1)$$

where:

- S = spacing (m)
- A = surface area (m²) = S (L+0,5 S)
- d = diameter of pipe (m)
- L = length of the pipe (m)
- q = drainage rate (mm/day)
- n = Manning's n (s/m^{1/3})
- S_o = slope of the pipe (m/m)

12.7.3 Main drainage pipes

The capacity of the main pipe is not the sum of the capacities of the lateral pipes, unless non-porous pipes are used. The surface drained by a pipe of a certain diameter is calculated in the same way as for lateral pipes.




Figure 12.7: General view of a herringbone drainage system

12.8 DESIGN OF LAYER DRAINAGE

12.8.1 General

Once again it should be stressed that the provision of layer drainage should be regarded not as the basic point of departure, but as a solution to the problem of a permeable road surface.

Layer drainage consists of:

- a permeable, open-graded subbase or base below the surface layer;
- filter layer or impermeable layer;
- a collector drain and perforated pipe;
- outlet pipes; and
- markers.




Figure 12.8: Typical section through a layer-drainage

It is essential to investigate the possibility of providing layer drainage whenever:

- The average annual rainfall > 300 mm a year.
- The horizontal drainage coefficient (HDC) < 100 times the design infiltration rate (DIR).
The DIR = 0,33 to 0,67 times the one-hour yearly rainfall (T=1) intensity and the HDC = the layer thickness x the permeability of the drainage layer.
- More than 250/10 t wheel loads per day would use the road during its design life.

12.8.2 Open-graded base and subbase

Open-graded layers should be constructed directly underneath the surface layer and should extend approximately 300 mm and 600 mm past the inner and outer shoulders respectively. Over these parts and underneath the layer, the open-graded layer should be protected from penetration by fine material. The minimum thickness of this drainage layer is 75 mm, and with such thin layers strict care should be taken that undesirable material is not mixed in.

Open-graded layers should be designed to convey water. The inflow consisting of water that has infiltrated through the surface and water from other sources such as channels, cuts, and so on, should be estimated.

The effectiveness of a drainage layer is determined by the permeability of the layer. Adequate permeability may be ensured by setting the following requirements:

- Minimum sieve size : 4,75 mm (no 4 sieve)
- Maximum sieve size : 19 – 37,5 mm
- Permeability (laboratory): > 3 000 m/day
- Design permeability: 0,33 to 0,5 of laboratory permeability.

12.8.3 Filter layer and collector drain

The filter layer and collector drain are similar to those described in **Section 12.3**.

12.8.4 Design formulae

For the purposes of this manual only formulae from Cedergren^(12.5) are given. The symbols that are used are defined below.

q	=	discharge per metre width (m ³ /s.m)
B	=	width of collector drain (m)
L	=	length of paving (1 m wide) subject to infiltration (m)
S	=	cross-slope of a drainage layer (m/m)
W	=	width of the drainage layer (m)
g	=	longitudinal slope of the road (m/m)
k _b	=	permeability of an open-graded layer (m/day)
k _t	=	permeability of the channel backfill (m/day)
n _b	=	porosity of an open-graded layer
	=	$\frac{V_e}{V} = \frac{\text{Volume of pores}}{\text{Total volume of material}}$
P	=	1h duration/1 year return period rainfall intensity (mm/h)
I	=	design infiltration rate (mm/h)

t_b	=	thickness of drainage layer (mm)
t'_b	=	effective thickness of drain layer (mm)
T	=	drainage period for layer (h)
i	=	hydraulic gradient, (m/m)
k_s	=	permeability of material (m/day)
t	=	depth of flow in material (mm)

The following formulae are used:

- The minimum thickness of a drainage layer:
 $t_b = \text{Effective thickness} + \text{say } 25 \text{ mm}$

$$t_b = \frac{24IW}{k_b S} + 25 \quad \dots(12.2)$$

- The time required for the drainage layer to drain:

$$T = \frac{24 W n_b}{k_b \left[S + \frac{t'_b}{2000W (1 + (g/s)^2)} \right]} \quad \dots(12.3)$$

- The minimum width of the collector drain

$$B = \frac{0,48IW}{k_t} \quad \dots(12.4)$$

- The inflow into a drainage layer, according to Darcy:

$$q = k_s i t \quad \dots(12.5)$$

12.9 OUTLETS, MARKERS AND INSPECTION REQUIREMENTS

12.9.1 Outlets

Outlets should be provided at regular intervals so that the system will always flow freely, and to facilitate maintenance. The following general principles should also be observed:

- Outlets should be provided at the lowest points on the pipes.
- Water should flow freely from an outlet, since a pump outlet is generally not economical.
- The outlet should be about 200 mm above the invert of the outlet channel to prevent silting up, and should be protected from penetration by plants.
- The area directly surrounding the outlet should be pitched to limit damming resulting from the growth of vegetation at the outlet.
- The final 6 m of the drainage pipe should be back-filled and compacted with an impermeable material, or should be provided with a cut-off or a storm water manhole outlet to prevent flow and erosion alongside the pipe.
- Wire netting or gauze should be provided at the outlet to prevent rats and mice from entering.

- When an excavation passes from a wet area to a dry area, a cut-off should be provided to force water from the wet area up to the pipe so that the dry area remains dry.

Figure 12.9 shows a typical outlet for a sub-surface drainage collector.




Figure 12.9: Detail of the outlet for sub-surface drainage collector

12.9.2 Markers

The start and end of sub-surface drainage pipes should be clearly marked or visible to ensure proper maintenance. They should be clearly numbered on galvanised plates that are conspicuously mounted on the road fencing. The construction of a conspicuous outlet is also acceptable as a proper marker.

12.9.3 Inspection requirements

Sound construction and maintenance practices ensure the effective working of a drainage system.

At the upper end of a filter drain an inspection eye could be installed. The inspection eye may be built into a storm water inlet or may rise to the surface at an angle of 45° by means of a rising limb. Inspection eyes are not normally used to clean seepage drains, but are very useful during construction for testing through-flow.

12.9.4 Manholes

Manholes should be placed not more than 150 m apart, if there are no other outlets.

12.10 REFERENCES

- 12.1 CSRA. (1994). Committee of State Road Authority. *Guidelines for the Hydraulic Design and Maintenance of River Crossings – Volume II: Legal Aspects*.
- 12.2 Koerner, R.M. (2002). *Designing with Geosynthetics*. 4th Edition. Prentice Hall.
- 12.3 Holtz, R.D., Christopher, B.R. and Berg, R.R. (1998). *Geosynthetic Design and Construction Guidelines*. FHWA.
- 12.4 AASHTO. (2000). *Standard Specification for Highway Applications*. Designation M288-00.

- Notes:

CHAPTER 13 – WEB-BASED LINKS AND SUPPORTING SOFTWARE

M van Dijk, SJ van Vuuren and GL Coetzee

13.1 INTRODUCTION

The purpose of this chapter is to provide relevant web-based links and details of the supporting material. A supporting flash drive/DVD at the back of the Drainage Manual contains some additional material, supporting documentation including the *Application Guide* and computer software. These items are briefly described in the following paragraphs.

13.2 WEB-BASED LINKS

Due to the evolving nature of the internet only a single link is provided in this document which will be kept unchanged. On this website a list of useful links will be provided relevant to this manual and issues relating to drainage.

<http://www.sinotechcc.co.za>

13.3 SUPPORTING FLASH DRIVE/DVD

The flash drive/DVD contains additional material and supporting documentation on a number of the aspects that can be viewed in Adobe Acrobat (pdf) format or downloaded. The visual material will aid in describing some drainage structures, potential problems and should emphasize the importance of these structures ensuring an optimal road infrastructure. **Figure 13.1** reflects the supporting flash drive/DVD “Intro Screen” which could be used to link to the supporting documentation, software and links. **Figure 13.2** to **Figure 13.4** indicates the contents covered in each of the sub-sections.




Figure 13.1: Supporting flash drive/DVD



Figure 13.2: Supporting material




Figure 13.3: Visual material



Figure 13.4: Software

Software programs were developed in parallel to the *Drainage Manual* to assist engineers/designers in the analyses and design of road drainage structures. Examples based on the material of each chapter have been included to demonstrate the use of the supporting software.

The supporting software includes the following:

- Utility Programs for Drainage
- Design rainfall estimation in South Africa
- Visual SCS-SA
- HEC-RAS
- HY-8
- EPA Storm Water Management Model
- Routing Utility
- BridgeLCC

These software programs are briefly discussed in the following paragraphs.

13.3.1 Utility programs for Drainage (UPD)

Utility Programs for Drainage is distributed as a demo-version on the supporting flash drive/DVD. The flash drive/DVD contains all the files and libraries necessary to install and review the program, UPD. The Utility Programs for Drainage is a suite of programs that will assist in the design and analyses of drainage structures. It consists of the following components:

- Economic calculations
- Flood calculations (Deterministic, empirical and statistical methods)
- Water surface profiles
- Basic hydraulics
- Surface drainage




Figure 13.5: Utility Programs for Drainage

The software's user manual is distributed with the installation CD in Adobe Acrobat format and the software has a user-friendly help file. This software package is shareware.

13.3.2 Visual SCS-SA

The United States Department of Agriculture's Soil Conservation Service (SCS) based techniques for the estimation of design flood volume and peak discharge from small catchments (i.e. $< 30 \text{ km}^2$) were originally adapted for use in southern Africa by Schulze and Arnold in 1979 ^(13.1). An updated version of the 1979 SCS design manual was produced in 1987 in the form of three reports published by the Water Research Commission ^(13.2, 13.3 & 13.4).

The above manually based method was computerised and the method is now widely used for the estimation of design floods from small catchments in South Africa. The *Visual SCS-SA* package (**Figure 13.6**), which is supplied on the accompanying flash drive/DVD (shareware), is for use on individual catchments (which can be divided into relatively homogeneous sub-catchments, each of which represent a portion of the catchment which has a similar hydrological response), but is not intended to provide a comprehensive flood estimation package allowing, *inter alia*, superimposition of multiple hydrographs, routing floods through dams and down river reaches and storage attenuation.




Figure 13.6: Visual SCS-SA software

13.3.3 Design rainfall estimation in South Africa

A computer programme with a graphical user interface, see **Figure 13.7**, has been developed in Java to estimate design rainfall depths for any location in South Africa. This software implements the procedures detailed in *Design rainfall and flood estimation in South Africa* report by Smithers and Schulze^(13.1). Utilising the procedures developed, design rainfall can be estimated at a spatial resolution of 1'x1' latitude and longitude for any grid point in South Africa for return periods of 2 to 100 years and for durations ranging from 5 minutes to 7 days. This software is freeware.




Figure 13.7: Design Rainfall estimation software

13.3.4 HEC-RAS

HEC-RAS is public domain software i.e. freeware and is also included on the supporting flash drive/DVD. HEC-RAS was developed by the Hydrological Engineering Centre and allows for the performing of one-dimensional steady flow and unsteady flow calculations, as well as sediment transport calculations. The HEC-RAS User's Manual, Hydraulic Reference Manual and Application Guide are all included in the package. **Figure 13.8** shows the main screen of the HEC-RAS software package.




Figure 13.8: HEC-RAS software

13.3.5 HY-8

HY-8 automates culvert hydraulic computations making culvert analysis and design easier. HY-8 automates the design methods described in HDS No. 5, "Hydraulic Design of Highway Culverts" dated September 1985, FHWA-IP-85-15. Hydraulic Engineering Circular No. 14 (HEC-14) (July 2006) describes several energy dissipating structures that can be used with culverts.

HY-8 enables users to analyse:

- The performance of culverts;

- Multiple culvert barrels at a single crossing as well as multiple crossings;
- Roadway overtopping at the crossing;
- Energy dissipating options; and
- Develop report documentation in the form of performance tables, graphs, and key information regarding the input variables.

Figure 13.9 depicts the HY-8 software package




Figure 13.9: HY-8 software

13.3.6 EPA Storm Water Management Model (SWMM)

The EPA Storm Water Management Model (SWMM) is a dynamic rainfall-runoff simulation model used for single event or long-term (continuous) simulation of run-off quantity and quality from primarily urban areas. The run-off component of SWMM operates on a collection of sub-catchment areas that receive precipitation and generate run-off and pollutant loads. The routing portion of SWMM transports this run-off through a system of pipes, channels, storage/treatment devices, pumps, and regulators. SWMM tracks the quantity and quality of run-off generated within each sub-catchment, and the flow rate, flow depth, and quality of water in each pipe and channel during a simulation period comprise of multiple time steps. This software is freeware.




Figure 13.10: EPA Storm Water Management Model (SWMM)

13.3.7 Routing Utility for the Investigation of Existing Hydraulic Structures

This routing utility was developed for the convenience of its users and can be used to assess the capacity criteria of existing culverts according to the specifications as given in **Chapter 10** of SANRAL's Drainage Manual.

The utility make use of the principle of level pool routing to determine the maximum outflow from a rectangular culvert. By considering the effect of upstream storage, provided that the area-elevation curve of the specific site is known the discharge from the culvert can be estimated for a specific inflow.

In order to open the utility Microsoft Excel 2010 is required with all macro settings enabled. The utility's user manual and readme file, together with the utility itself is distributed on the accompanying flash drive/DVD and is freeware.




Figure 13.11: Routing Utility for the Investigation of Existing Hydraulic Structures

13.3.8 BridgeLCC

BridgeLCC is user-friendly, life-cycle costing software developed by the National Institute of Standards and Technology (NIST) to assist bridge engineers in assessing the cost-effectiveness of new, alternative construction materials. The software uses a life-cycle costing methodology based on both ASTM standard E 917 and a cost classification developed at NIST.

BridgeLCC is specifically tailored for comparing new and conventional bridge materials, for example high-performance concrete versus conventional concrete, but works equally well when analysing alternative conventional materials. Also, it can be used to analyse pavements, piers and other civil infrastructure. This software depicted in **Figure 13.12** is freeware.




Figure 13.12: BridgeLCC

13.4 FEEDBACK

The project team would like to receive your comments and feedback on this chapter. Please visit the following website and voice your opinion, comments or provide suggestions for future software updates.

<http://www.sinotechcc.co.za>

13.5 REFERENCES

- 13.1 Schulze, R.E. and Arnold, H. (1979). *Estimation of Volume and Rate of Runoff in Small Catchments in South Africa*. ACRU Report No. 8, Department of Agricultural Engineering, University of Natal, Pietermaritzburg, RSA .
- 13.2 Schmidt, E.J. and Schulze, R.E. (1987a). *Flood volume and peak discharge from small catchments in Southern Africa based on the SCS technique*. WRC Report TT 31/87, Water Research Commission, Pretoria, RSA.
- 13.3 Schmidt, E.J. and Schulze, R.E. (1987b). *User manual for SCS-based design runoff estimation in Southern Africa*. WRC Report TT 31/87, Water Research Commission, Pretoria, RSA.
- 13.4 Schmidt, E.J., Schulze, R.E. and Dent, M.C. (1987). *Flood volume and peak discharge from small catchments in Southern Africa based on the SCS technique: Appendices*. WRC Report TT 31/87, Water Research Commission, Pretoria, RSA.
- 13.5 Smithers, J.C. and Schulze, R.E. (2003). *Design rainfall and flood estimation in South Africa*. WRC Report No. 1060/01/03, Water Research Commission, Pretoria. RSA

ADDENDA

SANRAL may from time to time issue addenda to this manual which is to be inserted in this space below. Such addenda will be placed on SANRAL's website www.sanral.co.za and it remains the user's responsibility to download these and update the Drainage Manual.

This 1st print includes corrections up to May 2013.

